





To LF 125KHz channel:

Inside this black frame we have the 125KHz antenna coil. Connect to the PCB with the 2 black wires and connector To HF 13.56MHz channel:

These printed lines on the PCB are the HF antenna for the 13.56MHz channel







