

CAGE Code: 0TMJ9

10800 Mavinee Drive Tel: 1-520-297-0844 Tucson AZ 85737 USA Fax 1-520-498-4924

# COMPONENT MAINTENANCE MANUAL WITH ILLUSTRATED PARTS LIST

**WELS CONTROL UNIT** 

PART NO. 100-2601-01

The technical data in this document (or file) is controlled for export under the Export Administration Regulations (EAR), 15 CFR Parts 730-774, ECCN: EAR99. Violations of these laws may be subject to fines and penalties under the Export Administration Act.

Initial Issue: JAN 05/2009 Manual Part Number: MM-0210-01 33-50-01

Page TP1 Revision No. – JAN 05/2009



#### SAFETY ADVISORY

WARNING:

BEFORE THE MATERIALS CALLED OUT IN THIS PUBLICATION ARE USED, KNOW THE HANDLING, STORAGE AND DISPOSAL PRECAUTIONS RECOMMENDED BY THE MANUFACTURER OR SUPPLIER. FAILURE TO COMPLY WITH THE MANUFACTURERS' OR SUPPLIERS' RECOMMENDATIONS CAN RESULT IN PERSONAL INJURY OR DISEASE.

#### WARRANTY/LIABILITY ADVISORY

SECURAPLANE ASSUMES NO RESPONSIBILITY FOR ANY SECURAPLANE EQUIPMENT WHICH IS NOT MAINTAINED AND/OR REPAIRED IN ACCORDANCE WITH SECURAPLANE'S PUBLISHED INSTRUCTIONS AND/OR SECURAPLANE'S REPAIR AUTHORIZATION. NEITHER DOES SECURAPLANE ASSUME RESPONSIBILITY FOR SPECIAL TOOLS AND TEST EQUIPMENT FABRICATED BY COMPANIES OTHER THAN SECURAPLANE.

INCORRECTLY REPAIRED COMPONENTS CAN AFFECT AIRWORTHINESS OR DECREASE THE LIFE OF THE COMPONENTS. INCORRECTLY FABRICATED SPECIAL TOOLING OR TEST EQUIPMENT CAN RESULT IN DAMAGE TO PRODUCT COMPONENTS OR GIVE UNSATISFACTORY RESULTS.

# **CONFIDENTIALITY NOTICE**

This document contains confidential and proprietary information, which is proprietary to Securaplane<sup>®</sup> and shall not be copied or reproduced, in whole or in part, or the contents divulged or used for manufacture, without the specific written permission of Securaplane. Recipient, by acceptance, use, or retention of this document, acknowledges and agrees to the foregoing and covenants to maintain the contents in confidence.

#### AIRCRAFT-ON-GROUND (AOG) SERVICE

For AOG service contact Securaplane at Tel: 1-520-297-0844 (US Toll Free: 1-800-279-7327). After business hours, follow the AOG directions in the recorded message.



#### STATEMENTS OF COMPLIANCE

Regulatory Information for WELS Control Unit (WCU) Radio Transceiver

- A. Statements and Conditions of Compliance
  - (1) This section contains information relative to domestic and foreign country Regulatory Approvals for the WELS radio.

# **USA – FCC Compliance**

This device complies with part 15 of the Federal Communications Commission (FCC) Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference
- (2) This device must accept any interference received, including interference that may cause undesired operation.

**FCC Section 15.21 statement** – "Changes or modifications not expressly approved by the manufacturer could void the user's authority to operate the equipment".

# **Canada - Industry Canada Statements**

This Class B digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la class B est conforme à la norme NMB-003 du Canada.

Europe – E13i
Japan –
Argentina –
Israel –
Brazil –
China CCC -
Malta –
Jordan –
India –
Malaysia –
Morocco –
Nigeria –

Eurana ETCI





# **RECORD OF REVISIONS**

Revision Number	Issue Date	Date Inserted	Ву		Revision Number	Revision Date	Date Filed	Ву
				_				
				_				
				_				



# **RECORD OF TEMPORARY REVISIONS**

Temporary Revision Number	Page Number	Issue Date	Ву	Date Removed	Ву





# SERVICE BULLETIN LIST

Service Bulletin / Revision Number	Issue Date	Date Incorporated or No Effect	Title





# **LIST OF EFFECTIVE PAGES**

<u>SUBJECT</u>	<u>PAGE</u>	<u>DATE</u>	<u>SUBJECT</u>	PAGE	<u>DATE</u>
Title Page	TP1 TP2	JAN 05/2009 BLANK		1009 1010 1011	JAN 05/2009 JAN 05/2009 JAN 05/2009
Safety/ Warranty/ Liability Advisory	SWLA-1 SWLA-2	JAN 05/2009 BLANK		1012 1013	JAN 05/2009 JAN 05/2009
Statements of Compliance	SOC-1 SOC-2	JAN 05/2009 BLANK		1014 1015 1016	JAN 05/2009 JAN 05/2009 JAN 05/2009
Record of Revision	ROR-1 ROR-2	JAN 05/2009 BLANK		1017 1018 1019	JAN 05/2009 JAN 05/2009 JAN 05/2009
Temporary Revisions	RTR-1 RTR-2	JAN 05/2009 BLANK		1020 1021 1022	JAN 05/2009 JAN 05/2009 JAN 05/2009
Service Bulletin List	SBL-1 SBL-2	JAN 05/2009 BLANK		1023 1024 1025	JAN 05/2009 JAN 05/2009 JAN 05/2009
List of Effective Pages	LEP-1 LEP-2	JAN 05/2009 JAN 05/2009		1026 1027 1028	JAN 05/2009 JAN 05/2009 JAN 05/2009
Table of Contents	TOC-1 TOC-2	JAN 05/2009 JAN 05/2009		1029 1030 1031	JAN 05/2009 JAN 05/2009 JAN 05/2009
Introduction	INTRO-1	JAN 05/2009		1032 1033	JAN 05/2009 JAN 05/2009
	INTRO-2 INTRO-3 INTRO-4	JAN 05/2009 JAN 05/2009 BLANK		1034 1035 1036	JAN 05/2009 JAN 05/2009 JAN 05/2009
Description and Operation	1 2	JAN 05/2009 JAN 05/2009		1037 1038 1039	JAN 05/2009 JAN 05/2009 JAN 05/2009
	3 4 5	JAN 05/2009 JAN 05/2009 JAN 05/2009		1040 1041 1042	JAN 05/2009 JAN 05/2009 JAN 05/2009
	6 7 8	JAN 05/2009 JAN 05/2009 JAN 05/2009		1043 1044 1045	JAN 05/2009 JAN 05/2009 JAN 05/2009
	9 10	JAN 05/2009 JAN 05/2009		1046 1047	JAN 05/2009 JAN 05/2009
	11 12	JAN 05/2009 JAN 05/2009		1048 1049 1050	JAN 05/2009 JAN 05/2009 JAN 05/2009
Testing and Fault Isolation	1001 1002 1003	JAN 05/2009 JAN 05/2009 JAN 05/2009		1051 1052 1053	JAN 05/2009 JAN 05/2009 JAN 05/2009
	1004 1005 1006	JAN 05/2009 JAN 05/2009 JAN 05/2009		1054 1055 1056	JAN 05/2009 JAN 05/2009 JAN 05/2009
	1007 1008	JAN 05/2009 JAN 05/2009		1057 1058	JAN 05/2009 JAN 05/2009

33-50-01

Page LEP-1 JAN 05/2009



# LIST OF EFFECTIVE PAGES

SUBJECT	<u>PAGE</u>	<u>DATE</u>	SUBJECT	<u>PAGE</u>	DATE
Schematics and Wiring Diagrams	2001 2002 2003 2004	JAN 05/2009 BLANK JAN 05/2009 BLANK			
Disassembly	3001 3002 3003 3004	JAN 05/2009 JAN 05/2009 JAN 05/2009 JAN 05/2009			
Cleaning	4001 4002	JAN 05/2009 JAN 05/2009			
Inspection/Check	5001 5002	JAN 05/2009 BLANK			
Assembly	7001 7002 7003 7004	JAN 05/2009 JAN 05/2009 JAN 05/2009 JAN 05/2009			
Fits and Clearances	8001 8002	JAN 05/2009 JAN 05/2009			
Special Tools, Fixtures, Equipment and Consumables	9001 9002	JAN 05/2009 JAN 05/2009			
Illustrated Parts List (IPL)	10001 10002 10003 10004 10005 10006 10007 10008 10009 10010	JAN 05/2009 JAN 05/2009 JAN 05/2009 JAN 05/2009 JAN 05/2009 JAN 05/2009 JAN 05/2009 JAN 05/2009 JAN 05/2009 BLANK			
Storage (Including Transportation)	15001 15002	JAN 05/2009 JAN 05/2009			



# TABLE OF CONTENTS

SECTION	<u>PAGE</u>
DESCRIPTION AND OPERATION	1
TESTING AND FAULT ISOLATION	1001
SCHEMATICS AND WIRING DIAGRAMS	2001
DISASSEMBLY	3001
CLEANING	4001
CHECK	5001
REPAIR	Not Applicable
ASSEMBLY	7001
FITS AND CLEARANCES	8001
SPECIAL TOOLS, FIXTURES, EQUIPMENT AND CONSUMABLES	9001
ILLUSTRATED PARTS LIST	10001
SPECIAL PROCEDURES	Not Applicable
REMOVAL	Not Applicable
INSTALLATION	Not Applicable
SERVICING	Not Applicable
STORAGE	15001
REWORK	Not Applicable



# **LIST OF FIGURES**

<u>FIGURE</u>	PAGE
Figure 1. WELS Control Unit (WCU)	3
Figure 2. J1 Connector Insert Arrangement	10
Figure 1001. WCU Test Setup	
Figure 1002. WCU Test Program V1.V00 – Comm Menu – Connected State	
Figure 1003. WCU Test Program – (Tester) Self Test Menu	
Figure 1004. WCU Test Program V1.V00 – Comm Menu – Disconnected State	
Figure 1005. WCU Test Program – WCU AutoRun Menu	
Figure 1006. WCU Test Program – WCU Main Status Menu	
Figure 1007. WCU Test Program – Message Menu – Over Voltage	
Figure 1008. WCU Test Program – WCU Outputs Status Menu	
Figure 1009. WCU Test Program – WCU Configuration Menu	
Figure 1010. WCU Test Program – WCU Configuration Menu	
Figure 1011. WCU Test Program – WCU Configuration Menu	
Figure 1012. WCU Test Program – WCU EEPROM Test and Initialization Menu	
Figure 1013. WCU Test Program – Message Menu	
Figure 1015. WCU Final Verification Test Setup with WELS Test Box PC	
Figure 1016. Message Menu – CAN Message	
Figure 1017. WCU Final Verification Test Setup with Interface and ARM Boards	
Figure 1018. Equipment Setup for Programming WCU	
Figure 1019. SAM-PROG v2.3 Menu	
Figure 1020. SAM-PROG Download Status	
Figure 2001. WELS Control Unit Schematic	
Figure 3001. WELS Battery Unit Removal	
Figure 7001. Front Case Adhesive Channel	
Figure 8001. WELS Control Unit Fits and Clearances	8002
IPL-Figure 1. WELS Control Unit Assembly	10006
IPL-Figure 2. Electronic Assembly	10008
LIST OF TABLES	
	DAGE
<u>TABLES</u>	<u>PAGE</u>
Table Intro 1. Applicable Documents	
Table 1. Measurement Parameters	
Table 2. WCU Connector J1 Pin Assignments	
Table 3. Leading Particulars	
Table 1001. Technical Support and Data Package(s) / Test Specifications	1001
Table 1003. WCU Acceptance Test Data Sheet	
Table 3001. Consumable Materials	
Table 4001. Consumable Materials	
Table 7001. Consumable Materials	
Table 9001. Consumable Materials	
Table 9002. Special Tools, Fixtures, and Test Equipment	
Table 10001. Vendor Code List	
Table 15001. Consumable Materials	

#### INTRODUCTION

#### TASK 33-50-01-99F-801-A01

1. <u>General Information</u>

SUBTASK 33-50-01-99F-001-A01

- A. Introduction
  - (1) This Component Maintenance Manual (CMM) has the maintenance instructions for the WELS Control Unit (WCU). Securaplane Technologies of Tucson, AZ, U.S.A. makes the WCU.
  - (2) This CMM has the off-aircraft procedures for the WELS Control Unit (WCU). This CMM is not for use by a mechanic working on a WCU installed on the aircraft. The WCU must be returned to Securaplane or a facility approved by Securaplane for repair.

# SUBTASK 33-50-01-99F-002-A01

- B Equipment Identification
  - (1) The configuration of the equipment is shown by part number, dash number, series number, and MOD number marked on the identification label.

NOTE: Incorporated MOD status is indicated on the WCU identification label by blackened MOD circle(s).

#### SUBTASK 33-50-01-99F-003-A01

- C. Applicable Documents
  - (1) The reference documents related to the WCU are listed in Table Intro 1.

Table Intro 1. Applicable Documents / TABLE 33-50-01-99A-001-A01

Documents	Document Number
Abbreviated Component Maintenance Manual, WELS Antenna Unit (WAU), 33-50-02	Securaplane MM-0211-01
Abbreviated Component Maintenance Manual, WELS Battery Unit (WBU), 33-50-03	Securaplane MM-0212-01
Operator's Manual, Securanet Field Strength Measurement System, 23-00-01	Securaplane OM-1013-01



# SUBTASK 33-50-01-99F-004-A01

- D. Product Support Services
  - (1) Product support for the WCU is available from Securaplane at:

Securaplane CAGE Code: 0TMJ9

10831 Mavinee Drive Tel: 1-520-297-0844

Tucson AZ 85737 USA Fax 1-520-498-4924

Email: support@securaplane.com Web: www.securaplane.com

#### SUBTASK 33-50-01-99F-005-A01

E. Verification Dates

(1) Dates of Shop Verification by actual performance:

Testing and Fault Isolation Verified TBD Disassembly Verified TBD Assembly Verified TBD

Engineering Technical Review Completed TBD

#### SUBTASK 33-50-01-99F-006-A01

- F. Revision Service
  - (1) This CMM is written in agreement with the Air Transport Association of America iSpec 2200 and AECMA Simplified English guidelines.
  - (2) A complete revision of this manual will be issued when necessary throughout the service life of the unit.
  - (3) A change bar in the margin will identify the revised text. If the entire page has changed, a change bar will appear in the lower right corner.

#### SUBTASK 33-50-01-99F-007-A01

- G. Electrostatic Discharge
  - (1) The items susceptible to electrostatic discharge are handled in agreement with IPC-A-610. Refer to the IPC-A-610C specification Sections 3.2 and 3.3 for the definition of the standards and conditions.

#### SUBTASK 33-50-01-99F-008-A01

- H. Maintenance Task Oriented Support System (MTOSS)
  - (1) The Maintenance Task Oriented Support System (MTOSS) system uses standard and unique number combinations to identify maintenance tasks and subtasks. The MTOSS numbering system includes the ATA chapter-section-subject number as well as a function code and unique identifiers. The purpose of the MTOSS numbering system is to provide a means for the automated sorting, retrieval and management of digitized data.



# SUBTASK 33-50-01-99F-009-A01

# J. Abbreviations

(1) Abbreviations which may be used in this manual are defined below.

<u>Abbreviation</u>	<u>Nomenclature</u>	<u>Abbreviation</u>	Nomenclature
Α	Ampere	LRU	Line Replaceable Unit
AC	Alternating Current	mA	Milliamperes
AOG	Aircraft on Ground	MAX	Maximum
ASSY	Assembly	MM	Millimeter(s)
ATA	Air Transport Association	MOD	Modification
BITE	Built-in-Test Equipment	NHA	Next Higher Assembly
С	Celsius and/or Centigrade	No.	Number
CAGE	Commercial and	ORIG	Original
014	Government Entity	OZ	Ounce
CM	Centimeter(s)	PN	Part Number
СММ	Component Maintenance Manual	PSIG	Pounds (each) square inch gage
CONT	Continued	Qty	Quantity
DC	Direct Current	REF	Reference
EIA	Electronic Industry Association	REV	Revision
F	Fahrenheit	SB	Service Bulletin
FAA	Federal Aviation	SI	Standards International
	Administration	ST	Street
FIG.	Figure	TBD	To Be Determined
FT	Feet	TR	Temporary Revision
Hz	Hertz	TYP	Typical
IEC	International Electrotechnical Commission	USA	United States of America
IEEE	Institute of Electrical and	V	Volt(s)
	Electronics Engineers	VAC	Volts Alternating Current
INC	Incorporated	VDC	Volts Direct Current
INTRO	Introduction	W	Watt
IPL	Illustrated Parts List	WAU	WELS Antenna Unit
IRE	Institute of Radio Engineers	WBU	WELS Battery Unit
KG	Kilogram(s)	WCU	WELS Control Unit
KPA	Kilopascal(s)	WELS	Wireless Emergency Lighting
LB	Pound(s)		System
LED	Light Emitting Diode		

33-50-01



# **DESCRIPTION AND OPERATION**

#### TASK 33-50-01-870-801-A01

Description

#### SUBTASK 33-50-01-870-001-A01

- A. Introduction
  - (1) This section has the physical description and operation for the WELS Control Unit (WCU).

#### SUBTASK 33-50-01-870-002-A01

- B. WELS Control Unit (WCU) Radio Transceiver General Design Information
  - (1) The WCU radio transceiver utilizes the unlicensed 2.4 GHz Industrial Scientific Medical (ISM) band and operates in a frequency Hopping Spread Spectrum (FHSS) mode to combat frequency interference.
  - (2) The WCU system frequency band is 2400 to 2483.5 M Hz. The WELS operational frequency band is comprised of 79 FHSS RF channels spaced 1 MHz apart.
  - (3) To comply with out-of-band regulations in each country a guard band is used at the upper and lower band edge.
    - The lower guard band is 2 MHz
    - The upper guard band is 3.5 MHz
  - (4) The design for radio transmitter power is classified as follows:
    - Minimum design output is 0.25 mW (-6 dBm)
    - Nominal design output is 1 mW (0 dBm)
    - Maximum design output 2.5 mW (4 dBm)
  - (5) The WCU uses an internal antenna for most installations. The WCU also has a provision for an external antenna if the WCU is installed in an area of the aircraft not conducive for operation with the internal antenna.
  - (6) The WCU uses one of two antennas depending on the location of the node within the aircraft. In the nominal case, each node will select its internal antenna. In areas where signal strength or node placement is an issue, nodes will use the external antenna.
  - (7) Antenna selection is accomplished via pin programming set by the wire harness at the node location.
  - (8) The internal antenna is a ¼ wave microstrip located adjacent to the programmable switch on the PWB (part of WCU p/n 100-2601-01). The other switch output feeds a SMA connector on the WCU and connects via coax to the approved external patch antenna (part number 100-2600-012) positioned to radiate to one or more other control units. Both antennas are designed and implemented by Securaplane Technologies. No other external antenna is approved for use on the assembly.

33-50-01



(9) The power limits specified are dictated by the class 2 Bluetooth radio transmitter implemented in the control unit as shown per the following:


	Gain (dbi)					
Antenna	2402 MHz	2480 MHz	Туре	Manufacturer	Power	Notes
Internal - Microstrip	-2.45	-3.4	1/4 wave dipole	Securaplane Technologies	0.25mw (-6dBm) - 2.5mW (4dBm)	Integrated on WCU PCB
External	2.73	1.11	Patch	Securaplane Technologies	0.25mw (-6dBm) - 2.5mW (4dBm)	Replaceable

#### SUBTASK 33-50-01-870-003-A01

- C. WCU Description
  - (1) The WCU is part of the Wireless Emergency Lighting System (WELS). The WELS system will provide illumination and signage to enable passengers and crew to evacuate the aircraft in an emergency.
  - (2) The WELS system will employ 28 WCU's to provide standalone short time power to the emergency lighting on a distributed basis. In addition another WCU may be installed to control the lights and signs inside the crew rest area.
  - (3) Each WCU is electrically identical. However each WCU is configurable to function as master prime unit, subordinate prime unit, crew rest remote unit, or other remote units. The configuration (location, class, or function) of a WCU is defined by pin strapping on its aircraft interface connector in conjunction with a loadable configuration data base.
  - (4) In a baseline configuration, one WCU will be assigned as the prime unit; three WCU's will be assigned as subordinate prime units, while all other WCU's will be assigned as remote units.
  - (5) All prime units will receive airplane status, control state data, configuration database downloads, BITE requests from the aircraft central computing resource via a wired CAN Bus. However only the master prime unit can send status to the aircraft central computer resource via the CAN Bus. No remote unit will be connected to the CAN Bus. All prime units communicate to the remote units via Bluetooth wireless links. In addition the prime units communicate to each other also via Bluetooth wireless links. In some situations where a remote unit or prime unit does not have reliable direct wireless access to a prime unit its wireless access will be indirect through a nearby remote unit. This network of interconnected Bluetooth piconets is referred to as a mesh network.
  - (6) The WCU consists of a battery charger powered from the aircraft 115VAC bus, a battery pack subsystem referred as the WELS Battery Unit (WBU), six lamp drivers that apply or disconnect battery voltage to separate strings of emergency lights, a Bluetooth wireless interface, a CAN Bus wired interface, a microprocessor based controller, a tri level control input which conveys the state of the emergency lighting system to the prime WCU's, and pins that are jumpered by the aircraft wire bundle to convey the hierarchy and lighting load of the WCU.



(7) The WCU is a small plastic assembly that contains the wireless control unit's electronics and replaceable battery pack. The assembly consists of the plastic case, the printed wire assembly, the battery pack, three Nylatch mounting fasteners, a battery latch, an I/O interface connector, and an antenna connector. The WCU is shown in Figure 1.



WELS Control Unit (WCU) Figure 1 / GRAPHIC 33-50-01-99B-001-A01

33-50-01

#### TASK 33-50-01-870-802-A01

#### Operation

#### SUBTASK 33-50-01-870-004-A01

- A. WCU Operation
  - (1) The WCU requires a Wireless Battery Unit (WBU) in order to operate. The WBU is a replaceable battery pack that plugs into the WCU.
  - (2) 115 VAC Input.
    - (a) The WCU receives a single phase, 360 to 800 Hz, 100 to 122VAC nominal (90 to 134VAC abnormal steady state) power from the aircraft to operate the battery charger portion of the WCU. All other portions of the WCU are powered from the output side of the battery charger.
    - (b) The WCU will not draw an input Volt Amp product in excess of 10.5 VA during charging of batteries.

NOTE: 10.5VA corresponds to a 115VAC off line charger having a power factor of 0.8 and efficiency of 75% operating from an input line

filter loading the line with 0.1uF capacitance and delivering 8.2V

at 0.75 A to the battery.

NOTE: The AC input to the WCU is fused to prevent propagation of

damage in the event of a component failure in the WCU.

- (c) The WCU will employ an input common mode line filter of sufficient order and low cutoff frequency to prevent common mode voltages and currents generated by the battery charger from conducting emissions into the aircraft wire bundle at levels in violation of EMC requirement D6-16050-5 sections 8.1.2, 8.2.1.
- (d) The WCU is capable of withstanding AC voltage transients 156% of nominal lasting 100ms without damage.

(For Reference Only: A 156% transient corresponds to a 254V peak difference across the AC input.)

(e) The WCU monitors for the presence or absence of 115VAC power. This status reports to the controller block as a switch closure (power present) or a switch open (power absent) on the digital input line AC\_ON#.

NOTE:

The controller block in turn will convert the switch open to a logic high via a resistive pull-up. The controller block will use this status in an algorithm to determine when to activate emergency lighting. The controller block will not declare the 115VAC as absent for interruptions of voltage lasting less than 0.25 second.

- (3) CAN Interface.
  - (a) The WCU supports communications with the aircraft 1Mbps CAN bus via a CAN 2.0 transceiver and 3 pins on the external connector: CANH, CANL, CAN\_SHIELD. The WCU contains no bus terminations. The CAN\_SHIELD is not grounded at the WCU.

33-50-01

Page 4 JAN 05/2009

- (4) Pin Strapping Inputs.
  - (a) The controller block reads the presence or absence of jumpers in the aircraft wire bundle that tie 5 individual pairs of pins (ID1-ID5 respectively to ID1\_RTN-ID5\_RTN respectively) together on the WCU external connector. The controller block converts this reading into an ID that will point into a downloaded configuration database as to the class of lighting load the WCU is expected to support.
  - (b) The controller block will also detect the presence or absence of a jumper in the aircraft wire bundle across the CRTL\_ENABLE and CTRL\_ENABLE\_RTN pins on the WCU external connector. If the jumper is present then the WCU is a prime unit and is connected to the CAN bus and the tri level control line. If the jumper is absent than the WCU is a remote unit.
- (5) System Control Input.
  - (a) Each prime WCU unit measures the DC voltage on the CONTROL pin relative to the SIGNAL GROUND pin on the WCU external connector to determine the control state of the WELS. Based on this measurement the controller block of the prime WCU unit defines the WELS as in one of three control states:

STATE MEASURED VOLTAGE

ON 0V to +6V

OFF >+6V to +15V

ARMED >+15V

- (6) Battery Loop In Out.
  - (a) To disconnect the battery charger and other active WCU circuitry from the battery pack subsystem (WBU) so that the battery pack maintains its charge whenever the WCU is disconnected from the aircraft wire bundle, the battery charger bus (VB) and the battery pack bus (B+) will be electrically isolated and routed to the BATTERY LOOP IN and BATTERY LOOP OUT pins respectively on the WCU external connector. When the WCU is plugged into the aircraft wire bundle a jumper in the bundle connects the pins together. This jumper is of sufficiently short length that it does not intrude into the lighting zone of the aircraft wire bundle.



#### (7) Lamp Driver Outputs.

- (a) The WCU will route the battery charger bus (BATTERY LOOP IN pin on the WCU external connector) to six overcurrent protected switchable lamp drivers circuits. The six lamp drivers in turn will connect to six pins (OUT1 OUT6 respectively) on the WCU external connector. The OUT1 OUT6 pins in turn pair up with the OUT1\_RTN OUT6\_RTN pins respectively on the WCU external connector to mate via the aircraft wire bundle connector to up to six twisted wire pairs in the aircraft wire bundle. Each twisted wire pair provides power to a set of emergency light fixtures. The OUT1\_RTN OUT6\_RTN pins will connect to the circuit ground plane which the lamp drivers reside on.
- (b) Each lamp driver will be capable of sourcing 1.18 A continuously (6.9 watts at 5.85 to 8.2v) with a voltage drop between its input and output not exceeding 150mv at maximum ambient temperatures yet will trip on a overcurrent that exceeds 1.5A for more than 400 microseconds. During a trip the lamp driver will automatically open the connection between its input and output and report the trip as an active high digital output (OUT\_1\_OC OUT\_6\_OC) to the controller block. The lamp driver will remain in trip until the controller block issues an active low reset command (OUT\_RESET#) common to all lamp drivers.
- (c) Each lamp driver will have an active low dedicated digital input (OUT\_1\_CMD# OUT\_2\_CMD#) which the controller block can use to command the lamp driver to close the connection between its input and its output provided the lamp driver is out of trip.
- (d) Each lamp driver will measure the current that it is sourcing and report the measurement as an analog voltage (OUT1\_I – OUT6\_I) to the controller block's A/D converter. Each lamp driver will detect when its output voltage is above 2.5v and report the detection as an active low digital output (OUT\_1\_VBIT# – OUT\_6\_VBIT#) to the controller block.

#### (8) Battery Charger.

- (a) The battery charger is an off line flyback type current mode operated switching power converter with a magnetically isolated battery level regulated output controlled via an opto coupler isolated voltage and current sensing feedback loop.
- (b) The off line converter incorporates full wave AC to DC line rectification, inrush current limiting and choke input bulk DC filtering to maintain a minimum AC power factor of 0.8 for all charger output loads up to and including 0.75A -10% and to limit inrush current during initial application of 115VAC power to 16A peak.

- (c) The feedback loop of the converter regulates the output by observing two error signals, one the difference between the voltage sensed and a voltage set point and the other the difference between the current sensed and a current set point. The two error signals after separate loop filter compensation /amplification are diode OR'd to form the drive signal to the converter pulse width modulator. An increase in drive voltage reduces the duty factor of the modulator to reduce current delivered to the output. The current sensed will also be converted to a low pass filtered analog voltage CHG\_I and sent to the controller block's A/D converter for further monitoring. The voltage sensed will also be converted into an analog voltage VF\_MON and sent to the controller block's A/D converter for further monitoring.
- (d) The current set point will be selectable by the micro controller via a digital control input LOW\_I. The current set point will be 0.75A +/-10%, 0.15A +/-10% respectively for a logic low, logic high respectively at this input. The voltage set point will be fixed at 8.2V +/-0.2V.
- (e) The converter will be disabled or enabled by the micro controller via a digital control input: CHG\_DISABLE. A logic high at this input prevents the converter switch transistor from turning on. A logic low allows normal operation.
- (f) The converter output will connect to the battery charger bus (VB) through a series diode to prevent converter circuitry that is powered from the converter output from discharging the battery pack whenever the converter is disabled or not receiving AC power. The converter voltage sense will be at the battery charger bus (VB) side of the series diode. The voltage sense will not draw more than 150 microamps from the bus when the converter is not operating.
- (9) Bluetooth Wireless Interface.
  - (a) The WCU will contain a complete, version 2.0 compliant, class 2 power level, basic rate Bluetooth radio subsystem to support wireless communications between WCU's at ranges up to 10 meters maximum.
  - (b) The radio subsystem consists of the following components:
    - Integrated Bluetooth baseband controller/ RF transceiver module with external crystal.
    - RF dielectric BPF to reduce receiver desensitization from out of band interferences.
    - Antenna switch to connect BPF and transceiver to internal antenna or to RF connector.
    - Internal Printed Inverted F (PIFA) antenna located at the edge of the PCB card well away from the battery charger and on the opposite side of the card from the battery pack (WBU) to optimize the antenna radiation pattern.



# COMPONENT MAINTENANCE MANUAL 100-2601

- RF connector to allow connection to an external antenna in cases where the WCU is located next to RF absorbent materials and is unable to establish a reliable wireless link to any other WCU.
- Local low noise dual linear voltage regulator preceded by an input LC ripple filter.
- (c) The WCU will utilize a National Semiconductor LMX5453 integrated Bluetooth 2.0 baseband controller/ RF transceiver module. The frequency reference for the module will be a 13.0 MHz crystal with an ESR of <100 ohms for low oscillator sideband noise and with an accuracy of better than 15 ppm from -15 to +55 deg C to insure that the cumulative frequency accuracy of the complete radio is always within 20 ppm.
- (d) The module will interface to the controller block via its UART port (module pins TXD, RXD, RTS#, CTS#).

NOTE: The signal naming of these module pins is as if the module is Data Terminal Equipment and not Data Set Equipment. That is, RTS# and TX are outputs whereas CTS# and RX are inputs. To prevent confusion, the interface lines from the controller block to module pins TXD, RXD, RTS#, CTS# will be called BT\_TXD, BT\_RXD, BT\_RTS#, BT\_CTS# respectively.

(e) The internal antenna identified earlier in this section will have characteristics equal to or better than the following:

• Center Frequency: 2442 MHz

Input Impedance: 50 ohms nominal

Return Loss vs Frequency:
 10 dB min from 2400 to 2485 MHz

Peak Gain (typ) vs Frequency:
 + 3dBi at 2442 MHz, 0 dBi at 2402 MHz or 2480MHz.

(f) The external RF connector is a SMA female bulkhead right angle PCB mount connector.

#### (10) Controller Block

- (a) The controller block consists of the following components:
  - Atmel AT91SAM7X256 32-bit RISC microcontroller.
  - 18.432 MHz crystal to control the frequency of the microcontroller.
  - 256kbit serial EEPROM.
  - 4Mbit serial FLASH memory.
  - JTAG connector to load the initial program.

33-50-01

- DEBUG PORT connector for initial debugging.
- POR chip to initialize the microcontroller at power up.
- 8 channel analog mux to select and route one of the OUT\_1 to OUT\_6 signals to an A/D input of the microcontroller.
- CAN Bus 2.0 transceiver.
- Dual linear voltage regulator to convert the battery charger bus voltage (VB) to supply voltages (3.3V, 5V) required for all digital logic within the WCU except the Bluetooth wireless block.
- (b) The Atmel microcontroller internal features include a CAN interface, 64kbytes of SRAM, 256kbytes of FLASH memory, an 8 channel 10-bit resolution ADC, etc. The integral non-linearity, offset error, and gain error of the ADC is +/- 3, +/- 2, +/-2 bits maximum respectively. Assuming the ADC reference is connected to the 3.3V (+/- 2.9 %) output of the dual linear regulator then the input scaling/ADC chain will measure the following parameters to within the uncertainties shown in Table 1.

Table 1. Measurement Parameters / TABLE 33-50-01-99A-002-A01

Parameter Sensed	Value	Input Scaling	Measurement Uncertainty	
Sys cntrl i/p voltage	12V	0.1350 V/V	+/- 4.0 %	(CONTROL – CONTROL_RETURN)
Lamp driver current	1.0A	2.0 volts/amp	+/- 3.9 %	(via OUT_1 – OUT_6 signals)
Charger output current	0.75A	3.16volts/amp	+/- 3.6 %	(via CHG_I signal)
Charger bus voltage	8.4V	0.3329 V/V	+/- 3.4 %	(VB)

NOTE: The uncertainties listed here were estimated from a statistical assumption that all contributions to the total uncertainty are statistically independent and that the variance of the total uncertainty is equal to the sum of the variances of the individual contributors.

(c) The microcontroller will shutdown or enables the 5V output of the dual linear regulator by applying a logic low or logic high respectively to the 5V\_ENABLE digital input of the regulator.

NOTE: The 3.3V output of this regulator is always enabled since this output provides the supply voltage to the microcontroller.




#### SUBTASK 33-50-01-870-005-A01

#### WCU External Electrical Interfaces

(1) The WCU has two electrical connectors. The I/O Interface Connector, designated J1, brings in airplane power and signals as well as sends out power to the emergency lights and signs. The Antenna Connector, designated J4, is used to connect to the Wireless Antenna Unit in locations where the remote antenna is needed. See Figure 2 for the WCU J1 connector layout.

NOTE: If the WAU is not needed install the dust cap on the antenna connector.



Insert Arrangement 15-35

Service Rating M

Number of Contacts 37

Contact Size 22D

J1 Connector Insert Arrangement Figure 2 / GRAPHIC 33-50-01-99B-002-A01



(2) The J1 pin out assignments is shown in Table 2.

Table 2. WCU Connector J1 Pin Assignments / TABLE 33-50-01-99A-003-A01

J1 Pin	Signal	
1	115 VAC	
2	115 VAC Return	
3	Reserved	
4	Driver # 1	
5	Driver # 1 Return	
6	Driver # 2	
7	Driver # 2 Return	
8	Driver # 3	
9	Driver # 3 Return	
10	Driver # 4	
11	Driver # 4 Return	
12	Driver # 5	
13	Driver # 5 Return	
14	Driver # 6	
15	Driver # 6 Return	
16	ID # 1	
17	ID # 1 Return	
18	Reserved	
19	Reserved	
20	Reserved	
21	ID # 2	
22	ID # 2 Return	
23	ID#3	
24	ID # 3 Return	
25	ID # 4	
26	26 ID # 4 Return	
27	27 ID # 5	
28		
29	29 Battery Loop Out	
30	Battery Loop In	
31	Control Enable	
32	Control Enable Return	
33	CANH	
34	CANL	
35	CAN Shield	
36	Control Return	
37	Control	



# TASK 33-50-01-870-803-A01

Leading Particulars

SUBTASK 33-50-01-870-006-A01 A. WCU Leading Particulars

(1) The leading particulars for the WCU are shown in Table 3.

Table 3. Leading Particulars / TABLE 33-50-01-99A-004-A01

Parameter	Specification		
Power:			
Input voltage	115 VAC		
Physical:			
Height	2.06 inches (52.32 mm) maximum (including the plunger and grommet)		
Width	4.43 inches (112.52 mm) maximum		
Length	6.02 inches (152.91 mm) maximum		
Weight	0.51 ± 0.05 lbs (0.23 ± 0.023 kg) (Without WELS Battery Unit)		
Bluetooth:			
Wireless interface	Version 2.0 compliant, class 2 power level		
Range	10 meters maximum		
Frequency band	ISM band of 2.4 to 2.485 GHz		
Maximum transmit lever	+4dBm		
Operating Environment	MINIMUM	MAXIMUM	
Ground Survival Temperature	-67°F (-55°C)	185°F (85°C)	
Short Term Operation	-40°F (-40°C)	158°F (70°C)	
Continuous Operation	5°F (-15°C)	131°F (55°C)	
Normal Ground Operation	-	113°F (45°C)	
Normal Flight Operation	-	86°F (30°C)	
Case Temperature	-	203°F (95°C)	
Connectors:	'		
J1 Circular Connector	BACC63CU15-35PN (MIL Standard D38999/20MD35PN)		
J1 Mating Connector	BACC63CT15-35SN (MIL Standard D38999/26MD35SN)		
J4 Antenna Connector	SMA RF Connector, mates with WELS Antenna Unit		

#### **TESTING AND FAULT ISOLATION**

# TECHNICAL SUPPORT AND DATA PACKAGE

#### 1. Introduction

A. This section describes the Return-To-Service test (RTS) for the Unit-Under-Test (UUT). The RTS is derived from the Technical Support and Data Package (TSDP) shown in Table 1001.

# 2. <u>Technical Support and Data Package (TSDP)</u>

A. The TSDP and Test Specification can be ordered from the address shown in paragraph 3. The Test Specification is the basis for the specified TSDP and the shop verified procedure in this CMM.

Technical Support and Data Package(s) / Test Specifications Table 1001

UUT PART NUMBER	TEST SPECIFICATION PART NUMBER/REVISION	TSDP PART NUMBER/REVISION
100-2601-01	210-2601-03 / Rev C	291-0001-01 / Rev -

#### 3. Ordering Information

A. The TSDP can be ordered from:

Securaplane CAGE Code: 0TMJ9

10831 Mavinee Drive Tel: 1-520-297-0844

Tucson AZ 85737 USA Fax 1-520-498-4924

Email: support@securaplane.com Web: www.securaplane.com

# TESTING AND FAULT ISOLATION

#### TASK 33-50-01-99F-802-A01

General Information

SUBTASK 33-50-01-99F-010-A01

A. Introduction

<u>WARNING</u>: BEFORE MATERIALS CALLED OUT IN THIS PUBLICATION ARE USED,

KNOW THE HANDLING, STORAGE, AND DISPOSAL PRECAUTIONS RECOMMENDED BY THE MANUFACTURER OR SUPPLIER. FAILURE

TO FOLLOW THE MANUFACTURERS' OR SUPPLIERS'

RECOMMENDATIONS CAN RESULT IN PERSONAL INJURY OR

DISEASE.

CAUTION: THESE PROCEDURES MUST BE DONE AT A STATIC-FREE

WORKSTATION IN ORDER TO PREVENT DAMAGE TO

ELECTROSTATIC SENSITIVE COMPONENTS.

<u>CAUTION</u>: THIS UNIT HAS ASSEMBLIES THAT ARE SUSCEPTIBLE TO DAMAGE

FROM INCORRECT HANDLING. DO NOT DROP OR HIT THE UNIT

DURING THESE PROCEDURES.

<u>CAUTION</u>: THESE PROCEDURES MUST BE DONE IN A CLEAN ENVIRONMENT IN

ORDER TO PREVENT DAMAGE TO MECHANICAL COMPONENTS.

(1) This section has the testing and fault isolation information for the WELS Control Unit

(WCU).

#### TASK 33-50-01-94B-801-A01

2. <u>Equipment and Materials</u>

#### SUBTASK 33-50-01-94A-001-A01

- A. Consumable Materials
  - (1) No consumable materials are needed for Testing and Fault Isolation procedures.

# SUBTASK 33-50-01-94B-001-A01

- B. Special Tools, Fixtures, and Test Equipment
  - (1) Special tools and test equipment used during the Testing and Fault Isolation procedures are shown in Table 1002.

NOTE: Equivalent alternatives can be used.

Special Tools, Fixtures, and Test Equipment Table 1002 / TABLE 33-50-01-99A-005-A01

Equipment	Characteristics	Accuracy	Source or (CAGE)
WELS Test Box	TE-1128-01		V0TMJ9
WCU Main Test Cable	160-2275-01		V0TMJ9
Battery Simulator Module	TE-2637-01		V0TMJ9
Battery Simulator Cable	TE-2633-01		V0TMJ9
WELS Battery Unit (Fully Charged to 8.4 Volts)	100-2602-01		V0TMJ9
Standard FF RS232 Communication Serial Cable (DB9 to DB9)	AK152-2-R		Commercially available
Computer	Microsoft Windows XP Professional Operating System with (2) available USB Ports and (1) available Serial Port. 512 MB RAM (memory) 10 MB of hard disk space available. PC must also have access to a printer.		Commercially available
WCU Test Program, V1.V00	050-0224-07341 Rev -		V0TMJ9
WCU Main Test Code (8MB Flash-U35)	050-0232-08031 Rev -		V0TMJ9
WCU RF Test Code	050-0230-07341 Rev -		V0TMJ9
WELS 787 Operational SW Code	050-0211-08237 Rev -		V0TMJ9
BlueTest2 Software	Version 1.0.0 Rev 1 (or later)		VU4252
Bluetooth Test Set	Anritsu MT8852A		VU4252
Adapter Cable (and windows driver)	National Instruments GPIB-USB-HS		V64667
Direct Connection Antenna Cable	Pasternack PN PE3876-60 (5 feet in length recommended)		V53919
Omnidirectional Antenna	Antenova PN 2010B4844-01		V53919
Digital Multimeter	True RMS Multimeter 0 to 10 VDC (Fluke 87)	1 %	V89536
J-Link (USB to JTAG Debugger/Programmer)	IAR Systems		V1QQS1
SAM-PROG v2.3 (or later)	Atmel Corp		V1FN41

# TASK 33-50-01-700-801-A01

3. <u>Test Procedures</u>

SUBTASK 33-50-01-700-001-A01

A. Test Requirements


(1) Do all tests with the test unit at the following conditions, unless otherwise specified by an individual test procedure.

Ambient room temperature +68 to 86°F (+20 to 30°C) Humidity Ambient up to 85% relative Input Voltage 115.0  $\pm$  5 VAC

- (2) Regularly examine and certify instrument accuracy/calibration in accordance with applicable government and commercial specifications.
- (3) Visually inspect the unit for signs of missing, broken, bent or cracked parts. Damaged parts must be replaced before the unit is tested.
- (4) Unless otherwise specified, all tolerances are ±1%.
- (5) Disassemble the WCU to subassembly level per the DISASSEMBLY section.
- (6) The test setup for the WCU is shown in Figure 1001.

NOTE: Before any tests are performed, ensure the WELS Battery Unit (WBU) is not still installed in the WCU. If the battery is installed continue to the DISASSEMBLY section for battery removal instructions.





WCU Test Setup Figure 1001 / GRAPHIC 33-50-01-99B-003-A01

### TASK 33-50-01-700-802-A01

4. WCU Test Procedures

NOTE: This section contains the test procedures for verifying the correct performance of the

WCU.

NOTE: The initial WCU Test Set Up uses the WELS Test Box to provide DC power (Simulated

Battery Power) to the UUT. The setup uses the "Battery Simulator Board" to measure the WCU regulated voltages, battery EEPROM verification, battery temperature read back

and to support JTAG programming of the WCU microcontroller.


NOTE: Record all measurements on the WCU Acceptance Test Data Sheet in Table 1003.

SUBTASK 33-50-01-700-002-A01

A. WELS Test Box Calibration Test

NOTE: The WELS Test Box performs a Self-Test on power up. The Self-Test results are displayed on the WCU TEST PROGRAM (Tester) Self-Test Menu in the Windows WCU Test Program. Refer to Figure 1001 for test setup.

- (1) Connect the standard FF RS232 serial cable between the Test Box Serial Connector (SC1) and the PC serial port (COM1) connector. Do not connect the remaining cables.
- (2) Connect AC Power cable to the AC connector on to the WELS Test Box but do not power up the Test Box at this time. Ensure the "AC ARM / AC DISABLE" switch on the top of the Test Box is set to "AC DISABLE". All 6 of the ID switches should be set to the "TEST" position.
- (3) Turn **ON** the WELS Test Box "**MAIN POWER**" switch.
- (4) Power-up the PC and log in. Run the Windows WCU Test Program on the PC.
  - (a) The WCU Test Program will automatically establish a connection between the WCU Test Program and the WELS Test Box. Refer to the WCU Test Program V1.V00 Comm Menu as shown in Figure 1002.
  - (b) Once a good connection is established the Tester Status box will switch from "FLT" to "OK", the UUT box will display "99" and the RX Status indicator will display a flashing green dot. Refer to Figure 1002.



WCU Test Program V1.V00 – Comm Menu – Connected State Figure 1002 / GRAPHIC 33-50-01-99B-004-A01


(5) Verify the following results in the WCU Test Program – (Tester) Self Test Menu. Refer to Figure 1003.

NOTE: The WCU Test Program – (Tester) Self Test Menu automatically displays the same time as the WCU Test Program V1.V00 – Comm Menu.

- (a) Verify the A/D and Mux Signals report 3300mV +/-50mv (3.3V RB column) and 0mV +/-25mV (GND RB column). Record voltages and Pass/Fail results on the Data Sheet.
- (b) Verify the Control Voltage +/- reports 10000mV +/-500mV (+ Input column) and 0mV +/-50mV (- Input column). Record voltages and Pass/Fail results on the Data Sheet.

NOTE: If these readings are out-of-tolerance, repair the WELS Test Hardware before continuing.






WCU Test Program – (Tester) Self Test Menu Figure 1003 / GRAPHIC 33-50-01-99B-005-A01

- (6) Disconnect the communication link between the WCU Test Program and the WELS Test Box by clicking on the "**Disconnect TB**" button in the WCU Test Program V1.V00 Comm Menu. Refer to Figure 1002.
  - (a) Once the connection has ended the Tester Status box will switch from "OK" to "FLT", the UUT box will display "?" and the RX Status indicator will be blank. Refer to Figure 1004.





WCU Test Program V1.V00 – Comm Menu – Disconnected State Figure 1004 / GRAPHIC 33-50-01-99B-006-A01

(7) Turn **OFF** the Test Box "**MAIN POWER**" switch. Leave AC Power Cable connected to Test Box.

SUBTASK 33-50-01-700-003-A01 B. Initial WCU Power-Up

NOTE: Refer to Figure 1001 for the test setup.

- (1) Carefully install the Battery Simulator Module in the WCU battery slot making sure not to bend any connector pins.
- (2) Connect the WCU Main Test Cable from the WCU Main connector on the WELS Test Box to the WCU I/O connector on the WCU under test.
- (3) Connect the Battery Simulator Cable from the WCU Battery connector on the WELS Test Box to the DC Power Connector on the Battery Simulator Module.
- (4) Leave the Test Box "MAIN POWER" switch set to OFF and "AC ARM / AC DISABLE" switch set to "AC DISABLE".

## COMPONENT MAINTENANCE MANUAL 100-2601

(a) Using a Multimeter, verify greater than 5 Meg ohms resistance between the following Test Box Interface Board Test Points. Record resistance values and Pass/Fail results on the Data Sheet.

a) GND and ACL

b) GND and ACH

c) BAT GND and ACL

d) BAT GND and ACH

**CAUTION:** 

BE SURE TO DISCONNECT THE MULTIMETER FROM THE TEST

POINTS BEFORE CONTINUING.

- (5) Ensure the "AC ARM / AC DISABLE" switch on top of the Test Box is in the "AC DISABLE" position.
- (6) Turn **ON** the WELS Test Box "**Main Power**" switch.

NOTE: The following instructions reference information presented in WCU Test Program – Comm Menu. Refer to Figure 1002.

- (7) Click on the "Connect TB" button in the WCU Test Program Comm Menu to establish a connection between the WCU Test Program and the WELS Test Box.
- (8) Once a good connection is established the Tester Status box will switch from "FLT" to "OK", the UUT box will display "99" and the RX Status indicator will display a flashing green dot.
- (9) The following menus will need to be displayed before continuing:

Display Self Test

Display UUT Main Status

**Display UUT Outputs** 

Display UUT Config

Display UUT EEPROM


Display Message Menu

Display Program AutoRun

- (10) Select each menu that needs to be displayed by checking the box next to each Menu description in the Menus section of the WCU Test Program V1.V00 Comm Menu.
- (11) Click on the "**Display Checked Menus**" button to display the menus that are selected.

NOTE: The following instructions reference information presented in WCU Test Program - AUTORUN MENU – Playback Macro Tab as shown in Figure 1005.





WCU Test Program – WCU AutoRun Menu Figure 1005 / GRAPHIC 33-50-01-99B-007-A01

- (12) Select file name "WCU\_RecordC.log" in the Record Name dropdown menu.
- (13) Click on the "Open Playback File" button.
- (14) The "Next Message" button is used from this point to perform the following steps. Do not follow the manual steps in this procedure unless you are troubleshooting. Follow the instructions that are displayed in both the "Step Play Comments" and "Step Play Line(s)" windows of the WCU Test Program WCU AutoRun Menu Playback Macro Tab. Continue from the RF Tests section after the automated process is complete.



NOTE:

The following steps have been automated to streamline the test processes and to ensure that all of the test steps are completed. Though this procedure was also written to support manual test processes the operator is required to use the automated test process. The manual test processes should only be used for troubleshooting purposes. The automated test process is not fully automated at this time. The operator must click the "**Next Message**" button to step through each individual test process. Disregard any other command buttons that are called out in the preceding sections. The "**Next Message**" button is the only button that is used during the automated test process. The operator must flip manual switches on the WELS Test Box when prompted to do so.

**CAUTION:** 

WHEN RUNNING THE AUTOMATED TEST PROCESS DO NOT CLICK ON ANY OTHER COMMAND BUTTONS EXCEPT FOR THE "Next Message" BUTTON. CLICKING ON ANY OTHER BUTTON WILL VOID THE AUTOMATED TEST.

- (15) Click on the "Next Message" button to begin the step through the following sections.
- (16) Turn **ON** the DC power by clicking on the "**Turn DC On**" button in the MAIN STATUS MENU. Refer to Figure 1006.
  - (a) Verify the MAIN STATUS MENU, OUTPUTS STATUS MENU and CONFIGURATION MENU, continue to flash the message "Waiting on UUT Reply" in the UUT Status area of each menu window. Record Pass/Fail result on the Data Sheet.
  - (b) Verify VB+/LD is 0mV +/-25mv in the Tester Status ReadBk column. Record voltage and Pass/Fail result on the Data Sheet.
  - (c) Verify V3.3 is 0mV +/-50mv in the Tester Status ReadBk column. Record voltage and Pass/Fail result on the Data Sheet.
- (17) Turn **OFF** the DC power by clicking on the "**Turn DC Off**" button in the MAIN STATUS MENU.


SUBTASK 33-50-01-700-004-A01

C. WCU Communication and Read Back Test

NOTE: The following instructions

The following instructions reference information presented in WCU Test Program - MAIN STATUS MENU as shown in Figure 1006 and OUTPUTS STATUS MENU as shown in Figure 1008.





WCU Test Program – WCU Main Status Menu Figure 1006 / GRAPHIC 33-50-01-99B-008-A01

- (1) Switch the "AC ARM / AC DISABLE" switch on the top of the Test Box to the "AC ARM" position.
- (2) Turn ON the AC power by clicking on the "Turn AC On" button in the MAIN STATUS MENU.

NOTE: The MAIN STATUS MENU, OUTPUTS STATUS MENU and CONFIGURATION MENU, will display read back values in the UUT Status area once CAN communication is established between the WELS Test Box and the UUT. If the Menu windows continue to flash the "Waiting on UUT Reply" message, after AC power has been turned on, the Test Software may not have been loaded into the Microcontroller Flash Memory. Refer to the "Write Main Test Software to Microcontroller Flash Memory" in the Test Software Programming Procedure section for instructions on how to download the test software.

- (3) Verify the following results in the MAIN STATUS MENU. Reference Figure 1006.
  - (a) Verify Control V is 10000mV +/-500mV in the UUT Status ReadBk column. Record voltage and Pass/Fail result on the Data Sheet.
  - (b) Verify AC ON/ON state is "Y" in both the UUT Status and Tester Status State columns. Record Pass/Fail result on the Data Sheet.



# COMPONENT MAINTENANCE MANUAL 100-2601

- (c) Verify charger state is "E" in the UUT Status State column. Record Pass/Fail result on the Data Sheet.
- (d) Verify VB+/LD is 8000mV +/-500mv in the UUT Status ReadBk column. Record voltage and Pass/Fail result on the Data Sheet.
- (e) Verify VB+/LD is 8000mV +/-500mv in the Tester Status ReadBk column. Record voltage and Pass/Fail result on the Data Sheet.
- (f) Verify VB+/OV ReadBk voltage is less than 100mv in the Tester Status -ReadBk column. Record voltage and Pass/Fail result on the Data Sheet.
- (g) Verify V3.3 is 3300mV +/-100mV in the Tester Status ReadBk column. Record voltage and Pass/Fail result on the Data Sheet.
- (h) Verify VREF 2.5 is 2500mV +/-100mV in the UUT Status ReadBk column. Record voltage and Pass/Fail result on the Data Sheet.
- (j) Verify V2.8 is 2800mV +/-100mV in the UUT Status ReadBk column. Record voltage and Pass/Fail result on the Data Sheet.
- (k) Verify that there are **no Over-Voltage conditions** reported in the MESSAGE MENU. Record Pass/Fail result on the Data Sheet. Refer to Figure 1007 for an example of an Over-Voltage failure condition.



WCU Test Program – Message Menu – Over Voltage Figure 1007 / GRAPHIC 33-50-01-99B-009-A01

(4) Using a Digital Multimeter, verify the following on the Battery Simulator Module:


NOTE: Use TP "GND" as ground reference when measuring voltage at TP V3p3.

- (a) Verify TP V3p3 measures 3300mV +/-100mV. Record voltage and Pass/Fail result on the Data Sheet.
- (b) Verify 3.3V value recorded in section C.(3)(g) of Data Sheet is within +/15mV of the value recorded in section C.(4)(a) of Data Sheet. Record
  Pass/Fail result on the Data Sheet.
- (5) Verify the following results in the OUTPUTS STATUS MENU. Refer to Figure 1008.
  - (a) Verify OUT 1 through OUT 6 states are "D" in the UUT Status EN/DIS column. Record Pass/Fail result on the Data Sheet.



## 100-2601

Verify Output voltages for OUT 1 through OUT 6 are less than 100mV in the (b) Tester Status - ReadBack column. Record Output voltages and Pass/Fail results on the Data Sheet.



WCU Test Program - WCU Outputs Status Menu Figure 1008 / GRAPHIC 33-50-01-99B-010-A01

- (6)Turn ON the DC power by clicking on the "Turn DC On" button in the MAIN STATUS MENU.
- (7) Enable the WCU battery by clicking on the "E" button in the MAIN STATUS MENU -Bat EN/EN - "CMD" column. Verify that the Bat EN/EN state changes from "D" to "E" in the UUT Status - State column.
- (8) Select "MED" from the MAIN STATUS MENU "CMD" column drop down menu for VB+/LD to enable the Medium charger load. Verify that the state changes to "M" in the Tester Status - State column for VB+/LD.
  - Verify the Chgr I value is 500mA +/-200mA in the MAIN STATUS MENU -(a) UUT Status - ReadBk column. Record Charge Current value and Pass/Fail result on the Data Sheet.
  - (b) Record, on the Data Sheet, the current VB+/LD voltage reported in the MAIN STATUS MENU - Tester Status - ReadBk column.
  - Verify VB+/LD drop is less than 500mV by subtracting VB+/LD value logged (c) on Data Sheet section C.(8)(c) from VB+/LD value logged on Data Sheet section C.(3)(e). Record voltage drop and Pass/Fail result on the Data Sheet.

- (9) Disable the battery charger by clicking on the "**D**" button in the MAIN STATUS MENU Charger "CMD" column. Verify that the state changes from "E" to "D" in the UUT Status State column for Charger.
- NOTE: Make sure the CAN bus communication remains stable when the Battery Charger is turned off. If CAN bus communication is lost, the MAIN STATUS MENU, OUTPUTS STATUS MENU and CONFIGURATION MENU will flash the message "Waiting on UUT Reply". This is only a status notification, not a failure.
  - (a) Record, on the Data Sheet, the current VB+/LD voltage reported in the MAIN STATUS MENU Tester Status ReadBk column.
  - (b) Verify VB+/LD drop is greater than 150mV by subtracting VB+/LD value logged on Data Sheet section C.(9)(a) from VB+/LD value logged on Data Sheet section C.(3)(e). Record voltage drop and Pass/Fail result on the Data Sheet.
- (10) Enable the battery charger by clicking on the "E" button in the MAIN STATUS MENU
   Charger "CMD" column. Verify that the state changes from "D" to "E" in the UUT Status State column for Charger.
  - (a) Verify the Chgr I value is 500mA +/-200mA in the MAIN STATUS MENU UUT Status – ReadBk column. Record Charge Current value and Pass/Fail result on the Data Sheet.
- (11) Turn **OFF** the AC power by clicking on the "**Turn AC Off**" button in the MAIN STATUS MENU. Verify that the state changes from "Y" to "N" in the UUT Status State column and the Tester Status State column as shown in Figure 1006.
- NOTE: Make sure the CAN bus communication remains stable when AC Power is turned off. If CAN bus communication is lost, the MAIN STATUS MENU, OUTPUTS STATUS MENU and CONFIGURATION MENU, will flash the message "Waiting on UUT Reply".
  - (a) Record, on the Data Sheet, the current VB+/LD voltage reported in the MAIN STATUS MENU Tester Status ReadBk column.
  - (b) Verify VB+/LD drop is greater than 150mV by subtracting VB+/LD value logged on Data Sheet section C.(11)(a) from VB+/LD value logged on Data Sheet section C.(3)(e). Record voltage drop and Pass/Fail result on the Data Sheet.
- (12) Turn **ON** the AC power by clicking on the "**Turn AC On**" button in the MAIN STATUS MENU. Verify that the state changes from "N" to "Y" in both the UUT Status and Tester Status State columns.
  - (a) Verify Charger state is "E" in the UUT Status State column. Record Pass/Fail result on the Data Sheet.
  - (b) Verify the Chgr I value is 500mA +/-200mA in the MAIN STATUS MENU UUT Status ReadBk column. Record Charge Current value and Pass/Fail result on the Data Sheet.



- (13) Select "**HIGH**" from the MAIN STATUS MENU "CMD" column drop down menu for VB+/LD to enable the High charger load. Verify that the state changes to "H" in the UUT Status State column for VB+/LD.
  - (a) Record, on the Data Sheet, the current VB+/LD voltage reported in the MAIN STATUS MENU Tester Status ReadBk column.
  - (b) Verify VB+/LD drop is less than 1000mV by subtracting VB+/LD value logged on Data Sheet section C.(13)(a) from VB+/LD value logged on Data Sheet section C.(3)(e). Record voltage drop and Pass/Fail result on the Data Sheet.
  - (c) Verify the Chgr I value is greater than 500mA in the MAIN STATUS MENU UUT Status – ReadBk column. Record Charge Current value and Pass/Fail result on the Data Sheet.
- (14) Change the charge mode from high to low by clicking the "L" button in the MAIN STATUS MENU Chgr I "CMD" column.
  - (a) Verify Chgr I state is "L" in the UUT Status State column. Record Pass/Fail result on the Data Sheet.
  - (b) Verify the Chgr I value is less than 200mA in the MAIN STATUS MENU UUT Status ReadBk column. Record Charge Current value and Pass/Fail result on the Data Sheet.
- (15) Select "**OFF**" from the MAIN STATUS MENU "CMD" column drop down menu for VB+/LD to disable charger load.
  - (a) Verify VB+/LD state is "0" in the TESTER Status State column. Record Pass/Fail result on the Data Sheet.

#### SUBTASK 33-50-01-700-005-A01

- D. WCU Battery Temperature Test
  - NOTE: The following instructions reference information presented in WCU Test Program MAIN STATUS MENU as shown in Figure 1006.
  - (1) Click on the "**Fetch Temp**" button in the Wels Test Program MAIN STATUS MENU to read back the battery temperature. The battery temperature will be displayed in Celsius.
    - (a) Record the battery temperature in Celsius on the Data Sheet.
    - (b) Verify the battery temperature is within +7/-2°C of the room ambient temperature recorded on the Data Sheet. Record Pass/Fail result on the Data Sheet.

### SUBTASK 33-50-01-700-006-A01

E. Output Section

NOTE: The following instructions reference information presented in WCU Test Program - MAIN STATUS MENU as shown in Figure 1006 and OUTPUTS STATUS MENU as shown in Figure 1008.

(1) Verify OUT 1 through OUT 6 Output Current values are less than 25mA in the OUTPUTS STATUS MENU - UUT Status – OUT CUR column. Record Output Current values and Pass/Fail results on the Data Sheet.

NOTE: The following steps will need to be performed for Output 1 through Output 6.

- (2) Turn on the Output being tested by clicking on the "**N**" button in the OUTPUTS STATUS MENU "CMD" column that corresponds to the Output being tested. Verify that the state of the CMD column changes from "N" to "Y" for the Output being tested
- (3) Verify the following results in the OUTPUTS STATUS MENU. Refer to Figure 1008.
  - (a) Verify EN/DIS state is "E" in the UUT Status EN/DIS column for the Output being tested. Record Pass/Fail result on the Data Sheet.
  - (b) Verify ACT/INA state is "A" in the UUT Status ACT/INA column for the Output being tested. Record Pass/Fail result on the Data Sheet.
  - (c) Verify Output Current is 1100mA +/-200mA in the UUT Status OUT CUR column for the Output being tested. Record Output Current and Pass/Fail result on the Data Sheet.
  - (d) Verify Output voltage is 7500mV +/-500mV in the Tester Status ReadBack column for the Output being tested. Record Output voltage and Pass/Fail result on the Data Sheet.
- (4) Apply a short to the Output being tested by clicking on the "**N**" button in the OUTPUTS STATUS MENU O SHORT "CMD" column.
- (5) Verify the following results in the OUTPUTS STATUS MENU. Refer to Figure 1008.
  - (a) Verify OVR/NRM state is "Y" in the UUT Status OVR/NRM column for the Output being tested. Record Pass/Fail result on the Data Sheet.
  - (b) Verify Output Current is 0mA +/-25mA in the UUT Status OUT CUR column for the Output being tested. Record Output Current and Pass/Fail result on the Data Sheet.
- (6) Verify for all other Outputs the following results in the OUTPUTS STATUS MENU. Refer to Figure 1008.
  - (a) Verify EN/DIS state is "D" in the UUT Status EN/DIS column for all other Outputs. Record Pass/Fail results on the Data Sheet.
  - (b) Verify ACT/INA state is "I" in the UUT Status ACT/INA column for all other Outputs. Record Pass/Fail results on the Data Sheet.
  - (c) Verify Output voltage is 0mV +/-10mV in the Tester Status ReadBack column for all other Outputs. Record Output voltages and Pass/Fail results on the Data Sheet.
- (7) Remove the short to the Output being tested by clicking on the "Y" button in the OUTPUTS STATUS MENU O SHORT "CMD" column.


- (8) Clear the short to the Output being tested by clicking on the "CLR" button in the OUTPUTS STATUS MENU O SHORT "CMD" column.
  - (a) Verify OVR/NRM state is "N" in the OUTPUTS STATUS MENU UUT Status

     OVR/NRM column for the Output being tested. Record Pass/Fail result on the Data Sheet.
- (9) Turn off the Output being tested by clicking on the "**Y**" button in the OUTPUTS STATUS MENU "CMD" column that corresponds to the Output being tested.
  - (a) Verify that the state of the CMD column changes from "Y" to "N" for the Output being tested. Record Pass/Fail result on the Data Sheet.
- (10) Make sure to complete steps E.(2) through E.(9)(a) for Output 1 through Output 6 before moving on to the next section.

#### SUBTASK 33-50-01-700-007-A01

- F. Configuration / ID Signals Test
  - NOTE: The following instructions reference information presented in WCU Test Program CONFIGURATION MENU as shown in Figure 1009, Figure 1010, and Figure 1011.
  - NOTE The WCU Test Program Configuration Menu is displayed when the Display Checked Menus is selected on the WCU Test Program V1.V00 Comm Menu. Refer to Figure 1002.
  - (1) Make sure ID Switches on Test Box are in the "**TEST**" position.
  - (2) Click on the "Pattern 1" button in the CONFIGURATION MENU.
  - (3) Verify the following in the CONFIGURATION MENU:
    - (a) Verify the UUT Status STATE column alternates between H & L beginning at ID 1 with "L" and ending at IDrtn with "L". Refer to Figure 1009. Record Pass/Fail results on the Data Sheet.
    - (b) Verify the Tester Status READBACK column values alternate between 2100mV +/-100mV and 300mV +/-100mV, beginning with ID 1 with 300mV +/-100mV and ending at IDrtn with 300mV +/-100mV. Refer to Figure 1009. Record READBACK voltage and Pass/Fail results on the Data Sheet.






WCU Test Program – WCU Configuration Menu Figure 1009 / GRAPHIC 33-50-01-99B-011-A01

- (4) Click on the "Pattern 2" button in the CONFIGURATION MENU.
- (5) Verify the following in the CONFIGURATION MENU:
  - (a) Verify the UUT Status STATE column alternates between H & L beginning at ID 1 with "H" and ending at IDrtn with "H". Refer to Figure 1010. Record Pass/Fail results on the Data Sheet.
  - (b) Verify the Tester Status READBACK column values alternate between 2100mV +/-100mV and 300mV +/-100mV, beginning with ID 1 with 2100mV +/-100mV and ending at CTRLen with 300mV +/-100mV. IDrtn READBACK value should be 3300mV +/-100mV. Refer to Figure 1010. Record READBACK voltage and Pass/Fail results on the Data Sheet.






WCU Test Program – WCU Configuration Menu Figure 1010 / GRAPHIC 33-50-01-99B-012-A01

- (6) Verify the following in the CONFIGURATION MENU. Refer to Figure 1011.
- (7) Ground the ID\_1RTN signal by selecting "1" from the "CMD" column drop down menu for rtnGND.
  - (a) Verify IDrtn drops to 0mV +/-100mV in the Tester Status READBACK column. Record voltage and Pass/Fail result on the Data Sheet.
  - (b) Verify rtnGND reports ID\_1RTN GRD in the CONFIGURATION MENU Tester Status READBACK column. Record Pass/Fail result on the Data Sheet.
- (8) Ground the ID\_2RTN signal by selecting "2" from the "CMD" column drop down menu for rtnGND.
  - (a) Verify IDrtn drops to 0mV +/-100mV in the Tester Status READBACK column. Record voltage and Pass/Fail result on the Data Sheet.
  - (b) Verify rtnGND reports ID\_2RTN GRD in the CONFIGURATION MENU Tester Status – READBACK column. Record Pass/Fail result on the Data Sheet.
- (9) Ground the ID\_3RTN signal by selecting "3" from the "CMD" column drop down menu for rtnGND.
  - (a) Verify IDrtn drops to 0mV +/-100mV in the Tester Status READBACK column. Record voltage and Pass/Fail result on the Data Sheet.

## COMPONENT MAINTENANCE MANUAL 100-2601

- (b) Verify rtnGND reports ID\_3RTN GRD in the CONFIGURATION MENU Tester Status – READBACK column. Record Pass/Fail result on the Data Sheet.
- (10) Ground the ID\_4RTN signal by selecting "4" from the "CMD" column drop down menu for rtnGND.
  - (a) Verify IDrtn drops to 0mV +/-100mV in the Tester Status READBACK column. Record voltage and Pass/Fail result on the Data Sheet.
  - (b) Verify rtnGND reports ID\_4RTN GRD in the CONFIGURATION MENU Tester Status – READBACK column. Record Pass/Fail result on the Data Sheet.
- (11) Ground the ID\_5RTN signal by selecting "5" from the "CMD" column drop down menu for rtnGND.
  - (a) Verify IDrtn drops to 0mV +/-100mV in the Tester Status READBACK column. Record voltage and Pass/Fail result on the Data Sheet.
  - (b) Verify rtnGND reports ID\_5RTN GRD in the CONFIGURATION MENU Tester Status READBACK column. Record Pass/Fail result on the Data Sheet.
- (12) Clear the ground to ID\_5RTN signal by selecting "**Off**" from the "CMD" column drop down menu for rtnGND.
  - (a) Verify IDrtn READBACK returns to 3300mV +/-100mV in the Tester Status READBACK column. Record voltage and Pass/Fail result on the Data Sheet.



WCU Test Program – WCU Configuration Menu Figure 1011 / GRAPHIC 33-50-01-99B-013-A01

### SUBTASK 33-50-01-700-008-A01

G. Control Voltage Test

NOTE: The following instructions reference information presented in WCU Test Program - MAIN STATUS MENU as shown in Figure 1006.

- (1) Select "ON" from the MAIN STATUS MENU "CMD" column drop down menu for Control V.
  - (a) Record, on the Data Sheet, the current Control V value reported in the MAIN STATUS MENU UUT Status ReadBk column.
  - (b) Verify Control V + input is 0mV +/-125mV and input is 0mV +/-50mV in the MAIN STATUS MENU Tester Status ReadBk column. Record input voltages and Pass/Fail result on the Data Sheet.
  - (c) Verify the Control V value recorded in section G.(1)(a) of Data Sheet is within +/- 250mV of the Control V (+ Input) value recorded in section G.(1)(b) of Data Sheet. Record Pass/Fail result on the Data Sheet.
- (2) Select "OFF" from the MAIN STATUS MENU "CMD" column drop down menu for Control V.
  - (a) Record, on the Data Sheet, the current Control V value reported in the MAIN STATUS MENU UUT Status ReadBk column.
  - (b) Verify Control V + input is 10000mV +/-500mV and input is 0mV +/-50mV in the MAIN STATUS MENU Tester Status ReadBk column. Record voltages and Pass/Fail result on the Data Sheet.
  - (c) Verify the Control V value recorded in section G.(2)(a) of Data Sheet is within +/- 250mV of the Control V (+ Input) value recorded in section G.(2)(b) of Data Sheet. Record Pass/Fail result on the Data Sheet.
- (3) Select "**ARM**" from the MAIN STATUS MENU "CMD" column drop down menu for Control V.
  - (a) Record, on the Data Sheet, the current Control V value reported in the MAIN STATUS MENU UUT Status ReadBk column.
  - (b) Verify Control V + input is 20000mV +/- 500mV and input is 0mV +/-50mV in the MAIN STATUS MENU Tester Status ReadBk column. Record voltages and Pass/Fail result on the Data Sheet.
  - (c) Verify Control V ReadBk value recorded in section G.(3)(a) is greater than 18000mV. Record Pass/Fail result on the Data Sheet.
- (4) Select "**OFS**" from the MAIN STATUS MENU "CMD" column drop down menu for Control V.
  - (a) Record, on the Data Sheet, the current Control V value reported in the MAIN STATUS MENU – UUT Status – ReadBk column.



## COMPONENT MAINTENANCE MANUAL 100-2601

- (b) Verify Control V + input is 20000mV +/- 500mV and input is 5000mV +/- 200mV in the MAIN STATUS MENU Tester Status ReadBk column. Record voltages and Pass/Fail result on the Data Sheet.
- (c) Verify the Control V value recorded in section G.(4)(a) is within +/- 500mV of the Control V + input voltage minus the Control V input voltage recorded in section G.(4)(b) of the Data Sheet. Record voltage difference between + input and input and Pass/Fail result on the Data Sheet.

Example: (+ input) – (- input) = Control V in UUT ReadBk column or

20000mV - 5000mV = 15000mV

### SUBTASK 33-50-01-700-009-A01

H. EEPROM Test

NOTE: The following instructions reference information presented in WCU Test Program – WCU EEPROM Test and Initialization Menu – EEPROM TEST MENU as shown in Figure 1012 and the MESSAGE MENU as shown in Figure 1013.

NOTE: Make sure each test has finished before starting the next test. The EEPROM 3 test takes the longest to complete (Approximately 14 seconds).

- (1) Run the EEPROM 1 Quick Test by clicking the "Perform EEPROM1 QTest" button in the WCU EEPROM Test and Initialization Menu EEPROM TEST MENU. When the test is complete the program will report Pass or Fail in the EEPROM TEST MENU UUT Status Quick Test Result column. The MESSAGE MENU will also report EEPROM 01 test results.
  - (a) Verify the EEPROM TEST MENU reports a "PASS" in the UUT Status Quick Test Result column for EEPROM 1 and verify the MESSAGE MENU reports the following message:

EEPROM 01 Test Results A5 A5 00 00 00 00 00 00


- (b) Record Pass/Fail result on the Data Sheet.
- (2) Run the EEPROM 2 Quick Test by clicking the "Perform EEPROM2 QTest" button in the WCU EEPROM Test and Initialization Menu EEPROM TEST MENU. When the test is complete the program will report Pass or Fail in the EEPROM TEST MENU UUT Status Quick Test Result column. The MESSAGE MENU will also report EEPROM 02 test results.
  - (a) Verify the EEPROM TEST MENU reports a "PASS" in the UUT Status Quick Test Result column for EEPROM 2 and verify the MESSAGE MENU reports the following message:

EEPROM 02 Test Results A5 A5 00 00 00 00 00 00


(b) Record Pass/Fail result on the Data Sheet.

- (3) Run the EEPROM 1 Full Test by clicking the "Perform EEPROM1 FTest" button in the WCU EEPROM Test and Initialization Menu EEPROM TEST MENU. When the test is complete the program will report Pass or Fail in the EEPROM TEST MENU UUT Status Full Test Result column. The MESSAGE MENU will also report EEPROM 01 test results.
  - (a) Verify the EEPROM TEST MENU reports a "PASS" in the UUT Status Full Test Result column for EEPROM 1 and verify the MESSAGE MENU reports the following message:
    - EEPROM 01 Test Results 00 00 00 00 00 00 00 00
  - (b) Record Pass/Fail result on the Data Sheet.
- (4) Run the EEPROM 2 Full Test by clicking the "Perform EEPROM2 FTest" button in the WCU EEPROM Test and Initialization Menu EEPROM TEST MENU. When the test is complete the program will report Pass or Fail in the EEPROM TEST MENU UUT Status Full Test Result column. The MESSAGE MENU will also report EEPROM 02 test results.
  - (a) Verify the EEPROM TEST MENU reports a "PASS" in the UUT Status Full Test Result column for EEPROM 2 and verify the MESSAGE MENU reports the following message:
    - EEPROM 02 Test Results 00 00 00 00 00 00 00 00
  - (b) Record Pass/Fail result on the Data Sheet.
- (5) Run the EEPROM 3 Full Test by clicking the "Perform EEPROM3 FTest" button in the WCU EEPROM Test and Initialization Menu EEPROM TEST MENU. When the test is complete the program will report Pass or Fail in the EEPROM TEST MENU UUT Status Full Test Result column. The MESSAGE MENU will also report EEPROM 03 test results.
  - (a) Verify the EEPROM TEST MENU reports a "PASS" in the UUT Status Full Test Result column for EEPROM 3 and verify the MESSAGE MENU reports the following message:
    - EEPROM 03 Test Results 00 00 00 00 00 00 00 00
  - (b) Record Pass/Fail result on the Data Sheet.





WCU Test Program – WCU EEPROM Test and Initialization Menu Figure 1012 / GRAPHIC 33-50-01-99B-014-A01



WCU Test Program – Message Menu Figure 1013 / GRAPHIC 33-50-01-99B-015-A01

33-50-01

Page 1026 JAN 05/2009 NOTE:

The first part of the automated test is now completed. The RF Test section is not automated and needs to be run manually. The second part of the automated test supports the Final Verification of WCU After WELS Software is Downloaded section.

#### SUBTASK 33-50-01-700-010-A01

J. RF Test

NOTE:

The previous tests tested the bulk of the board circuitry with a special test program designed to easily test the various board interfaces. The RF Test requires that RF software be loaded to drive the RF module.


CAUTION:

THE RF TEST REQUIRES THAT NO BLUETOOTH EMITTERS BE OPERATING WITHIN 32.8 FEET (10 METERS) OF THE TEST SET.

NOTE: The following software load process must be completed before proceeding:

- (1) Load the RF software per the "Write RF Software to Microcontroller Flash Memory" procedure in the Test Software Programming Procedure section.
- (2) Setup the WELS test equipment as shown in Figure 1014.





WCU RF Test Setup Figure 1014 / GRAPHIC 33-50-01-99B-016-A01

NOTE: ID1, ID2, ID3, ID4, ID5 and CTRLen are switches located on the WELS Test Box interface board. These switches can be selected for the

following positions; CLOSED, OPEN, or TEST.

NOTE: This section of the test will check the internal antenna (Antenna 1)

performance.

(3) Set ID1, ID2, ID3, ID4, ID5 and CTRLen switches on the WELS Test Box to the "OPEN" position.

(4) Attach the Omnidirectional Antenna to RF port on the Anritsu Bluetooth Test Set.

33-50-01

Page 1028 JAN 05/2009



- (5) Place the WCU under test within 6 inches of the Omnidirectional Antenna attached to the Anritsu Bluetooth Test Set.
- (6) Turn **ON** the AC power by clicking on the "**Turn AC On**" button in the WELS Test Program WCU Main Status Menu. Verify that the AC ON/ON State is "Y" in the Tester Status column.
- (7) Turn **ON** the DC power by clicking on the "**Turn DC On**" button in the WELS Test Program WCU Main Status Menu. Verify that the Bat EN/EN State is "Y" in the Tester Status column.
- (8) Turn on the Anritsu Bluetooth Test Set and wait for it to complete the power up sequence.
- NOTE: The following instructions reference information presented in BlueTest2 Program.
- (9) Run the BlueTest2 program on the PC.
  - NOTE: The Blue Test 2 program will appear as an icon on the desktop when it is loaded from its original media (CD or internet) to the computer.
- (10) In the BlueTest2 "system configuration" menu click the "Check Configuration" button.
- (11) Click "**OK**" button when prompted to "Make sure all the Bluetooth Test Sets are powered on".
- (12) Click "**OK**" button in the "EDR Message" window.
- (13) Click "**OK**" button in "System Confirmation" window.
- (14) Select the "Run Bluetooth Test" menu tab.
- (15) Click "**OK**" button in the "Run Test" window.
- (16) In "Script to Run" dropdown menu select "User Script 10".
- (17) Click "Run Test" button and wait for test to complete.
- NOTE: This test may take several minutes to complete.
  - (a) Verify that all tests have passed. Record Pass/Fail result on the Data Sheet.
- (18) Click "View Test Report" button to generate report.
- (19) Click "**Print**" button to print report. This report is to be kept with the data sheets for the WCU under test.
- (20) Close the Report Window by clicking on the "X" in the top right-hand corner of the window.
- NOTE: This section of the test will check the external antenna (Antenna 2) performance.
- (21) Set ID1, ID2, ID3, ID4, and CTRLen switches on the WELS Test Box to the "**OPEN**" position.



- (22) Set ID5 switch on the WELS Test Box to the "CLOSED" position.
- (23) Attach Direct Connection Antenna Cable between RF Port on the Anritsu Bluetooth Test Set and the External Antenna Connector (J4) on the WCU.

NOTE: The following instructions reference information presented in BlueTest2 Program.

- (24) In "Script to Run" dropdown menu select "User Script 3".
- (25) Click "Run Test" button and wait for test to complete.

<u>NOTE</u>: This test may take several minutes to complete.

- (a) Verify that all tests have passed. Record Pass/Fail result on the Data Sheet.
- (26) Click "View Test Report" button to generate report.
- (27) Click "**Print**" button to print report. This report is to be kept with the data sheets for the WCU under test.
- (28) Turn **OFF** the DC power by clicking on the "**Turn DC Off**" button in the WELS Test Program MAIN STATUS MENU.
- (29) Turn **OFF** the AC power by clicking on the "**Turn AC Off**" button in the WELS Test program MAIN STATUS MENU.

#### SUBTASK 33-50-01-700-010-A01

Final Verification of WCU After WELS Software is Downloaded


NOTE: The following software load process must be completed before proceeding:

- (1) Load the WELS software per the Operational Software Programming Procedure section.
- (2) Setup the WELS test equipment as shown in Figure 1015.

**CAUTION:** 

ENSURE THE WELS BATTERY UNIT IS FULLY CHARGED TO 8.1 VOLTS BEFORE INSTALLING INTO THE WCU UNDER TEST. THE OUTPUTS ARE DESIGNED TO TURN OFF IF THE BATTERY VOLTAGE DROPS BELOW 6500mV. USING A FULLY CHARGED BATTERY WILL PREVENT FALSE FAILURES, RELATED TO LOW BATTERY VOLTAGE, FROM OCCURRING.





WCU Final Verification Test Setup with WELS Test Box PC Figure 1015 / GRAPHIC 33-50-01-99B-017-A01

(3) Set ID1, ID2, ID3, ID4 and ID5 switches on the WELS Test Box to the "**OPEN**" position.

- (4) Set CTRLen switch on the WELS Test Box to the "CLOSED" position.
- NOTE: The following instructions reference information presented in WCU Test Program MAIN STATUS MENU as shown in Figure 1006 and OUTPUTS STATUS MENU as shown in Figure 1008.
- (5) Turn **ON** the AC power by clicking on the "**Turn AC On**" button in the WELS Test Program MAIN STATUS MENU. Verify that the AC ON/ON State column is "Y" in the Tester Status column.
- NOTE: The values reported in the UUT Status columns for the Main Status Menu and Outputs Status Menu are not valid and will either be starred or 9999.
- (6) Monitor all 6 Output voltages reported in the OUTPUTS STATUS MENU Tester Status ReadBack column for a minimum of 15 seconds and verify the following.
  - (a) Verify Output voltages remain at 0mV +/-25mV in the OUTPUTS STATUS MENU Tester Status ReadBack column for all Outputs. Record Output voltages and Pass/Fail results on the Data Sheet.
- (7) Click on the "**Op Can**" button in the Message Menu to enable CAN communication between WCU under test and WCU Test Program. Refer to Figure 1016.
  - (a) Verify that the following CAN messages appear in the "Message Menu". The 4 digits in **BOLD**, will change for each CAN message received.

RX CID: 0320 0803, RX Msg (0-3): 0 0 6 0


(b) Record Pass/Fail result on the Data Sheet.



Message Menu – CAN Message Figure 1016 / GRAPHIC 33-50-01-99B-018-A01

- (8) Turn **OFF** the AC power by clicking on the "**Turn AC Off**" button in the WELS Test program MAIN STATUS MENU.
- (9) Setup the WELS test equipment as shown in Figure 1017.





WCU Final Verification Test Setup with Interface and ARM Boards Figure 1017 / GRAPHIC 33-50-01-99B-019-A01

- (10) Ensure the WCU Interface Board and ARM Switch Board are configured as follows:
  - (a) Install a jumper in **CTRLen** position and remove jumpers from all other positions on the WCU Interface Board (TE-2627-01).
  - (b) Switch the S1 AC switch to the "**OFF**" position on the WCU Interface Board (TE-2627-01).
  - (c) Switch the S1 switch on the ARM Switch Board (TE-2628-01) to the "**UP**" 8V (OFF) position.



- (d) Ensure that the AC power cable from the WCU Interface Board is plugged into a 110VAC / 60Hz outlet.
- (11) Install a fully charged Battery Unit (100-2602-01) into the WCU under test.
- (12) The following steps are performed to verify that the WELS Software has been loaded correctly.
- (13) Turn **ON** the AC power to the WCU by switching the S1 AC switch to the "**ON**" position on the WCU Interface Board (TE-2627-01).
- (14) Switch the S1 switch on the ARM Switch Board (TE-2628-01) to the "MIDDLE" 0V (ON) position.
  - (a) Verify that all six output LED's (D1 through D6) on the WCU Interface Board are illuminated. Record Pass/Fail result on the Data Sheet.
- (15) Switch the S1 switch on the ARM Switch Board (TE-2628-01) to the "**DOWN**" 20V (ARM) position.
  - (a) Verify that all six output LED's (D1 through D6) on the WCU Interface Board are off. Record Pass/Fail result on the Data Sheet.
- (16) Turn **OFF** the AC power to the WCU by switching the S1 AC switch to the "**OFF**" position on the WCU Interface Board (TE-2627-01).
  - (a) Verify that all six output LED's (D1 through D6) on the WCU Interface Board are illuminated. Record Pass/Fail result on the Data Sheet.
- (17) Switch the S1 switch on the ARM Switch Board (TE-2628-01) to the "**UP**" 8V (OFF) position.
  - (a) Verify that all six output LED's (D1 through D6) on the WCU Interface Board are off. Record Pass/Fail result on the Data Sheet.
- (18) Disconnect the WCU under test and complete all associated paper work.
- (19) If the WCU does not successfully complete the WCU Test Procedures, remove and replace the Control PWA and repeat the WCU Test Procedures.
- (20) If after replacing the Control PWA the WCU does not successfully complete the WCU Test Procedures, remove and replace the Combined Interface PWA. Repeat the WCU Test Procedures.
- (21) If the WCU successfully completes the WCU Test Procedures, no further tests are required. The unit can be returned to service.



Table 1003. WCU Acceptance Test Data Sheet / TABLE 33-50-01-99A-006-A01

Make a copy of this WCU test data sheet and record the following parameters when specified in the test procedures.

Date			wcu	P/N	100-260	1-01	MOD Status		WCU S/N		
Tested	I By										
Room	Temperat	ure in	Celsius	sius			Room Humidity				
WELS	Test Box	P/N	TE-1128-	1128-01		S/N			Calibration Date		
Blueto	oth Test S	Set Mo	odel#	#   :		S/N	Calibration Date		Date		
DMM Model #				S/N	Calibration Date						
	<b>NSTRUCTIONS:</b> Enter all voltage and current values in millivolts and milliamps. Verify that each test result either Passes or Fails by checking the appropriate box.										

4.A	WELS TEST BOX CALIBRATION TEST				
4.A.(5)(a)	Verify the A/D and Mux Signals report 3300mV +/-50mv (3.3V RB column) and 0mV +/-25mV (GND RB column).	Tester Status			
	Signal	3.3V RB	GND RB	PASS	FAIL
	A/D Ch4, A/D Ch 5				
	MUX1 Ch6, MUX 1 CH 7				
	MUX2 Ch6, MUX 2 CH 7				
	MUX3 Ch6, MUX 3 CH 7				
4.A.(5)(b)	Verify the Control Voltage +/- reports 10000mV +/-500mV (+ Input column) and 0mV +/-50mV (- Input column).	Tester Status			
		+Input	-Input	PASS	FAIL
	Control Voltage +/-				

4.B	INITIAL WCU POWER-UP			
4.B.(4)(a)	Using the Multimeter, verify greater than 5 Meg ohms resistance between the following Test Box Interface Board Test Points.	ohms	PASS	FAIL
	a) GND and ACL			
	b) GND and ACH			
	c) BAT GND and ACL			
	d) BAT GND and ACH			
4.B.(16)(a)	Verify the MAIN STATUS MENU, OUTPUTS STATUS MENU and CONFIGURATION MENU, continue to flash the message "Waiting on UUT Reply" in the UUT Status area of each menu window.		PASS	FAIL
4.B.(16)(b)	Verify VB+/LD is 0mV +/-25mv in the Tester Status - ReadBk column.	Read Bk	PASS	FAIL
4.B.(16)(c)	Verify V3.3 is 0mV +/-50mv in the Tester Status - ReadBk column.	Read Bk	PASS	FAIL
4.C	WCU COMMUNICATION AND REEDBACK TESTS			
4.C.(3)(a)	Verify Control V is 10000mV +/-500mV in the UUT Status – ReadBk column.	Read Bk	PASS	FAIL
4.C.(3)(b)	Verify AC ON/ON state is "Y" in both the UUT Status and Tester Status – State columns.		PASS	FAIL
4.C.(3)(c)	Verify Charger state is "E" in the UUT Status – State column.		PASS	FAIL
	V			
4.C.(3)(d)	Verify VB+/LD is 8000mV +/-500mv in the UUT Status - ReadBk column.	Read Bk	PASS	FAIL
4.C.(3)(e)	Verify VB+/LD is 8000mV +/-500mv in the Tester Status - ReadBk column.	Read Bk	PASS	FAIL
4.C.(3)(f)	Verify VB+/OV ReadBk voltage is less than 100mv in the Tester Status - ReadBk column.	Read Bk	PASS	FAIL



4.C.(3)(g)	Verify V3.3 is 3300mV +/-100mV in the Tester Status – ReadBk column.	Read Bk	PASS	FAIL
4.C.(3)(h)	Verify VREF 2.5 is 2500mV +/-100mV in the UUT Status – ReadBk column.	Read Bk	PASS	FAIL
	W. W. Maria and a second of the second of th			
4.C.(3)(j)	Verify V2.8 is 2800mV +/-100mV in the UUT Status – ReadBk column.	Read Bk	PASS	FAIL
	Verify that there are no Over-Voltage conditions reported in the			
4.C.(3)(k)	MESSAGE MENU.		PASS	FAIL
4.0 (4)(-)	Verify TD V2=2 manage 2000mV / 400mV	TP	DACC	FAU
4.C.(4)(a)	Verify TP V3p3 measures 3300mV +/-100mV.	V3p3	PASS	FAIL
	Verify 2.2V value recorded in coation 4.C (2)(x) of Data Chaptia			
4.C.(4)(b)	Verify 3.3V value recorded in section 4.C.(3)(g) of Data Sheet is within +/-15mV of the value recorded in section 4.C.(4)(a) of Data Sheet.		PASS	FAIL
4.C.(5)(a)	Verify OUT 1 through OUT 6 states are "D" in the UUT Status – EN/DIS column.		PASS	FAIL
4.C.(5)(b)	Verify Output voltages for OUT 1 through OUT 6 are less than 100mV in the Tester Status - ReadBack column.	Read Back	PASS	FAIL
	OUT 1			
	OUT 2			
	OUT 3			
	OUT 4			
	OUT 5			
	OUT 6			
4.C.(8)(a)	Verify the Chgr I value is 500mA +/-200mA in the MAIN STATUS MENU – UUT Status – ReadBk column.	Read Bk	PASS	FAIL
4.C.(8)(b)	Record the current VB+/LD voltage reported in the MAIN STATUS MENU – Tester Status – ReadBk column.	Read Bk		



4.C.(9)(a)  Record the current VB+/LD voltage reported in the MAIN STATUS MENU – Tester Status – ReadBk column.  4.C.(9)(b)  Verify VB+/LD drop is greater than 150mV by subtracting VB+/LD value logged on Data Sheet section 4.C.(9)(a) from VB+/LD value logged on Data Sheet section 4.C.(3)(e).  4.C.(10)(a)  Verify the Chgr I value is 500mA +/-200mA in the MAIN STATUS MENU – UUT Status – ReadBk column.  Record the current VB+/LD voltage reported in the MAIN STATUS MENU – Tester Status – ReadBk column.  Verify VB+/LD drop is greater than 150mV by subtracting VB+/LD value logged on Data Sheet section 4.C.(11)(a) from VB+/LD value logged on Data Sheet section 4.C.(11)(a) from VB+/LD value logged on Data Sheet section 4.C.(11)(a) from VB+/LD value logged on Data Sheet section 4.C.(11)(a) Verify Charger state is "E" in the UUT Status – State column.  PASS FAIL  4.C.(12)(b)  Verify the Chgr I value is 500mA +/-200mA in the MAIN STATUS MENU – UUT Status – ReadBk column.  Read Bk  PASS FAIL  4.C.(13)(a)  Record the current VB+/LD voltage reported in the MAIN STATUS MENU – UUT Status – ReadBk column.  PASS FAIL  4.C.(13)(b)  Verify VB+/LD drop is less than 1000mV by subtracting VB+/LD value logged on Data Sheet section 4.C.(13)(a) from VB+/LD value logged on Data Sheet section 4.C.(13)(a) from VB+/LD value logged on Data Sheet section 4.C.(13)(a) from VB+/LD value logged on Data Sheet section 4.C.(13)(a) from VB+/LD value logged on Data Sheet section 4.C.(3)(e).  Verify the Chgr I value is greater than 500mA in the MAIN STATUS MENU – UUT Status – ReadBk column.  Read Bk  PASS FAIL	4.C.(8)(c)	Verify VB+/LD drop is less than 500mV by subtracting VB+/LD value logged on Data Sheet section 4.C.(8)(c) from VB+/LD value logged on Data Sheet section 4.C.(3)(e).	VB+/LD Drop	PASS	FAIL
4.C.(10)(a) MENU – Tester Status – ReadBk column.  4.C.(9)(b) Verify VB+/LD drop is greater than 150mV by subtracting VB+/LD value logged on Data Sheet section 4.C.(3)(e).  4.C.(10)(a) Verify the Chgr I value is 500mA +/-200mA in the MAIN STATUS MENU – Tester Status – ReadBk column.  4.C.(11)(a) Record the current VB+/LD voltage reported in the MAIN STATUS MENU – Tester Status – ReadBk column.  4.C.(11)(b) Verify VB+/LD drop is greater than 150mV by subtracting VB+/LD value logged on Data Sheet section 4.C.(11)(a) from VB+/LD value logged on Data Sheet section 4.C.(11)(b) Verify Charger state is "E" in the UUT Status – State column.  4.C.(12)(a) Verify the Chgr I value is 500mA +/-200mA in the MAIN STATUS MENU – UUT Status – ReadBk column.  4.C.(13)(a) Record the current VB+/LD voltage reported in the MAIN STATUS MENU – UUT Status – ReadBk column.  4.C.(13)(a) Record the current VB+/LD voltage reported in the MAIN STATUS MENU – UUT Status – ReadBk column.  4.C.(13)(a) Record the current VB+/LD voltage reported in the MAIN STATUS MENU – Tester Status – ReadBk column.  4.C.(13)(b) Verify VB+/LD drop is less than 1000mV by subtracting VB+/LD value logged on Data Sheet section 4.C.(13)(a) from VB+/LD value logged on Data Sheet section 4.C.(13)(a) from VB+/LD value logged on Data Sheet section 4.C.(13)(a) from VB+/LD value logged on Data Sheet section 4.C.(13)(a) from VB+/LD value logged on Data Sheet section 4.C.(3)(e).  4.C.(13)(b) Verify the Chgr I value is greater than 500mA in the MAIN STATUS Read Drop VBASS FAIL					
4.C.(19)(b) value logged on Data Sheet section 4.C.(3)(e).  4.C.(10)(a) Verify the Chgr I value is 500mA +/-200mA in the MAIN STATUS MENU – UUT Status – ReadBk column.  4.C.(11)(a) Record the current VB+/LD voltage reported in the MAIN STATUS MENU – Tester Status – ReadBk column.  4.C.(11)(b) Verify VB+/LD drop is greater than 150mV by subtracting VB+/LD value logged on Data Sheet section 4.C.(11)(a) from VB+/LD value logged on Data Sheet section 4.C.(3)(e).  4.C.(12)(a) Verify Charger state is "E" in the UUT Status – State column.  4.C.(12)(b) Verify the Chgr I value is 500mA +/-200mA in the MAIN STATUS MENU – UUT Status – ReadBk column.  4.C.(13)(a) Record the current VB+/LD voltage reported in the MAIN STATUS MENU – UUT Status – ReadBk column.  4.C.(13)(a) Verify the Chgr I value is 500mA +/-200mA in the MAIN STATUS MENU – Tester Status – ReadBk column.  4.C.(13)(a) Verify VB+/LD drop is less than 1000mV by subtracting VB+/LD value logged on Data Sheet section 4.C.(13)(a) from VB+/LD value logged on Data Sheet section 4.C.(13)(a) from VB+/LD value logged on Data Sheet section 4.C.(13)(a) from VB+/LD value logged on Data Sheet section 4.C.(13)(a) From VB+/LD value logged on Data Sheet section 4.C.(13)(a) From VB+/LD value logged on Data Sheet section 4.C.(13)(a) From VB+/LD value logged on Data Sheet section 4.C.(13)(a) From VB+/LD value logged on Data Sheet section 4.C.(13)(a) From VB+/LD value logged on Data Sheet section 4.C.(13)(a) From VB+/LD value logged on Data Sheet section 4.C.(13)(a) From VB+/LD value logged on Data Sheet section 4.C.(13)(a) From VB+/LD value logged on Data Sheet section 4.C.(13)(a) From VB+/LD value logged on Data Sheet section 4.C.(13)(a) From VB+/LD value logged on Data Sheet section 4.C.(13)(a) From VB+/LD value logged on Data Sheet section 4.C.(13)(a) From VB+/LD value logged on Data Sheet section 4.C.(13)(a) From VB+/LD value logged on Data Sheet section 4.C.(13)(a) From VB+/LD value logged on Data Sheet section 4.C.(13)(a) From VB+/LD value logged on Data Sheet section 4.C.(1	4.C.(9)(a)				
4.C.(19)(b) value logged on Data Sheet section 4.C.(3)(e).  4.C.(10)(a) Verify the Chgr I value is 500mA +/-200mA in the MAIN STATUS MENU – UUT Status – ReadBk column.  4.C.(11)(a) Record the current VB+/LD voltage reported in the MAIN STATUS MENU – Tester Status – ReadBk column.  4.C.(11)(b) Verify VB+/LD drop is greater than 150mV by subtracting VB+/LD value logged on Data Sheet section 4.C.(11)(a) from VB+/LD value logged on Data Sheet section 4.C.(3)(e).  4.C.(12)(a) Verify Charger state is "E" in the UUT Status – State column.  4.C.(12)(b) Verify the Chgr I value is 500mA +/-200mA in the MAIN STATUS MENU – UUT Status – ReadBk column.  4.C.(13)(a) Record the current VB+/LD voltage reported in the MAIN STATUS MENU – UUT Status – ReadBk column.  4.C.(13)(a) Verify the Chgr I value is 500mA +/-200mA in the MAIN STATUS MENU – Tester Status – ReadBk column.  4.C.(13)(a) Verify VB+/LD drop is less than 1000mV by subtracting VB+/LD value logged on Data Sheet section 4.C.(13)(a) from VB+/LD value logged on Data Sheet section 4.C.(13)(a) from VB+/LD value logged on Data Sheet section 4.C.(13)(a) from VB+/LD value logged on Data Sheet section 4.C.(13)(a) From VB+/LD value logged on Data Sheet section 4.C.(13)(a) From VB+/LD value logged on Data Sheet section 4.C.(13)(a) From VB+/LD value logged on Data Sheet section 4.C.(13)(a) From VB+/LD value logged on Data Sheet section 4.C.(13)(a) From VB+/LD value logged on Data Sheet section 4.C.(13)(a) From VB+/LD value logged on Data Sheet section 4.C.(13)(a) From VB+/LD value logged on Data Sheet section 4.C.(13)(a) From VB+/LD value logged on Data Sheet section 4.C.(13)(a) From VB+/LD value logged on Data Sheet section 4.C.(13)(a) From VB+/LD value logged on Data Sheet section 4.C.(13)(a) From VB+/LD value logged on Data Sheet section 4.C.(13)(a) From VB+/LD value logged on Data Sheet section 4.C.(13)(a) From VB+/LD value logged on Data Sheet section 4.C.(13)(a) From VB+/LD value logged on Data Sheet section 4.C.(13)(a) From VB+/LD value logged on Data Sheet section 4.C.(1					
4.C.(11)(a) MENU – UUT Status – ReadBk column.  Record the current VB+/LD voltage reported in the MAIN STATUS MENU – Tester Status – ReadBk column.  Verify VB+/LD drop is greater than 150mV by subtracting VB+/LD value logged on Data Sheet section 4.C.(11)(a) from VB+/LD value logged on Data Sheet section 4.C.(3)(e).  4.C.(12)(a) Verify Charger state is "E" in the UUT Status – State column.  PASS FAIL  4.C.(12)(b) Verify the Chgr I value is 500mA +/-200mA in the MAIN STATUS MENU – UUT Status – ReadBk column.  Record the current VB+/LD voltage reported in the MAIN STATUS MENU – Tester Status – ReadBk column.  Verify VB+/LD drop is less than 1000mV by subtracting VB+/LD value logged on Data Sheet section 4.C.(13)(a) from VB+/LD value logged on Data Sheet section 4.C.(13)(a) from VB+/LD value logged on Data Sheet section 4.C.(3)(e).  PASS FAIL	4.C.(9)(b)	value logged on Data Sheet section 4.C.(9)(a) from VB+/LD value	-	PASS	FAIL
4.C.(11)(a) MENU – UUT Status – ReadBk column.  Record the current VB+/LD voltage reported in the MAIN STATUS MENU – Tester Status – ReadBk column.  Verify VB+/LD drop is greater than 150mV by subtracting VB+/LD value logged on Data Sheet section 4.C.(11)(a) from VB+/LD value logged on Data Sheet section 4.C.(3)(e).  4.C.(12)(a) Verify Charger state is "E" in the UUT Status – State column.  PASS FAIL  4.C.(12)(b) Verify the Chgr I value is 500mA +/-200mA in the MAIN STATUS MENU – UUT Status – ReadBk column.  Record the current VB+/LD voltage reported in the MAIN STATUS MENU – Tester Status – ReadBk column.  PASS FAIL  4.C.(13)(a) Verify VB+/LD drop is less than 1000mV by subtracting VB+/LD value logged on Data Sheet section 4.C.(13)(a) from VB+/LD value logged on Data Sheet section 4.C.(3)(e).  PASS FAIL					
4.C.(11)(a) MENU – Tester Status – ReadBk column.  Werify VB+/LD drop is greater than 150mV by subtracting VB+/LD value logged on Data Sheet section 4.C.(11)(a) from VB+/LD value logged on Data Sheet section 4.C.(3)(e).  4.C.(12)(a) Verify Charger state is "E" in the UUT Status – State column.  PASS FAIL  4.C.(12)(b) Verify the Chgr I value is 500mA +/-200mA in the MAIN STATUS MENU – UUT Status – ReadBk column.  4.C.(13)(a) Record the current VB+/LD voltage reported in the MAIN STATUS MENU – Tester Status – ReadBk column.  Verify VB+/LD drop is less than 1000mV by subtracting VB+/LD value logged on Data Sheet section 4.C.(13)(a) from VB+/LD value logged on Data Sheet section 4.C.(3)(e).  4.C.(13)(b) Verify the Chgr I value is greater than 500mA in the MAIN STATUS Read Drop  PASS FAIL  Read Bk	4.C.(10)(a)			PASS	FAIL
4.C.(11)(a) MENU – Tester Status – ReadBk column.  Werify VB+/LD drop is greater than 150mV by subtracting VB+/LD value logged on Data Sheet section 4.C.(11)(a) from VB+/LD value logged on Data Sheet section 4.C.(3)(e).  4.C.(12)(a) Verify Charger state is "E" in the UUT Status – State column.  PASS FAIL  4.C.(12)(b) Verify the Chgr I value is 500mA +/-200mA in the MAIN STATUS MENU – UUT Status – ReadBk column.  4.C.(13)(a) Record the current VB+/LD voltage reported in the MAIN STATUS MENU – Tester Status – ReadBk column.  Verify VB+/LD drop is less than 1000mV by subtracting VB+/LD value logged on Data Sheet section 4.C.(13)(a) from VB+/LD value logged on Data Sheet section 4.C.(3)(e).  4.C.(13)(b) Verify the Chgr I value is greater than 500mA in the MAIN STATUS Read Drop  PASS FAIL  Read Bk					
4.C.(11)(b) value logged on Data Sheet section 4.C.(11)(a) from VB+/LD value logged on Data Sheet section 4.C.(3)(e).  4.C.(12)(a) Verify Charger state is "E" in the UUT Status – State column.  4.C.(12)(b) Verify the Chgr I value is 500mA +/-200mA in the MAIN STATUS MENU – UUT Status – ReadBk column.  4.C.(13)(a) Record the current VB+/LD voltage reported in the MAIN STATUS MENU – Tester Status – ReadBk column.  4.C.(13)(b) Verify VB+/LD drop is less than 1000mV by subtracting VB+/LD value logged on Data Sheet section 4.C.(13)(a) from VB+/LD value logged on Data Sheet section 4.C.(3)(e).  4.C.(13)(b) Verify the Chgr I value is greater than 500mA in the MAIN STATUS Read Drop PASS FAIL	4.C.(11)(a)				
4.C.(11)(b) value logged on Data Sheet section 4.C.(11)(a) from VB+/LD value logged on Data Sheet section 4.C.(3)(e).  4.C.(12)(a) Verify Charger state is "E" in the UUT Status – State column.  4.C.(12)(b) Verify the Chgr I value is 500mA +/-200mA in the MAIN STATUS MENU – UUT Status – ReadBk column.  4.C.(13)(a) Record the current VB+/LD voltage reported in the MAIN STATUS MENU – Tester Status – ReadBk column.  4.C.(13)(b) Verify VB+/LD drop is less than 1000mV by subtracting VB+/LD value logged on Data Sheet section 4.C.(13)(a) from VB+/LD value logged on Data Sheet section 4.C.(3)(e).  4.C.(13)(b) Verify the Chgr I value is greater than 500mA in the MAIN STATUS Read Drop Read Read Read Read Read Read Read Read					
4.C.(12)(b) Verify the Chgr I value is 500mA +/-200mA in the MAIN STATUS MENU – UUT Status – ReadBk column.  4.C.(13)(a) Record the current VB+/LD voltage reported in the MAIN STATUS MENU – Tester Status – ReadBk column.  4.C.(13)(b) Verify VB+/LD drop is less than 1000mV by subtracting VB+/LD value logged on Data Sheet section 4.C.(13)(a) from VB+/LD value logged on Data Sheet section 4.C.(3)(e).  4.C.(13)(a) Verify the Chgr I value is greater than 500mA in the MAIN STATUS  Read Bk  PASS FAIL  PASS FAIL	4.C.(11)(b)	value logged on Data Sheet section 4.C.(11)(a) from VB+/LD value	-	PASS	FAIL
4.C.(12)(b) Verify the Chgr I value is 500mA +/-200mA in the MAIN STATUS MENU – UUT Status – ReadBk column.  4.C.(13)(a) Record the current VB+/LD voltage reported in the MAIN STATUS MENU – Tester Status – ReadBk column.  4.C.(13)(b) Verify VB+/LD drop is less than 1000mV by subtracting VB+/LD value logged on Data Sheet section 4.C.(13)(a) from VB+/LD value logged on Data Sheet section 4.C.(3)(e).  4.C.(13)(a) Verify the Chgr I value is greater than 500mA in the MAIN STATUS  Read Drop  PASS FAIL					
4.C.(13)(a)  Record the current VB+/LD voltage reported in the MAIN STATUS MENU – Tester Status – ReadBk column.  Read Bk  Verify VB+/LD drop is less than 1000mV by subtracting VB+/LD value logged on Data Sheet section 4.C.(13)(a) from VB+/LD value logged on Data Sheet section 4.C.(3)(e).  PASS FAIL  AC (13)(b)  Verify the Chgr I value is greater than 500mA in the MAIN STATUS  Read  PASS FAIL	4.C.(12)(a)	Verify Charger state is "E" in the UUT Status – State column.		PASS	FAIL
4.C.(13)(a)  Record the current VB+/LD voltage reported in the MAIN STATUS MENU – Tester Status – ReadBk column.  Read Bk  Verify VB+/LD drop is less than 1000mV by subtracting VB+/LD value logged on Data Sheet section 4.C.(13)(a) from VB+/LD value logged on Data Sheet section 4.C.(3)(e).  PASS FAIL  AC (13)(b)  Verify the Chgr I value is greater than 500mA in the MAIN STATUS  Read  PASS FAIL					
4.C.(13)(a) MENU – Tester Status – ReadBk column.  Werify VB+/LD drop is less than 1000mV by subtracting VB+/LD value logged on Data Sheet section 4.C.(13)(a) from VB+/LD value logged on Data Sheet section 4.C.(3)(e).  PASS FAIL  AC (13)(a) Verify the Chgr I value is greater than 500mA in the MAIN STATUS  Read  PASS FAIL	4.C.(12)(b)			PASS	FAIL
4.C.(13)(a) MENU – Tester Status – ReadBk column.  Werify VB+/LD drop is less than 1000mV by subtracting VB+/LD value logged on Data Sheet section 4.C.(13)(a) from VB+/LD value logged on Data Sheet section 4.C.(3)(e).  PASS FAIL  AC (13)(a) Verify the Chgr I value is greater than 500mA in the MAIN STATUS  Read  PASS FAIL					
4.C.(13)(b) value logged on Data Sheet section 4.C.(13)(a) from VB+/LD value logged on Data Sheet section 4.C.(3)(e).  PASS FAIL  A C (13)(c) Verify the Chgr I value is greater than 500mA in the MAIN STATUS Read  PASS FAIL	4.C.(13)(a)				
4.C.(13)(b) value logged on Data Sheet section 4.C.(13)(a) from VB+/LD value logged on Data Sheet section 4.C.(3)(e).  PASS FAIL  A C (13)(c) Verify the Chgr I value is greater than 500mA in the MAIN STATUS Read					
Verify the Chgr I value is greater than 500mA in the MAIN STATUS Read	4.C.(13)(b)	value logged on Data Sheet section 4.C.(13)(a) from VB+/LD value	-	PASS	FAIL
	4.C.(13)(c)			PASS	FAIL



4.C.(14)(a)	Verify Chgr I state is "L" in the UUT Status – State column.		PASS	FAIL
4.C.(14)(b)	Verify the Chgr I value is less than 200mA in the MAIN STATUS MENU – UUT Status – ReadBk column.	Read Bk	PASS	FAIL
4.C.(15)(a)	Verify VB+/LD state is "0" in the TESTER Status – State column.		PASS	FAIL
4.D	WCU BATTERY TEMPERATURE TEST			
4.D.(1)(a)	Record the battery temperature in Celsius.	Temp		
4.D.(1)(b)	Verify the battery temperature is within +7/-2°C of the room ambient temperature recorded on the Data Sheet.		PASS	FAIL
4.E	OUTPUT SECTION			
4.E.(1)	Verify OUT 1 through OUT 6 Output Current values are less than 25mA in the OUTPUTS STATUS MENU - UUT Status – OUT CUR column.	OUT CUR	PASS	FAIL
	OUT 1			
	OUT 2			
	OUT 3			
	OUT 4			
	OUT 5			
	OUT 6			
	OUT 1 RESULTS			
4.E.(3)(a)	Verify EN/DIS state is "E" in the UUT Status – EN/DIS column for Out 1.		PASS	FAIL
4.E.(3)(b)	Verify ACT/INA state is "A" in the UUT Status – ACT/INA column for Out 1.		PASS	FAIL
4.E.(3)(c)	Verify Output Current is 1100mA +/-200mA in the UUT Status – OUT CUR column for Out 1.	OUT CUR	PASS	FAIL



4.E.(3)(d)	Verify Output voltage is 7500mV +/-500mV in the Tester Status – ReadBack column for Out 1.	Read Back	PASS	FAIL
		Duon		
4.E.(5)(a)	Verify OVR/NRM state is "Y" in the UUT Status – OVR/NRM column for Out 1.		PASS	FAIL
4.E.(5)(b)	Verify Output Current is 0mA +/-25mA in the UUT Status – OUT CUR column for Out 1.	OUT CUR	PASS	FAIL
4.E.(6)(a)	Verify EN/DIS state is "D" in the UUT Status – EN/DIS column for all other Outputs.		PASS	FAIL
	OUT 2			
	OUT 3			
	OUT 4			
	OUT 5			
	OUT 6			
4.E.(6)(b)	Verify ACT/INA state is "I" in the UUT Status – ACT/INA column for all other Outputs.		PASS	FAIL
	OUT 2			
	OUT 3			
	OUT 4			
	OUT 5			
	OUT 6			
4.E.(6)(c)	Verify Output voltage is 0mV +/-10mV in the Tester Status – ReadBack column for all other Outputs.	Read Back	PASS	FAIL
	OUT 2			
	OUT 3			
	OUT 4			
	OUT 5			
	OUT 6			
4.E.(8)(a)	Verify OVR/NRM state is "N" in the OUTPUTS STATUS MENU - UUT Status – OVR/NRM column for Out 1.		PASS	FAIL
	Notify that the state of the OMD and			
4.E.(9)(a)	Verify that the state of the CMD column changes from "Y" to "N" for Out 1.		PASS	FAIL

	OUT 2 RESULTS			
4.E.(3)(a)	Verify EN/DIS state is "E" in the UUT Status – EN/DIS column for Out 2.		PASS	FAIL
4.E.(3)(b)	Verify ACT/INA state is "A" in the UUT Status – ACT/INA column for Out 2.		PASS	FAIL
4.E.(3)(c)	Verify Output Current is 1100mA +/-200mA in the UUT Status –	OUT	PASS	FAIL
4.L.(0)(0)	OUT CUR column for Out 2.	CUR	1 700	IAL
4.E.(3)(d)	Verify Output voltage is 7500mV +/-500mV in the Tester Status – ReadBack column for Out 2.	Read Back	PASS	FAIL
4.E.(5)(a)	Verify OVR/NRM state is "Y" in the UUT Status – OVR/NRM column for Out 2.		PASS	FAIL
. –	Verify Output Current is 0mA +/-25mA in the UUT Status – OUT	OUT		
4.E.(5)(b)	CUR column for Out 2.	CUR	PASS	FAIL
4.E.(6)(a)	Verify EN/DIS state is "D" in the UUT Status – EN/DIS column for all other Outputs.		PASS	FAIL
	OUT 1			
	OUT 3			
	OUT 4			
	OUT 6			
4.E.(6)(b)	Verify ACT/INA state is "I" in the UUT Status – ACT/INA column for all other Outputs.		PASS	FAIL
	OUT 1			
	OUT 3			
	OUT 4			
	OUT 6			
	OUT 6			



4.E.(6)(c)	Verify Output voltage is 0mV +/-10mV in the Tester Status – ReadBack column for all other Outputs.	Read Back	PASS	FAIL
	OUT 1	24011		
	OUT 3			
	OUT 4			
	OUT 5			
	OUT 6			
4.E.(8)(a)	Verify OVR/NRM state is "N" in the OUTPUTS STATUS MENU - UUT Status – OVR/NRM column for Out 2.		PASS	FAIL
4.E.(9)(a)	Verify that the state of the CMD column changes from "Y" to "N" for Out 2.		PASS	FAIL
	OUT 3 RESULTS			
4.E.(3)(a)	Verify EN/DIS state is "E" in the UUT Status – EN/DIS column for Out 3.		PASS	FAIL
4.E.(3)(b)	Verify ACT/INA state is "A" in the UUT Status – ACT/INA column for Out 3.		PASS	FAIL
4.E.(3)(c)	Verify Output Current is 1100mA +/-200mA in the UUT Status – OUT CUR column for Out 3.	OUT CUR	PASS	FAIL
4.E.(3)(d)	Verify Output voltage is 7500mV +/-500mV in the Tester Status – ReadBack column for Out 3.	Read Back	PASS	FAIL
4.E.(5)(a)	Verify OVR/NRM state is "Y" in the UUT Status – OVR/NRM column for Out 3.		PASS	FAIL
4.E.(5)(b)	Verify Output Current is 0mA +/-25mA in the UUT Status – OUT CUR column for Out 3.	OUT CUR	PASS	FAIL



4 5 (0)( )	Verify EN/DIS state is "D" in the UUT Status – EN/DIS column for			400	
4.E.(6)(a)	all other Outputs.		Р	ASS	FAIL
	OUT 1				
	OUT 2				
	OUT 4				
	OUT 5				
	OUT 6				
4.E.(6)(b)	Verify ACT/INA state is "I" in the UUT Status – ACT/INA column for all other Outputs.		Р	ASS	FAIL
	OUT 1				
	OUT 2				
	OUT 4				
	OUT 5				
	OUT 6				
4.E.(6)(c)	Verify Output voltage is 0mV +/-10mV in the Tester Status – ReadBack column for all other Outputs.	Read Back	Р	ASS	FAIL
	OUT 1				
	OUT 2				
	OUT 4				
	OUT 5				
	OUT 6				
4.E.(8)(a)	Verify OVR/NRM state is "N" in the OUTPUTS STATUS MENU - UUT Status – OVR/NRM column for Out 3.		Р	ASS	FAIL
4.E.(9)(a)	Verify that the state of the CMD column changes from "Y" to "N" for Out 3.		Р	ASS	FAIL
	OUT 4 RESULTS				
4.E.(3)(a)	Verify EN/DIS state is "E" in the UUT Status – EN/DIS column for Out 4.		Р	ASS	FAIL
	Verify ACT/INIA state is "A" in the LILIT Status ACT/INIA selvers				
4.E.(3)(b)	Verify ACT/INA state is "A" in the UUT Status – ACT/INA column for Out 4.		Р	ASS	FAIL
4.E.(3)(c)	Verify Output Current is 1100mA +/-200mA in the UUT Status – OUT CUR column for Out 4.	OUT CUR	Р	ASS	FAIL

4.E.(3)(d)	ReadBack column for Out 4.	Back		FAIL
		Dack	PASS	. ,
	Varify OVD/NDM atota is "V" in the LILIT Status OVD/NDM			
	Verify OVR/NRM state is "Y" in the UUT Status – OVR/NRM column for Out 4.		PASS	FAIL
	Verify Output Current is 0mA +/-25mA in the UUT Status – OUT	OUT	PASS	FAIL
4.L.(0)(b)	CUR column for Out 4.	CUR	1700	IAL
	Varify EN/DIC state is "D" in the LILIT Status. EN/DIC column for			
	Verify EN/DIS state is "D" in the UUT Status – EN/DIS column for all other Outputs.		PASS	FAIL
	OUT 1			
	OUT 2			
	OUT 3			
	OUT 5			
	OUT 6			
4.5.(0)(1.)	Verify ACT/INA state is "I" in the UUT Status – ACT/INA column for		B400	E A !!
	all other Outputs.		PASS	FAIL
	OUT 1			
	OUT 2			
	OUT 3			
	OUT 5			
	OUT 6			
	Verify Output voltage is 0mV +/-10mV in the Tester Status – ReadBack column for all other Outputs.	Read Back	PASS	FAIL
	OUT 1	Dack		
	OUT 2			
	OUT 3			
	OUT 5			
	OUT 6 Verify OVR/NRM state is "N" in the OUTPUTS STATUS MENU -			
4.E.(8)(a)	UUT Status – OVR/NRM column for Out 4.		PASS	FAIL
/ <b>-</b> /u/2)	Verify that the state of the CMD column changes from "Y" to "N" for Out 4.		PASS	FAIL

	OUT 5 RESULTS			
4.E.(3)(a)	Verify EN/DIS state is "E" in the UUT Status – EN/DIS column for Out 5.		PASS	FAIL
	Novice A OT/INIA state is "A" is the LIHIT Otate as A OT/INIA selection			
4.E.(3)(b)	Verify ACT/INA state is "A" in the UUT Status – ACT/INA column for Out 5.		PASS	FAIL
4 = 4014 1	Verify Output Current is 1100mA +/-200mA in the UUT Status –	OUT	7100	
4.E.(3)(c)	OUT CUR column for Out 5.	CUR	PASS	FAIL
4.E.(3)(d)	Verify Output voltage is 7500mV +/-500mV in the Tester Status – ReadBack column for Out 5.	Read Back	PASS	FAIL
4.E.(5)(a)	Verify OVR/NRM state is "Y" in the UUT Status – OVR/NRM column for Out 5.		PASS	FAIL
4.E.(5)(b)	Verify Output Current is 0mA +/-25mA in the UUT Status – OUT CUR column for Out 5.	OUT CUR	PASS	FAIL
4.E.(6)(a)	Verify EN/DIS state is "D" in the UUT Status – EN/DIS column for all other Outputs.		PASS	FAIL
	OUT 1			İ
	OUT 2			
	OUT 4			. <u></u>
	OUT 6			
4.E.(6)(b)	Verify ACT/INA state is "I" in the UUT Status – ACT/INA column for all other Outputs.		PASS	FAIL
	OUT 1			
	OUT 2 OUT 3			
	OUT 4			
	OUT 6			

4.E.(6)(c)	Verify Output voltage is 0mV +/-10mV in the Tester Status – ReadBack column for all other Outputs.	Read Back	PASS	FAIL
	OUT 1			
	OUT 2			
	OUT 3			
	OUT 4			
	OUT 6			
4.E.(8)(a)	Verify OVR/NRM state is "N" in the OUTPUTS STATUS MENU - UUT Status – OVR/NRM column for Out 5.		PASS	FAIL
4.E.(9)(a)	Verify that the state of the CMD column changes from "Y" to "N" for Out 5.		PASS	FAIL
	OUT 6 RESULTS			
4.E.(3)(a)	Verify EN/DIS state is "E" in the UUT Status – EN/DIS column for Out 6.		PASS	FAIL
4.E.(3)(b)	Verify ACT/INA state is "A" in the UUT Status – ACT/INA column for Out 6.		PASS	FAIL
4.E.(3)(c)	Verify Output Current is 1100mA +/-200mA in the UUT Status – OUT CUR column for Out 6.	OUT CUR	PASS	FAIL
4.E.(3)(d)	Verify Output voltage is 7500mV +/-500mV in the Tester Status – ReadBack column for Out 6.	Read Back	PASS	FAIL
4.E.(5)(a)	Verify OVR/NRM state is "Y" in the UUT Status – OVR/NRM column for Out 6.		PASS	FAIL
4.E.(5)(b)	Verify Output Current is 0mA +/-25mA in the UUT Status – OUT CUR column for Out 6.	OUT CUR	PASS	FAIL
4.E.(6)(a)	Verify EN/DIS state is "D" in the UUT Status – EN/DIS column for all other Outputs.		PASS	FAIL
	OUT 1			
	OUT 2			
	OUT 3			
	OUT 4			
	OUT 5			



<b>4.E.(6)(b)</b> Verify ACT/INA state is "I" in the UUT Status – ACT/INA column for all other Outputs.		PASS	FAIL
OUT 1			
OUT 2			
OUT 3			
OUT 4			
OUT 5			
4.E.(6)(c) Verify Output voltage is 0mV +/-10mV in the Tester Status – ReadBack column for all other Outputs.	Read Back	PASS	FAIL
OUT 1			
OUT 2			
OUT 3			
OUT 4			
OUT 5			
4.E.(8)(a) Verify OVR/NRM state is "N" in the OUTPUTS STATUS MENU - UUT Status – OVR/NRM column for Out 6.		PASS	FAIL
4.E.(9)(a) Verify that the state of the CMD column changes from "Y" to "N" for Out 6.		PASS	FAIL
4.F CONFIGURATION / ID SIGNALS TEST			
<b>4.F.(3)(a)</b> Verify the UUT Status – STATE column alternates between H & L beginning at ID 1 with "L" and ending at IDrtn with "L".	State	PASS	FAIL
ID 1	L		
ID 2	Н		
ID 3	L		
ID 4	Н		
ID 5	L		
10 J			1
CTRLen	н		



4.F.(3)(b)	Verify the Tester Status – ReadBack column values alternate between 2100mV +/-100mV and 300mV +/-100mV, beginning with ID 1 with 300mV +/-100mV and ending at IDrtn with 300mV +/-100mV.	READ BACK	PASS	FAIL
	ID 1			
	ID 2			
	ID 3			
	ID 4			
	ID 5			
	CTRLen			
	IDrtn			
4.F.(5)(a)	Verify the UUT Status – STATE column alternates between H & L beginning at ID 1 with "H" and ending at IDrtn with "H".	State	PASS	FAIL
	ID 1	H		
	ID 2	L		
	ID 3	Н		
	ID 4	L		
	ID 5	Н		
	CTRLen	L		
	IDrtn	Н		
4.F.(5)(b)	Verify the Tester Status – READBACK column values alternate between 2100mV +/-100mV and 300mV +/-100mV, beginning with ID 1 with 2100mV +/-100mV and ending at CTRLen with 300mV +/-100mV. IDrtn READBACK value should be 3300mV +/-100mV.	READ BACK	PASS	FAIL
	ID 1			
	ID 2			
	ID 3			
	ID 4			
	ID 5			
	CTRLen			
	IDrtn			

4.F.(7)(a)	Verify IDrtn drops to 0mV +/-100mV in the Tester Status – READBACK column.	READ BACK	PASS	FAIL
4.F.(7)(b)	Verify rtnGND reports ID_1RTN GRD in the CONFIGURATION MENU – Tester Status – READBACK column.		PASS	FAIL
4.F.(8)(a)	Verify IDrtn drops to 0mV +/-100mV in the Tester Status – READBACK column.	READ BACK	PASS	FAIL
4.F.(8)(b)	Verify rtnGND reports ID_2RTN GRD in the CONFIGURATION MENU – Tester Status – READBACK column.		PASS	FAIL
4.F.(9)(a)	Verify IDrtn drops to 0mV +/-100mV in the Tester Status – READBACK column.	READ BACK	PASS	FAIL
4.F.(9)(b)	Verify rtnGND reports ID_3RTN GRD in the CONFIGURATION MENU – Tester Status – READBACK column.		 PASS	FAIL
4.F.(10)(a)	Verify IDrtn drops to 0mV +/-100mV in the Tester Status – READBACK column.	READ BACK	PASS	FAIL
4.F.(10)(b)	Verify rtnGND reports ID_4RTN GRD in the CONFIGURATION MENU – Tester Status – READBACK column.		PASS	FAIL
4.F.(11)(a)	Verify IDrtn drops to 0mV +/-100mV in the Tester Status – READBACK column.	READ BACK	PASS	FAIL
4.F.(11)(b)	Verify rtnGND reports ID_5RTN GRD in the CONFIGURATION MENU – Tester Status – READBACK column.		PASS	FAIL
4.F.(12)(a)	Verify IDrtn READBACK returns to 3300mV +/-100mV in the Tester Status – READBACK column.	READ BACK	PASS	FAIL

4.G.(1)(a) The GO OF THE G	TROL VOLTAGE TEST current Control V value reported in the MAIN STATUS MENU T Status – ReadBk column.  y Control V + input is 0mV +/-125mV and – input is 0mV +/-	Read Bk			
4.G.(1)(c) Sheet in se  4.G.(2)(a) The Graph of the second					
4.G.(1)(c) Sheet in se  4.G.(2)(a) The Graph of the second					
4.G.(2)(a) The din se  4.G.(2)(b) Verify +/-50 colur  4.G.(2)(c) Sheet in se	√ in the MAIN STATUS MENU - Tester Status – ReadBk nn.	+ input	- input	PASS	FAIL
4.G.(2)(a) The din se  4.G.(2)(b) Verify +/-50 colur  4.G.(2)(c) Sheet in se					
4.G.(2)(a) - UU  4.G.(2)(b Verify +/-50 colur  4.G.(2)(c) Verify Sheet in se	y the Control V value recorded in section 4.G.(1)(a) of Data et is within +/- 250mV of the Control V (+ Input) value recorded ction 4.G.(1)(b) of Data Sheet.			PASS	FAIL
4.G.(2)(a) - UU  4.G.(2)(b Verify +/-50 colur  4.G.(2)(c) Verify Sheet in se					
4.G.(2)(c) +/-50 colur 4.G.(2)(c) Verify Sheet in se	current Control V value reported in the MAIN STATUS MENU T Status – ReadBk column.	Read Bk			
4.G.(2)(c) +/-50 colur 4.G.(2)(c) Verify Sheet in se					
4.G.(2)(c) Sheet in se	y Control V + input is 10000mV +/-500mV and – input is 0mV mV in the MAIN STATUS MENU - Tester Status – ReadBk nn.	+ input	- input	PASS	FAIL
4.G.(2)(c) Sheet in se					
	y the Control V value recorded in section 4.G.(2)(a) of Data et is within +/- 250mV of the Control V (+ Input) value recorded ction 4.G.(2)(b) of Data Sheet.			PASS	FAIL
	current Control V value reported in the MAIN STATUS MENU T Status – ReadBk column.	Read Bk			
	y Control V + input is 20000mV +/- 500mV and – input is 0mV mV in the MAIN STATUS MENU - Tester Status – ReadBk nn.	+ input	- input	PASS	FAIL
	y Control V ReadBk value recorded in section 4.G.(3)(a) is ter than 18000mV.			PASS	FAIL
	current Control V value reported in the MAIN STATUS MENU T Status – ReadBk column.	Read Bk			
4.G.(4)(b   5000	y Control V + input is 20000mV +/- 500mV and – input is mV +/-200mV in the MAIN STATUS MENU - Tester Status – IBk column.	+ input	- input	PASS	FAIL

4.G.(4)(c)	Verify the Control V value recorded in section 4.G.(4)(a) is within +/- 500mV of the Control V + input voltage minus the Control V - input voltage recorded in section 4.G.(4)(b) of the Data Sheet.	Voltage Diff.	PASS	FAIL
4.H	EEPROM TEST			
4.H.(1)(a)	Verify the EEPROM TEST MENU reports a "PASS" in the UUT Status – Quick Test Result column for EEPROM 1 and verify the MESSAGE MENU reports the following message:  EEPROM 01 Test Results A5 A5 00 00 00 00 00 00		PASS	FAIL
	EEPROM 01 Test Results A5 A5 00 00 00 00 00 00			
4.H.(2)(a)	Verify the EEPROM TEST MENU reports a "PASS" in the UUT Status – Quick Test Result column for EEPROM 2 and verify the MESSAGE MENU reports the following message:		PASS	FAIL
	EEPROM 02 Test Results A5 A5 00 00 00 00 00 00			
4.H.(3)(a)	Verify the EEPROM TEST MENU reports a "PASS" in the UUT Status – Full Test Result column for EEPROM 1 and verify the MESSAGE MENU reports the following message:  EEPROM 01 Test Results 00 00 00 00 00 00 00		PASS	FAIL
4.H.(4)(a)	Verify the EEPROM TEST MENU reports a "PASS" in the UUT Status – Full Test Result column for EEPROM 2 and verify the MESSAGE MENU reports the following message:  EEPROM 02 Test Results 00 00 00 00 00 00 00		PASS	FAIL
	22. Now 62 100t Noodko 00 00 00 00 00 00			
4.H.(5)(a)	Verify the EEPROM TEST MENU reports a "PASS" in the UUT Status – Full Test Result column for EEPROM 3 and verify the MESSAGE MENU reports the following message:		PASS	FAIL
	EEPROM 03 Test Results 00 00 00 00 00 00 00 00			
4.J	RF TEST			
4.J.(17)(a)	Verify that all tests have passed.		PASS	FAIL
4.J.(25)(a)	Verify that all tests have passed.		PASS	FAIL

4.K	FINAL VERIFICATION OF WCU AFTER WELS SOFTWARE IS DOWNLOADED				
4.K.(6)(a)	Verify Output voltages remain at 0mV +/-25mV in the OUTPUTS STATUS MENU - Tester Status – ReadBack column for all Outputs.	Read Back		PASS	FAIL
	OUT 1				
	OUT 2				
	OUT 3				
	OUT 4				
	OUT 5				
	OUT 6				
4.K.(7)(a)	Verify that the following CAN message appears in the "Message Menu". The 4 digits below, that are in <b>BOLD</b> , will change in each CAN message received.  RX CID: 0320 <b>0303</b> , RX Msg (0-4): 0 0 0 0			PASS	FAIL
4.K.(14)(a )	Verify that all six output LED's (D1 through D6) on the WCU Interface Board are illuminated.			PASS	FAIL
4.K.(15)(a )	Verify that all six output LED's (D1 through D6) on the WCU Interface Board are off.			PASS	FAIL
4.K.(16)(a )	Verify that all six output LED's (D1 through D6) on the WCU Interface Board are illuminated.			PASS	FAIL
4.K.(17)(a )	Verify that all six output LED's (D1 through D6) on the WCU Interface Board are off.			PASS	FAIL


## TASK 33-50-01-700-802-A01

Test Software Programming Procedure

NOTE: This section contains the test software programming procedures for the WCU.

SUBTASK 33-50-01-700-011-A01

- A. Write Main Test Software to Microcontroller Flash Memory
  - (1) The test setup for programming the WCU is shown in Figure 1018.




Equipment Setup for Programming WCU Figure 1018 / GRAPHIC 33-50-01-99B-020-A01

NOTE: The following instructions reference information presented in WCU Test Program V1.V00 – Comm Menu – Connected State as shown in Figure 1002 and WCU Test Program - MAIN STATUS MENU as shown in Figure 1006.

- (2) Turn **ON** the WELS Test Box "**MAIN POWER**" switch.
- (3) Run the Windows WCU Test Program on the PC.
- (4) The WCU Test Program will automatically establish a connection between the WCU Test Program and the WELS Test Box. Refer to the WCU Test Program V1.V00 Comm Menu as shown in Figure 1002.
- Once a good connection is established the Tester Status box will switch from "FLT" to "OK", the UUT box will display "99" and the RX Status indicator will display a flashing green dot. Refer to Figure 1002.
- (6) The following menu will need to be displayed before continuing:

# **Display UUT Main Status**

- (7) Select the menu that needs to be displayed by checking the box next to the Menu description in the Menus section of the WCU Test Program V1.V00 Comm Menu.
- (8) Click the "Display Checked Menus" button to display the menu that is selected.
- (9) Turn **ON** the AC power by clicking on the "**Turn AC On**" button in the MAIN STATUS MENU as shown in Figure 1006.
- (10) Turn **ON** the DC power by clicking on the "**Turn DC On**" button in the MAIN STATUS MENU as shown in Figure 1006.



SAM-PROG v2.3 Menu Figure 1019 / GRAPHIC 33-50-01-99B-021-A01

NOTE: The following instructions reference information presented in the SAM-PROG Software Program as shown in Figure 1019 and Figure 1020.

- (11) Start the SAM-PROG software application on the PC.
- (12) Click on the "**Browse**" button and select the "**welsapp.bin**" file. The "**welsapp.bin**" file is located at the following location:

H:\RELEASE\050\0232\08031

- (13) Check "None" for the PIO indicator for successful programming option.
- (14) Select "**18432000**" as the Crystal Oscillator Frequency (Hz).
- (15) Check the "Auto-mode" option box.



(16) Click on the "Yes" button to connect to target and write to flash memory.

NOTE: During the flash memory download the "In progress:" and "Active Connection:" status will be "1".

(17) Once the download is complete, SAM-PROG will report whether the download was successful or not. Refer to Figure 1020.

## Successful Download



# Failed Download



SAM-PROG Download Status Figure 1020 / GRAPHIC 33-50-01-99B-022-A01

- (18) Close the SAM-PROG program by clicking on the "**EXIT**" button.
- (19) Turn **OFF** the AC power by clicking on the "**Turn AC Off**" button in the WELS Test Program MAIN STATUS MENU as shown in Figure 1006.
- (20) Turn **OFF** the DC power by clicking on the "**Turn DC Off**" button in the WELS Test Program MAIN STATUS MENU as shown in Figure 1006.

#### SUBTASK 33-50-01-700-012-A01

- B. Write RF Software to Microcontroller Flash Memory
  - (1) The test setup for programming the WCU is shown in Figure 1018.

NOTE: The following instructions reference information presented in WCU Test Program V1.V00 – Comm Menu – Connected State as shown in Figure 1002 and WCU Test Program - MAIN STATUS MENU as shown in Figure 1006.

- (2) Turn **ON** the WELS Test Box "**MAIN POWER**" switch.
- (3) Run the Windows WCU Test Program on the PC.
- (4) The WCU Test Program will automatically establish a connection between the WCU Test Program and the WELS Test Box. Refer to the WCU Test Program V1.V00 Comm Menu as shown in Figure 1002.
- Once a good connection is established the Tester Status box will switch from "FLT" to "OK", the UUT box will display "99" and the RX Status indicator will display a flashing green dot. Refer to Figure 1002.



(6) The following menu will need to be displayed before continuing:

## **Display UUT Main Status**

- (7) Select the menu that needs to be displayed by checking the box next to the Menu description in the Menus section of the WCU Test Program V1.V00 Comm Menu.
- (8) Click the "Display Checked Menus" button to display the menu that is selected.
- (9) Turn **ON** the AC power by clicking on the "**Turn AC On**" button in the MAIN STATUS MENU as shown in Figure 1006.
- (10) Turn **ON** the DC power by clicking on the "**Turn DC On**" button in the MAIN STATUS MENU as shown in Figure 1006.
- NOTE: The following instructions reference information presented in the SAM-PROG Software Program as shown in Figure 1019 and Figure 1020.
- (11) Start the SAM-PROG software application on the PC.
- (12) Click on the "Browse" button and select the "welsapp.bin" file. The "welsapp.bin" file is located at the following location:
  - H:\RELEASE\050\0230\07341
- (13) Check "**None**" for the PIO indicator for successful programming option.
- (14) Select "**18432000**" as the Crystal Oscillator Frequency (Hz).
- (15) Check the "Auto-mode" option box.
- (16) Click on the "Yes" button to connect to target and write to flash memory.
- NOTE: During the flash memory download the "In progress:" and "Active Connection:" status will be "1".
- (17) Once the download is complete, SAM-PROG will report whether the download was successful or not. Refer to Figure 1020.
- (18) Close the SAM-PROG program by clicking on the "**EXIT**" button.
- (19) Turn **OFF** the AC power by clicking on the "**Turn AC Off**" button in the WELS Test Program MAIN STATUS MENU as shown in Figure 1006.
- (20) Turn **OFF** the DC power by clicking on the "**Turn DC Off**" button in the WELS Test Program MAIN STATUS MENU as shown in Figure 1006.

#### TASK 33-50-01-700-803-A01

Operational Software Programming Procedure

NOTE: This section contains the operational software programming procedures for the WCU.

#### SUBTASK 33-50-01-700-013-A01

- A. Write WELS Software to the Microcontroller Flash Memory
  - (1) The test setup for programming the WCU is shown in Figure 1018.
  - (2) Install the WELS Software (Built Code).
  - NOTE: The following instructions reference information presented in the SAM-PROG Software Program as shown in Figure 1019 and Figure 1020 and the WCU Test Program MAIN STATUS MENU as shown in Figure 1006.
  - (3) Turn **ON** the AC power by clicking on the "**Turn AC On**" button in the WELS Test Program MAIN STATUS MENU. Verify that the AC ON/ON State column is "Y" for both the UUT Status and Tester Status.
  - (4) Turn **ON** the DC power by clicking on the "**Turn DC On**" button in the WELS Test Program MAIN STATUS MENU.
  - (5) Run the SAM-PROG program on the PC.
  - NOTE: The SAM-PROG program will appear as an icon on the desktop when it is loaded from its original media (CD or internet) to the computer.
  - (6) Perform the following steps in the SAM-PROG menu:
  - (7) Click on the "Browse" button and select the "welsapp.bin" file. The "welsapp.bin" file is located at the following location:
  - (8) Check "None" for the PIO indicator for successful programming option.
  - (9) Select "**18432000**" as the Crystal Oscillator Frequency (Hz).
  - (10) Check the "Auto-mode" option box.
  - (11) Click on the "Yes" button to connect to target and write to flash memory.
  - NOTE: During the flash memory download the "In progress:" and "Active Connection:" status will be "1".
  - (12) Once the download is complete, SAM-PROG will report whether the download was successful or not. Refer to Figure 1020.
  - (13) Close the SAM-PROG program by clicking on the "**EXIT**" button.
  - (14) Turn **OFF** the AC power by clicking on the "**Turn AC Off**" button in the WELS Test Program MAIN STATUS MENU as shown in Figure 1006.
  - (15) Turn **OFF** the DC power by clicking on the "**Turn DC Off**" button in the WELS Test Program MAIN STATUS MENU as shown in Figure 1006.

## **SCHEMATICS AND WIRING DIAGRAMS**

TASK 33-50-01-99F-803-A01

1. <u>General Information</u>


SUBTASK 33-50-01-99F-011-A01

- A. Introduction
  - (1) This section has the schematics for the WELS Control Unit (WCU). The WCU schematic is shown in Figure 2001.



THIS PAGE INTENTIONALLY LEFT BLANK





WELS Control Unit Schematic Figure 2001 / GRAPHIC 33-50-01-99B-023-A01



THIS PAGE INTENTIONALLY LEFT BLANK



## DISASSEMBLY

TASK 33-50-01-99F-804-A01 **General Information** 

SUBTASK 33-50-01-99F-012-A01

Α. Introduction

> WARNING: BEFORE MATERIALS CALLED OUT IN THIS PUBLICATION ARE USED.

> > KNOW THE HANDLING, STORAGE, AND DISPOSAL PRECAUTIONS RECOMMENDED BY THE MANUFACTURER OR SUPPLIER. FAILURE

TO FOLLOW THE MANUFACTURERS' OR SUPPLIERS'

RECOMMENDATIONS CAN RESULT IN PERSONAL INJURY OR

DISEASE.

CAUTION: DISASSEMBLY MUST BE DONE WITH PROPER ESD PRECAUTIONS.

FAILURE TO FOLLOW THIS CAUTION MAY RESULT IN DAMAGE TO

THE UNIT.

CAUTION: THIS UNIT HAS ASSEMBLIES THAT ARE SUSCEPTIBLE TO DAMAGE

FROM INCORRECT HANDLING, DO NOT DROP OR HIT THE UNIT

DURING THESE PROCEDURES.

CAUTION: THESE PROCEDURES MUST BE DONE IN A CLEAN ENVIRONMENT IN

ORDER TO PREVENT DAMAGE TO MECHANICAL COMPONENTS.

(1) This section has the disassembly information for the WELS Control Unit (WCU).

(2)Disassemble in a dry, bright, clean room.

(3)Be careful to prevent damage to parts that can be used again.

(4) Make sure the WELS battery unit has been removed from the WCU. See the WELS

Battery Unit Removal procedures in the DISASSEMBLY section.

Discard the circular connector gasket and the SMA connector gasket. NOTE:

#### TASK 33-50-01-94B-802-A01

2. **Equipment and Materials** 

SUBTASK 33-50-01-94A-002-A01

Consumable Materials Α.

> Consumable materials used during the Disassembly procedures are shown in (1)

Table 3001.

NOTE: Equivalent alternatives can be used.

Table 3001. Consumable Materials / TABLE 33-50-01-99A-007-A01

Name	Specification or Part Number	Source or (CAGE)
Cleaning Cloth	Lint-free	Commercially available
Isopropyl alcohol	Federal Specification TT-I-735	Commercially available



#### SUBTASK 33-50-01-94B-002-A01

- B. Special Tools, Fixtures, and Test Equipment
  - (1) No special tools, fixtures, or test equipment are needed for Disassembly procedures.

#### TASK 33-50-01-060-801-A01

3. Disassembly Procedures

#### SUBTASK 33-50-01-060-001-A01


A. WELS Battery Unit Removal

NOTE: The following procedures are required to remove the battery from the WCU only if the battery is still installed.

(1) Insert standard 3/32 inch hex key or similar size tool into battery latch hole. See Figure 3001.

NOTE: The tool needs to fit into a 0.125 inch (3.18MM) diameter hole.

- (2) Lift battery latch with tool.
- (3) Grip the battery pack on both sides and pull out.



WELS Battery Unit Removal Figure 3001 / GRAPHIC 33-50-01-99B-024-A01

33-50-01

Page 3002 JAN 05/2009

#### SUBTASK 33-50-01-060-002-A01

B. Disassemble the WCU Assembly

NOTE: Refer to the IPL Figure 1 for an illustration of the WCU assembly Numbers in parenthesis ( ) refer to item numbers on the illustration.

- (1) Remove three plungers (20) and three grommets (30) from the tabs located on the unit.
- (2) If the nameplate label (40) or RF transceiver label (50) is damaged, peel the damaged label from the unit.

NOTE: If the nameplate label (40) is removed, mark the new label with the identification information from the old label.

- (3) Clean the peeled area with a lint free cloth dampened with isopropyl alcohol and allow the cleaned area to air dry.
  - NOTE: Do not remove the nameplate label (40) or RF transceiver label (50) unless it is damaged.
- (4) Remove the male connector cap (60), nut and washer from the J4 antenna connector located on the front case (90).

NOTE: The nut and washer are part of the SMA connector as shown in IPL Figure 2.

- (5) Remove four screws (80), four lock washers (90) and four flat washers (100) from the front case (70).
- (6) Use a razor blade knife to cut the adhesive located on the edges where the front case (70) meets the back case (230).
- (7) Grasp the locking tabs on the front case (70), squeeze the locking tabs together and pull the front case away from the back case (230).
- (8) Pull the adhesive from the front case (70) and the back case (230). Clean the peeled area with a lint free cloth dampened with isopropyl alcohol and allow the cleaned area to air dry.
- (9) Remove the circular connector gasket (110) and the SMA connector gasket (120) from the electronic assembly (130). Discard gaskets.
- (10) Remove two screws (140), two lock washers (150) and two flat washers (160) from the electronic assembly (130).
- (11) Remove the electronic assembly (130) from the back case (230).
- (12) Remove two screws (180), two lock washers (190) and two flat washers (200) from the inside of the back case (230) and remove the battery clip bracket (170).
- (13) Remove the battery clip (210) and the compression spring (220) from the back case (230).

## SUBTASK 33-50-01-060-003-A01

C. Disassemble the Electronic Assembly

NOTE: Refer to the IPL Figure 2 for an illustration of the electronic assembly. Numbers in parenthesis ( ) refer to item numbers on the illustration.

- (1) Remove one screw (20), one lock washer (30) and one flat washer (40) from the combined interface PWA (10).
- (2) Remove the combined interface PWA (10) from the control PWA (50).

NOTE: The nut (70) and washer (80) are part of the SMA connector (60) and are procured with the SMA connector (60).



## **CLEANING**

TASK 33-50-01-99F-805-A01 1. General Information

SUBTASK 33-50-01-99F-013-A01

A. Introduction

WARNING: BEFORE MATERIALS CALLED OUT IN THIS PUBLICATION ARE USED,

KNOW THE HANDLING, STORAGE, AND DISPOSAL PRECAUTIONS RECOMMENDED BY THE MANUFACTURER OR SUPPLIER. FAILURE

TO FOLLOW THE MANUFACTURERS' OR SUPPLIERS'

RECOMMENDATIONS CAN RESULT IN PERSONAL INJURY OR

DISEASE.

<u>CAUTION</u>: THESE PROCEDURES MUST BE DONE AT A STATIC-FREE

WORKSTATION IN ORDER TO PREVENT DAMAGE TO

ELECTROSTATIC SENSITIVE COMPONENTS.

CAUTION: THIS UNIT HAS ASSEMBLIES THAT ARE SUSCEPTIBLE TO DAMAGE

FROM INCORRECT HANDLING. DO NOT DROP OR HIT THE UNIT

DURING THESE PROCEDURES.

CAUTION: THESE PROCEDURES MUST BE DONE IN A CLEAN ENVIRONMENT IN

ORDER TO PREVENT DAMAGE TO MECHANICAL COMPONENTS.

(1) This section has general procedures recommended by Securaplane to clean the WELS Control Unit (WCU). There is no disassembly required to clean the unit.

#### TASK 33-50-01-94B-803-A01

2. Equipment and Materials

SUBTASK 33-50-01-94A-003-A01

A. Consumable Materials

 Consumable materials used during the Cleaning procedures are shown in Table 4001.

NOTE: Equivalent alternatives can be used.

Table 4001. Consumable Materials / TABLE 33-50-01-99A-008-A01

Name	Specification or Part Number	Source or (CAGE) Code
Cleaning Cloth	MIL-C-85043	Commercially available

SUBTASK 33-50-01-94B-003-A01

B. Special Tools, Fixtures, and Test Equipment

(1) No special tools, fixtures, or test equipment are needed for Cleaning procedures.

33-50-01

Page 4001 JAN 05/2009

# TASK 33-50-01-100-801-A01 3. Cleaning Procedures

#### SUBTASK 33-50-01-100-001-A01

- A. Cleaning Practices
  - (1) Each part must be cleaned with the procedures in this section or the equivalent procedures used by an approved overhaul facility.
  - (2) These procedures agree with good shop procedures as used by the Securaplane facility. Clean parts are important to satisfactory operation.
  - (3) Use clean, dry lint-free cleaning cloth to dry parts.

## SUBTASK 33-50-01-100-002-A01

B. External Cleaning

NOTE: Cleaning is limited to external cleaning only.

(1) Clean the outside surfaces of the unit with a cleaning cloth.

NOTE: Use approved static sensitive bags for part storage after cleaning. Do not use tape, loose plastic, or rags to protect clean parts.

(2) Install dust cap (supplied with unit) on the J1 and J4 connector to protect against contamination and thread damage.

NOTE: Use approved caps, plugs and barrier materials for part storage after cleaning. Do not use tape, loose plastic, or rags to protect clean parts.

## INSPECTION/CHECK

#### TASK 33-50-01-99F-806-A01

1. General Check Information

SUBTASK 33-50-01-99F-014-A01

A. Introduction

(1) This section has the general procedures to check the WELS Control Unit (WCU). There is no disassembly required to check the unit.

#### TASK 33-50-01-94B-804-A01

2. Equipment and Materials

SUBTASK 33-50-01-94A-004-A01

A. Consumable Materials

(1) No consumable materials are needed for the Check procedures.

SUBTASK 33-50-01-94B-004-A01

- B. Special Tools, Fixtures, and Test Equipment
  - (1) No special tools, fixtures, or test equipment are needed for Check procedures.

TASK 33-50-01-210-801-A01

3. Check Procedures

SUBTASK 33-50-01-210-001-A01

- Internal Visual Checks
  - (1) There are no internal visual checks.

NOTE: Internal visual checks can only be done at an approved Securaplane facility.

SUBTASK 33-50-01-210-002-A01

- B. External Visual Checks
  - (1) Check the unit for nicks, cracks, scores, dents, scratches, corrosion, or broken welds that may affect the unit's operation.
  - (2) Check the identification, information, and instruction labels and make sure they are legible and securely attached.
  - (3) Check the connectors for broken, bent, or loose pins. Make sure the connectors are mounted correctly.
  - (4) Check the chassis assembly for loose or missing fasteners.



THIS PAGE INTENTIONALLY LEFT BLANK



## **ASSEMBLY**

TASK 33-50-01-99F-807-A01

General Information

SUBTASK 33-50-01-99F-015-A01

A. Introduction

WARNING: BEFORE MATERIALS CALLED OUT IN THIS PUBLICATION ARE USED,

KNOW THE HANDLING, STORAGE, AND DISPOSAL PRECAUTIONS RECOMMENDED BY THE MANUFACTURER OR SUPPLIER. FAILURE

TO FOLLOW THE MANUFACTURERS' OR SUPPLIERS'

RECOMMENDATIONS CAN RESULT IN PERSONAL INJURY OR

DISEASE.

CAUTION: ASSEMBLY MUST BE DONE WITH PROPER ESD PRECAUTIONS.

FAILURE TO FOLLOW THIS CAUTION MAY RESULT IN DAMAGE TO

THE UNIT.

<u>CAUTION</u>: THIS UNIT HAS ASSEMBLIES THAT ARE SUSCEPTIBLE TO DAMAGE

FROM INCORRECT HANDLING. DO NOT DROP OR HIT THE UNIT

DURING THESE PROCEDURES.

CAUTION: THESE PROCEDURES MUST BE DONE IN A CLEAN ENVIRONMENT IN

ORDER TO PREVENT DAMAGE TO MECHANICAL COMPONENTS.

(1) This section has the procedures to assemble the WELS Control Unit (WCU).

(2) Check the parts for damage. Refer to the INSPECTION/CHECK section.

(3) Assemble in a dry, bright, clean room.

NOTE: A new circular connector gasket and SMA connector gasket is required.

TASK 33-50-01-94B-805-A01

2. Equipment and Materials

SUBTASK 33-50-01-94A-005-A01

A. Consumable Materials

 Consumable materials used during the Assembly procedures are shown in Table 7001.

NOTE: Equivalent alternatives can be used.

Table 7001. Consumable Materials / TABLE 33-50-01-99A-009-A01

Name	Specification or	Source or
	Part Number	(CAGE)
Silicone Adhesive Clear	(3145) MIL-A-46146	Commercially available
Cleaning Cloth	MIL-C-85043	Commercially available
Isopropyl alcohol	Federal Specification TT-I-735	Commercially available

SUBTASK 33-50-01-94B-005-A01

Special Tools, Fixtures, and Test Equipment

(1) No special tools, fixtures, or test equipment are needed for the Assembly procedures.

## TASK 33-50-01-460-801-A01

## 3. <u>Assembly Procedures</u>

#### SUBTASK 33-50-01-460-001-A01

A. Assemble the Electronic Assembly

NOTE: Refer to the IPL Figure 2 for an illustration of the electronic assembly. Numbers in parenthesis ( ) refer to item numbers on the illustration.

(1) Install the combined interface PWA (10) to the control PWA (50).

NOTE: Make sure to fully mate all header connectors.

(2) Install one screw (20), one lock washer (30) and one flat washer (40) through the combined interface PWA (10) and into the control PWA (50). Tighten screw to 2-3 lb-in (0.2 – 0.3 N-m).

NOTE: The nut (70) and washer (80) are part of the SMA connector (60) and are procured with the SMA connector (60).

#### SUBTASK 33-50-01-460-002-A01

B. Assemble the WCU Assembly

NOTE: Refer to the IPL Figure 1 for an illustration of the WCU assembly Numbers in parenthesis ( ) refer to item numbers on the illustration.

(1) Install the battery clip (210), the compression spring (220), and the battery clip bracket (170) to the back case (230).

NOTE: Insert the spring (220) into the counterbore hole on the battery clip (210). Align the spring between the ribs on the back case when installing the battery clip.

(2) Install two flat washers (200), two lock washers (190), and two screws (180) through the inside of the back case (230) and into the battery clip bracket (170). Tighten screws to 4 - 5 lb-in (0.5 - 0.6 N-m).

NOTE: Check for correct spring operation after the battery clip bracket has been secured to the unit.

(3) Install the electronic assembly (130) into the back case (230).

<u>NOTE</u>: The electronic assembly slides into card guides located in the back case.

- (4) Install two flat washers (160), two lock washers (150), and two screws (140) through the electronic assembly (130) and into the back case (230). Tighten screws to 4-5 lb-in (0.5-0.6 N-m).
- (5) Install a new circular connector gasket (110) and a new SMA connector gasket (120) onto the electronic assembly (130).
- (6) Place the front case (70) with the locking tabs pointing upwards.
- (7) Apply adhesive (3145) around the entire channel on the front case (70). See Figure 7001 for front case channel location.


33-50-01

Page 7002 JAN 05/2009



- (8) Grasp the locking tabs on the front case (70), squeeze the locking tabs together and push the front case onto the back case.
- (9) Clean the excess adhesive from the external surfaces of the front case (70) and back case (230). Use Isopropyl alcohol and a clean cloth to remove excess adhesive.
- (10) Install four flat washers (100), four lock washers (90), and four screws (80) to the front case (70). Tighten screws to 4 5 lb-in (0.5 0.6 N-m).
- (11) Install one washer and one nut on the J4 antenna connector located on the front case (70). Tighten nut to 5.5 6.5 lb-in (0.6 0.7 N-m).
  - NOTE: The nut and washer are part of the SMA connector as shown in IPL Figure 2.
- (12) Install the male connector cap (60) on the J4 antenna connector located on the front case (70). Tighten cap to 5.5 6.5 lb-in (0.6 0.7 N-m).
- (13) If previously removed, install a new nameplate label (40) or RF transceiver label (50) onto the back case (230).
  - NOTE: If the nameplate label is replaced, mark the new label with the identification information from the old label.
- (14) Install three plungers (20) and three grommets (30) to the tabs located on the back case (230).
- (15) Continue to the TESTING AND FAULT ISOLATION section.





Front Case Adhesive Channel Figure 7001 / GRAPHIC 33-50-01-99B-025-A01

33-50-01

Page 7004 JAN 05/2009

# **FITS AND CLEARANCES**


## TASK 33-50-01-99F-808-A01

1. <u>General Information</u>

## SUBTASK 33-50-01-99F-016-A01

- A. Introduction
  - (1) This section has the Fits and Clearances for the WELS Control Unit (WCU).
  - (2) The WCU dimensions are shown in Figure 8001.





WELS Control Unit Fits and Clearances Figure 8001 / GRAPHIC 33-50-01-99B-026-A01

33-50-01

Page 8002 JAN 05/2009

# SPECIAL TOOLS, FIXTURES, EQUIPMENT AND CONSUMABLES

TASK 33-50-01-99F-809-A01

1. <u>General Information</u>

SUBTASK 33-50-01-94A-006-A01

A. Consumable Materials

(1) Consumable materials used are shown in Table 9001.

NOTE: Equivalent alternatives can be used.

Table 9001. Consumable Materials / TABLE 33-50-01-99A-010-A01

Name	Specification or Part Number	Source or CAGE Code	Use
Silicone Adhesive Clear	(3145) MIL-A-46146	Commercially available	Assembly
Cleaning Cloth	MIL-C-85043	Commercially available	Disassembly Assembly Cleaning Storage
Isopropyl alcohol	Federal Specification TT-I-735	Commercially available	Disassembly Assembly
Static Sensitive Bag	_	Commercially available	Storage

# SUBTASK 33-50-01-94B-006-A01

- B. Special Tools, Fixtures, and Test Equipment
  - (1) Special tools, fixtures, and test equipment used are shown in Table 9002.

NOTE: Equivalent alternatives can be used.

Table 9002. Special Tools, Fixtures, and Test Equipment / TABLE 33-50-01-99A-011-A01

Equipment	Characteristics	Source or (CAGE)	Use
WELS Test Box	TE-1128-01	V0TMJ9	Testing
WCU Main Test Cable	160-2275-01	V0TMJ9	Testing
Battery Simulator Module	TE-2637-01	V0TMJ9	Testing
Battery Simulator Cable	TE-2633-01	V0TMJ9	Testing
WELS Battery Unit (Fully Charged to 8.4 Volts)	100-2602-01	V0TMJ9	Testing
Standard FF RS232 Communication Serial Cable (DB9 to DB9)	AK152-2-R	Commercially available	Testing
Computer	Microsoft Windows XP Professional Operating System with (2) available USB Ports and (1) available Serial Port. 512 MB RAM (memory) 10 MB of hard disk space available. PC must also have access to a printer.	Commercially available	Testing
WCU Test Program, V1.V00	050-0224-07341 Rev -	V0TMJ9	Testing
WCU Main Test Code (8MB Flash-U35)	050-0232-08031 Rev -	V0TMJ9	Testing
WCU RF Test Code	050-0230-07341 Rev -	V0TMJ9	Testing
WELS 787 Operational SW Code	050-0211-08237 Rev -	V0TMJ9	Testing
BlueTest2 Software	Version 1.0.0 Rev 1 (or later)	VU4252	Testing
Bluetooth Test Set	Anritsu MT8852A	VU4252	Testing
Adapter Cable (and windows driver)	National Instruments GPIB-USB-HS	V64667	Testing
Direct Connection Antenna Cable	Pasternack PN PE3876-60 (5 feet in length recommended)	V53919	Testing
Omnidirectional Antenna	Antenova PN 2010B4844-01	V53919	Testing
Digital Multimeter	True RMS Multimeter 0 to 10 VDC 1% accuracy (Fluke 87)	V89536	Testing
J-Link (USB to JTAG Debugger/Programmer)	IAR Systems	V1QQS1	Testing
SAM-PROG v2.3 (or later)	Atmel Corp	V1FN41	Testing

# STORAGE (INCLUDING TRANSPORTATION)

# TASK 33-50-01-99F-811-A01

**General Information** 

SUBTASK 33-50-01-99F-022-A01

Α. Introduction

> WARNING: BEFORE MATERIALS CALLED OUT IN THIS PUBLICATION ARE USED.

> > KNOW THE HANDLING, STORAGE, AND DISPOSAL PRECAUTIONS RECOMMENDED BY THE MANUFACTURER OR SUPPLIER. FAILURE

TO FOLLOW THE MANUFACTURERS' OR SUPPLIERS'

RECOMMENDATIONS CAN RESULT IN PERSONAL INJURY OR

DISEASE.

THESE PROCEDURES MUST BE DONE AT A STATIC-FREE CAUTION:

WORKSTATION IN ORDER TO PREVENT DAMAGE TO

ELECTROSTATIC SENSITIVE COMPONENTS.

THIS UNIT HAS ASSEMBLIES THAT ARE SUSCEPTIBLE TO DAMAGE CAUTION:

FROM INCORRECT HANDLING. DO NOT DROP OR HIT THE UNIT

DURING THESE PROCEDURES.

THESE PROCEDURES MUST BE DONE IN A CLEAN ENVIRONMENT IN **CAUTION:** 

ORDER TO PREVENT DAMAGE TO MECHANICAL COMPONENTS.

(1) This section has the storage and shipping procedures recommended by

Securaplane for the WELS Control Unit (WCU).

(2)Refer to the CLEANING section before storing the WCU.

#### TASK 33-50-01-94B-806-A01

2. **Equipment and Materials** 

SUBTASK 33-50-01-94A-007-A01

Α. Consumable Materials

> (1) Consumable materials used during the Storage procedures are shown in

Table 15001.

NOTE: Equivalent alternatives can be used.

Table 15001. Consumable Materials / TABLE 33-50-01-99A-013-A01

Name	Specification or Part Number	Source or (CAGE) Code	
Cleaning Cloth	MIL-C-85043	Commercially available	
Static Sensitive Bag	_	Commercially available	



#### SUBTASK 33-50-01-94B-007-A01

- B. Special Tools, Fixtures, and Test Equipment
  - (1) No special tools, fixtures, or test equipment are needed for Storage procedures.

#### TASK 33-50-01-550-801-A01

Storage/Transportation Procedures

#### SUBTASK 33-50-01-550-001-A01

- A. Prepare the WCU for Storage or Transportation
  - (1) Clean the external surfaces with a clean, lint-free cloth.
  - (2) Put dust caps (supplied with unit) on the WCU connector J1 and J4 to protect against contamination.

#### SUBTASK 33-50-01-550-002-A01

B. Storage Conditions

NOTE: Store the WCU in the same ESD bag and shipping box as shown in the transportation procedures.

- (1) Store the unit at an ambient temperature of 77°F (25°C) and with humidity (less than 70%) to minimize the possibility of moisture contamination of the unit.
- (2) Store the unit in a non-corrosive area away from high temperatures, dust, moisture, and fumes.

#### SUBTASK 33-50-01-550-003-A01

- C. Transportation Procedures for Returning the WELS Control Unit to Securaplane
  - (1) Put the WCU in an appropriately sized ESD bag and then wrap the unit in bubble wrap.
  - (2) Use the Securaplane shipping box (PN S-968) or equivalent to transport the WCU.
  - (3) The packaging label for each shipping box will include the following information:

Securaplane Technologies

0TMJ9 (along with the bar code IAW ISO/TS 21849)

WELS Control Unit

100-2601-01 (along with the bar code IAW ISO/TS 21849)

S836Z300-200

Quantity

Unit(s) serial number (along with the bar code IAW ISO/TS 21849)

Date of Manufacture

Purchase order number

(4) Include a failure report with the aircraft type and the WCU serial number.

33-50-01

Page 15002 JAN 05/2009



#### ILLUSTRATED PARTS LIST

#### TASK 33-50-01-99F-810-A01

Illustrated Parts List Introduction

#### SUBTASK 33-50-01-99F-017-A01

- A. General Information
  - (1) The Illustrated Parts List (IPL) provides a breakdown of assemblies, subassemblies and detail parts of the unit. All parts are listed, except for parts which lose their identities by being permanently fastened to other parts or are part of an assembly not subject to disassembly.
  - (2) Bulk materials such as safety or electrical wire and tape, and consumable materials such as adhesives, sealants, lubricants, solder, paint, and primer are not included in the detailed parts lists. These materials are identified in the materials list at the beginning of each section.
  - (3) To find a part number when the part number is unknown, locate the part on the illustration and note the item number. Locate the item number on the detailed parts list. The part number will be shown on the same line. In some instances there are gaps in item number sequence and the item numbers are not sequential.

#### SUBTASK 33-50-01-99F-018-A01

- B. Explanation of Columns, Terms and Symbols in the Illustrated Parts List (IPL)
  - (1) FIG. & ITEM NO. column: The figure and item numbers key the detailed parts list to the applicable illustration. The first number represents the figure number of the illustration. The item number corresponds to an item number on the illustration.
    - (a) An item number not on the illustration is identified by a dash (-) preceding the item number.
    - (b) An item number followed by an alphabetical character such as A, B, C, etc., indicates the part listed is similar to the same item number without the alphabetical character. The difference could be each part is used for a different next higher assembly (NHA) or is an equivalent part. This will be noted in the NOMENCLATURE or EFF CODE columns.
  - (2) PART NUMBER column: This column contains the original manufacturer's part number of the assembly, subassembly, or detail part listed. Part numbers in this IPL are those of Securaplane, Tucson, Arizona, or are standard parts unless a Commercial and Government Entity (CAGE) code appears in the NOMENCLATURE column. Refer to paragraph 4 for details. The following phrases may be used in this column:
    - (a) NONPROC followed by an assigned number (for example NONPROC01) is used when no part number exists for the assembly. NONPROC assemblies are not procurable and may not be ordered. However, the detail parts of the assembly are procurable and may be ordered, unless otherwise specified.
    - (b) REF followed by an assigned number (for example REF001) is used when the part number of the part is more than fifteen digits. The original part number with more than fifteen digits is listed in the NOMENCLATURE column and is the part number to be used when ordering the part.

33-50-01

- (3) AIRLINE STOCK NO. column: This column is reserved for airline stock numbers and accommodates eleven characters.
- (4) NOMENCLATURE column: This column identifies the parts being listed by noun name followed by modifiers when applicable. This column also provides the following information.
  - (a) The relationship of each listed item to its next higher assembly (NHA) is shown by an indenture code. Each listed item is placed in the NOMENCLATURE column one indenture (one dot) to the right of the assembly to which it belongs. Items at equal indentures are all components of a single assembly or subassembly. An example of the indenture code system is shown below.

1 2 3 4 5 6 7

Assembly or Installation Descriptive Title

- . Assembly
- . Attaching Parts for Assembly
  - . Detail Parts for Assembly
- . . . Subassembly
- . . . Attaching Parts for Subassembly
- . . . Detail Parts for Subassembly
- . . . Sub-Subassembly
- . . . . . . . . Attaching Parts for Sub-Subassembly
- . . . . Detail Parts for Sub-Subassembly
- (b) Symbols used with the exception of effectivity and CAGE codes are as follows:
  - 1 (ATTACHING PARTS) Designates start of each group of attaching parts.
  - 2 -----\*---- Designates end of each group of attaching parts.
- (c) The following phrases may be used in this column:
  - ALT identifies the part is an alternate. The part is fully interchangeable in form, fit, and function with other item numbers shown.
  - NP identifies this part is Non-Procurable.
  - <u>3</u> DELETED identifies a part is no longer used.
  - 4 REPLD BY identifies the part is replaced and is two-way interchangeable with the item number shown. However, either part may be used.
  - <u>5</u> REPLS identifies the part replaces and is two-way interchangeable with the item number shown. However, either part may be used.

33-50-01



- SUPSD BY identifies the part is superseded and is one-way interchangeable with the item number shown. The old part can be used as replacement only where the old part was installed.
- SUPSDS identifies the part supersedes and is one-way interchangeable with the item number shown. The new part number can be used as replacement for both the old or new parts.
- (5) EFF CODE column: This column is used to show interchangeability relationships. It identifies different configurations in each figure and shows how parts relate to item 1 (or an alpha variant of item 1) in that figure only. A code letter A through Z (but not I and O) identifies each configuration. The same code is used in this figure to show all parts for a specified configuration. If a part is used on all configurations in that figure, the EFF CODE column is blank.
- (6) UNITS PER ASSY column: This column shows the quantity of each item used on one next higher assembly, subassembly or sub-subassembly. Quantities shown for attaching parts are the number required for the related part, subassembly or assembly and, therefore, may not be the total quantity used for the end item of the detailed parts list. The following letters may be used in this column:
  - (a) AR indicates "as required" and refers to variable quantity items such as shims, spacers or similar items.
  - (b) RF indicates "reference" and refers to items and their quantities which are listed elsewhere and are provided here as a reference only.
- (7) Abbreviations
  - (a) Standard abbreviations used in the IPL agree with MIL-STD-12.



### SUBTASK 33-50-01-99F-019-A01 C. Vendor (CAGE) Codes (V\_\_\_\_)

- (1) Vendor codes, specified by the letter "V", are shown in the nomenclature column of the DPL to identify the manufacturer of non-Securaplane parts.
- (2) The CAGE codes for the manufacturers of the parts, materials, special tools, and test equipment which may be referenced in this CMM are contained in Table 10001.

Table 10001. Vendor Code List / TABLE 33-50-01-99A-012-A01

Code	Vendor	Code	Vendor
VU4252	Anritsu EMEA LTD 200 Capability Green Luton, United Kingdom LU1 3LU	V0TMJ9	Securaplane Technologies Inc. 10800 N. Mavinee Drive Tucson, AZ 85737 USA
V1FN41	Atmel Corporation 2325 Orchard Pkwy San Jose, CA 95131-1034 USA	V1QQS1	IAR Systems Software Inc. 1065 E. Hillsdale Blvd Foster City, CA 94404-1613 USA
V53919	Pasternack Enterprises Inc 1851 Kettering Irvine, CA 92614-5617 USA	V64667	National Instruments Corporation 11500 N. Mopac Expy Bldg B Austin, TX 78759-3504 USA
V89536	Fluke Corporation 6920 Seaway Blvd. Everett, WA 98203-5829 USA		

#### SUBTASK 33-50-01-99F-020-A01

- D. Equipment Designator Index
  - (1) The Equipment Designator Index contains all equipment designators included in the Detailed Parts Lists. The equipment designators are listed alphabetically. The equipment designator index shows the applicable figure and item number where that specific equipment designator can be found.

# SUBTASK 33-50-01-99F-021-A01


- E. Numerical Index
  - (1) The Numerical Index contains all part numbers included in the Detailed Parts Lists. The part numbers are listed first alphabetically, then by numerical sequence. Referring to the Numerical Index with a known part number, the figure, item number, and total units per assembly can be found.



# **NUMERICAL INDEX**

PART NUMBER	AIRLINE PART NUMBER	FIGURE NUMBER	ITEM NUMBER	TOTAL REQUIRED
100-2601-01		1	-1	RF
101-2601-03		1	-10	1
120-2869-02		1	230	1
120-2870-01		1	70	1
120-2871-01		1	210	1
120-2872-01		1	170	1
120-4091-01		1	120	1
140-2601-02		2	50	1
140-2660-03		2	10	1
160-2274-04		1	130	1
160-2274-04		2	-1	RF
180-0349-01		1	50	1
190-0352-01		1	40	1
340-0001-01		2	60	1
373-0005-01		1	60	1
500-02560.250S		2	20	1
500-04400.250S		1	180	2
500-04400.3125S		1	140	2
500-04400.375S		1	80	4
520-02000.157S		2	40	1
520-04000.250S		1	100	4
520-04000.250S		1	160	2
520-04000.250S		1	200	2
522-02000.188S		2	30	1
522-04000.200S		1	90	4
522-04000.200S		1	150	2
522-04000.200S		1	190	2
566-0003-01		1	220	2
569-NY5P55150		1	20	3
569-0113-01		1	110	1
570-NY5G5520		1	30	3
89610-1143		2	80	RF
89611-0529		2	70	RF





WELS Control Unit Assembly Figure 1 / GRAPHIC 33-50-01-99B-027-A01


33-50-01

Page 10006 JAN 05/2009

FIG. & ITEM NO.	PART NUMBER	AIRLINE STOCK NO.	NOMENCLATURE 1234567	EFF CODE	UNITS PER ASSY
1	FART NOWIDER	NO.	1234307	CODE	ASSI
' <sub>-1</sub>	100-2601-01		WELS CONTROL UNIT		RF
-10	101-2601-03		. WELS CONTROL UNIT ASSY (NP)		1
20	569-NY5P55150		PLUNGER, PANEL FASTENER		3
30	570-NY5G5520		GROMMET, PANEL FASTENER		3
40	190-0352-01		LABEL, NAMEPLATE, WCU		1
50	180-0349-01		LABEL, RF TRANSCEIVER		1
60	373-0005-01		CAP, MALE CONNECTOR		1
70	120-2870-01		CASE, FRONT		1
			(ATTACHING PARTS)		
80	500-04400.375S		SCREW, 4-40 ¼ PHIL PAN SS		4
90	522-04000.200S		WASHER, #4 .2 LOCK SS		4
100	520-04000.250S		WASHER, #4 .25 FLAT SS		4
			*		
110	569-0113-01		GASKET, CIRCULAR		1
			CONNECTOR		
120	120-4091-01		GASKET, SMA CONNECTOR		1
130	160-2274-04		ELECTRONIC ASSY		1
			(SEE FIGURE 2 FOR		
			BREAKDOWN)		
			(ATTACHING PARTS)		
140	500-04400.3125S		SCREW, 4-40 5/16 PHIL PAN SS		2
150	522-04000.200S		WASHER, #4 .2 LOCK SS		2
160	520-04000.250S		WASHER, #4 .25 FLAT SS		2
			*		
170	120-2872-01		BRACKET, BATTERY CLIP		1
			(ATTACHING PARTS)		
180	500-04400.250S		SCREW, 4-40 ¼ PHIL PAN SS		2
190	522-04000.200S		WASHER, #4 .2 LOCK SS		2
200	520-04000.250S		WASHER, #4 .25 FLAT SS		2
			*		
210	120-2871-01		CLIP, BATTERY		1
220	566-0003-01		SPRING, COMPRESSION		2
			(.180 IN OD X .625 LON)		
230	120-2869-02		CASE, BACK		1
L					

<sup>-</sup> ITEM NOT ILLUSTRATED





Electronic Assembly Figure 2 / GRAPHIC 33-50-01-99B-028-A01

33-50-01

Page 10008 JAN 05/2009

510.0		41511115			
FIG. & ITEM		AIRLINE STOCK	NOMENCLATURE	EFF	UNITS PER
NO.	PART NUMBER	NO.	1234567	CODE	ASSY
2					
-1	160-2274-04		ELECTRONIC ASSY		RF
			(SEE FIGURE 1 FOR NHA)		
10	140-2660-03		. PWA, COMBINED INTERFACE		1
			(ATTACHING PARTS)		
20	500-02560.250S		. SCREW, 2-56 X ¼ PAN PHIL SS		1
30	522-02000.188S		. WASHER, #2 3/16 LOCK SS		1
40	520-02000.157S		. WASHER, #2 .157 SS		1
			*		
					_
50	140-2601-02		. PWA, CONTROL		1 1
60	340-0001-01		CONNECTOR, RF SMA RIGHT		1
			ANGLE BULKHEAD JACK		
70	89611-0529		NUT, SMA CONNECTOR (NP)		1
			FOR SPARES		
			REPLACEMENT ORDER		
			340-0001-01		
80	89610-1143		WASHER, LOCK, SMA		1
			CONNECTOR (NP) FOR SPARES		
			REPLACEMENT ORDER		
			340-0001-01		

<sup>-</sup> ITEM NOT ILLUSTRATED



THIS PAGE INTENTIONALLY LEFT BLANK