SK-5801

Remote Controlled RF Socket

USER GUIDER

Set-up

Insert the battery into the battery compartment of the remote control making sure polarity is correct.

For first use

Plug the socket into a main or wall socket, the LED will flash once per second (under learning code situation). Point the remote at the socket and hold down one of buttons of ON or OFF on the remote(1,2,3or4) until the LED flashes continuously in 2 seconds. And then the LED flashes once per second, that means the code was successfully learned by socket, the socket has memorized the code. Then press ON or OFF button which is chose, the socket works.

For advanced use

Under off situation, press ON/OFF switch on the socket last for 3 seconds or hold down the OFF button on the remote of which channel has learned code continuously for 3 seconds. Then the LED flashes once per seconds, that means the socket turns into learning situation. In this moment, it can learn another remote code.

ATTENTION: All RF receivers(socket,switch,connecting box,lamp holder) can be controlled by more than one remote. Under learning code situation, the receiver can learn more than one remote's codes.

Adapted Transmitter: T-03,T-05,T-06

To operate

Plug a lamp(or other electric device)into the socket and switch on the lamp. Then for on or off press the correct ON or OFF button just once.

Trouble shooting

If remote control will not operate RF socket-

- 1. The battery power may be low and the battery may be replacing.
- 2. The remote is too far away from the socket-move closer and try again.
- 3. The code is not learned successfully.

Clearing codes

In off situation, hold down the OFF button on the remote of which channel has learned code continuously for 3 seconds. Then the LED flashes once per second (under learning code situation), and hold down ALL OFF button continuously for 3 seconds. When the LED flashes from quickly to once per second, that means clearing code is successful. Alternatively-

In off situation, press ON/OFF switch on the socket continuously for 5 seconds , when the LED flashes from quickly to once per second, that means clearing code is successful.

I Voltage: 120Vac/60Hz
I Rating: Max. 1000W
I Frequency: 433.92MHz
I ON/OFF indication: LED
I Remote range: >20m
I Code setting: Self-teach in

I Battery type: A23 12V/DC

REMINDING

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

Warning: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTICE

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- —Increase the separation between the equipment and receiver.
- —Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- —Consult the dealer or an experienced radio/TV technician for help.