User Manual

For Avvio SN52S/ Avvio SN52

Contents

YOUR PHONE	4
PHONE OVERVIEW	4
GETTING STARTED	6
Battery	6
REMOVING AND INSTALLING BATTERY	6
CONNECTING TO NETWORK	8
INSERTING AND REMOVING SIM CARD	8
INSERTING AND REMOVING MEMORY CARD	9
Power on/off phone	10
PIN AND PUK	10
PHONE LOCK	11
LOCKING THE SCREEN	11
CONNECTING TO NETWORK	11
CONNECTING TO NETWORK	11
BASIC FUNCTIONS	
	12
BASIC FUNCTIONS	1 2
BASIC FUNCTIONS	12
MAKING A CALL	12121212
MAKING A CALL	
MAKING A CALL	
BASIC FUNCTIONS MAKING A CALL MAKING DOMESTIC CALLS. DIALING EXTENSION NUMBER OF FIXED-LINE TELEPHONE DIALING INTERNATIONAL CALLS. DIALING PHONE NUMBERS IN THE CALL RECORDS. EMERGENCY CALLS. ANSWERING A CALL	12 12 12 13 13 13
MAKING A CALL	12 12 12 13 13 13
BASIC FUNCTIONS MAKING A CALL MAKING DOMESTIC CALLS. DIALING EXTENSION NUMBER OF FIXED-LINE TELEPHONE DIALING INTERNATIONAL CALLS. DIALING PHONE NUMBERS IN THE CALL RECORDS. EMERGENCY CALLS. ANSWERING A CALL	1212121213131314
BASIC FUNCTIONS Making a Call Making domestic calls Dialing extension number of fixed-line telephone Dialing international calls. Dialing phone numbers in the call records. Emergency calls. Answering a Call. Call options.	1212121313131414

MAIN MENU	15
CALL LOG	16
GAMES	16
EXTRA	16
EBOOK READER	16
CALENDAR	17
ALARM	17
CALCULATOR	17
PHONEBOOK	17
ADD NEW CONTACT	17
SEARCHING FOR A CONTACT	18
ADD NEW GROUP	18
ADD NEW GROUP MEMBER	18
PORTAL MÓVIL	18
PORTAL MÓVIL MESSAGING	
	18
MESSAGING	18
MESSAGING	1819
MESSAGING E-MAIL AVVIO INSTANT MESSAGING AVVIO	181919
MESSAGING	18191919
E-MAIL AVVIO INSTANT MESSAGING AVVIO CREATE A NEW SHORT MESSAGE CREATE A NEW MULTIMEDIA MESSAGE	1819191919
MESSAGING E-MAIL AVVIO INSTANT MESSAGING AVVIO CREATE A NEW SHORT MESSAGE CREATE A NEW MULTIMEDIA MESSAGE SMS BACKUP	
MESSAGING E-MAIL AVVIO INSTANT MESSAGING AVVIO CREATE A NEW SHORT MESSAGE CREATE A NEW MULTIMEDIA MESSAGE SMS BACKUP BROADCAST MESSAGE	1819191919191919
MESSAGING E-MAIL AVVIO INSTANT MESSAGING AVVIO CREATE A NEW SHORT MESSAGE CREATE A NEW MULTIMEDIA MESSAGE SMS BACKUP BROADCAST MESSAGE CAMERA	18191919191919
MESSAGING E-MAIL AVVIO INSTANT MESSAGING AVVIO CREATE A NEW SHORT MESSAGE CREATE A NEW MULTIMEDIA MESSAGE SMS BACKUP BROADCAST MESSAGE CAMERA SETTINGS.	

USER PROFILES	21
SECURITY SETTINGS	21
CONNECTIVITY	22
RESTORE FACTORY SETTINGS	22
DISPLAY SETTINGS	23
MULTIMEDIA	23
TV	23
IMAGE VIEWER	23
VIDEO RECORDER	23
VIDEO PLAYER	24
AUDIO PLAYER	24
SOUND RECORDER	24
FM RADIO	25
FILE MANAGER	25
IDEAS	25
SEARCH	26
INPUT METHOD	26
ATTENTION AND PRECAUTIONS	27
FOR YOUR SAFETY	27
SECURITY REQUIREMENTS	28
MAINTENANCE	28

Your Phone

Phone Overview



NO.	Keys	Short Press	Press and Hold
<u> </u>			Tiolu
1	Dial key	Answer an incoming call.	
		Enter Call log	
2	Left soft key/	Open a context menu related with	Enter Twitter
	Twitter	current screen or Application.	
3	Navigation	Scroll the cursor	
	key/	Implement operation	
	OK key		
4	End key	End a call	Power on/off
		Lock keypad	
		Return to IDLE mode	

5	Right soft key/	Enter Phonebook	Enter facebook
	Facebook	Open the previous screen.	
6	Keypad	Input the corresponding characters	

Getting Started


Battery

The battery at its initial condition is charged to 50% full, and can be used after unwrapping.

Removing and installing battery

For removing:


- A. Push the battery back cover; Lift the battery up as indicated by the arrow; В.
 - Take the battery out.



For installing:

A. Place the metal contact points of the battery upward and flush with metal contact points in the battery bay, then insert the bottom of A. battery into battery bay.

B. Place the back cover of the battery onto the phone squarely, and push in the direction of the arrow till it clicks into place.



Charging Battery

While charging, the power supply indicator at phone's screen icon zone will flash in a rotation manner, if the phone is off while charging, a charging screen will still appear, indicating that the phone is recharging. If the phone is still being overused while the power supply is insufficient, the recharging indicator will appear on the screen after the recharging has started for a while.

When the power supply indicator at the screen's sicon zone shows full and stops flashing, it means charging has completed. If it takes place when the phone is off, the screen will display charging-finished icon.

The process generally takes about 2.5 hours. It is normal that the battery, the phone and the charger will become hot during the charging process.

Once charging is completed, disconnect the phone and the charger from the AC power supply.

Note: Battery must be charged in a well ventilated place with surrounding temperature at -10°C~+55°C, and it is imperative that a charger provided by manufacturer is used. Using unauthorized charger might cause danger, which also violates warranty terms prescribed by the manufacturer. If the charging temperature is too high or too low, the phone will automatically give warning and stop charging, so as to prevent damages to battery.

Connecting to Network

SIM card

A valid SIM (Subscriber Identity Module) card must be inserted in the phone before using it.

All information related to making connection to the network are recorded in the chips of SIM card, including the names, phone numbers and short messages you have stored in the SIM card Phone book. In order to prevent loss or damage of the info in the SIM card, it is necessary to avoid touching metal contact surface, and keep SIM card far from electricity current and magnet.

Inserting and removing SIM card

Power off the phone; remove battery and other external power connection, as shown in the image.

Insert SIM card into SIM card socket.

When you need to remove SIM card, please power off the phone first, remove battery, then remove the card.





Inserting and removing memory card

Power off the phone; remove battery and other external power connection.

Insert memory card into card slot as shown in the image.



Power on/off phone

To power on, please press and hold the Power key. Then the screen will display the prompts like Enter phone password, SIM card password in sequential order as per the setting done by user. Once the appropriate password is entered, the phone will search for network connection and latch accordingly to the appropriate network.

To power off, please press and hold the Power key.

PIN and PUK

To prevent illegal usage, PIN (Personal Identification Number) code is adopted to encrypt for protection of your SIM card. Selecting this option and if having set up PIN code protection, you have to enter PIN code each time you power on the phone.

Press and hold the Power key to close the phone; Enter PIN code, use clear to delete input-errors, Tap "OK" key for end. For instance, if PIN setting is 1234, then enter the following input: 1 2 3 $\,$ 4 "OK".

If there are three consecutive input errors, your SIM card will be locked up by the network, the phone will inquire PUK code.

Note: Your service provider will set up a standard PIN (4 to 8 digits) number for your SIM card; you should change it into your private password as soon as possible. PUK code will be provided by the network provider.

Phone lock

The phone lock protects your phone from unauthorized use. The default phone lock code is 0000. You can change it into any numeric string of 4 to 8 digits.

If the phone lock function is enabled, you need to enter the correct phone lock code when the phone is powered on or in the standby mode.

Locking the screen

If the Auto Keypad Lock function is enabled and the phone is idle for a preset period in standby mode, the keypad is locked automatically. To unlock the screen, Press LSK then # key.

Note: When the keypad is locked, you can Press the Dial key to answer an incoming call or make emergency calls.

Connecting to network

After SIM card is successfully unlocked, the phone will automatically search available network (with searching showing on the screen). Once the connection is made, the name of the service provider will be displayed on the screen. At this time your phone has been connected to the service network.

Note: If the screen prompts "Emergency", this means you have moved out of the normal network coverage (service range) or your card has not passed authentication, but you can still transmit emergency calls based on signal strength.

Basic Functions

Making a call

When the logo of service provider appears on the display screen, you can dial or receive calls. The info bar at the upper left corner of the display screen shows network signal strength (when there are 5 info bars the signal is at its strongest).

The call quality is very likely to be affected by obstructions.

Making domestic calls

Enter phone number, and then press Dial Key to make the call. If the user needs to change phone number, press right soft key "Clear" back and delete numbers. Dialing animation will be displayed on the screen during dialing. Call state info will be shown on the screen after the called party ends the call

You can enter and dial domestic call following the order: (Area code) (Phone number) (Dial)

Dialing extension number of fixed-line telephone

Some extension numbers of fixed-line telephone cannot be connected directly, you must dial the power board phone number, then press * key to power continually, until the screen displays "P", then dial extension number.

You can dial extension numbers of fixed-line telephone in the following order:

(Area code) (Power board number) P (Extension number) Dial Key

Dialing international calls

To make an international call, you may press the pre-digit symbol "+" for international long distance call, which will enable you to make a call from any country without knowing the local international access code.

You can enter numbers in the following sequence to make an international call:

(+) (Country code) (complete phone number) (Dial Key) After inputting prefix number, input the code and the complete phone number of the wanted country. The country code follows usual practice, such as Germany 49, UK 44, Sweden 46, India 91 etc. Like making an international call, the "0" before city code number should be dropped.

Dialing phone numbers in the call records

In standby state press Dial key to view the record for all calls.

All phone numbers in the list can be dialed directly by pressing the Dial key.

When the list is displayed, press "OK" to read the details, then press left soft key (options) to Save or Delete the number.

Emergency calls

As long as in the network service range (which can be confirmed by checking the signal strength bars on the top left corner of the screen), you can always call emergency service. If your network supplier does not provide roaming service in your area, the screen will display "Emergency", to inform you that only emergency call is permitted. If you are within the network service range, you can also make emergency calls even without the SIM card.

Answering a call

An incoming call can be accepted with the single press of dial key. If earphone has been connected, use the button on the earphone to answer a call, and if it is not convenient for you to press it, set automatic answer as on, assuring that the earphone is plugged on, so as to answer calls automatically while the phone rings or vibrates. If Any Key answer function is chosen, then a call can be answered on pressing any key, other than End key Up/Down key and right soft key.

Call options

In call connected state, pressing left soft key "Options" can enter call option, or pressing "H-Free" to activate speakerOperation methods of call options are the same with that of Function menu.

This call options can only be viewed during call process, moreover, the functions of call waiting, call holding, and conference calls need service support, please contact your service provider for details.

Conference*: Enter multiple party conference call state. By following the prompts, you can have the following functions: receive waiting calls, add them into multiple party call, maintain the multiple party call, talk privately with one party of the conference while maintaining all other callers, connect one party in the call conference with another party while exiting the multiple party call oneself, maintain one party of the multiple party call and end current call and all other maintained calls.

Note: The menu marked * items will only appear in special circumstances. For conference function, it is necessary to apply for service supply to corresponding service operator.

Using the menus

The phone offers a range of functions that allow you to tailor it to your needs.

These functions are arranged in menus and submenus which can be accessed by scrolling or using the appropriate shortcut.

Accessing a menu function

- 1. Press Left soft key in standby mode.
- 2. Press Navigation key to scroll to the desired main menu.
 - 3. Press Left soft key to enter the submenu.

Exiting a menu function

You can return to the previous menu level by press right soft key or press End key to return to standby state.

MAIN MENU

Menu guides you to the various applications, features and utilities available in your device.

The Menu structure as follow:

Call log	SIM Toolkit	Games	Extra
Phonebook	Portal móvil	Messages	Camera
Settings	Multimedia	Ideas	Search

Call log

Every phone number you have dialed or received will be stored in the list of phone call records. The latest dialed, received and missed numbers will be listed, according to their types, in the respective menu of dialed calls, received calls and missed calls. When call record list is full, the old numbers will automatically be deleted.

- Select Menu >Call log,or in standy mode press the dial key to view the records.
- 2. Select one type records, then press the left soft key to view the list
- 3. Select a contact or number ,press left soft key to enter the list,you can do the corresponding operation

Games

The built-in a web page,you can browser,a game named Snake you can play,an Internet communication application Twitter on your phone allow you to use the functions to connect with other people. At the same time,you can install java program by youself.

Extra

Ebook reader

To read the text stored in storage. Now only support .txt format files. When focused one file, press<Options>, you can choose

Open E-Book - to open current file

Clean up bookshelf - to delete all the bookshelf

Global setting - to set the view parameter, including font type, font size, scroll type, scroll speed, full screen status, encoding format and storage memory.

Book info - to view the information of current file

Delete - to delete current file

Delete all files - to delete all file in current folder

Sort by - to sort the files in list according to name, type, time or size Apply default system settings - to use the global parameter as current setting

Help—to know how to use this application.

Calendar

- 1. Select Menu > Extra > Calendar
- 2. Press left soft key to do some operations such as select view to view the event and so on

Alarm

- 1. Select Menu > Extra > Alarm
- 2. Press left soft key to edit an alarm,you can set the time, repeat ,alarm tone ,snooze and alert type

Calculator

- 1.Select Menu >Extra > Calculator
- 2. Press the number keys to input number, * key to input decimal point , $\# \mbox{ key to switch sign}$
- 3. Press the navigation key to select operational symbol and OK key to get the result.

Phonebook

Add new contact

- 1. Select Phonebook , then select Add new contact.
 - 2. Press OK key to edit contact.

If you want to save to SIM, you can only edit name and number.

- 4. Finish editing, press OK key, pop-up message to preserve the contact person.
- 5. Press Left soft key(Yes)to save; press Right soft key(No)to exit.

Searching for a Contact

Select Menu > Phonebook or Press Right soft key in standby mode
 Enter the first letter of the contact name in the search bar.

Contacts who have names that start with this letter will be displayed.

Add new group

Select Phonebook,then press Left soft key to select Caller groups.

- 2. The cursor focus Add new group,press OK key.
 - 3. Edit the group settings
 - 4. Press OK key to save the group

Add new group member

- 1. Select a group, press the left soft key then select view members.
 - 2. Press left soft key to add the contacts saved in phone.

Portal móvil

Use browser to open this application

Messaging

E-mail Avvio

1.Enter Messages>E-mail Avvio
 2.Select a type you want to login,then input your account
 3.After Login in successfully,you can receive or send email.

Instant Messaging Avvio

1.Enter Messages>Instant Messaging Avvio
 2.There are 6 Real-time chat tools,you can Login in one or several.then you can chat with your friends.

Create a new short message

- 1. Enter Messages>Write message>Text message
- 2. Edit content,you can press the Left soft key (**Options**) and select the required items.
- When having finished, Press the OK key and select Enter number or Add from Phonebook then press ok to send.

Create a new Multimedia Message

- 1. Enter Messages>Write message>Multimedia message
- 2. In the Edit content interface, Press the Left soft key and select the items you want to send, you can add picture, audio, video and subject .

SMS backup

- 1. Enter Messages>SMS backup
- 2. Select Inbox, Drafts, Outbox, Sent messages or Archive to backup
 - 3. Select the location, phone or memory card.

Broadcast message

Press (**Ok**) to enter this menu, and to set the parameter according to the menu hints.

This function needs support from the OPERATER, please connect with them to activate this service.

Camera

- 1. Select Menu >Camera
- 2. Press OK key to take photos. After taking, press Right soft key(**Back**) to save the photo and to take another photos.
- 3. Press Left soft key(**Options**) to select Send, Delete or Use as wallpaper.

Settings

Phone settings

You can set Time and date,Schedule power on/off, Language,Pref.input method, Shortcuts , Display,Dedicated key, Flight mode and LDC backlight.

Call settings

Call settings including Call waiting, Call divert, Call barring, Line swithching, Low Battery protect, Reject by SMS and Advanced settings. The Advance settings include Blacklist, Auto redial. Call time reminder, Auto call record and Answer mode.

Network settings

Network selection:This feature allows you to automatically or manually choose your network operator.

Internet service: You can access WAP sites and use WAP-based services on your phone. To access the WAP sites through your phone, you need to subscribe the corresponding service from the service provider and set the relevant parameters on your phone first.

For details about the service and the charges, contact your service

provider.

You can access the wap site by select homepage , Bookmarks , Search or input URL or Recent pages

Data account:Press left soft key to edit the exist account ,add ps account, delete or set as default.In the edit view ,you can set account name,APN and so on

Note: Please ensure your data account parameters is right, it relates to you whether can surf internet and send-receive multimedia text GPRS transfer pref.:you can select data prefer or Call prefer

User profiles

There are 4 profiles for you to select one as current profile: In every profile item, press left soft key (**Options**) to enter Activate and Customize.

In Customize, you can choose: Alert type, Ring type,SIM card incoming,Ringtone volume and so on.

Security settings

SIM Security: You can choose to set/change the PIN for SIM.

Phone Security: You can lock or unlock the device. Enter the password to activate or deactivate the phone lock. When the device is locked, you will be asked to enter the phone password. 4-8 numbers can be used for the phone password. The default phone password is 0000.

Auto keypad lock: to set how long to lock the screen automatically when in the idle mode

Certificate manager:

Mobile Tracker:

Connectivity

Bluetooth

Power:on/off Bluetooth function.when the Bluetooth is on, main LCD interface status bar will display the Bluetooth icon.

Wvisibility: whether the device can be searcher.

My device: show the devices which had matched with my device. Search audiodevice: open the search Bluetooth hands-free devices

My Name: View name of the device.

Advanced: Include the following

Set audio path: set up voice to transfer path for Bluetooth headset or remain in the machine.

Storage: set up the storage, such as phone, memory card, or always ask. Bluetooth device address: show the Bluetooth device physical address . Wifi

The WiFi allows you to access network using a wireless connection, from virtually anywhere within its operating range. Keep in mind however, that the number, thickness, and location of walls ,ceilings, or other objects that the wireless signals must mass through, may limit this

range.
Data account

Please refer to the data account the upper page mentioned

Restore factory settings

This function allows you to reset the most of the phone setting to the original setting when it is produced. The phone password is needed to access this function. The default password is "0000"

Display settings

You can set Wllpaper, Screen saver, Power on/off display, Show date and time, and Display operator name

Multimedia

ΤV

- 1. Select Menu >Multimedia>TV
- 2. Press Left soft key to enter the menu list, to set Region,you can scan then select Program list to select channel.
- 3. In the player view, you can press * key to scan the channels. Up or down key to adjust the volume, left or right key to switch the channel

Image Viewer

- 1. Select Menu > Multimedia > Images Album.
- 2. Press Left soft key (**Options**) to do some operations.
 - 3. Press OK key to view the picture you selected.
- 3 Viewing the picture, you can press left key or right key to view previous or next picture, press the number 1to amplify or 3 key to rotate.

Video recorder

- 1. Select Menu > Multimedia > Video recorder
- 2. Press OK key to film or pause a video, press Right soft key to stop filming. After filming, it will inquire wheahter need to save, press Left soft key to choose "Yes", press Right soft key to choose "No".
- 3. Press Left soft key(**Options**), and select Camcorder settings,Video settings,Effect settings and so on.

Video player

- 1. Select Menu > Multimedia > Video player.
- 2. Press the left soft key to select play , send, rename, delete sort by or storage
 - The keypad operations during video playback are as follows:
 Press OK key to play/pause the current video.
 Press the up/down key to adjust the volume.
 Press the # key to toggles full screen and # key to exit
 Press left/right key to fast forward or rewind.

Audio player

- 1. Select Menu >Multimedia>Audio player
- 2. Press the left soft key(list) to enter the songs list
- 3. Select an item and press Left soft key to focus a song then to play. Access the playing interface and adjust the Play and Pause of the music by the OK key.

Press the up/down key to adjust the volume.

Press left/right to choose the previous/next audio file.

Long press left/right key to fast forward or rewind.

- Press Right soft key (Back) to return.
 Chang the settings
- 1. Select Menu >MultimediaAudio player
- 2. Press the left soft key(list) to enter the songs list
- 3. Press the left soft key(options) then select Settings.

Sound recorder

- 1. Select Menu > Multimedia > Sound recorder.
- 2. Press OK key to record or press left soft key (Options) and select

New Record.

During the recording process, press Left soft key or OK key to pause/continue.

3. Press Right soft key (Stop) to stop recording.

FM radio

- Select Menu > Multimedia > FM radio to activate the FM radio.
 After loading, the phone plays a program.
 - On the FM Radio screen, you can do as follows: Press the up/down key to adjust the volume. Press left/right key to tune by 0.1 MHz.

Press * key then left or right key to auto search previous or next channel
3. Press left soft key (**Options**) and select Channel list, Manual input,
Auto Search, Settings and so on.

File manager

You can use File Manager to organize your files in folders in the memory card.

If a memory card is inserted, the files stored on it are organized separately.

Select Memory card and select Options to Open, New folder, Rename, Delete, Sort by.

Ideas

There are 11 application links, it is very convenient for you to connect using brower.

Search

It is Yahoo! Engine, when you open the application, you input some words you want to search, then it will automatically search some informations.

Input method

This mobile phone provides a variety of input methods,press ctrl key to change the input method.

Attention and Precautions

For your safety

 \triangle

Remember to comply with legal requirements and local restrictions when using the phone, for example, in aero plane, petrol stations, hospital or while driving

Always keep your handsfree to operate the vehicle while driving. Your first consideration while driving should be road safety. Don't use handset while driving.

As per the law, phone should not be used at refueling point near fuel or chemicals.

Mobile phones can interfere with the functioning of medical devices such as hearing aids or pacemakers. Keep at least 20 cm(9 inches) between the phone and pacemaker. When using the mobile phone hold it to the ear which is furthest away from the pacemaker. For more information, consult your doctor.

All wireless phones may be susceptible to interference, which could affect performance. The phone may cause interference in the vicinity of TV sets, radios and PCs.

The mains voltage (V) specified on the power supply unit must not be exceeded. Otherwise the charging device may be damaged. The power supply must be plugged into an easily accessible AC mains power socket when charging the battery. The only way to turn off the charging device after charging the battery is to unplug it.

Only qualified personnel may install or repair this product.

When connecting to any other product, read its user guide for

detailed safety instructions. Do not connect incompatible products.

Use only approved enhancements and batteries. Do not connect incompatible products.

Security Requirements

Before making or answering a call, you should pay attention to the local laws about the use of wireless mobile phones and take them into account in practical use.

Traffic safety

Pay attention to traffic safety. Do not use your mobile phone while driving. Park before making or answering a call.

Flight Safety

Please turn off your GSM mobile phone before the airplane takes off in order to protect airplane's communication system from interference. Using mobile phone before the plane taking off should get aircrew's permission according to safety regulations.

Environment Safety

Do not use your mobile phone near precision electronic equipment. Radio wave interference may cause malfunctioning of such electronic equipment and other problems.

Operating of mobile phone may interfere with medical devices like hearing aids and pacemakers.

Do not use your phone in a potentially dangerous atmosphere. Please strictly observe with the restrictions on the use of wireless devices.

Maintenance

Battery instructions

When the phone automatically turns off or indicates the alarm information of power shortage, please charge the battery in time. For the first few times, please charge the battery fully.

When not in use, please separate the battery with power supply.

Overcharging will shorten the life of the battery.

Do not expose your products to extreme high or low temperatures.

Caution

Risk of explosion if battery replaced aced by an incorrect type. Dispose of used batteries according to the instructions. Operating temperature range: -10 $^{\circ}\text{C}$ ~+55 $^{\circ}\text{C}$ Do not use damaged battery.

Do not expose your mobile phone to direct sunlight or in hot areas. High temperatures can shorten the life of electronic devices.

Do not expose the battery into fire or throw it away. Return the wear-out battery to the provider or put it in the appointed recycle place. Do not put it in familial rubbish.

Follow these guidelines to protect your products:

keep the products out of children's reach

Keep your product dry. Do not expose it to liquid or moisture.

Do not short-circuit the battery, as this can cause excessive heat to bring about fire.

Do not expose your mobile phone to direct sunlight or in hot areas. High temperatures can shorten the life of electronic devices.

Do not attempt to disassemble the mobile phone and battery by yourself.

Non-expert handling of the devices may damage them.

Prevent liquid from leaking into your phone.

Please use original accessories. Using any unauthorized accessories may affect your mobile phone's performance.

The mobile phone can be charged with shieled USB cable.

Note: The performance of your phone depends on your local network operator's card and how you actually use it. We are not responsible for any damages due to inappropriate use.

FCC Regulations:

- ●This mobile phone complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
- ●This mobile phone has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiated radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.
 Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help.
 Changes or modifications not expressly approved by the party
 responsible for compliance could void the user's authority to operate the
 equipment.

RF Exposure Information (SAR)

This mobile phone meets the government's requirements for exposure to radio waves.

This phone is designed and manufactured not to exceed the emission limits for exposure to radio frequency (RF) energy set by the Federal Communications Commission of the U.S. Government.

The exposure standard for wireless mobile phones employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit set by the FCC is 1.6W/kg. *Tests for SAR are conducted using standard operating positions accepted by the FCC with the phone transmitting at its highest certified power level in all tested frequency bands. Although the SAR is determined at the highest certified power level, the actual SAR level of the phone while operating can be well below the maximum value. This is because the phone is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are to a wireless base station, the lower the power output.

The highest SAR value for the model phone as reported to the FCC when tested for use at the ear is 0.333 W/kg and when worn on the body, as described in this user guide, is 0.404 W/kg (Body-worn measurements differ among phone models, depending upon available enhancements and FCC requirements.)

While there may be differences between the SAR levels of various phones and at various positions, they all meet the government requirement.

The FCC has granted an Equipment Authorization for this model phone with all reported SAR levels evaluated as in compliance with the FCC RF exposure guidelines. SAR information on this model phone is on file with the FCC and can be found under the Display Grant section of http://www.fcc.gov/oet/fccid after searching on FCC ID: WVBASN52.

For body worn operation, this phone has been tested and meets the FCC RF exposure guidelines for use with an accessory that contains no metal and the positions the handset a minimum of 1.5 cm from the body. Use of other enhancements may not ensure compliance with FCC RF exposure guidelines. If you do not use a body-worn accessory and are not holding the phone at the ear, position the handset a minimum of 1.5 cm from your body when the phone is switched on.