
# **User Manual of**

# **Projector Mobile Phone**

**GSM/GPRS Digital Mobile Phone** 



December 2009

# **Table of Contents**

1	Safety and Precautions	6
2	Appearance and Keypad Instructions of Mobile Phone	8
	Back View:	
		8
	Battery cartridge view:	
	Top View:	9
		9
	Bottom view:	9
	2.2 Icons of Display Screen States	
3 ′	2.3 List of Mobile Phone Specifications	
<i>.</i>	3.1 Battery	

3.2 Network Connection		. 12
4 Quick Starter		. 14
4.1 Power ON/ OFF		. 14
4.2 Make Calls		. 14
4.2.1 Dial Status	14	
4.2.2 Dial Status	14	
4.2.3 Make the Domestic Calls	14	
4.2.4 Dial extensions of fixed-line telephones	15	
4.2.5 Make the International Calls	15	
4.2.6 Dial the numbers in call record	15	
4.3 Emergency Calls		. 15
4.4 Answer Calls		. 15
4.5 Call Services		. 16
4.5.1 Process of Call	16	
4.5.2 Operations of Functions	16	
4.5.3 Call Options	16	
4.6 Auto DTMF		. 16
5 Use the Functional Menu		. 17
5.1 Function of selecting scrolled search		. 17
5.2 Function of selecting shortcuts		. 17
5.3 Exit from Menu		. 17
6 Telephone Book		. 18
7 Message		. 19
7.1 SMS		. 19
7.1.1 In-Box	19	
7.1.2 Out-Box	19	
7.1.3 Compile Short Message	19	
7.1.4 Common Phrase	20	
7.1.5 SMS Setting	20	
7.2 MMS		. 20
7.2.1 Compile MMS	20	
7.2.2 In-Box	20	
7.2.3 Out-Box	21	
7.2.4 Draft	21	
7.2.5 Template	21	
7.2.6 MMS Settings	21	
7.4 Voice Mailbox		. 21
7.5 Cell Broadcast		. 21
8 Call Center		. 22
8.1 Call Record		. 22
8.1.1 Call Record of SIM Card 1		. 22
8.1.1.1 Delete the Call Record of SIM Card 1		. 22
8.1.1.2 Call Duration of SIM Card 1		. 22
8.1.1.3 Call Charge of SIM Card 1		. 22
8.1.1.4 SMS Counter of SIM Card 1		. 23
8.1.1.5 GPRS Counter of SIM Card		. 23
8.2 General Call Settings		. 23
8.2.1 Call Settings of SIM Card 1	23	

8.2.2 Auto Re-dial: When this feature is activated, the phone will automat	ically re-dial after call
failure every time.	24
8.2.3 Quick Dial: Set the shortcut dial function. Press the corresponding n	umeric key in standby
interface for a long time to call the pre-set phone numbers.	24
8.2.4 IP Dial: Input IP number and press ENTER to complete the setting to can	icel and edit the number
After IP number is set, you can use IP function in the telephone book or call	record to automatically
add the pre-set IP number before the numbers you dialed to call	24
8.2.5 More	24
9.1 SIM Card Settings	25
9.2 Calibration of Touch Screen	25
9.3 Mobile Phone Settings	25
9.4 Network Settings	26
9.5 Safety Settings	26
9.5.1 Safety Settings of SIM Card	26
9.5.2 Safety Settings of SIM Card 2	26
9.5.3 Phone Lock	26
9.5.4 Keypad Lock	27
9.5.5 Change the password: Change the phone lock password	27
9.6 Restore the Default Settings	27
10 Multi-media	
10.1 Camera	27
10.2 Photo Album	28
10.3 Video Recorder	28
10.4 Video Player	28
10.5 Music Player	
10.6 Recording	29
10.7 FM Broadcast	
10.8 FM Timing Record	30
10.9 Composer	
10.10 Mobile TV	
11 File Management	
12 Entertainment and Games	32
12.1 Games	32
13 Echo Mode	
13.1 General Mode	
13.2 Meeting Mode	
13.3 Outdoor Mode	
13.4 Indoor Mode	
13.5 Earphone Mode	
13.6 Bluetooth Mode	
14 Tool Kit	
14.1 Calendar	
14.2 To-Do	
14.3 Alarm Clock	
14.4 Universal Time	
15 Network Service	
15.1 STK Service	
15.2 WAP	35

15.3 Data Account	35
16 Additional Functions	36
16.1 Calculator	36
16.2 Conversion of Exchange Rate	36
16.3 Stopwatch	36
16.4 E-Book	36
16.5 Bluetooth	37
17 Mode Settings	38
18 USB Functions	39
19 Input Methods	40
19.1 Overview	40
19.2 Instructions of Input Methods	40
19.2.1 Handwriting Input Method40	
19.2.2 Intelligent Pinyin (Spelling) Input Method	
19.2.3 English Input Method	
19.2.4 Digital Input Method	
19.2.5 Stroke Input Method43	
20 Appendix	45
20.1 Security of Battery	45
20.2 Usage and Maintenance	45
20.3 Troubleshooting	46

#### 1 **Safety and Precautions**

⚠Note: Please read the following briefings carefully and observe the rules seriously to avoid hazards or infringement of the law.



#### **Caution during Driving**

Please observe all local laws and regulations. Please drive with two hands if possible during driving. put the mobile phone into the mobile phone holder, never put it onto the vehicle seats to prevent it from falling during scram. Upon any hazards, the airbag will inflate rapidly; so please never put any objects on the airbag or within the operating scope of it, including the fixed and handheld wireless device. The wireless device improperly installed inside the vehicles may cause serious personal injuries possibly when the airbag is being inflated.



# Please power off on plane

Interference from mobile phone may affect the security of planes and it's illegal to use the mobile phone on planes. So please power off your mobile phone on planes.



# Please power off in the blasting operation area

Please power off your mobile phone in or near the blasting operation area in strict accordance with the concerning laws or statutes.



# Please power off near the dangerous goods

Never use the mobile phone in the service station or places with dangerous goods like fuels and chemical agents, etc.



# In the hospital

Please observe the concerning laws or statutes of hospital to use the mobile phone in the hospital. Please power off near the medical facilities. The use of any wireless transmission equipment including mobile phone may interfere with the medical facilities not protected completely and well. To use any personal medical device, like rhythmoiphone and acousticon, etc., make sure the medical facilities used by you are equipped with proper external radio frequency protective device and precautions for users.



# Interference

All mobile phones may be interfered by radio, which may affect the performances of mobile phone.



# Specialized services

Only the professionals can install or repair the mobile phone. The improper installation or reparation of mobile phone may lead to hazards and violation of the warranty clauses.



# Accessories and Battery

Please only use the accessories and battery recognized by the phone manufacturer. It's recommended to return the used batteries to the mobile phone manufacturer or litter them to the appointed public obsolete and used battery recovering areas, and never put them together with other garbage or dispose them randomly.



# Reasonable Use

Just use the mobile phone in normal ways. Never put your mobile phone to the extremely high-temperature conditions, over 60°C, like the windows with direct sunshine. Please wipe and clean your mobile with wet or antistatic cloth instead of the dry or static cloth. Please keep your cell phone dry and clean as it is not waterproof.




#### **Emergency Calls**

Make sure the power supply of mobile phone is connected and in service status, and you can use it to dial the emergency call number of 112. During the standby state of mobile phone, you can input the emergency call numbers like 112, 119 and 110, etc., press the DIAL key to call. After being switched on, please brief the emergency cases and do not end the conversation without the permission of operators.


⚠Note: Like any mobile phone, some characteristics of this mobile phone may not be supported for the causes of network coverage or radio signals transmission. Some networks cannot even support 112 emergency call services. So please do not rely on the mobile phone for the particularly crucial communications like medical first aid purpose completely. Please inquire and check with your local network operator.

# 2 Appearance and Keypad Instructions of Mobile Phone

# Front View:




# **Back View:**




# **Battery cartridge view:**






# **Top View:**



# **Bottom view:**



# 2.2 Icons of Display Screen States

spiay screen states				
Signal intensity indication of SIM Card 1				
Signal intensity indication of SIM Card 2				
GPRS connection				
SMS not read of SIM Card 1				
SMS not read of SIM Card 2				
Service message not read				
Calls unanswered of SIM Card 1				
Calls unanswered of SIM Card 2				
Call forwarding of SIM Card 1				
Call forwarding of SIM Card 2				
Keypad is locked				
Keypad is unlocked				
Alarm clock				
Vibration and ring tone				
Ring tone				
Ring tone after vibration				
Vibration mode				
Battery power				
Bluetooth activation				
Bluetooth connected to Internet successfully				
MMS not read of SIM Card 1				
MMS not read of SIM Card 2				
Calls refused to answer				
Earphone mode				

# **2.3** List of Mobile Phone Specifications

Function	Description	Remarks
Model	Bar phone	
Dimensions	113*49*17	
Screen display	320*240	QVGA
Type of SIM Card	Common SIM Card	*

Built-in memory space	761K	
Frequency band used	850/900/1800/1900	*
Capacity of telephone book	Capacity of SIM Card depends on the types; the	*
Capacity of telephone book	cell phone can save 500 telephone numbers	
MP3	Supported	
MP4	Supported	
T-Flash Card	Supported	
CCD camera	Built-in	
GPRS	Supported	*
SMS/ MMS	Supported	
WAP	Supported	
Bluetooth	It supports Bluetooth stereo music play	
Data transmission	USB data line	
Recording	Supported	
Background light	Supported	
Chord music ring tone	Supported	
Call forwarding /call barring	Supported	*
Call waiting /multi-party	Supported	*
conversation		
Alarm clock /calendar / universal	Supported	
time		
Telephone book / groups	Supported	
STK	Supported	*
Auto Re-dial	Supported	
E-book	Supported	
Chinese and English Input Method	Supported	
Dual SIM	Supported	

Note: \* indicates that the corresponding functions or services shall be supported by Internet connection or SIM Card.

# 3 To Begin with

Please read this section carefully before using this cell phone. This section will instruct you how to insert and unlock SIM Card, tell you the information about digital GSM network, how to install and maintain your phone battery and how to charge the battery.

#### 3.1 Battery

Please run out the battery power for the first use and then charge it completely for use again; repeat this course for continuously three times, the battery will come to the best state of use.

#### 3.1.1 Load and Unload the Battery

Unloading steps: First pull the battery cartridge cover downward and then raise the protruding part of battery upward and take it out.

Loading steps: First clip the upper part of battery into the slot and then load the lower part of battery to place.

#### 3.1.2 Charge the Battery

- Insert the charger to the power supply;
- Insert the charger plug into the mobile phone faucet;
- Then the power indication symbol on the right upper corner of mobile phone screen will flicker; if the phone is powered off when it's charged, the screen will still display the charging symbol. If the cell phone is still used with low power, the power indication symbol will only appear on the screen after the battery is charged for a period of time;
- When the power indication symbol on the right upper corner of mobile phone screen is full and does not flicker again, it indicates the charging is completed. If the phone is powered off when it's charged, the screen still displays the charge completeness prompt. Charging will last for 2-3 hours. It's normal that the battery, mobile phone and charger get warmer during charging;
- When charging is completed, please disconnect the AC mains socket, mobile phone and charger.

**Warning**: Please put the mobile phone in a well-ventilated place with the temperature between -40°C and +55°C during charging, use the charger supplied by the mobile phone manufacturer. Use of the charger not recognized may lead to hazards and violation of recognition and warranty clauses of this mobile phone.

# 3.1.3 Battery Use

Please charge the battery when your mobile phone powers off automatically or it warns "Low Power" on a timely basis. The cell phone will automatically adjust to reduce the charging time if the battery power has not run out before charging.

The phone standby time and service time presented by the phone manufacturer are based on the ideal operating conditions. And in actual practice, the operating hours of battery vary as per the network status, operating conditions and modes of use.

#### 3.2 Network Connection

#### 3.2.1 SIM Card

This unit is a dual SIM phone; your network operator will provide two plug-in SIM Cards for your mobile phone. The SIM Card serves as the key for you to access the digital GSM network. Please insert the effective SIM Card into the mobile phone before using it, and you can insert two SIM Cards at the same time, switch to dual SIM modes and single SIM card mode, etc. in ON state.

Any information about network connection and your call records, as well as the names, phone numbers and short message received and saved in the cards, are saved in SIM Card. SIM Card may be take out from your mobile phone, and put into any GSM mobile phone for use, the new mobile phone will automatically read the SIM Card.

To prevent your message in the card from missing and damaging, never touch the metal plane of card and

put the SIM Card away from the electromagnetic conditions. Once SIM Cards are damaged, you cannot access GSM network.

#### 3.2.2 Insert and Take out SIM Card

- Generally put SIM Card into the card and take it out before loading it into the phone.
- Turn off the mobile phone and remove the battery and other external power source.
- Aim the SIM Card notch at SIM Card holder notch, and put it into the card slot with the metal side downward.
- Please first turn off the phone, unload the battery and then take out the SIM Card from the card slot.

Warning: Please take out the mobile phone before taking out the SIM Cards. Never insert or take out the SIM cards when the external power source is still connected, or your SIM Card may be damaged.

#### 3.2.3 SIM Card Lock

SIM Cards are encrypted for protection with PIN1 (Personal Identification Number) to prevent them from being used illegally. When this function is selected, you have to key in PIN 1 Code first upon startup every time to unlock the SIM Cards and make or answer calls. The users can cancel the SIM Card protection, but the SIM Cards may be used without authorization. First, press and hold the Hookup key for a period of time to turn on the mobile phone, then key in PIN 1 Code, clear it with touch pen and you can delete the input errors and press Return key to end it with the touch pen. For example, if the PIN 1 Code is set as 1234, please key in numbers of 1234. Your SIM Cards will be locked by service network if you keyed in the code for successively three times and the mobile phone will ask you to input PUK Code.

⚠Note: Your network operator will set a standard PIN code for your SIM Card, you shall change it to your private password as soon as possible.

#### 3.2.4 Phone Lock

You can set the mobile phone password to prevent them from being used illegally. When this function is selected, you have to key in mobile phone password after having inputted PIN Code if you have set PIN code protection first upon startup every time to unlock and use the phone. The users can cancel the mobile phone password, but the mobile phone may be used without authorization.

Key in the mobile phone password, clear it by the touch pen or delete the input error and finally press Return key to end it with the touch pen. For example, if the mobile phone password is set as 1122, just key in numbers of 1122. If you forget your mobile phone password, you have to contact with your retailer or the local authorized service center to unlock the mobile phone password.

#### 3.2.5 Connect to Internet

After SIM Cards are decrypted successively, the mobile phone will automatically search for your registered network or other local available networks and the screen will display the texts of "Search for Network". Once searched, the network operator name will appear in the middle of screen and at this time, your mobile phone enters into standby status.

△ Note: When the screen prompts "only for emergency calls", it indicates that your phone is out of the working network coverage, yet you can still make the emergency calls as per the signal intensity.

# 4 Quick Starter

#### 4.1 Power ON/ OFF

#### 4.1.1 Power ON

Press the power key for a long time to power on the mobile phone.

If the screen displays "Please insert SIM Card 1/ SIM Card 2" upon startup, please press the Power key for a long time to power off and check if your SIM Card 1 and SIM Card 2 are installed correctly or if they are installed.

Just input the correct mobile phone password or PIN Code when your mobile phone asks you to key in the mobile phone password or PIN Code upon startup. If don't know about PIN Code, please get contact with your network operator. The default mobile phone password is 1122.

#### 4.1.2 Power OFF

Press the power key for a long time to power off the mobile phone, and the power supply of mobile phone will be disconnected when the power-off animation appears on the screen.

#### 4.2 Make Calls

The notification bar at the left upper corner of display screen displays the network signal intensity (the signal is most intensified when there are 4 notification bars). The quality of services is much affected by obstacles, so the signal intensity may be improved effectively by moving within a small scope during use.

Dial numbers in the following ways:

- Find the telephone number, please refer to Telephone instructions for details, in the main menu and access
  to the contact interface, select the desired number and directly press the DIAL key on SIM Card 1 or SIM
  Card 2.
- Press the right function key in the standby interface to access the telephone list, select one record and press the DIAL key on SIM Card 1 or SIM Card 2 to make a call.
- In the interface of Unanswered Calls, Answered Calls and Dialed Calls lists in the call records of SIM Card 1 /SIM Card 2, access the Option interface of this record, press the DIAL key on SIM Card 1 or SIM Card 2 to dial the telephone number in the record of dialed calls.
- The keypad is locked in standby status, just directly key in the numeric keys on the keypad and then press the DIAL key on SIM Card 1 or SIM Card 2 to make a call.

#### 4.2.1 Dial Status

Click an arbitrary numeric key to access Dial Status.

The phone will display the signal and power symbols and other icons during dial and prompt the cursor location with the flickering upright slash.

• Press \* key twice to input + to dial the international calls; press \* key for three times to input P for auto DTMF (automatically dial the extension number) like 075521097618P613.

#### 4.2.2 Dial Status

• Key in numbers in Dial interface and press the DIAL key on SIM Card 1 or SIM Card 2 to make a call and enter into the DIAL status.

The screen will display the signal and power indication during dialing; when the number exists in the telephone book, it will display the corresponding names; otherwise, it just displays the phone number and the number attribution. Press HOOKUP key to hook up the current call during dialing.

#### 4.2.3 Make the Domestic Calls

The simplest method to make a call is to input the telephone numbers with numeric keys, and add the zone
code except for local domestic calls to make the call. To modify the telephone number, use the touch pen to
clear the character before the cursor.

The screen ill display Being Dialed during dialing and will display the conversation status and information after the called has hooked up, like the call time.

Press the HOOKUP key to end the call.

Make the domestic calls: Area code + telephone number + dial

#### 4.2.4 Dial extensions of fixed-line telephones

Some extensions of fixed-line telephones cannot be dialed directly, you have to first dial the central exchange and then the extension numbers. If you insert a symbol, i.e., P symbol for pause, between the central exchange and extension numbers upon keying in the telephone numbers, this phone will complete the whole dial for your and automatically dial the extension number. Steps to input P: Input the phone numbers in DIAL interface and press \* key for successively three times to input P.

Dial the extensions of fixed-line telephones:

Area code + central exchange number + P+ extension number + dial

#### 4.2.5 Make the International Calls

Press \* key twice in DIAL interface to input + and the screen will display the prefix character \* before the international phone number, it makes you to dial the number from any country when you know little about the prefix of local international number.

Input the prefix first and then the country code and complete phone number. The country codes shall subject to the common practice of the world; that of Germany is 49, that of British is 44 and that of Sweden is 46.

Like dialing the international numbers, please exclude 0 before the city code during dialing.

Make the international calls: + country code + complete telephone number + dial

#### 4.2.6 Dial the numbers in call record

Every telephone number you dialed and received are saved in the mobile phone. The mobile phone also provides all call records for your inquiry. The old phone numbers will be automatically deleted when the telephone book is full. You can press this menu to dial the numbers in the call record as usual.

When the telephone numbers appear in the list, you can access the call record with the touch pen and select the options of call record, save it by the touch pen till this number is added to the telephone book.

#### 4.3 Emergency Calls

In any country or area available with digital GSM network, you can make the emergency calls when you are located within the Internet coverage, you can know it by the Internet signal intensity indication bar displayed on the left upper corner of mobile phone screen. If your network operator fails to provide the roaming services in the area, the screen will display the texts of "Only for Emergency Calls" to tell you that you can only make such calls. You can still make emergency calls even if your phone is not inserted with SIM Card if you are located within the Internet coverage.

#### 4.4 Answer Calls

The phone will enter into the Incoming Call interface when your number is called and make ring tones or vibration according to the ring tone set presently.

The screen will display the signal and power indication when you are answering a call; if the incoming call number exists in the telephone book, it will display the name corresponding to this number; otherwise, it only display the number and the SIM Card properties of incoming call.

Answer calls by the DIAL key of SIM Card 1 or SIM Card 2 and refused to answer calls by the Hookup key;

Note: You can use the earphone switch to answer calls if the earphone is inserted and you can automatically answer the calls if you have set the auto answer and inserted the earphone 5 seconds of incoming call.

#### 4.5 Call Services

#### 4.5.1 Process of Call

Access to the process of call when both ends are connected through.

Items displayed on the screen during calls include caller picture if you have set it; name or phone number; call duration if you have activated this feature in the phone settings and SIM Card status of call.

#### **4.5.2 Operations of Functions**

Touch the options during calls with the touch pen to access the call service options; you can press the Hookup key to hook up the present call; the current call will be automatically held if you make new call.

- Hookup key: It's used to hook up calls.
- Left and right direction keys: It's used to switch over several calls.
- Up and Down direction keys: It's used to adjust the volume of microphone.
- Left function key: It's used to access the call options during calls.

# 4.5.3 Call Options

Access the call options in Call Interface with the touch pen. This interface is only visible during calls. You can operate as below for Call Options:

- Hold the single call: Pause one of calls during Multi-party Conversation.
- End the single call: End the current call.
- New conversation: When one of calls is paused during Multi-party Conversation, you can make a new call.
- Telephone book: Access the telephone book menu.
- Message center: Access the message menu.
- Record: Record the conversation.
- Mute: Turn on or off the mute mode.
- DTMF: Send DTMF signals.

△ Note: Some menu options only appear in particular cases or should be supported by the local network.

#### 4.6 Auto DTMF

The phone will automatically access DTMF (automatically dial the extension number) when the numbers inputted contain P after it is switched in.

# **5** Use the Functional Menu

# 5.1 Function of selecting scrolled search

Press the left function key of MENU or touch MENU on the touch screen with touch pen in standby status to access the Functional Menu interface, or press OPTIONS during calls to access the call option MENU.

Use the Up, Down, Left and Right keys on the keypad in all main menu or submenu to scroll to the desired function and then press the Left function key to access the function options; you can press the UP and DOWN keys in Page Turn menu to turn pages; in touch mode, directly use the auxiliary pen to touch it to access the function options.

# **5.2** Function of selecting shortcuts

There are shortcut numbers in both the submenus and menu options, corresponding to the due index numbers. Press the shortcut numbers of menu options to access the corresponding options, and input the shortcut number in the submenu options in the menu list to highlight and select the corresponding options.

# 5.3 Exit from Menu

Generally, you can press the Right function key or use the auxiliary pen to touch the RETURN button on the touch screen in the functional menus to exit from the menu options; or you can press the Hookup key to directly return to the standby status.

# 6 Telephone Book

This mobile phone is equipped with three kinds of memory banks, including SIM Card 1, SIM Card 2 and mobile phone, the capacity of mobile phone is 500 records and those of SIM Cards are subject to the types of SIM Cards.

Access the Telephone Book interface in the main menu interface.

You can select and access the following functions in the telephone book:

- Quick search: Search the records of desired contact persons quickly: In this menu, you can quickly search for the contact. For example, the first letter of contact person you want to search with the family name of 
  Zhao is z, just press the numeric key 9 for four times or press letter Z on the keypad of display screen once, et sic de similibus. After having found the records of corresponding contacts, press the Left function key to dial the number of the record by IP from SIM Card 1 /SIM Card 2 (the number selected will be dialed by IP mode), send SMS, send MMS, check, edit, delete, copy, move, copy and send the business card, etc.
- **Search for contact**: Search the records in the telephone book by names.
- Add contacts: Add a new contact record into the telephone book; you can select the memory position in SIM Card 1, SIM Card 2 or this phone. The records are different slightly in memory formats that are saved in SIM Card and mobile phone.
- Copy All: This phone provides six copying modes, including from SIM Card 1 to mobile phone, from mobile phone to SIM Card 1, from SIM Card 2 to mobile phone, from mobile phone to SIM Card 2, from SIM Card 1 to SIM Card 2 and from SIM Card 2 to SIM Card 1.
- **Delete**: Delete all or delete one by one from SIM Card 1, SIM Card 2 or mobile phone. To delete all, please input the mobile phone password, same with the phone password.
- Caller group: This phone provides five caller groups for you; you can separately set up the group name, caller ring tone, caller picture, video linkage and group members for them.
- Other numbers: You can edit and delete the numbers saved in SIM Card 1 and SIM Card 2, like owner number, service numbers and emergency numbers, etc.
- **Setting**: You can set the functions of telephone books, including memory status, prior storage position, business card setting, my business card, business card version and pronunciation of contact names in the telephone book.
- Caller picture: Set the pictures displayed in the interface of incoming caller and called.
- Caller ring tone: You can select the ring tones in the echo mode for the caller ring tone, and set them as the incoming caller ring tone of new contacts, original contacts or caller groups.

# 7 Message

Access the Message Menu from the main menu interface.

#### **7.1 SMS**

Touch the SMS menu with the touch pen and access SMS Menu.

This mobile phone supports the enhanced EMS, i.e., you can send and receive the short message inserted with such attachment as pictures, ring tone and animation. Short message will be saved to SIM Card or mobile phone as set up by the user when the short message capacity is not full. When you cannot receive any new message when the short message capacity is full and a flickering icon will appear on the top of home screen to warn you that the In-Box is full; then just delete some short message to release new free space to the In-Box, and your mobile phone may continue to receive new short message.

#### 7.1.1 In-Box

This menu contains the In-Box of SIM Card 1 and In-Box of SIM Card 2.

You can check the received short messages in these two In-Boxes, and reply, delete, edit, forward and copy them into the mobile phone /SIM Card, move them to the mobile phone /SIM Card, delete all, copy all of them, check the number used (dial or save the number) and web-site used (directly link to the web-site contained in the web-site. When there is no message, the In-Box screen will display "Blank" and read aloud.

#### **7.1.2 Out-Box**

This menu contains the Out-Box of SIM Card 1 and Out-Box of SIM Card 2.

You can read the sent short message saved in the out-box in this menu, send, edit, delete and copy them from SIM Card 1 /SIM Card 2 to the mobile phone /SIM Card, move then to the mobile phone /SIM Card, delete all, move all of them, check the number used and web-site used.

#### 7.1.3 Compile Short Message

Access the interface of Compile Short Message and operate as below:

- To edit, use the touch pen to touch the input methods at the bottom of screen to select Intelligent Pinyin (Spelling) input method, Intelligent Case-sensitive English Input Method, Capital & Lowercase Letters input method, digital input method, Pinyin (Spelling) input method or Stroke input method, the edition interface will switch to the selected input method interface.
- To input short message contents, touch the Option with the touch pen and complete the edition of SIM Card 1 /SIM Card 2, use the template, insert into objects, text formats, insert numbers, insert names, insert bookmark and edit the input method. To delete the contents completed, first use the touch pen to clean them. After having complied the short message, select the OPTION and use the touch pen to select to send it from SIM Card 1 or SIM Card 2; access the SEND options and select to send, save and send, save, send to multiple parties and to groups. Press ENTER key with the touch pen to send message and directly input the numbers or search for the numbers to be sent to by touch pen in the interface of Number to Send. After having selected, pres ENTER key with the touch pen to send the short message.
- Return to the short message interface after sending out. The phone will receive the message report if you have set up the short message report feature, please refer to Short Message Settings for the setting method. Note: Please refer to the Input Method section for details of character input.

#### 7.1.4 Common Phrase

You can set some phrases commonly used in this menu for convenient selection and use. Open the Common Phrase option with the touch pen, and you can see some default phrases, touch one of them to edit, delete it or establish new short message to the template. Select EDIT to access the interface of Edit the Common Phrase; edit it, save and modify it with the touch pen. Select DELETE and touch YES with the touch pen to delete the selected phrase; touch NO with the touch pen to return to the Common Phrase interface. Select new message to access the interface of Edit Short Message.

#### 7.1.5 SMS Setting

This menu contains the SMS settings separately for SIM Card 1 and SIM Card 2, i.e., please make the necessary settings first to use SMS function.

Access the submenu and set the following items:

- **Mode setting:** Set the suitable mode for the short message of mobile phone. Enter into all modes to set the folder name, SMS center number, validity period of short message and sending format.
- State setting: Set whether or not to turn on the message report and/or reply path.
- Capacity inquiry: Check the space occupation status of mailboxes in SIM Card or mobile phone.
- **Storage position**: Select SIM Card or mobile phone as the storage position.

#### **7.2 MMS**

#### 7.2.1 Compile MMS

Create MMS contents.

- Addressee: Input the information about the addressee as one or multiple telephone number or E-mail address, 20 at the most. Press the left soft key "EDIT" and then select to add phone numbers or E-mail addresses, or add new phone numbers or E-mail addresses. Select "ADD NUMBER" and press the left soft key SEARCH when the edition area is blank to browse the telephone book and select phone numbers in it, then press ENTER to add the selected numbers; Select OPTION and then EDIT on the addressee notification bar already edited to modify the current phone number or E-mail address; select DELETE to delete the current phone number or E-mail addresses; press ENTER key to confirm the modification of addressee.
- Copy: Phone numbers or E-mail addresses for carbon copy with the same operations of ADDRESSEE.
- Blind Courtesy Copy: Phone numbers or E-mail addresses for blind courtesy copy with the same operations
  of ADDRESSEE.
- Subject matter: Input the subject matter.
- Contents to be edited: You can edit the texts, set input method, add pictures, add voice, add video files, add attachment, add new page before, add new page after, add texts to bookmark, preview, set the interval time, edit pictures, edit voice, edit video files and edit attachment, etc.;

After having completed the new MMS content, press Up and Down keys to select all ports of MMS, press EDIT to modify it, press COMPLETE to access OPTION menu, select SEND to send the MMS, select SAVE & SEND to send it and save it to Out-Box at the same time, select SAVE TO DRAFT to save it to the draft, select SAVE AS TEMPLATE to save it into the templates, select SEND OPTIONS to access the setting page of MMS, select EXIT and the mobile phone will ask you whether or not to SAVE and after having selected the desired option, return to the MMS submenu interface.

#### **7.2.2 In-Box**

It contains all received MMS message and for the MMS currently selected, you can check, reply, reply by short message, reply to all, forward, delete, delete all, save as template, details of message and items used.

#### **7.2.3 Out-Box**

It contains all sent MMS list and for the MMS currently selected, you can check, forward, edit, delete, delete all, save as template, details of message and items used.

#### **7.2.4 Draft**

It contains MMS list not yet sent out and for the MMS currently selected, you can check, send, edit, delete, delete all, save as template, details of message and items used.

#### **7.2.5** Template

This menu contains two template modes of User-defined Template and Pre-set Template.

# 7.2.6 MMS Settings

- Edit: You can edit and set the editing mode, picture zoom-out and auto signature.
- Send: You can set the period of service, report of sent message, report of read message, priority, time interval and sending time.
- Receive: You can set the master network, roaming network, sending reading report and allowing sending report.
- Filter: You can set the filtering of anonymous senders and advertisement information.
- Server: You can set, edit and select the network parameters of SIM Card 1 and SIM Card 2.
- Memory status: You can check the MMS memory status.

⚠ Note: Please ask your network operator if it can provide the MMS network services and how to apply for the services.

#### 7.4 Voice Mailbox

You can separately edit the voice mailboxes of SIM Card 1 and SIM Card 2. You can save the received voice message into the network in this menu and you must dial the voice mailbox number to listen to the message.

- **Edit**: You can add and edit the voice mailbox number, to make it much faster and more convenient to use the functions of voice mailbox.
- Connect to voice: Call the voice mailbox number you set to listen to the leave message.

#### 7.5 Cell Broadcast

You can separately set the cell broadcast of SIM Card 1 and SIM Card 2 with the menus detailed as below:

- Receiving mode: Select to turn on or off it to receive or refuse to receive the cell broadcast information.
- Reading information: Access this menu to read the cell broadcast information you customized by you.
- Language: Set the receiving languages of cell broadcast.
- Channel setting: Set the cell broadcast channel, you can select, add new, edit and delete the channels.

⚠Note: The services of cell broadcast and voice mailbox are provided by the operator, so please contact with your operator for application.

# 8 Call Center

Move the cursor to the call center in the main menu to access this menu.

# 8.1 Call Record

#### 8.1.1 Call Record of SIM Card 1

Your mobile phone may save 20 recently unanswered calls, 20 dialed calls and answered calls and you can check these records by this menu.

- Click **unanswered calls** to check the list of unanswered calls.
- Click dialed calls to check the list of dialed calls.
- Click **answered calls** to check the list of answered calls.

In the call record list interface, touch the selected call record with the touch pen to check the details of this record, including date, dialing time, number and call duration.

In the interface of detailed information, touch **Options** with the touch pen to operate the call record selected present:

- Delete: Delete this record.
- Save: Save this number directly into the telephone book of SIM Card or this phone.
- Call: Dial this phone number from SIM Card 1.
- Edit: Edit this phone number and save it into the telephone book.
- **Send SMS:** Directly edit and send SMS from this number.
- **Send MMS:** Directly edit and send MMS from this number.

# 8.1.1.1 Delete the Call Record of SIM Card 1

You can select to delete all call records, or separately delete the record lists of unanswered calls, dialed calls and answered calls.

#### 8.1.1.2 Call Duration of SIM Card 1

There are four submenus for call durations, including last call duration, total dialed calls, total answered calls and return all time values to zero.

- Last call duration: Check the call duration value.
- Total dialed calls: Check the gross time of dialed calls.
- **Total answered calls**: Check the gross time of answered calls.
- **Return all time values to zero**: Clear the timing data and re-start to time.

#### 8.1.1.3 Call Charge of SIM Card 1

The service fees may be charged by the accumulated time duration.

- Last call charge: Check the last call charge.
- All call charges: Check the accumulated call charges.
- Return the call charges to zero: Input PIN 2 Code to clear the price calculator and re-start to charge.
- Cost restriction: You can read, modify or cancel this function. You have to key in PIN 2 Code to modify
  and cancel this function.
- Price and rate: You can read, modify or cancel this function. You have to key in PIN 2 Code to modify and cancel this function.

⚠Note: You have to key in PIN 2 Code for some operations and please get contact with your network operator to get this code.

#### 8.1.1.4 SMS Counter of SIM Card 1

- **Sent**: Record the quantity of sent short message.
- **Received**: Record the quantity of received short message.

You can click **RESET** with the touch pen to separately clear these two short message counters.

# 8.1.1.5 GPRS Counter of SIM Card

- Sent last time: Record the bytes sent last time.
- Received last time: Record the bytes received last time.
- **Send all**: Record the total bytes sent.
- Receive all: Record the total bytes received.
- Clear the counter: Clear the data and re-counter.

# 8.2 General Call Settings

#### 8.2.1 Call Settings of SIM Card 1

- Local number
  - > System pre-settings: Sending the number or not applies the default value.
  - ➤ **Hide the number:** The opposite party cannot see this phone number during calls, it shall be supported by the operator.
  - **Send number:** The opposite party may see this phone number during calls.
- Call waiting: You can choose to turn on or off the call waiting functions, select INQUIRY to check the current call waiting status.
- call forwarding
  - ➤ **Unconditional forwarding**: When this function turns ON, the incoming calls may be forwarded to the phone number you pre-set in any case.
  - Forward upon contact failure: When this function turns ON, the incoming calls may be forwarded to the phone number you pre-set when the caller cannot contact with you.
  - No Answer Forward: When this function turns ON, the incoming calls may be forwarded to the phone number you pre-set when your mobile phone does not answer the calls.
  - Forward on busy: When this function turns ON, the incoming calls may be forwarded to the phone number you pre-set when your mobile phone is busy.
  - Forward all data incoming calls: When this function turns ON, the incoming calls may be forwarded to the phone number you pre-set when the incoming calls are data calls.
  - **Cancel to forward**: Cancel all call forwarding services.
- Call barring: Restrict the calls to be dialed.
  - **Barring Outgoing calls:** Restrict the outgoing calls.
  - **Barring incoming calls**: Restrict the incoming calls.
  - **Cancel the barring:** Cancel the pre-set barring by inputting the password.
  - **Change the password:** Change the password.
- **Line Switching**: You can switch to Line 1 or 2, and Line 1 is the default one.

Note: If Line 2 is selected, ability to make outgoing calls depends on the services provided by network operator.

• Close the groups: You can select the group list to be closed.

- **8.2.2 Auto Re-dial:** When this feature is activated, the phone will automatically re-dial after call failure every time.
- **8.2.3 Quick Dial:** Set the shortcut dial function. Press the corresponding numeric key in standby interface for a long time to call the pre-set phone numbers.
- **8.2.4 IP Dial:** Input IP number and press ENTER to complete the setting to cancel and edit the number. After IP number is set, you can use IP function in the telephone book or call record to automatically add the pre-set IP number before the numbers you dialed to call.

#### 8.2.5 More

- **Prompt of call duration**: Display the call duration during conversation so that you can know about the call time actually and select to end the call to save call charge. You can select the prompt type of OFF, One Sound or Periodical.
- **Display of call duration**: You can turn on or off the display of call duration.
- Auto time limit: You can set to automatically hook up at some time during calls.

# 9 Settings

Access the Setting menu interface from the main menu. You can set your mobile phone in this menu, including SIM Card settings, touch screen calibration, mobile phone settings, network settings, security settings and restore to factory setting.

# 9.1 SIM Card Settings

- Turn on two SIM cards; Select to turn on both SIM Card 1 and SIM Card 2 at the same time.
- Only turn on SIM Card 1: Select to turn on SIM Card 1.

  When this option is selected, the mobile phone will switch to SIM Card 1 and turn off SIM Card 2;
- Only turn on SIM Card 2: Select to turn on SIM Card 2.

  When this option is selected, the mobile phone will switch to SIM Card 2 and turn off SIM Card 1;

  (Viewed from the back of mobile phone, SIM Card 2 is located above and SIM Card 1 is located below)
- Flight mode: In flight mode, the communication function of mobile phone is turned off, you cannot make calls, send message and contact with the base station.

In this mode, the mobile phone turns off the signal related functions, but still provides other functions, like viewing the telephone book, watch the articles and movies, etc. on the mobile phone.

Note: At present, the civil aviation departments have not launched the statute concerning Flight Mode, so the passengers should still observe the relative regulations on the planes before going aboard to power off the mobile phone; you can switch to this mode in the mean time like nights to save power— As most power of mobile phone is consumed for signals and so signals are turned off in flight mode.

## 9.2 Calibration of Touch Screen

When you think the mobile phone responds inaccurately when the touch pen touches a certain position on the touch screen, please calibrate the touch screen. Click the center of with the touch pen as per the prompt till the screen prompts the completeness of calibration. When calibration fails every time after you have clicked the center, please restore to factory setting.

#### 9.3 Mobile Phone Settings

- **Time and date**: Set the time and date.
  - > Set the city: Select a city for the local time zone of this phone.
  - **Time/ date settings**: Set the present time and date.
  - Format settings: Set the display format of time and date as 12 or 24-hour system; date format setting: Year- Month- Date, Month- Date, Year, Day-Month- Year, Date / Month / Year, Month / Date / Year and Year / Month / Date.
- Timing Power-On/ Off: You can set 4 time periods to power on or off at the time periods.
- Language: Set the display language of mobile phone menus, including English and simplified Chinese.
- **Pre-set input method**: Select a default input method.
- Standby menu display: You can set the following items as per your preference:
  - **Wallpaper:** You can select the wallpaper for standby interface.
  - > Screen saver: You can select the screen saver pictures.
  - **On Animation:** You can select the On Animation.
  - ➤ Off Animation: You can select the Off Animation.
  - ➤ **Display the date and time**: Select to turn on or off this function to set whether or not to display the present time in standby interface.
  - > **Display the owner number**: Select to turn on or off this function to set whether or not to display the owner number in standby interface.
- Greetings: When it is activated, the phone will display the greetings upon startup and when it is disabled, it

will not.

- **Appoint the function keys**: You can set up the functions of Up, Down, Left and Right navigation keys in the standby interface.
- **Auto update time**: Select to turn on or off this function to set whether or not to automatically update time.
- **Handwriting settings:** You can set the speed and color of handwriting pen.
- UART settings: You can select SIM Card 1 or SIM Card 2 upon connecting USB line.
- Other settings: You can select to set the brightness and time of LCD background light.

# 9.4 Network Settings

You can set SIM Card 1 and SIM Card 2 separately.

#### Network Selection

- ➤ **Auto**: Automatically search for the local network of SIM Cards.
- Manual: Search for all networks available at present and register manually.
- **Preferred network**: You can pre-store several of your favorite networks.

# 9.5 Safety Settings

# 9.5.1 Safety Settings of SIM Card

#### Lock of SIM Card 1

You can set the safety options of mobile phone in this menu to prevent the mobile phone or SIM Cards from being used illegally. PIN Code may prevent your SIM Card from being used illegally. If PIN Code is turned off at present, just select to turn on the protection with PIN Code, and the phone will ask you to key in PIN Code upon startup; If PIN Code is turned on at present, you can select to turn off the protection with PIN Code, select Safety Settings —> Change Password —>PIN Code to set new PIN Code, please input the old PIN Code, new PIN Code and re-input the new PIN Code as per the prompts.

⚠Note: SIM Card will be locked if PIN Code is inputted incorrectly for successively three times; then you have to input PUK Code to unlock SIM Card. PIN Code and PUK Code may be provided to you together with SIM Card. If not, please get contact with your network operator. The default PIN Code is generally 1234, please change it to your own password as soon as possible.

#### Fixed dialing

If supported by your SIM Card, you can restrict to only dial the selected telephone numbers. When this function is enabled, you can only dial the telephone numbers in the fixed dialing list or the telephone numbers initializing by certain numbers in the list.

Enter into the submenu of Fixed Dialing to make the following settings:

- **Mode**: Turn on or off the fixed dialing function, you have to input PIN 2 Code.
- Fixed dialing list: Input the telephone numbers for fixed dialing.

⚠Note: You have to input PIN 2 Code to turn on or off the fixed dialing function; please get contact with your network operator to obtain PIN 2 Code. Open the menu of Fixed Dialing, enter into the folder and to display the numbers for fixed dialing.

- **Dial barring**: Contrary to the fixed dialing, you can set to bar some phone numbers in this menu.
- Change the password: Change the passwords, including PIN 1 Code and PIN 2 Code.

#### 9.5.2 Safety Settings of SIM Card 2

Please refer to the safety settings of SIM Card 1 for details

#### 9.5.3 Phone Lock

The phone lock may prevent your mobile phone from being used illegally.

Press the phone lock to turn on the mobile phone lock password protection and the phone will ask you to

key in the mobile phone lock password upon startup next time; press it again to turn off the mobile phone lock password protection.

**Note:** The default mobile phone lock password is 1122; please change it to your private password as soon as possible.

# 9.5.4 Keypad Lock

It's used to set the waiting time of keypad lock. When it is set, the keypad will be locked automatically when the mobile phone is not used within the et time. To unlock the keypad, first press the right function key and then press # key to unlock the keypad.

#### **9.5.5 Change the password:** Change the phone lock password.

△ **Note:** Some functions shall be supported by your network operator.

## 9.6 Restore the Default Settings

Input the phone lock password of 1122 in this menu, press ENTER key and restore the relative parameters of mobile phone to the initial values. Data in the mobile phone will be still kept.

# 10 Multi-media

Access the Multi-media interface from the main menu.

#### 10.1 Camera

Select the Camera menu and select the following items for operations: press the left and right navigation keys to adjust the exposure compensating factor of camera; change the special effect settings; set the white balance; set the delayed shooting time; set step-and-repeat mode; set the night shot mode; set picture quality and set picture sizes for photography. Press OK key in the Preview interface to complete the shooting and prompt to save the pictures. You can press # key in Preview status to switch to full screen. Or you can press the left function key of Options in Preview status for the following operations:

#### Switch to camera

You can select the front and back CCD camera and access to take pictures

#### Photo Album

- **View**: View the selected pictures.
- **Preview mode:** You can select the list mode or matrix mode.
- Forward: You can forward the pictures as wallpaper, screen saver, startup animation, shut-off animation, to the telephone book, to MMS and to Bluetooth.
- **Rename**: Rename the selected pictures.
- **Delete**: Delete the selected pictures.
- **Delete all**: Delete all pictures.
- Sort: Sort all pictures by name, by type, by time, by sizes or NONE and arrange them by the initial record
- Storage path: You can select to store the pictures to the mobile phone or memory card.

# Camera Settings

- Shutter sound: The optional sound effect modes include Sound Effect 1, Sound Effect 2, Sound Effect 3 and Shut off.
- Avoid flicker: The optional modes include 50Hz and 60Hz, 50Hz shall be applied for the indoors fluorescent lamp lighting conditions in China.

#### • Picture Settings

**Picture size:** Press [8] key in Shooting Preview status to switch the settings. The optional modes

include 240×320 and 640×480; the bigger is the size, the more space the picture files occupy.

➤ **Picture quality**: Press [7] key in Shooting Preview status to switch the settings. The optional modes include low class, middle class and high class; the higher is the quality grade, the more space the picture files occupy.

#### Storage Path

You can select to save the pictures to the mobile phone or memory card.

# • Restore to the Default Settings

Restore all settings to the default ones.

#### 10.2 Photo Album

In this menu, you can quickly view the functions of photo album files; please refer to Camera -> Photo Album of Section 10.1.

#### 10.3 Video Recorder

Access the multi-media interface and touch the video recorder with the touch pen to access the record preview interface. To preview, press the Left and Right keys to adjust the exposure compensating factor of camera; or press the Up and Down keys to adjust the amplification factor of camera. Press the Center key to start to record video or press the left function key OPTION in preview status for the following operations:

#### • Vide recorder settings

Set the relative parameters of video records:

Avoid flicker: The optional modes include 50Hz and 60Hz, 50Hz shall be applied for the indoors fluorescent lamp lighting conditions in China.

# Storage Path

You can select to save the pictures to the mobile phone or memory card.

#### • Restore to the Default Settings

Restore all settings to the default ones.

#### 10.4 Video Player

Select the Movie Player submenu and access the movie list:

- Use the Up and Down keys to select the file to be played, press OPTION key to play, forward, rename, delete the movie, delete all files, sort and select the storage position.
- Directly click the movie to be selected with the auxiliary pen for corresponding operations.

During the movie play, press the Left and Right keys to control the movie play progress and press OK key to play/ pause the movie.

# 10.5 Music Player

Please the Up and Down keys in Music Player interface to adjust the volume; press OK key to play/ pause; press the left direction key to play the previous music and press the right direction key to play the next music.

Press LIST key in Music Player interface to access the present play list of mobile phone, you can select the options to play the music files in the list, show the details, add them into ring tone base, update the play list and set them.

Select the SETTING menu to set the following items:

#### • Plav:

- **List**: Select the music play path as the mobile phone or memory card.
- Automatically generate the list: Set to turn on or of this option. When it is set to ON, you can Update the Play List; if the music play path is set as from the mobile phone, it will update the music files in the [Archive Management] \Mobile Phone Directory into the play list; if the music play path is set as

from the memory card, it will update the music files in [Archive Management]\ Memory Card Directory into the play list without bothering to modify them manually. When it is set to OFF, you can select the music files from newly added folders by OPTION to the play list, remove the single music file from the play list or remove all music files from the play list.

- Repeat: You can use the Left and Right keys and set the repeat play mode of music as OFF (no repeat play), single music and all.
- Random: Set the play order separately as ON (random play) and OFF (play as per the current list order).
- ➤ **Background play**: Press the Left and Right keys to set this OPTION as ON to enable the mobile phone play music in other operator interfaces, except for sound operations, camera operations or record interfaces.
- **Bluetooth stereo output:** Select to turn on or off the Bluetooth stereo output status.
- **Bluetooth stereo earphone**: Display the Bluetooth stereo earphone status.
- **Power display style:** This phone provides two display styles, and you can select to shut off it.
- Lyrics display: You can turn on or off the lyrics display.

⚠Note: As this music player only automatically put the music saved in My Music folder in the memory into the play list, so you'd better save the downloaded music into My Music Folder of memory.

**Warning:** Upon using the music play functions of mobile phone, the users shall make sure to adjust the volume to a proper level to prevent it from impairing your hearing.

# 10.6 Recording

This mobile phone supports three record formats of WAV, AMR and AWB; you can select one format for recording, can record the conversation and save it to AUDIO directory of file management.

Touch RECORD with the touch pen in multi-media menu and access the RECORD interface. For the existing record file, touch it with the touch pen to access:

- Record: Make a new record. Touch RECORD with the touch pen to start recording; then you can record all
  kinds of voice, press the left function key to Pause/ Continue to record and after completing the record,
  press the right function key and select STOP. Then you can re-edit the filename, and press the left function
  key or OK key to access OPTION, select to save the record.
- **Play**: Play the record file selected currently.
- Attach: Attach and add a new record after the record file selected currently, record in WAV format is not supported by this phone.
- **Rename**: Rename the record file selected currently.
- **Delete**: delete the record file selected currently.
- Delete All: Delete all record files.
- Set: Set the storage position, record format and voice quality. When the file format is changed, the mobile phone screen will display the time available for recording.
- Forward: Send the current record to the echo mode, MMS and Bluetooth. After being sent to the ring tone base of echo mode, the record file may be used as the ring tone of incoming call or alarm clock; after being sent to MMS, the record file may be forward to others in MMS format; after being sent to the Bluetooth, the record file may be forward to others via Bluetooth device.

⚠Note: When call comes from the recording, the recording procedure will be interrupted and record made before the incoming call will automatically saved into the phone.

⚠ Note: Please take pictures, image pickup and record allowed by laws.

#### 10.7 FM Broadcast

- **Channel list**: Play the set channel list rapidly.

- **Manual input**: Skip to the channels inputted manually rapidly.
- Auto search and settings: Search for channels automatically and set them into the list.
- **Settings**: In this menu, you can set the background play, turn on/off the mobile phone speaker and record formats, etc.
- **Record**: Record the FM programs.
- **Attach**: Play the files saved after FM recording.
- **File list**: Save the files saved after FM recording.

**Note:** With this function, you can listen to the broadcast and the broadcasting effect depends on the coverage of broadcast stations within the particular scope.

# 10.8 FM Timing Record

You can set the time, date and channels and record the programs in the set channels and set time points.

#### 10.9 Composer

Press the left function key and enter into Music Composing interface, press OPTION to set the following items: Play, Play Speed, Select Music Instrument and Save.

#### **10.10 Mobile TV**

Your mobile phone is built in with the handheld video broadcasting receiver that may receive the telecast, then pull out the antenna at the tail of mobile phone to automatically search for the TV channels. With the function of watching TV programs, you can select and access the menu of Mobile Phone TV.

In Play interface, you can click the desired buttons and icons to adjust the volume, video measurement and shooting screenshot.

Press different OPTIONS to set the following items:

- Channel List: The optimal channel list already searched.
- Area Settings: Select the local area.
- Channel Search: Automatically search for TV channels.
- \* Notice that the video effect received by the mobile phone TV is subject to the coverage of local TV signals.

# 11 File Management

Access the File Management interface from the main menu to save and control various kinds of files and documents, including graphs, audio and video files, etc. This mobile phone provides 761K of memory space; also you can use the memory card to extend the capacity. When you access the File Management menu, all and remaining available memory space will appear on the right upper corner of screen. Touch the OPTIONS on the mobile phone or memory card with the touch pen upon inserting the memory card to display all folders and select the following items:

- Open: Open an appointed file folder.
- Create a new Fold: Create a new file folder.
- **Format**: Format the files.

**Note:** By selecting FORMAT, you will lose all data saved in the file system.

Touch the file folders with the touch pen to check the different file foldes; touch the OPTIONs for the following operations:

• Open: Open this file folder and check the contents.

- Create a new Fold: Create a new file folder.
- **Rename:** Change this folder name.
- **Delete**: Delete this file folder.
- Sort: Select the folder sort means as by names, by types, by time or sizes, or None (not sorting). Note: Some file folders in this menu are hidden in default status and so when the user save the files in relative formats in the rooth directory of mobile phone, the system will automatically display them, then the user can move these files to the corresponding file folders.

# 12 Entertainment and Games

#### **12.1 Games**

This mobile phone only provides one game; please refer to the User Instructions for the details operations.

#### Continue

In this OPTION, you can select to continue with the game interrupted last time and not re-start. During games, you can press the right function key to exit from the OPTION list and then CONTINUE option will appear at this time.

# New Game

Restart the game.

#### Game Mode

With this function, you can set the difficulty level of game and this function is only available for Mah-jong game.

#### Top Ranking

With this function, you can check various levels of highest score records of this game.

# • Game Help

With this function, you can see the simple game rules before starting the game. Press the left function key to check game rules.

#### • 12.2

- **Background sound effect**: Turn on or off the background sound effect.
- **Sound effect:** Turn on or off the sound effect of game
- ► **Game vibration**: Turn on or off the game vibration.

# 13 Echo Mode

Access the Echo Mode interface from the main menu.

The user can select different echo modes, and at the same time, the user can self define a few of echo modes. This phone can provides six types of echo modes, including generally mode, meeting mode, outdoor mode, indoor mode, earphone mode and Bluetooth mode.

#### 13.1 General Mode

You can select to activate or make Personal Settings in this menu.

- Activate: Active the general mode.
- **Personal Settings**: Access this mode for self-definition items, including ring tone settings, volume, ring pattern, ring type, incoming numbers pronounced orally, warning tone, answer mode.
  - ➤ Ring tone settings: Change the ring tones for the incoming calls of SIM Card 1 /SIM Card 2, startup, shut-off, message and keypad tones of SIM Card 1 /SIM Card 2. You can select the pre-set ring tones or select the recorded or downloaded ring tones.
  - **Volume:** Adjust the volume of ring tone and keypad tone, with Levels 1-7 for options.
  - ➤ **Ring pattern:** Select one ring pattern as ring tone, vibration, vibration and ring tone or ring tone after vibration.
  - **Ring type:** Select the ring type as one sound, continuous sound or increasing ring.
  - Warning tone: Set the warning tone of several events as warning tone, error, network connection or call connection.
  - Answer mode: Set the answer mode as answer by arbitrary key except for Dial and Power keys, also you can set the answer mode as answer mode in earphone mode.

#### 13.2 Meeting Mode

The operations are same with those of general mode.

#### 13.3 Outdoor Mode

The operations are same with those of general mode.

# 13.4 Indoor Mode

The operations are same with those of general mode.

# 13.5 Earphone Mode

It will automatically access the earphone mode when the earphone is inserted. This mode is not furnished with startup options. The personal setting operations are same with those of general mode.

#### 13.6 Bluetooth Mode

It will automatically access the Bluetooth mode when the Bluetooth is turned on. The personal setting operations are same with those of general mode.

 $\triangle$ Note: Press # key in standby status to turn on or off the mute mode.

# 14 Tool Kit

Access the Tool Kit interface from the main menu.

#### 14.1 Calendar

With this function, the user can check and edit the events at the appointed data. Select the CALENDAR menu and press the optional function key for the following functions:

- **Time table**: You can check or edit the schedule of current day; please refer to the "To-do" Section for detailed operations.
- New To-do: Add new schedules.
- Skip to the appointed date: Skip to the appointed date to check or edit the schedule of current day.
- Inspect by week/ by month: Inspect by week/ by month.
- Lunar calendar: Turn on or off the lunar calendar settings and set whether or not to display the lunar calendar upon setting the calendar inquiry.

#### 14.2 To-Do

You can check all stored missions. To-Do menu contains the memorandum of missions from the beginning to the updated items. You can make the following operations for the existing To-Do items:

- **View**: View the details of selected mission.
- Add: Add a new mission.
- **Edit**: Edit the selected mission.
- **Delete:** Delete the selected mission.
- **Delete All:** Delete all missions listed for the selected date.
- Send time schedule: Send the memorandum by SMS, MMS or Bluetooth or save it into the file folder.

# 14.3 Alarm Clock

Five alarm clocks are provided for the user and the user can set them as per their own demands. The alarm clock icon will not be displayed if the alarm clock is not turned on.

- Select to turn On/Off it.
- Set the time to trigger the alarm clock.
- Select the desired alarm clock cycles as once, every day, self-defined time as one day or several days in a
  week by pressing the direction keys to select and completing the selection after having activated the
  functional menu.
- Select the snooze time: The default time is 1 to 10 minutes.
- Optional ring patterns include ring tone, vibration and ring tone & vibration.
- Press the right function key to complete the operations.

Note: When you select SNOOZE or do not operate during an alarm clock rings to stop it, the alarm clock will consider that the user has not heard the ring tone in a default state; it will ring again 4 minutes later as the default, the user can set and change this default value; When you still select SNOOZE or do not operate, the alarm clock will ring again for every 4 minutes to warn the user. It will ring for three times and then automatically turn off when you still select SNOOZE or do not operate.

# 14.4 Universal Time

You can use the left and right navigation keys or touch the left and right keys on the top of screen with the touch pen to select the city map or browse the city maps in all time zones on the world map and at the same time, the date and time of selected city will appear on the top of screen, the city, date and time will appear at the bottom of screen.

# 15 Network Service

Access the Network Service interface from the main menu.

#### 15.1 STK Service

This function shall be provided by your network operator. If the SIM Card and network operator don't provide this service, you cannot use this function. Please get contact with your network operator for more information.

**Note:** The different SIM Cards will display the different contents.

#### 15.2 WAP

- Home page: Access this menu to directly link to the web-site default in the mobile phone, and obtain the information about recreation, movie, fashion, making friends and games, etc.
- Bookmark: You can select to enter into the pre-set WAP web-site in this phone.
- History web-site records: The web-sites recently logged in from the mobile phone will be saved into this menu, you can directly select and access the record.
- Stored web-sites: Store the web-sites edited before hand.
- Please input address: Edit the web-site you want to log in.
- Service In-Box: The cell phone can receive the network service message.
- Set: Set the network by options shown as below: Select SIM Card, Edit Setting Files, Browse Options, Service Message Settings, Clear Cache and Clear the Personal Information, etc..

# 15.3 Data Account

Check the information about the account and the manufacturer has made the relative settings before delivery.

# 16 Additional Functions

Access the Additional Functions interface from the main menu.

#### 16.1 Calculator

This cell phone provides the calculator for the user, with plus, minus, multiply and divide operations. The steps of using the calculator are shown as below:

- Input the first number: Input the first number to be calculated when 0 appears on the screen and press # key to input the decimal point.
- Input the operational symbol: Use the touch pen or press the direction keys to select such operational symbols as +, -,  $\times$  and  $\div$  on the screen.
- Input the second number.
- Result: Press ENTER key or touch = symbol with the touch pen to show the result on the screen.
- Continue to calculate: To calculate with the existing result, still use the touch pen to key in the operational symbol and the second number to calculate.
- Clear: Press the right function key to clear numbers as per the existing input status. The screen will be
  cleared to 0 when result is calculated. It only clears the current operated numbers or operational symbol if
  you are inputting the number to be operated.
- Exit from calculator function: Press RETURN functional key to exit and when there is no RETURN soft key on the screen, just press CLEAR functional key to exit step by step.

# 16.2 Conversion of Exchange Rate

You can convert the exchange rates with this function. Input the exchange rate and touch ENTER key with the touch pen, and then input the currencies and numbers to be conversed and finally touch ENTER key with the touch pen to get the value conversed between the local and foreign currencies.

#### 16.3 Stopwatch

# 16.3.1 General Stopwatch

This menu provides two timing functions of timing separately and timing by cycles.

- **Timing separately**: It can time separately and every record can only record 20 timing durations at the maximum.
- **Timing by cycles**: It can record the timing record every cycle and every record can only record 20 cycles at the maximum.
- **View the record**: Access to view the timing record and it will be blank if there is no record here.

#### 16.3.2 Island Stopwatch

You can use 4 directional keys to measure the time at every direction. Press one navigation key and the island stopwatch starts to time, and the stopwatch in other directions will suspend timing. To clear the island stopwatch to zero, first press STOP key and press CONTINUE for a long time, the island stopwatch will be cleared to zero.

#### 16.4 E-Book

Touch the E-BOOK menu with the touch pen to operate the E-book as below:

- Open the E-book: Open and read the E-BOOK.
- **Update**: Update and arrange the E-BOOKS in the folder.
- **System Default Settings**: Set the E-BOOK options, including text style, font, size, page curl, auto page curl, page curl speed, full screen, coding method and storage position.
- **Information**: Check the title, size and file format of current E-BOOK.

- **Delete:** Delete the current E-BOOK.
- **Delete All:** Delete all E-BOOKS in this folder.
- For: Sort the E-BOOK by name, by type, by time, by size and None.
- **Execute the system default settings:** Put all settings of E-BOOK to the system default settings.
- **Help**: Help you how to use some shortcut operations.

#### 16.5 Bluetooth

This mobile phone supports Version 2.0 Bluetooth specifications and applies the Bluetooth antenna technique; the mobile phone can be connected to the compatible Bluetooth device by the wireless antenna within 10 meters, approximately 33 feet. As the device supporting wireless Bluetooth technique communicates with radio wave, so your mobile phone may not be aimed rightly at other Bluetooth device. However, wireless Bluetooth connection may be disturbed by such barriers like walls or other electronic device.

Access this menu to set the Bluetooth as below:

- Activate the Bluetooth: You can turn on or off it
- Search for the handheld device: First activate the Bluetooth before accessing this menu and at the same time, activate the Bluetooth earphone (please refer to the Instructions of Bluetooth Earphone for detailed operations). Access this menu to search for the handheld device and after it has searched the Bluetooth device, it will prompt to input the password for matching; just input the Bluetooth earphone password and after matching successfully, you can use the Bluetooth device for calls and MP3 functions, etc.

Note: Different manufacturers will set the different passwords; so please refer to the Instructions of Bluetooth Device.

- My Device: The handheld device name will be displayed when the Bluetooth is matched successfully and is being connected.
- Connected Device: The name of connected handheld device will be displayed.
- Set: In this menu, you can set the relative information of this cell phone as below:
  - This phone may be searched: You can turn on or off it
  - Name of this phone: You can change the name of this phone.
  - > Request for Certification: You can turn on or off it
  - > Set the sound path: You can select to leave on this mobile phone or switch to the handheld device.
  - File transfer setting: Access to set the shared directories and directory authority. In the directory authority setting, you can select the free access or read-only.
- My Bluetooth: Instructions of Bluetooth Device.

Note: MP3 may only be listened only when the Bluetooth earphone is a stereo one.

# 17 Mode Settings

You can set the normal modes and projection mode of mobile phone in this menu.

This mobile phone provides projection function. Select **Projection Mode** to open the Projection Module and the functions of this mobile phone will not be affected when it is used as a general projector. Press the Projection Shortcut for a long time to project the internal data and you can view the contents on the projection curtain, press the navigation keys and ENTER key to select and operate the corresponding menus. Please refer to the Instructions for the usage of all menus or select the Projection of Internal Data Source option in the Mode Setting menu in the main interface to switch to the projection mode. Press the navigation keys and ENTER key to select and operate the corresponding menus. Please refer to the Instructions for the usage of all menus. In the Projection Mode, press the Projection Shortcut Key shortly to switch to the high-brightness mode; vice versa, press the Projection key for a long time to exit from the high-brightness mode.

Note: Then LCD screen will dim and you cannot use the touch screen. **The mobile phone shell will get** warmer during projection.

# 18 USB Functions

The use of USB data line will turn on the charging feature of USB. In the operating system of Windows2000 /XP, you may not install the drivers to use USB data line; in the operating system of Windows98 /98SE, you can download the driver to install and use the USB device. USB provides 3 different functions:

- Compact Flash USB Drive: Connect the data line supplied together with the mobile phone onto the computer and if the mobile phone turns on, the mobile phone will pop out the USB setting interface with three options; please select the storage position; if mobile phone is still OFF, you need not to set and the computer will automatically find the storage space of mobile phone and display USB disc symbol in the computer and you can view and modify the disc contents on the computer.
- Web camera: Connect the data line supplied together with the mobile phone onto the computer, the mobile phone will pop out the USB setting interface with three options; please select the web camera. Then the CCD camera of mobile phone will serve as the computer CCD camera.

**Note:** This function is available only when the mobile phone is ON.

• Serial Interface: Connect the data line supplied together with the mobile phone onto the computer, the mobile phone will pop out the USB setting interface with three options; please select the Serial Interface. Install the software supplied with the cell phone as per the prompt appearing on the computer to dial up.

**Note:** This function shall be supported by network, please contact with the network operator where necessary.

# 19 Input Methods

#### 19.1 Overview

This mobile phone supports keypad input and touch handwriting input methods.

In the touch handwriting input mode, the mobile phone supports to input Chinese, English (upper and lower cases), numbers and symbols.

In the touch handwriting input mode, the user can input in two methods: one is to use the touch pen for handwriting input by the handwriting identification feature of the phone and the other is to click the analogue keypad at the bottom of Edit interface to input.

## 19.2 Instructions of Input Methods

# 19.2.1 Handwriting Input Method

The handwriting identifying input of this mobile phone is applied with the advanced character recognition technique that supports the handwriting functions including number, English and Chinese.

The user can click the Input Information alert bar on Edit interface as per its own desire to switch over the supported handwriting recognition types. For example, if the user wants to input English, he can switch the handwriting recognition type to English input mode.

After having selected the desired handwriting recognition type, the user can directly writing with the auxiliary pen in the handwriting area. A while after having completed the handwriting input, the screen will display the result of automatic selecting and identifying characters and display the alternative characters. If the characters desired by you are not displayed, please click and select the alternative ones to substitute. This cell phone supports the Chinese association function, so please directly click the associated characters and input it to the position where the cursor locates.

## 19.2.2 Intelligent Pinyin (Spelling) Input Method

In the state of Pinyin (Spelling) Input Method, the definitions of keypad are shown as below:

Keys	Corresponding Characters or Functions	Remarks
Numeric Key 2	abc	
Numeric Key 3	def	
Numeric Key 4	ghi	
Numeric Key 5	jkl	Spelling
Numeric Key 6	mno	characters
Numeric Key 7	pqrs	
Numeric Key 8	tuv	
Numeric Key 9	wxyz	
* Key	Press this key to call out the characters for input	
# Key	Switch the input methods	
UP navigation key	Page Up	
Down navigation key	Page Down	
Left navigation key	Scroll to the left	
Right navigation key	Scroll to the right	
left function key	Select the candidate character inputted	
right function key	Return or Clear	
Power key	Return to the Standby interface	
OK key	Select the candidate character inputted	

# • Input with the auxiliary pen:

- ➤ **Key in pinyin/ spelling characters**: Click the corresponding letters on the screen according to the pronunciation spelling of words to be inputted in order to input the desired spelling characters. During the input, the mobile phone will associate and display the possible Chinese characters in the candidate field according to the letters already inputted.
- > Select, determine and input the characters: Select the desired Chinese characters in the screen, and click to select them.
- Select the associated characters: Associated input may offer the associated phrase of last letter, you can click the screen to select the desired Chinese characters.

Press **I** to input spacebar.

Press **t** to exchange lines.

Press **t** to delete the letters or characters inputted.

Press **1** to open the analogue keypad interface.

Press to close the analogue keypad interface.

# Input with Keypad:

- **Key in pinyin/ spelling characters**: Directly press the numeric keys of 2-9 on the keypad and the screen will display the letter combination keyed in, just select the desired combination. For example, to input "新", just continuously press the numeric keys of 9, 4 and 6 where the pinyin/ spelling letters of this word "xin" are located, the corresponding letter combination will appear and just select "xin".
- Select, determine and input the characters: Press the Up and Down navigation keys to turn pages up and down and the **Left and Right navigation keys** to find the candidate Chinese characters and press **left function key** or **OK key** to select the desired Chinese characters.
- > Select the associated characters: Associated input may offer the associated phrase of last letter, you can use Up and Down navigation keys to turn pages up and down and the Left and Right navigation keys to find the candidate Chinese characters and press left function key or OK key to select the desired Chinese characters. Then just press \* key to call out the Chinese character for input.
- Edit the inputted words: Press the Left and Right navigation keys to move the cursor right and left, press the Up and Down navigation keys to move the cursor up and down, and press the right function key to delete the Chinese characters.
- > Switch the input methods: Press # key to switch over the current input method circularly and the corresponding icons will be displayed on the icon area on the screen.

#### 19.2.3 English Input Method

In the state of English Input Method, the definitions of keypad for English Input Method (including upper and lower case English input) are shown as below:

Keys	<b>Corresponding Characters or Functions</b>	Remarks
Numeric Key 0	0 and spacebar	
Numeric Key 1	Character	
Numeric Key 2	ABC2; abc2	
Numeric Key 3	DEF3; def3	
Numeric Key 4	GHI4; ghi4	
Numeric Key 5	JKL5; jkl5	
Numeric Key 6	MNO6; mno6	
Numeric Key 7	PQRS7; pqrs7	
Numeric Key 8	TUV8; tuv8	
Numeric Key 9	WXYZ9; wxyz9	
* Key	Press * key to call out the character input box	
# Key	Switch the input methods	

UP navigation key	Move up the cursor	
Down navigation key	Move down the cursor	
Left navigation key	Move the cursor to the left	
Right navigation key	Move the cursor to the right	
right function key	Return or Clear	
Power key	Return to the Standby interface	

# • Input with Auxiliary Pen

Input English letters: Click and press the corresponding letters on the screen to input letters according to the words you want to input.

Press the screen to move the cursor.

Press 
to input spacebar.

Press **t** to exchange lines.

Press **t** to delete the letters inputted.

Press **t** to open the analogue keypad interface.

Press to close the analogue keypad interface.

# Input with Keypad

General operations for English Input Method:

Every key is used to input a few of characters. Just press it repeatedly and rapidly till the desired character appears.

To input the English punctuation marks and some special symbols in English Input state (including upper and lower case English), just press \* key to call out the special symbol input box.

Press # key to switch the input methods.

Press Numeric Key 0 to input a spacebar in Upper or Lower Case state.

Press the right function key to clear the input errors and press the right soft key for a long time to clear all items inputted currently.

#### 19.2.4 Digital Input Method

The definitions of keypad for digital input method are shown as below:

Definitions of Keypad for Digital Input Method

Keys	Corresponding Characters or
	Functions
Numeric Key 1	1
Numeric Key 2	2
Numeric Key 3	3
Numeric Key 4	4
Numeric Key 5	5
Numeric Key 6	6
Numeric Key 7	7
Numeric Key 8	8
Numeric Key 9	9
Numeric Key 0	0
# Key	Switch the input methods
UP navigation key	Move up the cursor
Down navigation key	Move down the cursor
Left navigation key	Move the cursor to the left
Right navigation key	Move the cursor to the right

left function key	OPTION
right function key	Return or Clear
Power key	Return to the Standby interface

# • Input with Auxiliary Pen

Press the numbers on screen to input the corresponding numbers.

Press 
to input spacebar.

Press **t** to exchange lines.

Press **t** to delete the letters inputted.

Press **t** to open the analogue keypad interface.

Press to close the analogue keypad interface.

# • Input with Keypad

General operations for Digital Input Method:

Press Numeric Keys 0-9 to input the corresponding numbers.

Press # key to switch the input methods.

Press the right function key to clear the input errors and press the right soft key for a long time to clear all items inputted currently.

# 19.2.5 Stroke Input Method

The definitions of keypad for stroke input method are shown as below:

Numeric Keys	Strokes of Source Letter	Basic Strokes	Name	Words for Example
	-	_	Horizontal stroke	王 十 在
1		1	Rising stroke	次红刁
2	I	1	Vertical stroke	中 业
2		J	Vertical hook stroke	小水打
3	)	)	Left falling stroke	八你所
4	`	`	Dot	六 学 州
4		/	Right falling stroke	人八火
	٦	$\neg$	Horizontal hook stroke	写 字 皮
		٦	Horizontal turning stroke	口已户
		刁	Horizontal Turning Hook Stroke	包 力 羽
		フ	Horizontal Left-falling stroke	又之社
5		3	Horizontal Turning Turning	及 廷
3			left-falling Stroke	
		3	Horizontal Left-falling Curved Hook	队 那 部
			Stroke	
		3	Horizontal plus twice hold and hook	乃 奶 扬
			Stroke	
6	)	)	Curved hook stroke	家 狗 豹
7	L	上	Vertical Turning stroke	山巨屯
		2	Left-falling Turning Stroke	去 约 能
		<	Left-falling Dot Stroke	女 巡 巢
		l	Vertical Rising Stroke	衣 以 饭
		l	Slanting Hook Stroke	我 或 民
		)	Lying Hook Stroke	心必
		L	Vertical Curved Stoke	四 西

		L	Vertical Curved Hook Stroke	已也毛
		4	Vertical Turning Left-falling Stroke	专
		4	Vertical Turning Turning Hook	马与张
			Stroke	
		5	Vertical Turning Turning Stroke	鼎
8	?	(Intelligence Keys)		
		つ	Horizontal Turning Curved Hook	飞九风
	_	乙	Horizontal Turning Curved Hook Stroke	飞九风
9	٦.	7		飞九风投船凹

#### General operation orders of stroke input method:

- **Key in strokes**: Press the corresponding numeric keys as per the standard strokes of Chinese characters to input the strokes and the mobile phone will display the candidate Chinese characters corresponding to the strokes inputted; with the stroke input method, you can input the indexing component of Chinese characters; press the **left function key** to select the indexing component; and press the **right function key** to delete the last stroke.
- Select, determine and input the characters: Press the Up and Down navigation keys to turn pages up and down and the Left and Right navigation keys to scroll the cursor right and left to find the candidate Chinese characters and press left function key to select the desired Chinese characters.
- Select the associated characters: Press the Up and Down navigation keys to turn pages up and down and
  the Left and Right navigation keys to scroll the cursor right and left and press left function key to select
  the desired Chinese characters.
- Edit the inputted words: Press the Left and Right navigation keys to move the cursor right and left, press the Up and Down navigation keys to move the cursor up and down, and press the right function key to delete the Chinese characters.

# 20 Appendix

## 20.1 Security of Battery

- Please only use the battery specified by your mobile phone manufacturer. The use of any other accessories may nullify all warranty service clauses. Your mobile phone manufacturer will bear no liability for the damages caused by your use of accessories not produced by the mobile phone manufacturer.
- The new battery will only come to the optimal performances after having been completely charged and discharged for twice and thrice.
- The battery may be charged and discharged for hundreds of times, but will nullify finally. For this account,
  please purchase and replace with new battery when finding the call time and standby time of battery are
  curtailed obviously.
- Please disconnect the power supply of charger when it is not used and never connect the battery to the charger for over one week as charging in excess may abridge the service life of battery.
- Never cause the short circuit of battery contacts with the metal objects like the keys in pocket, etc..
- Never bend or open the battery forcibly.
- Never dip the battery in water or put it to fire.
- Charge the battery in the temperature closer to room temperature. And it's impossible to charge battery when the temperature is below 0 centigrade or above 45 centigrade.

# **20.2** Usage and Maintenance

This mobile phone is a hi-end product, so please use it carefully. Please refer to the following proposals to use and maintain this mobile phone in a better way.

- Put the parts of mobile phone in places out of the reach of children.
- Keep the mobile phone dry as rain water, moisture and all kinds of liquids or moisture may contain the minerals that may erode the electric circuit.
- Never put or use the mobile phone in dusty and dirty places.
- Never put the mobile phone in hi-temperature places as high temperature may curtail the service lives of electronic device and damage the battery, or distort or melt some plastic parts.
- Never put the mobile phone in low temperature places and it may produce moisture inside the phone when
  the mobile phone is moved from low temperature place to high temperature place, it may damage the
  circuit board.
- Never try to dismantle the mobile phone as improper handling of non-professionals may destroy the device.
- Never throw, knock on or jolt the mobile phone, the gruff usage may damage the internal main board.
- Never clean the mobile phone with irritant chemicals, detergent or corrosive detergent. Please wipe and clean the mobile phone slightly with the soft cloth dipped in the moderate suds.
- Never paint the mobile phone as it may affect the moving parts of phone and affect the normal operation of it.
- Only use the qualified replaceable antenna provided together with the mobile phone and the use of unrecognized antenna or other parts may destroy the mobile phone.
- If the mobile phone is wetted by carelessness, please power it off and take out the battery, wait for the mobile phone to dry within 24 hours and re-use it.
- During the use of this mobile phone, please apply the energy-saving means by tune down the volume and curtailing the background lamp service time on the screen, etc. and it's helpful to prolong the standby time of mobile phone.
- Never contact the metal objects, except for the particularly configured charger interface and data line interface, with the mobile phone charger interface to avoid short circuit.

# 20.3 Troubleshooting

In case of any anomaly during the operation of mobile phone, please refer to the following table to solve the failures. If the failures cannot solved, please get contact with the dealer or service provider.

FAQ	Causes	Solutions	
It cannot connect to Internet when using the wireless	The network service provider does not provide the service or you have not applied for the service	Please contact with your network service provider to ask how to apply and use the service	
Internet service	You have not set it correctly	Please refer to the introduction of wireless Internet service	
	SIM Card is damaged	Contact with your network service provider	
SIM Card fault	SIM Card is not loaded correctly	Examine the SIM Card	
	SIM Card metal surface is dirty	Wipe with clean cloth	
Poor reception	Radio wave cannot be effectively transmitted when the mobile phone is used in the place with poor receiving effect, like high-rise or basement	Make or answer calls in place with sound signals	
	Use the mobile phone during the call intensive period with busy services	Never use the mobile phone during busy hours	
Startup failure	Battery power runs out	Replace with new battery	
Failure to make calls	Call barring feature is enabled	Cancel the call barring feature	
	SIM Card is null and void	Contact with your network service provider	
Failure to connect to Internet	Out of the GSM service zone	Move to the service zone of network service provider	
	Signals are weak	Try in the place with stronger signals	
	Inconformity of voltage and the nominal charger voltage	Please apply the voltage in compliance with the nominal charger voltage	
Failure to charge	Non-standard charger is used	Please use the charger specially designed for this mobile phone	
	Poor contact	Examine if the plug is connected well	

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help.