AV8OR ACE Basic Operation



- 1. SD CARD Slot Make sure the correct SD card is inserted into the SD CARD Slot.
- 2. **VOLUME** Rotate the **VOLUME** knob counter-clockwise to increase the volume and clockwise to decrease the volume.
- 3. **POWER** To turn power on, hold the **POWER** button down until the startup screen shows. To turn power off, hold the **POWER** button down until the **POWER OFF** screen shows.
- 4. **RESET** Push the **RESET** button on the back of the case to reboot the system.
- 5. **ZOOM IN/ZOOM OUT** Press the "+" or "-" side of the **ZOOM IN/ZOOM OUT** button to enlarge or decrease the current view on the screen.
- 6. **DIRECT TO** Press the **DIRECT TO** button to create a course to the selected destination.
- 7. **VIEWS** Press the **VIEWS** button to change the screen to predefined views or pages.
- 8. **MENU** Press the **MENU** button from any page to return to the Main Menu page.

From the MAIN MENU page:

• Tap the GO fly soft key for Aviation Mode.



Tap the GO drive soft key for Automotive Mode.



• Tap the **Multimedia** soft key to listen to music, view a movie, look at photos or view an E-Book.



• Tap on the **Settings** soft key to view the **GPS Status**, adjust the **Backlight**, adjust the **Volume**, view the **System Info**, adjust the **Bluetooth** settings or to go into **Initial Setup** mode. Refer to the AV8OR ACE User's Guide to configure the initial setup options.

