




# User Guide (Carrier)

**AurusLink+ Outdoor CPE**

**Release 16 Self Install**

**Model CFW-3211/3212**



## Important notice

This device, like any wireless device, operates using radio signals which cannot guarantee the transmission and reception of data in all conditions. While the delay or loss of signal is rare, you should not rely solely on any wireless device for emergency communications or otherwise use the device in situations where the interruption of data connectivity could lead to death, personal injury, property damage, data loss, or other loss. Casa Systems accepts no responsibility for any loss or damage resulting from errors or delays in transmission or reception, or the failure of the Casa Systems AurusLINK+ 5G Outdoor CPE to transmit or receive such data.

## Safety and hazards



### Warning –

Do not connect or disconnect cables or devices to or from the USB port, SIM card tray, or Ethernet port in hazardous locations such as those in which flammable gases or vapours may be present, but normally are confined within closed systems; are prevented from accumulating by adequate ventilation; or the location is adjacent to a location from which ignitable concentrations might occasionally be communicated.

## Copyright

Copyright© 2022 Casa Systems. All rights reserved.

The information contained herein is proprietary to Casa Systems. No part of this document may be translated, transcribed, reproduced, in any form, or by any means without prior written consent of Casa Systems.

Trademarks and registered trademarks are the property of Casa Systems or their respective owners. Specifications are subject to change without notice. Images shown may vary slightly from the actual product.



### Note –

This document is subject to change without notice.

## Document history

This document applies to the following CPE model:

### AurusLink+ Outdoor CPE – CFW-3211/3212

Ver.	Document description	Date
v1.00	Initial document release	23 December, 2022

*Table i. – Document revision history*

# Contents

1	Document overview .....	6
1.1	Introduction .....	6
1.1.1	Organisation of this Document.....	6
	Section 1 – Device description and general overview of end-user installation .....	6
	Section 2 – Device configuration details .....	6
1.2	Target audience .....	6
1.2.1	Notation.....	7
2	Product introduction.....	8
2.1	Product overview.....	8
2.2	Package contents.....	8
2.2.1	Other tools required.....	8
3	Physical dimensions and interfaces.....	9
3.1	Physical dimensions.....	9
3.1.1	CFW-3211/3212.....	9
3.2	Interface .....	10
3.2.1	CFW-3211/3212.....	10
3.2.2	PoE injector.....	12
3.3	LED indicator lights .....	13
3.3.1	CFW-3211/3212.....	13
3.3.2	LED Auto-dim functionality .....	14
3.4	Mounting bracket .....	15
3.4.1	Mounting bracket assembly instructions .....	15
3.4.2	Overview of completed mounting.....	16
4	Aurora Smartphone installation APP overview .....	17
4.1	Download App.....	17
4.1.1	Scan QR code .....	17
4.2	Prepare the device .....	18
4.2.1	Insert SIM card.....	18
4.2.2	Connect Ethernet cable and bottom panel to device.....	19
4.2.3	Connect Ethernet cable to PoE injector .....	19
4.2.4	Power on your device.....	20
4.2.5	Connect device to Smartphone app.....	20

4.3	App Installation .....	21
4.3.1	Site survey.....	21
4.3.2	Perform signal reception Tests.....	21
4.3.3	Save good or excellent locations.....	22
4.3.4	Identify each possible location.....	22
4.3.5	Install at best location .....	23
4.3.6	Perform connection check.....	23
4.3.7	Success – enjoy internet access .....	23
5	Advanced set up of the AurusLINK+.....	24
5.1	Log in as Administrator via Web UI .....	24
5.2	Confirming a successful connection .....	25
6	User interface .....	26
6.1	Status.....	26
6.1.1	System information.....	27
6.1.2	Cellular connection status.....	28
6.1.3	WWAN connection status.....	29
6.1.4	Advanced status .....	30
6.1.5	Neighbouring cell information .....	33
6.1.6	LAN .....	33
6.1.7	Bluetooth.....	34
6.1.8	GPS .....	35
6.1.9	NIT.....	36
6.2	Networking.....	37
6.2.1	Wireless WAN .....	37
6.2.1.1	Wireless WAN profiles .....	37
6.2.1.2	Band selection .....	40
6.2.1.3	RAT selection .....	41
6.2.1.4	Operator settings .....	41
6.2.1.5	Roaming control.....	42
6.2.1.6	Cell lock .....	42
6.2.1.7	SIM security.....	44
6.2.2	LAN .....	45
6.2.2.1	LAN Configuration .....	45
6.2.2.2	DHCP configuration .....	46
6.2.2.3	VLAN .....	47
6.2.3	Firewall.....	49
6.2.3.1	NAT.....	49
6.2.3.2	MAC whitelist .....	51
6.2.4	Routing.....	52
6.2.4.1	Static Routing.....	52

6.2.5	Service assurance .....	54
6.2.5.1	Result.....	54
6.3	Services.....	55
6.3.1	Network Time (NTP).....	55
6.3.2	Aurora App (Bluetooth) Server.....	56
6.3.3	TR-069.....	56
6.3.3.1	TR-069 configuration .....	57
6.3.4	DNS Server.....	58
6.3.5	Geofence.....	59
6.3.5.1	Add Geofence.....	61
6.4	System.....	62
6.4.1	Log – System log.....	62
6.4.1.1	Log – System log settings .....	62
6.4.1.2	QXDM over Ethernet.....	64
6.4.2	Ping diagnostics.....	65
6.4.3	System configuration.....	66
6.4.3.1	Restore factory defaults.....	66
6.4.3.2	Web server settings .....	68
6.4.3.3	Administrator credentials.....	69
6.4.3.4	Web UI credentials.....	70
6.4.3.5	Settings backup/restore.....	71
6.4.3.6	Runtime Configuration.....	72
6.4.4	Firmware upgrade.....	73
6.4.5	Access control.....	74
6.4.6	Reboot .....	75
6.4.7	Field test .....	76
6.4.8	Encrypted Debug Information.....	78
6.4.8.1	Generate.....	78
6.4.8.2	Download .....	78
Appendix A – Safety and compliance.....		79
RF Exposure.....		79
FCC Statement .....		79
Operating temperature.....		80
Company details .....		80
Product details .....		80
Appendix B – Configuring Radio Access Technologies.....		81

# 1 Document overview

## 1.1 Introduction

This document provides all the information needed to set up, configure and deploy the CFW-3211/3212 Outdoor CPE antenna.

### 1.1.1 Organisation of this Document

This Carrier User Guide is designed for use by a carrier's technical support personnel, it includes two sections:

#### **Section 1 – Device description and general overview of end-user installation**

This section is designed to give end-users all the information they need to understand their new device and install it using the recommended Smartphone application method.

A separate *User Guide* for end-users is planned to be produced containing only this first section.

#### **Section 2 – Device configuration details**

The second section is designed to give technical personnel of the ISP in depth descriptions of all advanced settings available in the CPE.

This allows each ISP to preconfigure their devices to their individual requirements or alternatively allows them to reconfigure units remotely.

The contents of this *User Guide* contains both sections and is meant for use by ISP technicians.

## 1.2 Target audience

This document is intended for experienced hardware installers who understand telecommunications terminology and concepts.

Specifically it is for carrier technicians who will pre-configure the Outdoor CPE devices prior to distribution to end users. Also included are the installation instructions which the end user will use to install the device on their own premises.



**Note –**

It is assumed by Casa Systems that end users will not be expected to log in to WebUI at any time, nor will they be provided any of the username / password credentials.

## 1.2.1 Notation

The following symbols may be used in this document:



**Note** – This note contains useful information.



**Important** – This is important information that may require your attention.



**Warning** – This is a warning that may require immediate action in order to avoid damage or injury.

## 2 Product introduction

### 2.1 Product overview

The AurusLINK+ Outdoor CPE is a self-Install, Release 16 CPE device that allows easy connection to mobile networks providing access to broadband Internet. The unit itself is specified as an outdoor product in terms of IP rating, environmental, etc.

The AurusLink+ Outdoor CPE is designed to be affixed by adhesive tape on the exterior of a window. If windows cannot be opened, for example in a high rise building, the CPE can be affixed to the inside of the window.

### 2.2 Package contents

The in-box contents include:



Figure 1 – Package contents [images not to scale]

If any of these items are missing or damaged, please contact your sales representative immediately.

#### 2.2.1 Other tools required

- 1 x Smartphone with the Aurora Installation application installed used during installation.

## 3 Physical dimensions and interfaces

### 3.1 Physical dimensions

#### 3.1.1 CFW-3211/3212

Below are details of the layout and physical dimensions of the CFW-3211/3212.




Figure 2 – CFW-2211/3212 Outdoor CPE dimensions

CFW-3211/3212 Dimensions

<b>Height</b>	138.4mm (5.44 in)
<b>Width (excluding mount)</b>	85mm (3.34 in)
<b>Depth (excluding mount)</b>	25mm (.98 in)
<b>Weight (excluding mount)</b>	~240gr (~ 8.5oz)

Table 1 - CFW-3211/3212 device dimensions

## 3.2 Interface

### 3.2.1 CFW-3211/3212




Figure 3 – Interfaces – CFW-3211/3212

Item	Description
<b>Bottom of the CPE</b>	
Antenna panel	Includes an integrated 4x4 MIMO Low-Gain OMNI Directional Antenna
Reset button	<p>Push a thin wire such as a paperclip into this small opening to reset the device. This button provides two options:</p> <ul style="list-style-type: none"> <li>Press and hold for <b>less than 5 seconds</b> to reboot to <b>Normal</b> mode. This will restart the unit with the same configuration settings</li> <li>Press and hold for <b>5 to 15 seconds</b> to reset the router to its <b>Installer</b> level settings. This will restart the unit with the same settings present at installation time.</li> </ul>

Item	Description
	<p><b>Other Reset Options</b></p> <p>This <b>Installer Reset</b> is the safest reset option and should be the first one attempted when troubleshooting a problem.</p> <p>In addition to <b>Installer Reset</b> two other types of reset are available through the User Interface: <b>Carrier Reset</b> and <b>Full Factory Reset</b></p> <p>For more information on the differences between these three options, go to section <b>6.4.3.1 Restore factory defaults</b> of this guide.</p>
<b>SIM slot</b>	Insert the Nano SIM 4FF here, if the correct side is up it will clip into place. If it does not clip into place, remove the SIM and turn it or flip it and try again.
<b>Ethernet Port</b>	Connect the Ethernet connector which passes through the bottom panel into the Ethernet port. The Ethernet provides power and data connectivity to the Power over the Ethernet (PoE) device inside the premises.
<b>Screw holes (2)</b>	Threaded screw holes for the two Hex-screw fasteners on the bottom panel
<b>Bottom Panel</b>	
<b>Bottom cover panel</b>	The bottom cover panel has the Ethernet cable passing through it. Once the Ethernet cable is plugged into the Ethernet port the bottom panel will fit into the recess on the bottom of the antenna box
<b>Hex-screw fasteners</b>	Use the supplied hex wrench to tighten the bottom panel onto the bottom of the antenna box

Table 2 – Interfaces – CFW-3211/3212

### 3.2.2 PoE injector



Figure 4 - CFW-3211/3212 PoE injector dimensions

CFW-3211/3212 Dimensions

Length	~68mm (.98 in)
Width	~39mm (3.34 in)
Height	~25mm (~ .98in)
Weight	~35gr (~1.25oz)

Table 3 - CFW-3211/3212 PoE injector dimensions

## 3.3 LED indicator lights

### 3.3.1 CFW-3211/3212

Below are details of the colour, actions and meaning of the three LED lights on the side of the CFW-3211/3212.



Figure 5 – CFW-2211/3212 LED indicator lights



Figure 6 – LED cut out on side of mounting bracket

Icon	LED Color	Action	Indicated status
	Blue	Solid	Connected to WWAN
	Red	Solid	SIM PIN/PUK locked / Other connectivity issues related to WWAN (e.g. wrong APN, etc.)
	Blue	Flashing	Device booting
	Blue	Solid	Signal strength is good/excellent -105dBm = < RSRP and 10 = < SINR (values could be re-defined by one RD8 for "good RSRP threshold" and one RDB for "good SINR threshold")
	Green	Solid	Signal strength is fair -105dBm > RSRP and 10 > SINR (values could be re-defined by above RD8s)
	None	Off	No service, limited service

Icon	LED Color	Action	Indicated status
	Green	Flashing	Device starting up
	Green	Solid	Ethernet to RG established
	None	Off	Ethernet to RG not established

Table 4 - CFW-3211/3212 LED display

### 3.3.2 LED Auto-dim functionality

The AurusLINK+ LEDs are programmed by default to switch themselves off 30 minutes after power up to reduce unwanted inside and outside glare of the LEDs through the Window. The user has the option to override this feature during installation via the Aurora Installation APP.

When the Auto LED off feature is enabled, the LEDs will only come back on either:

- when an Error situation (indicated by a RED LED) occurs, or
- when the device is rebooted via the power switch.

If the LEDs come back on, then once all red LEDs disappear the timer for the "Auto LED Off" feature shall be started again.

The carrier has the option to change the timer value from 30 minutes in the factory.

## 3.4 Mounting bracket

The AurusLINK+ 5G Outdoor CPE antenna uses a plastic mounting bracket that is stuck with strips of special adhesive tape which will stick to the window but is not sticky to touch.

The mounting bracket can be fixed to either the outside (preferred option) or inside of an external window and may be moved multiple times provided that each window location was thoroughly cleaned with the supplied alcohol wipes prior to fixture.



*Empty bracket with LED cutout  
and up arrow*

*CPE being snapped into bracket*

*CPE and Bracket with adhesive strips*

*Figure 7 – Plastic Mounting bracket*



**Note** – Other types of mounting brackets(wall/pole/rail) are available, contact Casa Systems sales or product support if required.

### 3.4.1 Mounting bracket assembly instructions



**Important** – Prior to mounting, you should identify the best location using the Aurora AP, and refer to section 4 of this User Guide.

- 1 Note the direction of the arrow on the inside of the mounting bracket.
- 2 Snap the CPE onto the mounting bracket with the top of the casing oriented to the top of the bracket as indicated by its up arrow.

The LED lights should be visible through the LED cut out on the side of the mounting bracket.

- 3 Clean the window where you intend to mount the bracket with the supplied alcohol wipes.
- 4 Peel off the paper covers on the three adhesive strips on the back of the mounting bracket.
- 5 Firmly press the mounting bracket and antenna against the glass so that the adhesive sticks.

### 3.4.2 Overview of completed mounting




Figure 8 - CFW-3211/3212 with mounting bracket attached to window

## 4 Aurora Smartphone installation APP overview

The Android and IOS Smartphone application (freely available on appropriate APP stores) is designed to aid the consumer through the installation process.

The Smartphone application provides all the guidance required by the end consumer to set up and start the antenna: from unboxing, through site survey measurements around the home, and then final installation,

Utilising easy to understand terminology and graphics, combined with non technical language and performance indicators, the application is suitable for non technical end-consumers.



**Note** – If you do not have a Smartphone, the installation is possible utilising the LED lights on the side of the device. Contact the Customer Service department of your service provider for more information.;

### 4.1 Download App

Open a fully charged Android or IOS Smartphone.

#### 4.1.1 Scan QR code

The QR code is located on the side of the box that the CPE came in:



Figure 9 – QR codes on the side of the packing box

Scan the QR code that corresponds to your type of Smartphone.



**Note** – If the QR codes are not present on the box, then the instruction and QR code can be found on the welcome card inside the box

Follow the instructions on your Smartphone to download and install the app.

If you cannot download the application using the QR code, you can go to either the



**Note** –

- App store (for iPhones), or
- Goggle Play (for Android phones),

search Aurora Installation Application and download and manually install it.

## 4.2 Prepare the device

### 4.2.1 Insert SIM card

There are two options for SIM card provision:

- For some carriers the SIM card will already be pre-inserted, and hence this step (4.2.1) and the next (4.2.2) will not be required.
- For carriers where the SIM card will not be pre-inserted steps 4.2.1 and 4.2.2 will be required.

To insert a SIM card.

- 1 If the bottom panel with ethernet cable is attached, using the supplied hex key to unscrew the two Hex screws on the bottom panel and lift off the panel to reveal the SIM card slot
- 2 While holding the SIM card relative to the front of the antenna casing, orient the SIM card so that the metallic circuits are facing upward and the clipped corner is in the top right.

Use *only* the Nano-SIM 4FF supplied by your provider.

 Note –



- 3 Push the SIM card into the slot as shown below.



**Nano SIM 4FF**  
Figure 10 – Placing the SIM card into the SIM card reader

The SIM card slot employs a 'Push Push' system to lock the card in place.

Push the SIM card in once and the spring locking mechanism will click to secure the SIM card in the slot.

When locked in place a small amount (~1mm) of the card will protrude off the face of the bottom panel.

4 To remove the SIM card, rapidly push the SIM card in twice and the spring will eject the card.

#### 4.2.2 Connect Ethernet cable and bottom panel to device

Connect the end of the Ethernet cable on the inside of the weatherproof joiner to the port on the bottom of the CPE.




Figure 11 – Fix waterproof panel to bottom of CPE diagram

Place the weather seal over the end of the device and use the Allen key tool to tighten the bolts.

#### 4.2.3 Connect Ethernet cable to PoE injector

Connect the other end of the 5m Ethernet cable to the side of the supplied Power supply marked "To 5G modem only".




Figure 12 – PoE connection diagram

#### 4.2.4 Power on your device

Connect the power supply to a power outlet.




Figure 13 – Power point close to window diagram

The power point must be within 5 meters of the window.

#### 4.2.5 Connect device to Smartphone app

If you do not already have the App on your Smartphone, install the App using the QR code printed on the CPE's label.

Open your smartphone and click the App icon.

The Smartphone App will guide you through how to connect to your CPE.

When the app has connected to the device, the app will indicate "Success".

## 4.3 App Installation

Follow the steps in the App on your Smartphone to complete the installation.

### 4.3.1 Site survey

Find the best location, the app includes Tips to find the best location"




Figure 14 – Plan the site survey

### 4.3.2 Perform signal reception Tests

For best signal testing, hold the device in the open window with logo facing outwards. Hold the device as high as possible.




Figure 15 – Signal testing

### 4.3.3 Save good or excellent locations

When you get a good or excellent for a location click the **Save location** button to add it to the app.




Figure 16 – Test signal strength

### 4.3.4 Identify each possible location

When saving good or excellent locations, add a meaningful name so that you can identify which window it relates to.




Figure 17 – Record acceptable locations

### 4.3.5 Install at best location




Figure 18 – Install the device on window

### 4.3.6 Perform connection check

Once installed, connect to router and perform a connection check following the instructions in the app.




Figure 19 – Perform connection check

### 4.3.7 Success – enjoy internet access

The AurusLINK+ is now installed. The APP can now be closed.

In the case of Red LEDs appearing in the future, the user should consult the APP for instructions.

## 5 Advanced set up of the AurusLINK+

The AurusLINK+ 5G Outdoor CPE series of antennas all use the same firmware.

The AurusLINK+ CFW-3211/3212 will be shipped pre-configured for the carrier.

For advanced configuration, log in to the web-based user interface of the AurusLINK+ as an administrator.

**Important** - It is NOT INTENDED for End Users (Consumers) to have access to the Web UI of this device. The configuration tools and settings contained in this section of this Carrier User Guide are only for the information of carrier technicians and should not be made available to the end user.

### 5.1 Log in as Administrator via Web UI

To log in to the web-based user interface:

- 1 Open a web browser (e.g. Chrome, Safari, etc.), type <http://192.168.1.1> into the address bar and press Enter.

**Important** - Some service providers/carriers have opted to use a different URL to access the Web UI. If you encounter difficulty logging in, consult the instructions provided by your service providers/carriers or contact your service provider/carrier's technical support.

- 2 The web-based user interface **Login** screen is displayed.




Figure 20 – Log in prompt for the web-based user interface

- 3 Enter the login **User Name** and **User Password**.

Administrator account	
User Name	admin
User Password	roofclimberabove

Table 5 - Management account login details – Administrator account

**Important** - Please note that manufacturer recommends that the User Password be changed by the mobile carrier at the time of factory production prior to shipping to the end user. If you do not know the new password, or if the default value "roofclimberabove" does not work on first time installation, please contact your local mobile carrier or Casa Systems representative.

## 5.2 Confirming a successful connection

To confirm the connection status, click the **Status** menu item at the top of the page to display the **Status** page. Select the **CELLULAR CONNECTION STATUS** and **WWAN CONNECTION STATUS** items to expand them.




Figure 21 - Main menu items

The details of the connection are displayed.

^ CELLULAR CONNECTION STATUS		
SIM status SIM OK	Operator selection Automatic	Allowed bands LTE Band 1,2,3,4,5,7,8,12,13,14,17,18,1 9,20,25,26,28,29,30,32,34,38, 39,40,41,42,43,46,48,66,71
Signal strength (dBm) -92 dBm (Low)	Provider Telstra	NR5G NSA Band 1,2,3,5,7,8,12,14,20,25,28,38, 40,41,48,66,71,77,78,79
Network registration status Registered, home network	Roaming status Not roaming	NR5G SA Band 1,2,3,5,7,8,12,14,20,25,28,38, 40,41,48,66,71,77,78,79
		Current band LTE Band 7 - 2600MHz
		Connection (RAT) NR5G
		Coverage NR5G
^ WWAN CONNECTION STATUS		
Profile name	WWAN IP 123.209.233.25	APN
Status up	DNS server 10.4.27.70	Connection uptime 20:52:05
IPv6 status down	10.4.149.70 WWAN IPv6	Max DL 10 Kbps
	IPv6 DNS server	Max UL 9 Kbps
		Current DL 0 Kbps
		Current UL 0 Kbps

Figure 22 - Cellular Connection Status and WWAN Connection Status

If the device is connected, the **Status** field displays "up".

## 6 User interface

The AurusLINK+ features a user interface with top and left-sided menus. The menu across the top of the screen is the highest-level menu.

There are four main menu items: **Status**, **Networking**, **Services** and **System**

The **Networking**, **Services** and **System** menus each feature a submenu on the left of the screen that allow you to navigate to different features within that area.

The **Status** screen is somewhat different in that it contains various windows which can be expanded to display information about the device.

### 6.1 Status

The **Status** page of the web interface provides system related information and is displayed when you log in to the AurusLINK+ management console.




Figure 23 - The Status menu page – first screen after log in

The status page has links to pages displaying

- SYSTEM INFORMATION
- CELLULAR CONNECTION STATUS
- WWAN CONNECTION STATUS
- ADVANCED STATUS
- NEIGHBOURING CELL INFORMATION
- LAN details
- BLUETOOTH MAC address details
- GPS connection details *see 6.1.8*
- NIT Smart Antenna Tool readings *see 6.1.9*

Toggle the display of the sections by clicking the or buttons to show or hide them.

## 6.1.1 System information




Figure 24 - System Information

System Information	
Device Version	
System up time	The current uptime of the AurusLINK+.
Device name	The manufacturer's name of this device.
Model	The manufacturer's model number.
Hardware version	The hardware version of the AurusLINK+.
Serial Number	The serial number of the AurusLINK+.
Firmware version	The firmware version of the AurusLINK+
Cellular module	
Model	The type of phone module
Module firmware	The firmware revision of the phone module.
IMEI	The International Mobile Station Equipment Identity number used to uniquely identify a mobile device.

Table 6 - System Information fields

## 6.1.2 Cellular connection status




Figure 25 - Cellular Connection Status

### Cellular Connection Status

<b>SIM status</b>	Displays the activation status of the AurusLINK+ on the carrier network.
<b>Signal strength (dBm)</b>	The current signal strength measured in dBm.
<b>Network registration status</b>	The status of the AurusLINK+'s registration for the current network.
<b>Operator selection</b>	The mode used to select an operator network.
<b>Provider</b>	The current operator network in use.
<b>Roaming status</b>	The roaming status of the AurusLINK+.
<b>Allowed bands</b>	The bands to which the AurusLINK+ may connect.
<b>Current band</b>	The current band being used by the AurusLINK+.
<b>Coverage</b>	The type of mobile coverage being received by the AurusLINK+.

Table 7 - Cellular Connection Status fields

### 6.1.3 WWAN connection status

WWAN CONNECTION STATUS		
Profile name	WWAN IP 123.209.233.25	APN
Status up	DNS server 10.4.27.70 10.4.149.70	Connection uptime 20:52:05
IPv6 status down	WWAN IPv6 IPv6 DNS server	Max DL 10 Kbps  Max UL 9 Kbps  Current DL 0 Kbps  Current UL 0 Kbps

Figure 26 - WWAN Connection Status

#### WWAN Connection Status

Profile name	The name of the active profile.
Status	The IPv4 connection status of the active profile.
IPv6 status	The IPv6 connection status of the active profile.
WWAN IP	The IPv4 address assigned by the mobile broadband carrier network.
DNS server	The primary and secondary IPv4 DNS servers for the WWAN connection.
WWAN IPv6	The IPv6 address assigned by the mobile broadband carrier network.
IPv6 DNS server	The primary and secondary IPv6 DNS servers for the WWAN connection.
APN	The Access Point Name currently in use.
Connection uptime	The length of time of the current mobile connection session.
Max DL	Maximum download speed in Kbps (Kilobits Per Second)
Max UL	Minimum upload speed in Kbps (Kilobits Per Second)
Current DL	Current download speed in Kbps (Kilobits Per Second)
Current UL	Current upload speed in Kbps (Kilobits Per Second)

Table 8 - WWAN Connection Status fields

## 6.1.4 Advanced status

^ ADVANCED STATUS		
	Non-NR5G	NR5G
Mobile country code		
505	ECGI	NCGI
Mobile network code		
01	505010134607648	N/A
SIM ICCID		
89610182000245747263	eNodeB	gNodeB
IMSI		
505013516117762	525811	N/A
Packet service status		
Attached	Cell ID	gNB Cell ID
	134607648	N/A
	PCI	gNB PCI
	38	957
	Channel number (EARFCN)	Channel number (NR ARFCN)
	3148	640992
	Reference Signal Received Power (RSRP)	SSB Channel number (SSB ARFCN)
	-96 dBm	640032
	Reference Signal Received Quality (RSRQ)	SCS
	-11 dB	30 kHz
	Signal to Interference plus Noise Ratio (SINR)	Reference Signal Received Power (SS-RSRP)
	11.6 dB	-100 dBm
	CQI	Reference Signal Received Quality (SS-RSRQ)
	11	-12 dB
	Scell band	Signal to Interference plus Noise Ratio (SS-SINR)
	LTE Band 7 - 2600MHz	17 dB
	Scell PCI	NR CQI
	362	0
	Scell channel number (EARFCN)	Synchronisation Signal Block (SSB) Index
	2950	0
	Scell state	
	CONFIGURED-DEACTIVATED	

Figure 27 - Advanced Status

### Advanced status

Mobile country code	The Mobile Country Code (MCC) of the AurusLINK+.
Mobile network code	The Mobile Network Code (MNC) of the AurusLINK+.
SIM ICCID	The Integrated Circuit Card Identifier of the SIM card used with the AurusLINK+, a unique number up to 19 digits in length.
IMSI	The International Mobile Subscriber Identity is a unique identifier of the user of a cellular network.
Packet service status	Displays whether the packet service is attached or detached. When APN or username/password is changed, the device detaches and reattaches to the network.

### Non-NR5G

ECGI	E-UTRAN Cell Global Identifier. The globally unique identity of a cell in E-UTRA. The ECGI concatenates the PLMN-Id and the ECI (E-UTRAN Cell Identifier). The ECI concatenates the eNodeB ID and the Cell ID
eNodeB	Also known as the Evolved Node B, this is the hardware element in the LTE network that communicates directly with mobile devices.
Cell ID	A unique code that identifies the base station from within the location area of the current mobile LTE network signal.
PCI	Physical Cell ID of the LTE Cell.
Channel number (EARFCN)	The channel number of the current cellular connection.
Reference Signal Received Power (SS-RSRP)	A cell-specific reference signal used to determine RSRP.
Reference Signal Received Quality (SS-RSRQ)	RSRQ calculates signal quality taking into consideration the RSSI. It is calculated by $N \times \text{RSRP} / \text{RSSI}$ where N is the number of Physical Resources Blocks (PRBs) over which the RSSI is measured.
NR CQI	Channel Quality Indicator. This is a value between 1 and 15 with 15 being the highest rating.
Scell band	The frequency band of the secondary cell (Scell).
Scell PCI	The Physical Layer Cell Identity (PCI) of the Scell.
Scell channel number (EARFCN)	The E-UTRA Absolute Radio Frequency Channel Number (EARFCN) will uniquely identify the LTE band and carrier frequency.
Scell state	The current state of the Scell.

**NR 5G**

<b>NCGI</b>	NR Cell Global Identifier. This concatenates the PLMN-Id (PLMN Identifier) and the 36bit NCI (NR Cell Identity). This information is not available when the device is operating in LTE or 5G Non-Standalone mode.
<b>gNodeB</b>	The gNodeB (gNB) is the term given to network equipment that transmits and receives wireless communications between UE and a mobile network
<b>gNB CellID</b>	A unique code that identifies the base station from within the location area of the current mobile 5G network signal. This is not available when the device is operating in LTE or 5G Non-Standalone mode.
<b>gNB PCI</b>	Physical Cell ID of the 5G NR Cell.
<b>Channel number (NR ARFCN)</b>	The channel number of the current 5G cellular connection.
<b>SSB Channel number (SSB ARFCN)</b>	The Synchronisation Signal Block channel number of the current 5G cellular connection.
<b>SCS</b>	The size of current SubCarrier Spacing (SCS) expressed in KHz
<b>Reference Signal Received Power (SS-RSRP)</b>	Synchronisation Signal Reference Signal Received Power (SS-RSRP). The linear average over the power contributions (in Watts) of the resource elements that carry Secondary Synchronisation Signal (SSS).
<b>Reference Signal Received Quality (SS-RSRQ)</b>	Secondary Synchronisation Signal Reference Signal Received Quality. SS-RSRQ calculates signal quality taking into consideration the RSSI. It is calculated by $N \times \text{SS-RSRP} / \text{NR carrier RSSI}$ where N is the number of Physical Resources Blocks (PRBs) over which the NR RSSI is measured.
<b>NR CQI</b>	The 5G NR Channel Quality Indicator (CQI).
<b>Synchronisation Signal Block (SSB) Index</b>	This is a key part of beam management. It is a value comprised of Primary Synchronisation Signal (PSS), Secondary Synchronisation Signal (SSS) and the Physical Broadcast Channel (PBCH).

Table 9 - Advanced Status fields

## 6.1.5 Neighbouring cell information

^ NEIGHBOURING CELL INFORMATION				
PCI	EARFCN	RSRP	RSRQ	Serving
293	2950	-90.8	-10.4	LTE
201	2950	-106.1	-17.0	LTE
130	2950	-109.0	-18.6	LTE

Figure 28 - Cell Information

### Neighbouring cell information

PCI	The Physical Cell ID.
EARFCN	E-UTRA Absolute Radio Frequency Channel Number. Uniquely identifies the LTE Band and carrier frequency.
RSRP	Reference Signal Received Power (RSRP).
RSRQ	Reference Signal Received Quality (RSRQ).
Serving	The radio signal being served e.g. 5G NR, LTE.

Table 10 - Cell Information fields

## 6.1.6 LAN

Click the LAN submenu under LAN to view the LAN connection information.

^ LAN	
IP	192.168.1.1 / 255.255.255.0
MAC address	D0:DB:...
Ethernet port status	<input checked="" type="checkbox"/> Up / 1000 Mbps / FDX
IP passthrough host MAC	80:E8:2...

Figure 29 - LAN Information

**LAN**

<b>IP</b>	The IP address and subnet mask of the AurusLINK+.
<b>MAC address</b>	The MAC address of the AurusLINK+.
<b>Ethernet port status</b>	Displays the current status of the Ethernet port and its operating speed.
<b>IP passthrough host MAC</b>	The MAC address of the connected gateway.

Table 11 - LAN Information fields


**6.1.7 Bluetooth**

Figure 30 - Bluetooth Information

**Bluetooth**

<b>MAC address</b>	The MAC address of the Bluetooth module.
--------------------	--

Table 12 - Bluetooth Information fields

## 6.1.8 GPS

Please note that not all AurusLINK+ devices support GPS.

 **Note** – In case GPS is not supported on your device, the menu item on the Status page will be disabled and this screen will not be accessible.

When a Global Positioning System signal is accessed, its details will display in the **GPS** page.



Figure 31 - GPS signal Information

GPS	
<b>Latitude</b>	The angular distance of a place north or south of the earth's equator, usually expressed in degrees and minutes
<b>Longitude</b>	The angular distance of a place east or west of the Greenwich meridian, usually expressed in degrees and minutes.
<b>Altitude</b>	The height of an object or point in relation to sea level or ground level.
<b>Height of geoid</b>	The height of an object from sea level if the Earth was under the influence of gravity and its own rotation alone.

<b>PDOP</b>	Position Dilution of Precision. Possible error in location due to GPS satellite location.
<b>Horizontal uncertainty</b>	Possible error in horizontal (latitude/longitude) location due to GPS satellite location.
<b>Vertical uncertainty</b>	Possible error in altitude location due to GPS satellite location.

Table 13 - GPS signal Information fields

## 6.1.9 NIT

Please note that not all AurusLINK+ devices support NIT.

 **Note** – In case NIT is not supported on your device, the menu item on the Status page will be disabled and this screen will not be accessible.

Click the **NIT** to view the antenna's **Azimuth** and **Downtilt** values as measured by the Smart Antenna Tool.



Figure 32 – NIT Information


## 6.2 Networking

### 6.2.1 Wireless WAN

#### 6.2.1.1 Wireless WAN profiles

 **Important** – Changing any of these settings can cause the AurusLINK+ to lose Internet connectivity. Please do not change any of these settings unless instructed to do so.

The **Wireless WAN profiles** page allows you to configure and enable/disable connection profiles. To access this page, click the **Networking** menu, and then select **Wireless WAN profiles** from the menu on the left.



Profile no.	Profile name	Status	APN	IP passthrough	Map to LAN/VLAN
1		<input type="button" value="On"/> <input type="button" value="Off"/>	blank	<input type="button" value="On"/> <input type="button" value="Off"/>	bridge0 <input type="button" value="v"/>
2		<input type="button" value="On"/> <input type="button" value="Off"/>	ims	<input type="button" value="On"/> <input type="button" value="Off"/>	None <input type="button" value="v"/>
3		<input type="button" value="On"/> <input type="button" value="Off"/>	sos	<input type="button" value="On"/> <input type="button" value="Off"/>	None <input type="button" value="v"/>
4		<input type="button" value="On"/> <input type="button" value="Off"/>	blank	<input type="button" value="On"/> <input type="button" value="Off"/>	None <input type="button" value="v"/>
5		<input type="button" value="On"/> <input type="button" value="Off"/>	blank	<input type="button" value="On"/> <input type="button" value="Off"/>	None <input type="button" value="v"/>
6		<input type="button" value="On"/> <input type="button" value="Off"/>	blank	<input type="button" value="On"/> <input type="button" value="Off"/>	None <input type="button" value="v"/>

Table 14 - Wireless WAN Profiles page

Each profile refers to a set of configuration items which are used by the AurusLINK+ to activate a Packet Data (PDP) context. Under normal scenarios, you may have a single profile enabled.

Multiple profiles can be used for simple fast switching of PDP settings such as APN, or for advanced networking configuration where multiple simultaneous PDP contexts may be required. Use the **Status On/Off** button to select the profile to use.

Use the **IP Passthrough On/Off** button to allow or restrict IP Passthrough when the respective profile is in use.

Specify the path to map from LAN to VLAN in the **Map to LAN/VLAN** drop down menu. The options are: **None**, **bridge0** or a **VLAN**


 **Note** – When mapping a profile to the LAN, “**Bridge0**” should be chosen.

 **Important** – The **same VLAN MUST NOT be used in multiple profiles**, even if the other profile or profiles are not enabled.

The **Profilename** and **APN** are defined when the Wireless WAN profile settings are configured, see next section.

## Configuring a Wireless WAN profile

- 1 Click the edit  button corresponding to the **Profile** that you wish to create or modify.
- 2 The **Wireless WAN Profile settings** page is displayed.



The dialog box is titled "WIRELESS WAN PROFILE SETTINGS". It contains a "PROFILE SETTINGS" section with the following fields:

- Enable: On/Off switch (On is selected).
- Name: Text input field.
- APN: Text input field.
- Username: Text input field.
- Password: Text input field with a visibility toggle icon.
- Authentication type: Drop-down menu (None is selected).
- PDP type: Drop-down menu (IPv4v6 is selected).
- MTU size: Text input field (1-1500).
- IP passthrough: On/Off switch (On is selected).
- Allow admin access: On/Off switch (On is selected).
- Modem profile: Drop-down menu (1 is selected) with a note: "modem profile changes require a reboot to take effect".

At the bottom are "Save" and "Cancel" buttons.

Figure 33 - Wireless WAN Profile Settings

Item	Definition
Enable	Toggle the enable button to <b>On</b> or <b>Off</b> , as desired.
Name	The name of the APN for easy identification on the Wireless WAN profile page. This name is only used to identify the profile on the AurusLINK+.
APN	Enter the APN (Access Point Name) configured for the corresponding profile.
Username	The username used to log on to the corresponding APN (if required).
Password	The password used to log on to the corresponding APN (if required).
Authentication type	The authentication type required by your provider. This can be set to: <b>None</b> , <b>PAP</b> or <b>CHAP</b>
PDP Type	<p>Select the <b>PDP type</b> (IP protocol) to use for the connection.</p> <ul style="list-style-type: none"> <li>a <input checked="" type="radio"/> <b>IPv4</b> – Sets a single stack IPv4 connection through which the AurusLINK+ receives only IPV4 network and DNS addresses.</li> <li>b <input checked="" type="radio"/> <b>IPv6</b> – Sets a single stack IPv6 connection through which the AurusLINK+ receives only IPV6 network and DNS addresses.</li> </ul> <p> <b>Note</b> – Before selecting this PDP type, check with your carrier to confirm that single stack IPV6 connectivity is supported.</p> <p>c <input checked="" type="radio"/> <b>IPv4v6</b> – Sets a dual stack connection allowing simultaneous IPV4 and IPV6 network connectivity. The AurusLINK+ receives both IPv4 and IPV6 network and DNS addresses.</p> <p>This is the default <b>PDP type</b></p>
Allow Admin Access	Select enable if remote SSH, TR-069 or WebGUI access to the device should be possible via this Wireless WAN Profile.
	 <b>Note</b> – SSH/HTTP/HTTPS can be individually restricted in the <b>Access Control</b> menu. Note also that this will automatically be enabled if the profile is selected in the <b>TR-069 settings</b> menu.
MTU size	Sets the Maximum Transmission Unit size. This may be from 1 to 1500 bytes.
IP passthrough	Allows a downstream device, such as a router, to manage the connection. The downstream device connects to the Internet and receives a WAN IP address so that all Internet traffic is passed to the downstream device. Internet traffic is still terminated at the gateway (AurusLINK+) and passed through to a downstream device, so the carrier is still able to connect to the gateway.
Save button	Click the <b>Save</b> button to apply the changes.

Table 15 - Wireless WAN Profile Settings page

### 6.2.1.2 Band selection

Select individual bands from the following band groupings: LTE, NR5G NSA or NR5G SA

**LTE BAND**

<input checked="" type="checkbox"/> LTE Band 1 - 2100MHz	<input checked="" type="checkbox"/> LTE Band 2 - 1900MHz	<input checked="" type="checkbox"/> LTE Band 3 - 1800MHz	<input checked="" type="checkbox"/> LTE Band 4 - 1700MHz	<input checked="" type="checkbox"/> LTE Band 5 - 850MHz
<input checked="" type="checkbox"/> LTE Band 7 - 2600MHz	<input checked="" type="checkbox"/> LTE Band 8 - 900MHz	<input checked="" type="checkbox"/> LTE Band 12 - 700MHz	<input checked="" type="checkbox"/> LTE Band 13 - 700MHz	<input checked="" type="checkbox"/> LTE Band 14 - 700MHz
<input type="checkbox"/> LTE Band 17 - 700MHz	<input checked="" type="checkbox"/> LTE Band 18 - 800MHz	<input checked="" type="checkbox"/> LTE Band 19 - 800MHz	<input checked="" type="checkbox"/> LTE Band 20 - 800MHz	<input checked="" type="checkbox"/> LTE Band 25 - 1900MHz
<input checked="" type="checkbox"/> LTE Band 26 - 850MHz	<input checked="" type="checkbox"/> LTE Band 28 - 700MHz	<input checked="" type="checkbox"/> LTE Band 29 - 700MHz	<input checked="" type="checkbox"/> LTE Band 30 - 700MHz	<input checked="" type="checkbox"/> LTE Band 32 - 1500MHz
<input checked="" type="checkbox"/> LTE Band 34 - TDD 2100	<input checked="" type="checkbox"/> LTE Band 38 - TDD 2600	<input checked="" type="checkbox"/> LTE Band 39 - TDD 1900	<input checked="" type="checkbox"/> LTE Band 40 - TDD 2300	<input checked="" type="checkbox"/> LTE Band 41 - TDD 2500
<input checked="" type="checkbox"/> LTE Band 42 - TDD 3500	<input checked="" type="checkbox"/> LTE Band 43 - TDD 3700	<input checked="" type="checkbox"/> LTE Band 46 - TDD 5200	<input checked="" type="checkbox"/> LTE Band 48 - TDD 3600	<input checked="" type="checkbox"/> LTE Band 66 - 1700MHz
<input checked="" type="checkbox"/> LTE Band 71 - 600MHz				

**NR5G NSA BAND**

<input checked="" type="checkbox"/> NR5G NSA BAND 1	<input checked="" type="checkbox"/> NR5G NSA BAND 2	<input checked="" type="checkbox"/> NR5G NSA BAND 3	<input checked="" type="checkbox"/> NR5G NSA BAND 5	<input checked="" type="checkbox"/> NR5G NSA BAND 7
<input checked="" type="checkbox"/> NR5G NSA BAND 8	<input checked="" type="checkbox"/> NR5G NSA BAND 12	<input type="checkbox"/> NR5G NSA BAND 14	<input checked="" type="checkbox"/> NR5G NSA BAND 20	<input checked="" type="checkbox"/> NR5G NSA BAND 25
<input checked="" type="checkbox"/> NR5G NSA BAND 28	<input checked="" type="checkbox"/> NR5G NSA BAND 38	<input checked="" type="checkbox"/> NR5G NSA BAND 40	<input checked="" type="checkbox"/> NR5G NSA BAND 41	<input checked="" type="checkbox"/> NR5G NSA BAND 48
<input checked="" type="checkbox"/> NR5G NSA BAND 66	<input checked="" type="checkbox"/> NR5G NSA BAND 71	<input checked="" type="checkbox"/> NR5G NSA BAND 77	<input checked="" type="checkbox"/> NR5G NSA BAND 78	<input checked="" type="checkbox"/> NR5G NSA BAND 79

**NR5G SA BAND**

<input checked="" type="checkbox"/> NR5G SA BAND 1	<input checked="" type="checkbox"/> NR5G SA BAND 2	<input checked="" type="checkbox"/> NR5G SA BAND 3	<input checked="" type="checkbox"/> NR5G SA BAND 5	<input checked="" type="checkbox"/> NR5G SA BAND 7
<input checked="" type="checkbox"/> NR5G SA BAND 8	<input checked="" type="checkbox"/> NR5G SA BAND 12	<input type="checkbox"/> NR5G SA BAND 14	<input checked="" type="checkbox"/> NR5G SA BAND 20	<input checked="" type="checkbox"/> NR5G SA BAND 25
<input checked="" type="checkbox"/> NR5G SA BAND 28	<input checked="" type="checkbox"/> NR5G SA BAND 38	<input checked="" type="checkbox"/> NR5G SA BAND 40	<input checked="" type="checkbox"/> NR5G SA BAND 41	<input checked="" type="checkbox"/> NR5G SA BAND 48
<input checked="" type="checkbox"/> NR5G SA BAND 66	<input checked="" type="checkbox"/> NR5G SA BAND 71	<input checked="" type="checkbox"/> NR5G SA BAND 77	<input checked="" type="checkbox"/> NR5G SA BAND 78	<input checked="" type="checkbox"/> NR5G SA BAND 79

Figure 34 - Wireless WAN – Band selection page

To set a device up for different LTE, 5G Non-Standalone (NR5G NSA) and 5G Standalone (NR5G SA) modes, refer to: *Appendix B – Configuring Radio Access Technologies*



Depending upon the model of AurusLINK+ different frequency bands will be available for selection. Please refer to your model's datasheet to ascertain which bands are applicable.

### 6.2.1.3 RAT selection

Select the preferred RAT (Radio Access Technology) from the following: LTE or NR5G




Figure 35 - Wireless WAN – Radio Technology selection page

To set a device up for different LTE, 5G Non-Standalone (NR5G NSA) and 5G Standalone (NR5G NSA) modes, refer to: *Appendix B – Configuring Radio Access Technologies*

### 6.2.1.4 Operator settings

The **Operator Setting** screen lets you select whether to have the AurusLINK+ automatically select the most appropriate operator and access technology, or if you set it to **Manual**, you can override and lock it to a particular carrier or access technology.




Figure 36 - Wireless WAN – Operator Settings

### 6.2.1.5 Roaming control

Select **On** to enable Roaming Control.




Figure 37 - Roaming control page

### 6.2.1.6 Cell lock

The Cell lock function allows you to specify a list of cells that the AurusLINK+ will not deviate from.

Two types of cells can be locked: **LTE** and **NR5G**




Figure 38 – Cell Lock page

#### Adding an LTE cell lock

To add an LTE cell to the list:

- 1 Next to **LTE Cell Lock List**, click on the **Add** button
- 2 Enter the **PCI** and **EARFCN** values of the cell that you want to lock to.




Figure 39 - LTE Cell Lock settings

- 3 Click on the **Save** button. It will be added to the **LTE Cell Lock List** on the **Cell Lock** page.
- 4 Repeat steps 1 to 3 for all the LTE cells that you wish to add.

### Adding an NR cell lock

To add an NR5G cell to the list:

- 1 Next to the **NR5G Cell Lock List**, click on the **Add** button.
- 2 Enter the gNB, NR ARFCN, Subcarrier Spacing and NR SA band values for the NR5G cell that you want to lock to.




Figure 40 - NR5G Cell Lock settings

- 3 Click on the **Save** button. It will be added to the **NR5G Cell Lock List** on the **Cell Lock** page.
- 4 Repeat steps 1 to 3 for all the NR5G cells that you wish to add.

### 6.2.1.7 SIM security

The **SIM security** settings page can be used for authenticating SIM cards that have been configured with a security PIN.

#### Unlocking a PIN locked SIM

If the SIM card is locked, you will receive a notice when you access the Status page after which you will be directed to the PIN settings page to enter the PIN. The PIN settings page lists the status of the SIM at the top of the page.

If you are not redirected to the PIN settings page, to unlock the SIM:

- 1 Click on the **Networking** menu from the top menu bar, and then click **SIM security settings**.




Figure 41 - Wireless WAN - SIM Security settings page

- 1 Enter the PIN in the **Current PIN** field (enter numbers only).
- 2 Click on the **Save** button to save the PIN and unlock access.
- 3 Once unlocked, you may toggle the **PIN protection** switch to the **Off** position if you no longer wish to have access locked by a PIN.

## 6.2.2 LAN

### 6.2.2.1 LAN Configuration

The **LAN** configuration page is used to configure the LAN settings of the AurusLINK+.

To access the LAN configuration page, click the Networking menu at the top of the screen, then click the LAN menu on the left.

The default IP of the LAN port is: **192.168.1.1** with subnet mask: **255.255.255.0**

To change the IP address or Subnet mask, enter the new **IP Address** and/or **Subnet mask** and click the **Save** button.

 **Note** – If you change the IP address, remember to refresh the Ethernet interface of your device, or set an appropriate IP address range, then enter the new IP address into your browser address bar to access the AurusLINK+.




Figure 42 - LAN Information


#### LAN Configuration

<b>IP</b>	The IP address of the AurusLINK+.
<b>Subnet mask</b>	The subnet mask of the AurusLINK+.
<b>Hostname</b>	The label used to identify the device.

Table 16 - LAN Information fields

### 6.2.2.2 DHCP configuration

You can manually set the start and end address range to be used to automatically assign to DHCP clients when they are connected and the lease time of the assigned addresses.



The screenshot shows the 'DHCP' configuration page. At the top, there is a 'DHCP' label with an 'On' button (highlighted in orange) and an 'Off' button. Below this, there are two sets of input fields for 'DHCP start range' and 'DHCP end range', each consisting of four input boxes. The 'DHCP start range' is set to 192.168.1.100 and the 'DHCP end range' is set to 192.168.1.199. Below these is a field for 'DHCP lease time (seconds)' with a value of 120, accompanied by a note '(>=120)'. At the bottom is a 'Save' button.

Figure 43 - DHCP Configuration page

Enter the desired DHCP options and click the **Save** button.

### 6.2.2.3 VLAN

A Virtual Local Area Network (VLAN) is a subnetwork used to group devices located on separate physical networks. This useful feature allows you to partition your network without the need for additional cabling or wireless access.

Figure 44 - VLAN Rules list page

### VLAN Settings

 **Note** – VLANs can only be assigned to APN Profiles 2-6.

Click the **Add** button in the **VLAN RULES** section to create a VLAN rule:

- 1 Click the **+Add** button on the VLAN Configuration page.

The **VLAN Settings** page will open:

**VLAN**

Configuring VLAN rules may cause your device to reboot.

Device will reboot when going from zero to one or more enabled VLANs, and the reverse. The reboot will take about 1-2 minutes, during which you won't be able to access your device.

**VLAN SETTINGS**

Rule name

VLAN ID  0-4094

IP address

Subnet mask

DHCP enable  On  Off

DHCP start range

DHCP end range

DHCP lease time (seconds)  ( $\geq 120$ )

Allow admin access  On  Off

Enable  On  Off

**Save** **Reset** **Cancel**

Figure 45 - VLAN Settings page

2 In the **Rule name** field, enter a name for the VLAN rule. This is a name that allows you to easily identify the VLAN.

3 In the **VLAN ID** field, enter a number between 0 and 4094 which will be used by the network to identify the VLAN uniquely.



**Note** – The values 253, 254 and 255 are reserved and cannot be assigned to VLANs as **VLAN IDs**.

4 In the **IP address** field, enter the IP address for this device on the VLAN.

5 In the **Subnet mask** field, enter the Subnet mask for the device on the VLAN.

6 In the **DHCP start range** and **DHCP end range** fields, enter the IP address range for the VLAN. Addresses within this range will be assigned automatically to devices connecting to this VLAN.

- 7 In the **DHCP lease time (seconds)** field, enter the number of seconds that the DHCP lease will be valid for. This value must be 120 or higher.
- 8 In the **Allow Admin Access** field, select **Enable ON** if local SSH or WebGUI access to the device should be possible via this VLAN.

 **Note** – SSH/HTTP/HTTPS can be individually restricted in the **Access Control** menu.

- 9 Set the **Enable** toggle to the **ON** position.
- 10 Click the **Save** button to apply the settings.

## 6.2.3 Firewall

### 6.2.3.1 NAT

The Port forwarding list is used to configure the Network Address Translation (NAT) rules currently in effect on the AurusLINK+. To access the Port forwarding page, click the **Networking** menu at the top of the screen, click the **Firewall** menu on the left.




Figure 46 – NAT Port forwarding list

The purpose of the port forwarding feature is to allow mapping of inbound requests to a specific port on the WAN IP address to any connected device.

 **Note** – Some carriers block inbound connections, or require a public IP address in order to get inbound requests.

#### Adding a port forwarding rule

To create a new port forwarding rule:

- 1 Next to the protocol you wish to create a rule for (IPv4 or IPv6), click the **+Add** button.

The port forwarding settings screen is displayed.




Figure 47 - Port Forwarding Settings

- 2 In the **Rule name** field, enter a name for the rule so that it can be easily identified.
- 3 In the **Profile No.** field, enter a number that corresponds to the Wireless WAN Profile that you want to use for the rule.
- 4 Use the **Protocol** drop-down list to select the type of protocol you want to use for the rule. The protocols selections available are **TCP**, **UDP** and **TCP/UDP**.
- 5 In the **Public port** field, enter a number between 1 and 65535 to use for the communication port from the AurusLINK+ out to the mobile network.
- 6 In the **Local IP Address / Local IPv6 Address** field, enter the IP address of LAN equipment to which traffic should be routed or a wildcard IP address (0.0.0.0) that allows all IP addresses to access the traffic.
- 7 In the **Local port** field, enter a port number to use for traffic to the local device. This may be an integer between 1 and 65535.
- 8 Ensure that the **Enable** toggle button is set to the **ON** position.
- 9 Click the **Save** button to confirm your settings.
- 10 To delete a port forwarding rule, click the **X** button on the Port forwarding list for the corresponding rule that you would like to delete. To edit an existing rule, click the **EDIT** button.

### 6.2.3.2 MAC whitelist

The MAC filter feature allows you to apply a policy to the traffic that passes through the router, both inbound and outbound, so that network access can be controlled based on the MAC address of the device seeking to make a connection.

To access the MAC filtering page, click the **Networking** menu at the top of the screen, click the **Firewall** menu on the left, then click the **MAC whitelist** menu item.




Figure 48 – MAC whitelist page

To create an access filter based on MAC address:

- 1 Click the **Add** button.

The **MAC WHITELIST SETTINGS** page will open.

- 2 Enter a **Name** to reference the whitelisted device with.
- 3 Enter the **MAC address** you want to allow access to
- 4 Click the **Enable** toggle key so that it is in the **On** position.
- 5 Click the **Save** button.

## 6.2.4 Routing

### 6.2.4.1 Static Routing

To view the Static Routing settings, click **Networking** then **Routing > Static** menu on the left.

The **Static Routing** page contains details of defined **Static Routes** and well as the **Active Routes**.

Route name	Destination	Netmask	Gateway	Interface	Metric
Gaming_01	169.253.251.0	255.255.255.0	11.0.0.105	wwan interface	15000

Destination	Gateway	Netmask	Flags	Metric	Ref	Use	Interface
169.254.251.0	0.0.0.0	255.255.255.0	U	0	0	0	ecm0
192.168.1.0	0.0.0.0	255.255.255.0	U	0	0	0	bridge0

Figure 49 – Static/Active routing lists

Click the **Add** button to define a new Static Route.

#### Static Route Configuration

Click the **Add** button to open the **Route Configuration** page:




Figure 50 – Route configuration page

#### Route configuration

Route name	Enter a meaningful name.
Destination IP address	Enter the destination IP address of the route.
Netmask	Enter a netmask specification.
Gateway IP address	Enter the gateway's IP address.
Network interface	Select the Network interface from the drop down list.
Metric	Enter a metric in the range of 0 through 32766
Save button	Click to save the changes and add the new route configuration to the Static Routing List.
Cancel button	Close the window and discard the current entries. Note – if you want to delete an existing Static Route, click the  delete button on the Static Routing List to remove the route permanently from the system.

Table 17 – Route configuration fields

## 6.2.5 Service assurance

To conduct a check on general status of selected WWAN profiles and other tests click the **Networking** menu at the top of the screen, then click the **Service assurance** menu item on the left.

The screenshot shows the Service Assurance page of the casa systems interface. On the left, a sidebar lists 'Wireless WAN', 'LAN', 'Firewall', 'Routing', and 'Service assurance' (which is highlighted in orange). The main content area is titled 'SERVICE ASSURANCE' and contains the following text: 'Conducting check on general status and doing tests on selected WWAN profile(s)'. A dropdown menu shows 'WWAN profile(s) 1 (telstra.internet)'. Below this, there are fields for 'Domain name for DNS test', 'Destination for ping test', and 'URL for web test'. A dropdown menu for 'Request method in web test' is set to 'GET'. A large 'Start' button is present. At the bottom, a 'Result' section shows 'Status Failed' and 'Progress stage Error UE is not attached'.

Figure 51 – Service assurance page

From the **WWAN profiles** list select the service you want to monitor.

When the settings are complete, click the **Start** button to commence the test.

### 6.2.5.1 Result

In this section the **Status**, **Progress stage** and any **Error** message will be displayed.

## 6.3 Services

### 6.3.1 Network Time (NTP)

The NTP (Network Time Protocol) settings page allows you to configure the AurusLINK+ to synchronize its internal clock with a global Internet Time server and specify the time zone for the location of the device. This provides an accurate timekeeping function for features such as System Log entries and Firewall settings where the current system time is displayed and recorded. Any NTP server available publicly on the internet may be used. The default NTP server is time.nrc.ca.

To access the Network time (NTP) page, click the **Services** menu at the top of the screen then click the **Network time (NTP)** menu item on the left.




Figure 52 - Network Time (NTP) page

### 6.3.2 Aurora App (Bluetooth) Server

The **Aurora App (Bluetooth) Server** is used to facilitate communication with the Aurora smartphone installation app.

Switch **Enable** to **On** before starting the Aurora installation app on an Android device.




Figure 53 - Aurora App (Bluetooth) server page

When an installation has been completed, you have the option to disable the Aurora App server, but be aware that next time you try to find the antenna via the app, it will not be able to discover the antenna until the Aurora App server has been re-enabled.

When the Aurora App (Bluetooth) server is enabled it is automatically activated upon device power up for a maximum of a few minutes. After that period of time the server is automatically deactivated. It can be re-activated at a later time by rebooting the device from the power switch.

### 6.3.3 TR-069

The TR-069 (Technical Report 069) protocol is a technical specification also known as CPE WAN Management Protocol (CWMP). It is a framework for remote management and auto-configuration of end-user devices such as customer-premises equipment (CPE) and Auto Configuration Servers (ACS). It is particularly efficient in applying configuration updates across networks to multiple CPEs.

TR-069 uses a bi-directional SOAP/HTTP-based protocol based on the application layer protocol and provides several benefits for the maintenance of a field of CPEs:

- Simplifies the initial configuration of a device during installation
- Enables easy restoration of service after a factory reset or replacement of a faulty device
- Firmware and software version management

- Diagnostics and monitoring



**Note -** You must have your own compatible ACS infrastructure to use TR-069. To access and configure the TR-069 settings, you must be logged into the router with the root account.

When a factory reset of the router is performed via TR-069, the TR-069 settings are preserved.

The CPE sends “inform” messages periodically to alert the ACS server that it is ready. These inform messages can also be configured to accept a connection request from the ACS server. When a connection is established, any tasks queued on the ACS server are executed. These tasks may be value retrieval or changes and firmware upgrades.

### 6.3.3.1 TR-069 configuration

To configure TR-069:

- 1 Click the **Enable TR-069** toggle key to switch it to the **ON** position.

**TR-069**

**TR-069 CONFIGURATION**

Enable TR-069  On  Off

ACS URL

ACS username  acs

ACS password  \*\*\*

Verify ACS password  \*\*\*

Connection request username  cpe

Connection request password  \*\*\*

Verify connection request password  \*\*\*

Enable periodic ACS informs  On  Off

Inform period  600 (30-2592000) secs

Randomise initial inform  On  Off

**LAST INFORM STATUS**

Start at

End at

**TR-069 DEVICEINFO**

Manufacturer NetComm Wireless Limited

ManufacturerOUI 18F145

ModelName casa\_cfw2331

Description Casa Systems Casa-CFW2331

ProductClass CFW2331 Series

SerialNumber 203499201300016

**Save**

Figure 54 - TR-069 Configuration

- 2 In the **ACS URL** field, enter the Auto Configuration Server's full domain name or IP address.
- 3 Use the **ACS** username field to specify the username used by the server to authenticate the CPE when it sends an "inform" message.
- 4 In the **ACS password** and **Verify ACS password** fields, enter the password used by the server to authenticate the CPE when it sends an "inform" message.
- 5 In the **Connection request** username field, enter the username that the CPE uses to authenticate the Auto Configuration Server during a connection request to the CPE.
- 6 In the **Connection request password** and **Verify password** fields, enter the password that the CPE uses to authenticate the Auto Configuration Server during a connection request to the CPE.
- 7 The inform message acts as a beacon to inform the ACS of the existence of the router. Select **Enable periodic ACS informs** toggle key to **ON** in order to turn on the periodic ACS inform messages.
- 8 In the **Inform Period** field, enter the number of seconds between the inform messages.
- 9 Click the **Save** button to save the settings.

### 6.3.4 DNS Server

Enter the IP addresses of the **Primary DNS server** and **Secondary DNS server**.

DNS SERVER

DNS SERVER CONFIGURATION

Primary DNS server

Secondary DNS server

DNS cache size  (0~5000)

DNS local TTL  (0~86400 seconds)

Save

Figure 55 - DNS Server page

Set a **DNS cache size** of between 0 and 5000.

Set the **DNS local TTL** (Time-To-Live) time between 0 and 86,400 seconds.

Click the **Save** button to apply the settings to the DNS server.

## 6.3.5 Geofence

Please note that not all AurusLINK+ devices support GPS or its Geofencing functionality.

**Note** – In case GPS and Geofence are not supported on your device, the **Geofence** menu item on the **Services** menu will be disabled and this screen will not be accessible.

To access the Geofence screen, select the **Services** item from the top menu bar then select the **Geofence** menu item.

Geofence allows you to designate a circular area and then uses the router's GPS position to monitor when the gateway moves out of or in to that area.




Figure 56 – Geofence options

Item	Description
<b>GEOFENCE CONFIGURATION</b>	
<b>Enable</b> button	Toggles Geofence operation On or Off. When on your currently defined Geofences appear in the Geofence list, see below.
<b>Coordinate units</b>	Select either: <ul style="list-style-type: none"> <li>● DMS (Degrees/Minutes/Seconds), or</li> <li>● Decimal degrees</li> </ul> Changing this will change the display in the <b>GEOFENCE LIST</b> lower on the page, and the <b>GEOFENCE CONFIGURATION</b> page, see below.

Item	Description
Measurement system	Select either: <ul style="list-style-type: none"> <li>● metric, or</li> <li>● imperial</li> </ul> <p>Changing this will change the display in the <b>GEOFENCE LIST</b> lower on the page, and the <b>GEOFENCE CONFIGURATION</b> page, see below.</p>
Save button	Saves any changes made on this page
Add button	Click to add a new Geofence definition. The add Geofence configuration screen will open, see next section below.
GEOFENCE LIST	This table contains all your currently defined Geofences.
Name	A user defined reference name.
Latitude / Longitude	The Latitude and Longitude coordinates defined in the <b>GEOFENCE CONFIGURATION</b> page display. The <b>Coordinate units</b> selection will determine which system displays: DMS or decimal degrees
Radius	Set a radius from the centre of the geofence point. The <b>Measurement system</b> selection will determine which system displays: Kilometres or miles
Status	In if the router is inside the radius. Out if the router is outside the radius.
Edit button	Click this to edit an existing Geofence in the list. The user interface is the same as the add Geofence configuration screen, see next section below.
Delete button	Click to remove the geofence from the list.

Table 18 – Geofence user interface

### 6.3.5.1 Add Geofence

Click the **+Add** button to create a new Geofence (note that editing an existing Geofence uses the same configuration page).

The screenshot shows a 'GPS GEOFENCE' configuration dialog box. The 'GEOFENCE CONFIGURATION' section contains the following fields:

- Name:** Delivery\_ZoneB
- Latitude:** 39.099722 (decimal degrees)
- Longitude:** -94.578333 (decimal degrees)
- Radius:** 27.96 (>= mile)

Below the fields are three buttons: 'Open Google Maps' (orange), 'Save' (grey), and 'Cancel' (grey).

Figure 57 – Configure Geofences


Item	Description
<b>Name</b>	When you Add a new Geofence you will be prompted to enter a meaningful name. This will be its reference in the Geofence list page.
<b>Latitude / Longitude</b>	Enter the Latitude and Longitude coordinates of the centre of the geofence. The <b>Coordinate units</b> selection will determine which system displays: DMS or decimal degrees
<b>Radius</b>	Set a radius from the centre of the geofence point for the fence line. The <b>Measurement system</b> selection will determine which system displays: Kilometres or miles
<b>Open Google Maps</b> button	When coordinates have been entered, click the <b>Google maps</b> button to show where you expect the centre of the geofence to be. For example:
	
<b>Save</b> button	Saves the new Geofence (Add) or saves the changes to an existing Geofence (Edit).
<b>Cancel</b> button	Closes the <b>Add/Edit</b> page and returns to the Geofence list without saving any changes.

Table 19 – Geofence configuration options

## 6.4 System

### 6.4.1 Log – System log

The System Log enables you to troubleshoot any issues you may be experiencing with the AurusLINK+. To access the System Log page, click the **System** menu. A page containing the **System Logs** buttons are displayed.




Figure 58 - System Log page

You can download the log file to your local computer by clicking on the **Download** button.

A .txt log file will be downloaded to your browser's Download folder.

The **Clear** button clears the log file when logging to non-volatile memory is enabled (refer to the System log settings section). It does not clear the log/message buffer.

#### 6.4.1.1 Log – System log settings

To access the System log settings page, click the **System** menu item then select the **Log** menu on the left and then select **System log settings** from the drop-down menu.




Figure 59 - System Log Settings

## Log capture level

The log capture level defines the amount of detail that the system log stores. This setting also affects the Display level setting on the System log page. The system will capture and display events for the selected level and all the events at levels below it. For example, setting it to "Notice" will show "Notice", "Warning" and "Error" events.

Item	Definition
Debug	Show extended system log messages with full debugging level details.
Info	Show informational messages.
Notice	Show normal system logging information.
Warning	Show warning messages.
Error	Show error condition messages only.

Table 20 – System log detail levels

## Volatile log

Contents of Volatile memory is stored temporarily.

- 1 Specify the maximum **Log buffer size** (100-512 kilobytes).
- 2 Click the **Save** button.

A drawback of log data saved in volatile memory is that the log data is stored in RAM and therefore when the unit loses power, or is rebooted, the device will lose any log information stored in the RAM.

Non-volatile memory is the type of memory in which data remains stored even if it is powered-off. To ensure that log information is accessible between reboots of the AurusLINK+ there are two options:

- Click On to enable the **Log to non-volatile memory** option.
- Use a **Remote Syslog Server**.

## Non-volatile log

When the AurusLINK+ is configured to log to non-volatile memory, the log data is stored in flash memory, making it accessible after a reboot of the device. Up to 512kb of log data will be stored before it is overwritten by new log data. Non-volatile logging can lead to Flash memory wear. This facility is intended for debugging only.

- 1 Click On to enable the **Log to non-volatile memory** option.
- 2 Specify the maximum **Log file size** (500-5000 kilobytes).
- 3 Click the **Save** button.

## Remote syslog server

The AurusLINK+ can be configured to output log data to a remote syslog server. This is an application running on a remote computer which accepts and displays the log data. Most syslog servers can also save the log data to a file on the computer on which it is running allowing you to ensure that no log data is lost between reboots.

To configure the AurusLINK+ to output log data to a remote syslog server:

- 1 Click the **System** menu from the top menu bar. The **System log** item is displayed.
- 2 Under the **Remote syslog server** section, enter the IP address or hostname of the syslog server in the **IP / Hostname [:PORT]** field.



Figure 60 – Remote syslog server configuration

You can also specify the port number after the IP or hostname by entering a semi-colon and then the port number e.g. 192.168.1.102:514.

If you do not specify a port number, the AurusLINK+ will use the default UDP port 514.

- 3 Click the **Save** button to save the configuration.

### 6.4.1.2 QXDM over Ethernet

For debugging, you can use QXDM over Ethernet. QXDM is a Qualcomm tool used for capture and analysis of mobile signalling data.

To use QXDM over Ethernet:

- 1 Click on the **Enable** toggle key to set it to the **On** position.
- 2 Enter the Server IP address.



Figure 61 - QXDM over Ethernet page

- 3 Click the **Save** button to begin the capture and analysis of mobile signalling data.

## 6.4.2 Ping diagnostics

Ping Diagnostics are used to send controlled ping packets to determine the status of the link. These are small packets of data that the AurusLINK+ sends to a remote address and if the connection is up, a reply is received.

**PING DIAGNOSTICS**

**PING DIAGNOSTICS CONFIGURATION**

Host

Number of repetitions  (1-4294967295)

Timeout  (1-4294967295) ms

Data block size  (1-65535)

DSAC  (0-63)

Interface  v

Protocol version  v

**Request**

**PING DIAGNOSTICS RESULT**

Diagnostics state None

Success count 0

Failure count 0

Minimum response time 0 ms

Maximum response time 0 ms

Average response time 0 ms

Figure 62 - Ping Diagnostics page

Use Ping Diagnostics to test the status of the network connection:

- 1 In the **Host** field, enter the domain name or IP address that you want to send a ping request to for the test.
- 2 In the **Number of repetitions** field, enter the number of times you want the AurusLINK+ to continue the ping requests.
- 3 In the **Timeout** field, enter the number of milliseconds to wait before the ping request times out if there is no response.
- 4 In the **Data block size** field, enter the number of bytes that the ping packet is made up of.

- 5 In the **DSCP** field, enter an integer between 0 and 63 which acts as a classification code according to the Differentiated Services Code Point (DSCP) definition.
- 6 In the **Interface** drop-down list, select the interface that the ping test is to be performed on. If no interface is selected, the default interface rmnet\_data0 is used.
- 7 In the **Protocol** drop-down list, select the IP protocol to use for the test.
- 8 Click on the **Request** button. The **PING DIAGNOSTIC RESULT** section updates with the results of the ping request.

## 6.4.3 System configuration

### 6.4.3.1 Restore factory defaults

Restoring factory defaults will reset the AurusLINK+ to its factory default configuration. There are three different levels of factory reset. The Installer level reset is the lowest level reset and should be the first one attempted when troubleshooting. The Carrier reset level is the next highest level and erases additional settings while the Full Factory reset option will reset all settings to their factory defaults.

To restore the AurusLINK+ to its factory default settings, please follow these steps:

- 1 Open a browser window and navigate to the IP address of the AurusLINK+ (default address is <http://192.168.1.1>).
- 2 Log in to the AurusLINK+ Web User Interface (refer to section 5.1 Log in as Administrator via Web UI on page 24).
- 3 Select the **System** item from the top menu bar, then **System configuration** on the left menu and then select the **Restore factory defaults** menu item.




Figure 63 - Restore Factory Defaults page

4 Select a reset type to perform: **Installer Reset**, **Carrier Reset** or **Full Factory Reset**

Reset type	Description
<b>Installer Reset</b>	<p>This will only reset settings that have been changed after the installation, usually via the web interface.</p> <p>This is the safest reset option and should be the first one attempted when troubleshooting a problem.</p>
<b>Carrier Reset</b>	<p>This will reset the device with the carrier-defined default settings to operate on the network.</p> <p>This also resets the user-configured options to their default settings. Use this reset type only if the Installer Reset did not resolve the problem.</p>
<b>Full Factory Reset</b>	<p>Typically used for refurbishment or to remove an erroneous configuration. This will remove all settings including the carrier settings that are required for the device to operate on the network.</p> <p>This option should not be used unless you really know what you are doing. (All configurations, NVs and settings are completely removed)</p>

5 A notice is displayed informing you that the process may take one or two minutes.




Figure 64 – Restore Factory Defaults Confirmation Message

6 Click **OK** to reboot the AurusLINK+.


7 The AurusLINK+ reboots with the default settings applied.

There is also a manual reset button on the bottom of the CPE.

**Note** – The manual reset button supports two types of reset.  
For more information refer to **3.2 Interface** on page 10 of this User Guide.

### 6.4.3.2 Web server settings

You can configure whether the AurusLINK+'s web server uses HTTP or HTTPS and the server port. Additionally, you can generate a web server certificate by entering data in all the fields under the **Generate web server certificate** section.



The screenshot shows a configuration interface for a web server. At the top, there is a 'WEB SERVER SETTING' section with an 'HTTPS' toggle switch set to 'On' (grayed out), an 'HTTP server port' input field set to '80' with a range of '1-65535', and a 'Save' button. Below this is a 'GENERATE WEB SERVER CERTIFICATE' section. It displays a certificate serial number: '1D85740223F26758F7274F773692973E26C357FC'. It includes fields for 'Not before' (Apr 19 05:13:23 2021 GMT), 'Not after' (Jul 23 05:13:23 2023 GMT), 'Server key size' (2048), and dropdowns for 'Country' (AU), 'State' (NSW), 'City' (Sydney), 'Organization' (Casa Systems), and 'Email' (cad-support@casa-systems.com). At the bottom is a 'Server certificate' section with a 'Generate' button.

Figure 65 - Web server settings

### 6.4.3.3 Administrator credentials

Use this page to change the **Password** used to access the AurusLINK+ via SSH.

The default **User Name** and **User Password** for SSH access should be obtained from your local mobile carrier or Casa Systems representative:

CHANGING ADMINISTRATOR CREDENTIALS

**Changing administrator credentials**

Changing administrator password which can be used for logging into the device via SSH, if enabled.

Username root

Current password

New password

Confirm new password

Save

Figure 66 - Changing administrator credentials

Enter the **Password** in the table to into the **Current password** field if you have not previously created a new SSH access Password.

If you have created a new SSH access Password but have forgotten it, you will have to **Restore factory default** settings, see section [6.4.3.1](#), above.

#### 6.4.3.4 Web UI credentials

Use this page to change the default Password that you initially used to log in via the Web User Interface (refer to section *5.1 Log in as Administrator via Web UI* on page 24).

CHANGING WEB UI CREDENTIALS

Changing Web UI credentials

Username admin

Current password roofclimberabove

New password

Confirm new password

Save

Figure 67 - Changing web interface credentials

The default **User Name** and **User Password** for Web UI access are as follows:

##### Administrator account access via Web UI

Username	admin
Password	roofclimberabove

Table 21 - Login details - Administrator account via Web UI



Important

Please note that User Password is recommended to be changed by the mobile carrier at the time of factory production.

Please contact your local mobile carrier or Casa Systems representative if the default value does not work on first time installation.

Enter the **Password** in the table to into the **Current password** field if you have not previously created a new Web UI access Password.

If you have created a new Web UI access password but have forgotten it, you will have to **Restore factory default** settings, see section *6.4.3.1*, above.

### 6.4.3.5 Settings backup/restore

Use this page to save your current settings in a backup file and then to retrieve the backup file to restore your previous settings should this be necessary.

To **SAVE A COPY OF CURRENT SETTINGS**:

- 1 Enter a **Password** for the new backup file.
- 2 Enter the same password into the **Confirm password** field
- 3 Click the **Save** button.

**SETTINGS BACKUP AND RESTORE**

**SAVE A COPY OF CURRENT SETTINGS**

Password

Confirm password

**RESTORE SAVED SETTINGS**

Select file to upload  Not uploaded

Password

Figure 68 - Setting backup/restore page

A .zip folder will be downloaded to the download folder of your browser. We suggest that you move this to a secure folder.

To **RESTORE SAVED SETTINGS**:

- 1 Click the **Choose a file** button and navigate to the backup file.
- 2 Select the file and the word **Uploaded** will appear after the button
- 3 Enter the **Password** you created when making the backup file.
- 4 Click the **Restore** button.

5 The following warning message will appear:




Figure 69 – Confirmation of restore message

6 Click the **OK** button to proceed with the restoration of your previous settings.

#### 6.4.3.6 Runtime Configuration

Runtime Configuration can be used to load a configuration file containing carrier-specific settings such as MBN changes which are not available via the web user interface. It is used for late binding of carrier configurations at the time of installation.

Runtime Configuration files can only be created by Casa Systems engineers. Please speak to your Casa Systems representative for more information.

To access the Runtime Configuration page, select **System > System configuration > Runtime configuration**




Figure 70 - Runtime configuration page

To apply runtime configuration:

- 1 Select the **Choose a file** button and locate the configuration file.
- 2 Select the file. The word **Uploaded** appears next to the button.
- 3 Select the **Apply** button to install the configuration file.
- 4 The device automatically reboots after successful upload of the configuration file.

The following runtime configuration IDs will be read and displayed on this page. They are 15-digit configuration IDs that uniquely identify the configuration file.

#### 6.4.4 Firmware upgrade

To access the Firmware upgrade page, navigate to **System**, then click **Firmware Upgrade** on the left side menu.




Figure 71 - Firmware Upgrade page

To upgrade the firmware of the AurusLINK+:

- 1 Click the **Choose a file** button, then locate the firmware file on your computer.
- 2 To remove all current settings select **On** for **Reset to default config**.  
Selecting **Off** for **Reset to default config** will save all current user defined settings and apply them using the new firmware.
- 3 Click the **Upgrade** button.
- 4 The AurusLINK+ performs the firmware upgrade and then reboots.

## 6.4.5 Access control

The Access Control page turns on or off access to the antenna via different protocols. You can specify certain protocols to have different settings from local or remote connections.




Figure 72 - Access Control page

Item	Definition
<b>Remote Access Control</b>	
HTTP Enable	Enables/disables HTTP access to the web interface of the antenna from a remote connection.
HTTPS Enable	Enables/disables HTTPS access to the web interface of the antenna from a remote connection.
Update server certificate link	If necessary, click this link to go to the <b>WEB SERVER SETTINGS</b> page. Refer to <b>6.4.3.4 Web UI credentials</b> on page 70 for details on updating this certificate.
SSH Enable	Enables/disables SSH access to the antenna from a remote connection.
Ping Enable	Enables/disables a response to pings from a remote connection.
<b>Local Access Control</b>	
HTTP Enable	Enables/disables HTTP access to the web interface of the CPE from a local connection.

Item	Definition
HTTPS Enable	Enables/disables HTTPS access to the web interface of the antenna from a local connection.
SSH Enable	Enables/disables SSH access to the antenna from a local connection.

Table 22 - Access Control options



**Note -** It is **not possible** to disable both Local HTTP and HTTPS simultaneously via the WebUI in order to stop accidental lock out of the WebUI.

Intentional lock out of the WebUI from local access can be performed by disabling both local HTTP and HTTPS via TR-069.

## 6.4.6 Reboot

The **Reboot** option in the **System** section performs a soft reboot of the device. This can be useful if you have made configuration changes you want to implement.

To reboot the AurusLINK+:

- 1 Click the **System** menu item from the top menu bar.
- 2 Click the **Reboot** button from the menu on the left side of the screen.
- 3 The AurusLINK+ displays a warning that you are about to perform a reboot.




Figure 73 - Reboot warning message

- 4 If you wish to proceed, click the **Reboot** button.
- 5 A warning popup will advise that "It may take 1-2 minutes to reboot your device. Are you sure you want to continue?"




Figure 74 - Reboot confirmation message

- 6 Click **OK** to continue with the reboot process.

## 6.4.7 Field test

The Field test page contains NR5G cell information which may be useful when troubleshooting signal strength issues. This screen can be found by navigating to **System > Field test**.

FIELD TEST									
LTE PCELL INFORMATION									
PCI	EARFCN	Band	Bandwidth						
38	3148	7	20MHz						
LTE SCELL INFORMATION									
CC ID	PCI	EARFCN	Band	Bandwidth	UL configured	State			
1	362	2950	7	20MHz	0	CONFIGURED-DEACTIVATED			
NR5G SERVING CELL INFORMATION									
CC ID	Cell ID	DL ARFCN	UL ARFCN	Band	Band type	DL BW	UL BW	DL max MIMO	UL max MIMO
7	957	640992	640992	78	SUB6	80MHz	80MHz	4	1

Figure 75 - Field test

### FIELD TEST data

#### LTE PCell Information

PCI	The Physical Cell ID
ERFCN	E-UTRA Absolute Radio Frequency Channel Number.
Band	The LTE band number
Bandwidth	The LTE band's current bandwidth

## FIELD TEST data

### LTE SCell Information

CCID	The cell identifier
PCI	The Physical Cell I
ERFCN	E-UTRA Absolute Radio Frequency Channel Number
Band	The LTE band number
Bandwidth	The LTE band's current bandwidth
UL configured	Indicated whether the cell is configured
State	The current state of the LTE Scell

### NR5G Serving Cell Information

Cell ID	The physical cell identifier
DL ARFCN	Downlink Absolute Radio Frequency Channel Number.
UL ARFCN	Uplink Absolute Radio Frequency Channel Number.
Band	The NR5G band
Band type	The type of the NR5G band, e.g. Sub6 or mmWave.
DL BW	Downlink bandwidth.
UL BW	Uplink bandwidth.
DL max MIMO	Downlink maximum Multiple Input Multiple Output (MIMO).
UL max MIMO	Uplink maximum Multiple Input Multiple Output (MIMO).

Table 23 - NR5G Serving cell information

## 6.4.8 Encrypted Debug Information

The Encrypted Debug Information page contains additional information which may be useful when troubleshooting an issue.

To create a debug file navigate to **System > Encrypted Debug Information**.




Figure 76 - Encrypted Debug Information page

### 6.4.8.1 Generate

Click the **Generate** button to create a debug file.

While the generation process is taking place the browser will be unavailable and the message "*Please wait*" will be displayed.

After a few minutes the generation process will end, the browser will become available and the "*Success – Encrypted debuginfo file is generated successfully*" message will be displayed at the top of the page.

### 6.4.8.2 Download

Click the **Download** button to download the new file into your browser's default downloads folder.

The following debug file will be saved in your browser's default downloads folder: **debuginfox.tar.gz**

This debug file is encrypted and can only be decrypted by Casa Systems personnel.



**Note** – The file cannot be decrypted by users.

Normally this file will only be generated if Casa Technical Support requests it.

# Appendix A – Safety and compliance

## RF Exposure

Your device contains a transmitter and a receiver. When it is on, it receives and transmits RF energy. When you communicate with your device, the system handling your connection controls the power level at which your device transmits.

This device meets the government's requirements for exposure to radio waves.

This device is designed and manufactured not to exceed the emission limits for exposure to radio frequency (RF) energy set by the Federal Communications Commission of the U.S. Government.

This equipment complies with radio frequency (RF) exposure limits adopted by the Federal Communications Commission for an uncontrolled environment.

This equipment should be installed and operated with minimum distance 20cm between the radiator& your body.

## FCC Statement

### FCC compliance

Federal Communications Commission Notice (United States): Before a wireless device model is available for sale to the public, it must be tested and certified to the FCC that it does not exceed the limit established by the government-adopted requirement for safe exposure.

### FCC regulations

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This device has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

## Operating temperature

- -40°C to 55°C

## Company details

### Casa Systems, Inc.

100 Old River Road, Andover, Massachusetts 01810 USA

<https://www.casa-systems.com/contact-us/>

## Product details

Product: 5G Sub-6 Self Install Outdoor CPE

Model No: CFW-3212

## Appendix B – Configuring Radio Access Technologies

This device supports the following modes of operations in various combinations

- **LTE** (3GPP Core Network Option 1)
- **5G Non Standalone** (3GPP Core Network Option 3x)
- **5G Standalone** (3GPP Core Network Option 2)

Please refer to the following table to understand which modes of operation are possible and how to configure them.

Mode	Allowed RAT			Supported	How to Configure	
	LTE	5G NSA	5G SA		RAT Selection Menu	Band Selection Menu
LTE Only	Yes	No	No	Yes	Select LTE only	Select LTE Frequency Bands
LTE + 5G NSA	Yes	Yes	No	Yes	Select LTE + 5G NR	Select LTE + NSA Frequency Bands
5G NSA Only	No	Yes	No	No	–	–
LTE + 5G NSA + 5G SA	Yes	Yes	Yes	Yes	Select LTE + 5G NR	Select LTE + NSA + SA Frequency Bands
LTE + 5G SA	Yes	No	Yes	No	–	–
5G NSA + 5G SA	No	Yes	Yes	No	–	–
5G SA Only	No	No	Yes	Yes	Select 5G NR	Select SA Frequency Bands

Appendix table 1 – RAT/Band Selection table

Use this table in conjunction with the settings described in sections *6.2.1.3 RAT selection* and *6.2.1.2 Band selection* of this guide.



Note – 5G Standalone Mode is not supported when utilising mmWave frequency bands.