Bluetooth RS-232 Adapter

User manual for BT-232B and BT-232B-E models





BT Adapter

Model



White Box Dimension: 10.5 x 5.5 x 5 (cm)

Total Package Weight: 110 g





White Box Dimension: 10.5 x 5.5 x 5 (cm)

Total Package Weight: 120 g





1. Packing Contents

1.1 BT-232B Package Contents:


- RS-232 adapter x 1
- Battery power line and connector x 1
- User manual x 1
- USB Cable x 1

1. Packing Contents

1.1BT-232B-E Package Contents:

- RS-232 adapter x 1
- Battery power line and connector x 1
- User manual x 1
- USB Cable x 1
- External Dipole Antenna x 1

- 2. Before using the adapter
- 2.1 For BT-232B-E model, fasten the external antenna to the adapter before performing Quick Guide 3.1
- 2.2 Power input (Please chose one): Mini USB cable (Default) or DB9 connector Pin 9 (VCC, 5VDC, 1.5A Max.) or external battery (3~3.7 VDC Li-Polymer Battery or 3 units standard A, AA or AAA battery)
- 2.3 Most built-in Bluetooth is in class 2, the 10 meters range, for PC or NB. You will need use the class 1 adapters on both sides if you need to reach over 100 meters range.
- 3. Quick Guide
- 3.1 Using the USB cable provided in the package, plug the mini USB connector into the Bluetooth RS-232 adapter then connect it to the power adapter with USB or PC
- 3.2 Turn on the power from the slide switch. The red LED power is on.



3.4 Check the RS-232 setting on 2 sides if they both have the following values:

Baud rate: 19200 bps

Data bit: 8Parity: noneStop bit: 1

Flow control: none
 If not, please modify the setting by using hyper terminal software and the setup command via
 COM port. (See section 11 for the setup commands.)

- 3.5 Two RS-232 adapter connections in a master-slave environment (See section 3.3 for illustration). Upon first connection, it is in slave-mode by default and can be set to master-mode using the setup command (See "ROLE" command in section 11).
- 3.6 If you are using PC or NB, start the IVT software or the built in Bluetooth management software, like Toshiba.

4. How to use external battery

 Standard A, AA or AAA battery: 3 units for each model.



Li-Polymer Battery: 3~3.7 VDC.
 The capacity depends on the applications. General working power consumption: 100 mAh (for reference)



5. Factory Settings for COM port and Bluetooth:

Baud rate: 19200 bps

Data bit: 8Parity: noneStop bit: 1

Flow control: none

Bluetooth PIN code is "1234"
 Bluetooth default setting: To inquire default values, see section 11 for the setup command.

- 6. Reset Button (Pressed with a clip or pin into the hole)
- 6.1 Disconnect and reconnect a wireless connection (after a short press).
- 6.2 Restore the factory settings (after over three seconds' press).

7. Slide Switch

Use the slide switch to swap between DTE/DCE. By switching, you can set the adaptor either as a DTE (towards antenna connector) or a DCE (towards RS232 connector).

- 8. Power Supply: The adaptor can be powered via the following source.
- 8.1 USB cable
- 8.2 External Battery: Please refer to section 4.

LED Status:

Status	Description	
Power LED off	No power supply.	
Power LED on	The power input is equal or larger than 3.5	
	Volt (Please check the command "DETECT")	
Power LED (0.5 sec) blinking	The power input is lower than 3.5 Volt	
	(Please check the command "DETECT")	
Link LED off	No pairing established.	
Link LED fast (0.1 sec) blinking	Pairing (slave or master mode).	
Link LED foot (0.2 goo) blinking	Discoverable and waiting for a	
Link LED fast (0.3 sec) blinking	connection (slave mode).	
Link LED slow (0.9 sec) blinking	Inquiring (master mode).	
Link LED very slow (1.2 sec) blinking	Connecting (master mode).	
Link LED steadily on	Connection established.	

- 10. Configuration the parameters of the COM port
- 10.1 Configure via Hyper terminal, Telnet or other COM port tool freeware.
- 10.2 Use the downloadable Bluetooth Serial Adapter's configuration software provided by the distributor.

11. Setup Command set (Please type in all capital letter or all lowercase letter)

Command	Value	Description		
<<<		Set the local adapter change the data mode into command mode.		
		The command will be unavailable if the data pass through within 1		
		second when after set the command. Switch the data mode to the command.		
<<<		The time interval between each character will be more than the		
	?	time: [500ms] "<" [500ms] "<" [500ms] "<" [1500ms]		
<<<=	Y	Inquire the current setting. Turn on the "<<<" command		
(Default)	N	Turn off the "<<<" command		
	IN	Set the remote adapter change the data mode into command mode from		
>>>		the local adapter in connecting status. The command is available after		
		500 ms when data transferring finished.		
>>>		Switch the remote adapter from the data mode to the command.		
		The time interval between each character will be more than the		
		time: [1 sec] "<" [1 sec] "<" [2 sec]		
>>>=	?	Inquire the setting status of the ">>>" command.		
(Default)	Υ	Turn on the ">>>" command		
	N	Turn off the ">>>" command		
ADDRESS=		This command is used to display the Bluetooth address of the local		
		adaptor.		
	?	Inquire the Bluetooth address of the local adaptor.		
AT		Check the connection status between control terminal and the RS-232		
		adapter. Response: "OK" when the connection is ok. Response:		
ΛΤ		"ERROR" when the connection is not ok.		
AT AUTO=		Test the RS-232 status when first connect the adapter with the contraction for the con		
AUTO=		This command is used to enable/disable auto-connection feature. It is available only when the adaptor is in the master role.		
The		The command is available when DIP=N. The system will not re-start		
		after change.		
	Υ	The Master role adapter will connect the latest paired Bluetooth device		
		automatically.		
(Default)	N	The user will connect the Bluetooth device manually.		
,	?	Inquire the current setting.		
BAUD=		This command is used to specify the baud rate of COM port.		
		The command will need 200 ms delay.		
	1200	1200 bps		
	2400	2400 bps		
	4800	4800 bps		
9600		9600 bps		
(Default)	19200	19200 bps		
	38400	38400 bps		
	57600	57600 bps		
	115200	115200 bps		
	230400	230400 bps		
	460800	460800 bps		

er Manual V2.6	1	Date. 2013.06.29			
	921600	921600 bps			
	R	Restore the default settings. (Baud rate =19200 bps)			
	?	Inquire the current baud rate.			
CONNECT=		This command is used to establish a connection manually. It is available			
		only when the adaptor is in the master role.			
	DEVICE	Connect the adaptor to a specified Bluetooth device manually.			
		It is available only when "DEVICE=xxxxxxxxxxxx" is executed.			
	1~8	Connect the adaptor to a Bluetooth device in the neighborhood found through "SEARCH=?"			
	xxxxxxxxxx	Connect the remote adapter by type the MAC address directly without searching.			
	?	Display the MAC address of the latest paired device.			
	Υ	Recover the latest connection in the command mode.			
	N	Disconnect the two adapters in the command mode			
	Р	Connect the previous connected adapter.			
DEFAULT=		This command is used to restore the default settings and originate a warm start.			
	Υ	Restore the default settings (e.g. 19200 bps).			
		The command will re-start the system for 1 second.			
DETECT=		The command is used to detect the voltage of the power supply and set			
(5 (1)	N	the alert value of low power.			
(Default)	Y	Disable the voltage detection Enable the voltage detection			
	R	Restore the default value (3.5 Volt)			
	X.X	Setup the range of voltage detection from 3.0 to 3.7 Volt. The "x" indicate			
	^.^	the number.			
	?	Inquire the setting ststus			
DEVICE=		For security purpose, this command is used to specify a unique			
		remote Bluetooth serial adaptor to be connected.			
		In the master role, the adaptor pairs and connects with the designated			
		remote slave address. If the adaptor is in the slave mode, this command			
		is a filter condition to accept the inquiry of the master device.			
xxxxxxxxxxx		"xxxxxxxxxxx" is a string of 12 hexadecimal digits.			
	R	Restore the status in which the adaptor can connect with any remote address.			
	?	Inquiry the designated address that can be paired and connected.			
DFU=		Device Firmware Upgrade			
	Υ				
DIP=		Set the DIP switch function.			
	?	Inquire the setting status of the DIP switch function.			
	Υ	Turn on the function of the DIP switch. The "ROLE" and "AUTO"			
		command are not available to set the "Master" or "Slave".			
(Default) N Turn off the function of the DIP switch. The "ROLE		Turn off the function of the DIP switch. The "ROLE" and "AUTO"			
		command are available when the DIP=N.			
DISCOVER=		This command is used to specify whether the adaptor can be discovered			
		or connected by remote devices.			
		This command is available only when the adaptor is in the slave role.			
	N	The adaptor enters the undiscoverable mode. If a pair has been made,			
		the original connection can be resumed. But other remote master device			

er Manual V2.6		Date. 2013.06.29			
		cannot discover this adaptor.			
(Default)	Υ	The adaptor enters the discoverable mode.			
	?	Inquire the current setting.			
ECHO=		This command is used to specify whether the adaptor echoes			
		characters received from the UART back to the DTE/DCE.			
	N	Command characters received from the UART are not echoed back to			
		the DTE/DCE.			
(Default)	Y	Command characters received from the UART are echoed back to the			
		DTE/DCE.			
	?	Inquire the current setting.			
FLOW=		This command enable or disable flow control signals (CTS/RTS) of the			
		UART port. Note, the setting is not affected by DEFAULT.			
		The command will need 1 second delay.			
(Default)	N	Disable flow control.			
	Υ	Enable flow control.			
	?	Inquire the current setting			
NAME=		This command is used to specify a name for the adaptor.			
		You can specify a friendly name using 0 to 9, A to Z, a to z, space and –,			
		which are all valid characters. Note that "first space or -, last space or -			
		isn't permitted". The default name is "Serial Adaptor".			
(Default)	Serial	Default device name			
	Adaptor				
	xxxx	"xxxx" is a character string with the length from 2 to 30.			
	R	Restore the default settings name="Serial Adaptor".			
?		Inquire the name of the local adaptor.			
PARITY= This command is		This command is used to specify parity bit setting of COM port.			
		The command will need 200 ms delay.			
(Default) N		None parity bit			
	0	Odd parity			
	E	Even parity			
	?	Inquire the current setting.			
PIN=		This command is used to specify a PIN. The default PIN is "1234".			
		Paired adaptors should have a same PIN. This command is used to			
		specify a PIN. The default PIN is "1234" and the length is not smaller			
		than 4. Paired adaptors should have a same PIN. The PIN code			
		includes the numeral and English characters.			
(Default)	1234				
	xxxx	"xxxx" is a 4~16 digit string or English character (in capital or lower			
		case)			
	N	Cancel authentication by PIN.			
	R	Restore the default settings PIN="1234".			
	?	Inquire the current PIN.			
PROMPT= The cor		The command is used to decide whether result messages are prompted			
		when Setup commands are executed. The result messages are:			
		OK/ERROR for command execution, or CONNECT/DISCONNECT/Try			
		Connect Device for connection status.			
(Default)	Y	Prompt result messages.			
	N	Not prompt result messages.			
	?	Inquire the current setting.			

RECONNECT=		The command is used to re-connect the lost link for the Master adapter.	
	?	Inquire the current setting.	
	Υ	Re-connect is Enable	
(Default)	N	Re-connect is disable	
ROLE=		This command is used to specify whether the adaptor is in the master or	
		slave role. If the device role is changed, the adaptor will reboot and all	
		paired addresses will be cleared. The command is available when the	
		adapter is in DIP=N status. The command will need 1 second delay.	
	M	Set the adaptor to the master role.	
(Default)	S	Set the adaptor to the slave role.	
	?	Inquire the current role of the adaptor.	
RSSI=		Received signal strength indication	
	?	Display the Received signal strength indication in command mode when	
		connected.	
		1. Strong: RSSI>-9	
		2. Medium: -9>RSSI>-20	
		3. Weak: RSSI<-20	
SEARCH=		This command is used to search for any Bluetooth device in the	
		neighborhood within one minute. If any device is found, its name and its	
		12-digit-address will be listed. The search ends with a message "Inquiry	
		ends. xx device(s) found." This command is available only when the	
		adaptor is in the master role by manual.	
	?	Inquire Bluetooth devices in the neighborhood, listing 8 devices the	
OTATUO		maximum	
STATUS=		Inquire all the current setting of the adapter.	
	Т	Inquire the inner temperature of the IC in centigrade	
	?	Display the current setting of the adapter	
STOP=		This command is used to specify one or two stop bits of COM port.	
		The command will need 200ms delay.	
(Default)	1	One stop bit.	
	2	Two stop bits.	
	?	Inquire the current setting.	
VERSION=	This command is used to inquiry the firmware version.		
	?	Inquire the version codes.	

Remark: If you need to customized the command, please call.


12. Command is not available in the status:

No	Command	Not available command in the conditions		
1	ROLE=S	SEARCH=?, CONNECT=?, CONNECT=P, CONNECT=xxxxxxxxxxxxxxxx,		
		CONNECT=DEVICE		
2	AUTO=Y	SEARCH=?, CONNECT=?, CONNECT=P, CONNECT=xxxxxxxxxxxxxxxx,		
		CONNECT=DEVICE		
3	DIP=Y	ROLE=M, ROLE=S , AUTO=Y , AUTO=N , DISCOVER=Y, DISCOVER=N		
4	<<<	SEARCH=?, CONNECT=?, CONNECT=P, CONNECT=xxxxxxxxxxxxxxxx,		
		CONNECT=DEVICE , DFU=Y		
5	>>>	SEARCH=?, CONNECT=?, CONNECT=P, CONNECT=xxxxxxxxxxxxxxxx,		
		CONNECT=DEVICE , DFU=Y		

	6	Not connection	RSSI=?	CONNECT=Y	CONNECT=N
--	---	----------------	--------	-----------	-----------

13. RS232 Interface


13.1 Pin-out:



13.2 Signals:

Pin	Signal	DTE Direction	DCE Direction	Description
1	CD	Input	Output	Not connected
2	TxD	Output	Input	Transmitted data
3	RxD	Input	Output	Received data
4	DSR	Input	Output	Contact manufacturer to set this
5	GND	N/A	N/A	Signal ground
6	DTR	Output	Input	Contact manufacturer to set this
7	CTS	Input	Output	Clear to send
8	RTS	Output	Input	Request to send (Default)
9	Vcc	Input	Input	Power supply (5VDC, 1.5A Max.)

14. DSR/DTR Connection:



15. Example: Procedures for auto link and in group which will be undiscoverable

STEP1: Set slave part, PIN= "your password for pairing"

STEP2: Set master part, ROLE=M, PIN= "your password for pairing", RECONNECT=Y, AUTO=Y

STEP3: Search the neighboring Bluetooth devices and wait for link after pairing

STEP4: Set slave part, DISCOVER=N

If you need more than two sets in the same space, please set the different PIN code for each pairs. They will connect the paired units when the power on.

Specification	Description		
Baud Rate	Support 1.2/2.4/4.8/9.6/19.2/38.4/57.6/115.2 Kbps		
Coverage	Up to 100 m		
Connection	Point-to-point (pico net)		
Signal	TxD, RxD, GND, CTS/RTS, and DSR/DTR		
RS-232 Interface	D SUB 9-pin female		
Standard	Bluetooth specification version 2.0+EDR		
Profiles	Serial Port Profile and Generic Access Profile		
Data Bit	8 bit		
Frequency	2.400 to 2.485 GHz		
Hopping	1,600/sec, 1MHz channel space		
Modulation	GFSK-1 Mbps, DQPSK-2 Mbps, and 8-DPSK-3 Mbps		
Tx. Power Max. 12.91 dBm			
Rx. Sensitivity -86 dBm typical			
Antenna Omni Antenna			
Antenna Gain Omni Antenna max. 2dBi			
Power Supply +5 to +6V DC			
Current Consumption Max. 90 mA			
Operation	-20°C to +75°C		
External Battery Input	3~5 VDC input		
	3.3 VDC Rechargeable Li-Polymer Battery or AAA x 3		
Dimension 30 mm(W) x 45mm (H) x 15mm (D)			

Federal Communications Commission (FCC) Statement RADIO FREQUENCY INTERFERENCE STATEMENT

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try correcting the interference by one or more of the following measures:

- Reorient the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into and outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: A shielded-type power cord is required in order to meet FCC emission limits and also to prevent interference to the nearby radio and television reception. It is essential that only the supplied power cord be used.

You are cautioned that changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.

It is necessary to keep ≥20 cm safety distance from product operating.

Declaration:

- The information contained in this document is subject to change without notice.
- 2. Document Release V2.6, Date: 2013.08.29
- 3. Firmware Version: V 4.6.3 FCC ID: XJ8-BT-232B (CCAB09LP2610T2 C 1177