## **Operational Description**



## 1. Network

: Wi-Fi, Wired network. The default setting is Wired network.

To use WIFI, you need to set Wi-Fi and press the OK( button.

## 2. IP Setting

: Dynamic IP(DHCP), Static IP. The default setting is DHCP.

DHCP: IP-subnet mask and Gateway are not used because the DHCP server assigns these parameters.

To apply DHCP,

1. In IP setting option, choose DHCP IP and press the OK( button.

2. Select the setup below to apply the configuration.

Static IP: The system's IP-address, IP-subnet mask and Gateway must be specified in the IP-address.

## To apply Static IP,

- 1. In IP setting option, choose Static IP and press the OK( button...
- 2. Input information IP address, subnet, gateway, DNS1 and DNS2
- 3. Select the setup below to apply the configuration.

