RCL-T700 Manual

A. EASY INSTALLATION INSTRUCTION

- Step ① Lock the antenna to the right corner of the 3-On-Call Transmitter.

 (Fit over plug and twist left to lock antenna in place)
- Step 2 Plug the 3-On-Call Transmitter A/C adaptor into the 3-On-Call Transmitter and then into a standard outlet. A surge protector is recommended.
- Step 3 Fit the pagers on the chargers. A charging indicator will illuminates to indicate charging. Pager will be fully charged in 2 hours.

B. SYSTEM SETTING

To enter programming mode, press the "SETUP" button and enter the password "0987" followed by "ENTER" If the password is accepted, the display will show " Menu Option F1:Up F2:Down

Use the "F1" or "F2" key to scroll through the several menu options or press "CANCEL" key to exit the system setting menu.



1. Set Time

With this feature, you can setup current time into the RCL transmitter.

- At the "Set Time" menu, set the hour using "No." key and then press "ENTER" key.
- Then set the minutes using "No." key and press "ENTER" key.
- Press "No.1" key to select "AM", "No.2" is to select "PM". After selection of it, then
 press "ENTER" key
- After the correct time is set, press the "ENTER"

2. Set Alerts

With this feature, you can have the option of changing the way your pagers alert.

To change the alert mode of your pagers, follow these instructions:

- Remove all the pagers from the charger base or unplug the power supply that is connected to the charger base.
- At the "Set Alerts" menu, press the "ENTER" key
- If the "Change?" menu appears, press "No.1" key to select "Yes", "No.2" key is to select "No", then press "ENTER" key (press "CANCEL" key, and return to the main menu)
- Select one of 1~6 Alert modes, then press "ENTER" key.
 1) Vibration 2) Beef 3) Flash 4) Vib/Flash 5) Beep/Flash 6) Beep/Vib/Flash (Use the "F1" key to scroll through these 6 alert modes)
- The pagers will now respond with your new selected alert mode.
- Return all the pagers to the charger base or plug the power supply. The pagers are ready to receive the page with its new alert mode.

3. Set Alert Time

With this feature, you can set the alert time, how long the pager alerts, when the pager receive the signal from the transmitter.

To change the Alert time mode of your pagers, follow these instructions :

- Remove all the pagers from the charger base or unplug the power supply that is connected to the charger base.
- At the "Set Alerts Time" menu, press "Enter" key.
- If the "Change?" menu appears, press "No.1" key to select "Yes" or "No.2" key to select "No". Then press "ENTER" key. (Press "CANCEL" key to exit, and return to the main menu)

- Select one of 1~8 Alert time modes, then press "ENTER" key
 1) 06 SEC 2) 30 SEC 3) 45 SEC 4) 60 SEC 5) 90 SEC 6) 120 SEC 7) 180 SEC 8) Continuance
 (Use the "F1" key to scroll through the 8 alert time modes)
- The pagers will now respond with your new selected alert time mode.
- Return all the pagers to the charger base or plug the power supply. The pagers are ready to receive the page with its new alert mode.

4. Out of Range

With this feature, the pagers will play a melody when taken out of range from the transmitter to inform the guest that they are located "Out of Range" and will miss their page. The melody will only stop, when they return back within range.

To turn the Out of Range "USE" or "NOT"

- Remove all the pagers from the charging unit or unplug the power supply that is connected to the charger base
- At the "Out of Rng" menu, press "Enter" key.
- Press "No.1" key, then "ENTER" key to turn the Out of Range "USE" ("No.2" key is to select "NOT")
- Return all the pagers to the charger base or plug the power supply. The pagers
 are ready to receive the page with its new message mode.

5. Auto MSG

With this feature, you can choose if you will send some designated messages.

- Remove all the pagers from the charger base or unplug the power supply that is connected to the charger base.
- At the "Auto MSG" menu, press "ENTER" key
- Then press "No.1" key, then "ENTER" key to select "USE".
 ("No.2" key is to select "NOT")
- Return all the pagers to the charger base or plug the power supply. The pagers are ready to receive the page with its new message mode.

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES.

OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS:

(1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND

(2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED,

INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRED OPERATION. IQ TRANSCEIVER INSTRUCTION MANUAL

NOTE: THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THIS EQUIPMENT. SUCH MODIFICATIONS COULD VOID THE USER S AUTHORITY TO OPERATE THE EQUIPMENT.

NOTICE

This manual, software and electronic circuitry are copyrighted. All rights reserved. Under the copyright laws, this manual, software and electronic circuitry may not be copied, in whole or in part without written prior consent of Lee Technology.

All information provided in this document is carefully prepared and offered in good faith as a guide in the installation, use and servicing of our products. Installers must ensure that the final installation operates satisfactorily within the relevant regulatory requirements. Lee Technology accepts no responsibility for incorrect installation. Lee Technology reserves the right to change products, specifications and installation data at any time without notice.

Lee Technology makes certain limited warranties with respect to defective diskettes, documentation and electronic circuitry. Please see the associated information contained on this page.

LIMITED WARRANTY

With respect to the physical documentation and physical electronic circuitry enclosed herein, Lee Technology warrants the same to be free of defects in materials and workmanship for a period of one year from the date of purchase. In the event of notification within the warranty period of defects in material or workmanship, Lee Technology will replace the defective diskettes, documentation and electronic circuitry. The remedy for breach of this warranty shall be limited to replacement and shall not encompass any other damages including but not limited to loss of profit and special incidental, consequential, or other similar claims.

Lee Technology Korea specifically disclaims all other warranties, expressed or implied, including but not limited to implied warranties of merchantability and fitness for a particular purpose with respect to defects in the documentation and electronic circuitry and the program license granted herein, in particular, and without limiting operation of the program license with respect to any particular application, use or purpose.

IMPORTANT SAFTEY INFORMATION

RF EXPOSURE STATSURE STATEMENT

Your Pager Transmitter contains a radio frequency transmitter.

When the button is pushed the transmitter sends our RF singnals.

CAUTION: To comply with FCC RF exposure compliance requirements,

A separation distance of at least 8 inches(20Cm) must be maintained

Between the antenna of this transmitter and all persons, during

Normal operation. The antenna used for this transmitter must not be co-

Located or operating in conjunction with any other antenna of transmitter.

Unauthorized antennas, modifications, of attachments could damage the

Transceiver and may violate FCC regulations.

NOTE: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful

interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.