

# Portable Bluetooth® **Transmitter**



We hope you enjoy your Portable Bluetooth® Transmitter from RadioShack. This transmitter enables devices without Bluetooth capabilities to connect to Bluetooth-enabled devices. For example, you can wirelessly connect a phone or MP3 player to a Bluetooth-enabled speaker or headphones. Please read this user's guide before using your new transmitter.

# Package Contents

- Portable Bluetooth Transmitter
- Micro-USB Charging Cable
- User's Guide

## **Specifications**

Battery Chemistry	Built-in 500mAh	L
Bluetooth Protocol		Lit ·
Battery Charging Time	2.5 hours	•
Play Time		
Operation Range	32.8 ft. (10m)	

Specifications are subject to change and improvement without notice. Actual product may vary from the images found in this document.

# **Charge Your Transmitter**

The charging indicator lights red when charging and turns off when fully charged. Unplug the charging cable when the transmitter is fully charged.

**Note:** When the battery is low, the charging indicator flashes red. The transmitter powers off if not charged within 5 minutes.



#### ithium Battery Notes:

- Recycle lithium batteries. Do not dispose of them in the trash.
- Do not burn or bury batteries. Do not puncture or crush. Do not
- Charge batteries on a fireproof surface away from flammable items or liquids.
- Do not charge inside an automobile, especially while driving
- If the electrolyte in the cells should get on your skin, thoroughly wash with soap and water. If in the eyes, rinse thoroughly with cool water. Immediately seek medical attention.
- Follow the instructions for charging the transmitter and do not charge longer than recommended. Unplug the USB cable when the battery is charged.

### **Use Your Transmitter**



- 2. Turn on your speaker and make sure your speaker is in pairing mode (refer to your speaker's user's quide). The transmitter pairs automatically, and the Bluetooth indicator lights steadily.
- your audio device's 3.5mm headphone jack.
- 4. Use your audio device's playback controls.
- 5. Turn off your transmitter after use.

## Device Not Pairing?

Many Bluetooth-enabled devices, such as

3. Plug your transmitter's built-in cable into

speakers, remember the most recently paired source (music, smartphone, etc.) and automatically reconnect when turned on. This is convenient, but can prevent you from connecting to a new source.

If you can't pair your transmitter, you may need to disconnect it from its previous source.

# If the previously paired speaker is not available. press the **Pairing** button to search for your To clear your transmitter's pairing history,

- press and hold the **Pairing** button for 2 seconds (Bluetooth indicator flashes 5 times). If no speaker is connected within 10 minutes.
- the transmitter automatically enters sleep mode (Bluetooth indicator turns off). To resume searching, turn the transmitter off, then on again.
- The transmitter will disconnect from your speaker if they are too far apart (Bluetooth indicator flashes quickly). To reconnect, move the transmitter closer to the speaker within 1 minute.
- Nearby Bluetooth devices can interfere with vour transmitter's connection. If this happens. move other Bluetooth devices at least 32.8 ft. (10m) from your transmitter.

#### FCC Information

Notes:

the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a

residential installation. This equipment generates, uses. and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult your local RadioShack store or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment This device complies with Part 15 of the FCC Rules.

(1) this device may not cause harmful interference, and (2) this device must accept any interference received. including interference that may cause undesired operation

# **Limited Warranty**

materials and workmanship under normal use by the original purchaser for ninety (90) days after the date of purchase from a RadioShack-owned store or an authorized RadioShack franchisee or dealer. RADIOSHACK MAKES NO OTHER EXPRESS WARRANTIES.

This warranty does not cover: (a) damage or failure caused by or attributable to abuse, misuse, failure to follow instructions, improper installation or maintenance, alteration, accident. Acts of God (such as floods or lightning), or excess voltage or current; (b) improper or incorrectly performed repairs by persons who are not a RadioShack Authorized Service Facility: (c) consumables such as fuses or batteries; (d) ordinary wear and tear or cosmetic damage; (e) transportation, shipping or insurance costs; (f) costs of product removal, installation, set-up service, adjustment or reinstallation; and (q) claims by persons other than the original purchaser. Should a problem occur that is covered by this warranty. take the product and the RadioShack sales receipt as

proof of purchase date to any RadioShack store in the U.S. contact RadioShack at: RadioShack will, at its option, unless otherwise provided by RadioShack Customer Relations law (a) replace the product with the same or a comparable 300 RadioShack Circle Fort Worth, TX 76102 product, or (b) refund the purchase price. All replaced products, and products on which a refund is made.

become the property of RadioShack. Operation is subject to the following two conditions: RADIOSHACK EXPRESSLY DISCLAIMS ALL WARRANTIES AND CONDITIONS NOT STATED IN THIS LIMITED WARRANTY. ANY IMPLIED WARRANTIES

IMPLIED WARRANTY OF MERCHANTABILITY AND, IF APPLICABLE, THE IMPLIED WARRANTY OF FITNESS. The Bluetooth® word mark and logos are owned by FOR A PARTICULAR PURPOSE, SHALL EXPIRE ON THE RadioShack warrants this product against defects in

HAVE NO LIABILITY OR RESPONSIBILITY TO THE

PURCHASER OF THE PRODUCT OR ANY OTHER

PERSON OR ENTITY WITH RESPECT TO ANY LIABILITY.

LOSS OR DAMAGE CAUSED DIRECTLY OR INDIRECTLY

THAT MAY BE IMPOSED BY LAW, INCLUDING THE

Bluetooth SIG. Inc. and any use of such marks by EXPIRATION OF THE STATED WARRANTY PERIOD. RadioShack Corporation is under license. EXCEPT AS DESCRIBED ABOVE, RADIOSHACK SHALL

> ©2014 RadioShack Corporation. All rights reserved. RadioShack is a registered trademark used by RadioShack Corporation.

and products.

BY USE OR PERFORMANCE OF THE PRODUCT OR

ARISING OUT OF ANY BREACH OF THIS WARRANTY

INCLUDING, BUT NOT LIMITED TO, ANY DAMAGES

OF THE POSSIBILITY OF SUCH DAMAGES.

RESULTING FROM INCONVENIENCE AND ANY LOSS OF

INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL

DAMAGES, EVEN IF RADIOSHACK HAS BEEN ADVISED

Some states do not allow limitations on how long an

implied warranty lasts or the exclusion or limitation of

warranty gives you specific legal rights, and you may also

have other rights which vary from state to state. You may

www.RadioShack.com

Directive," which protects the environment

by restricting specific hazardous materials

**RoHS** Complies with the European Union's "Restriction of Hazardous Substances"

incidental or consequential damages, so the above

limitations or exclusions may not apply to you. This

TIME, DATA, PROPERTY, REVENUE, OR PROFIT AND ANY

in China 1201669

12/12/2014 3:18:26 PM

1201669 UG EN.indd 1-9

ON/OFF

- Charging

Bluetooth