



Quick Reference Guide

STP9000 series hand-portable radio



STP9000 STP9100*

* Same as the STP9000, without a keypad.




1 Antenna

6

- 2 Earpiece for full-duplex calls. Microphone for half-duplex calls
- 3 Blue LED
- 4 Missed Events key (soft key)
- 5 Colour display with backlight
 - Right context key
- 7 Red key (Cancel/Home)
- 8 Microphone for full-duplex calls
- 9 Alphanumeric keypad with backlight and loudspeaker behind


- 10 Green key (Select/Send)
- 11 Left context key
- 12 Navigation keys
- 13 PTT (Press-To-Talk) button
- 14 Soft key
- 15 Mode/Power key
- 16 Tri-Coloured LED
- 17 Navi-knob
- 18 Emergency button

STP9200



- 1 Antenna
- 2 Earpiece for full-duplex calls. Microphone for half-duplex calls
- 3 Blue LED
- 4 Missed Events key (soft key)
- 5 Monochrome display with backlight
- 6 Soft key
- 7 Red key (Cancel/Home)
- 8 Function keys I, II, III
- 9 Loudspeaker for half-duplex calls

- 10 Microphone for full-duplex calls
- 11 **Green** key (Select/Send)
- 12 Navigation keys
- 13 PTT (Press-To-Talk) button
- 14 Soft key
- 15 Mode/Power key
- 16 Tri-Coloured LED
- 17 Navi-knob
- 18 Emergency button



- 19 RFID tag
 22 Accessory attachment point
 20 Battery
 23 Rugged Accessory Connector (RAC)
 24 Fability approaches
 24 Fabruary approaches
- 21 Facility connector 24 External antenna connector

Power on Press and hold (2 seconds) the Mode key.

Power off From the Home screen, press and hold (2 seconds) the

Mode key, then follow the instructions to power off.

Adjust the volume

Rotate the Navi-knob.

Home screen The Home screen displays when the radio powers

on and when it is idle. To quickly return to the Home screen from any other screen, press and hold (2

seconds) the **Red** key.

Lock Keypad

STP9000: From the Home screen, press the * Star key, then press the **OK** context key. To unlock the keypad, press the * Star key, then press the **OK** context key.

Menu To enter the menu, from the Home screen press the

Menu context key or the **Down** navigation key. Use the navigation keys to scroll through the menus and options. To open a sub-menu or menu option, select it (highlight it) and press the **Select** context key or the **Green** (k) key. To return to a higher level menu, press

the Back context key or Red 3 key.

Invert the display

From the Home screen, press the **Menu** context key or the **Down** navigation key. Select **Options > Settings > Display Settings > Invert Display**. Press the **Toggle** context key or the **Green** (key to switch between normal and inverted display. A tick appears in the check box when the display is inverted.

Activating a soft key

Special features such as SmartMenus can be assigned to a soft key. To activate a soft key function, press and release a programmable side button. **STP9000:** Press and hold (1 second) any one of the 0-9, * and # keys to activate a soft key function. **STP9200:** Press and hold (1 second) any of the Function keys.

Alarm Call

WARNING! Do not hold the radio close to your ear. Press and hold (2 seconds) the Emergency button. Press the PTT button and speak into the top microphone. If your radio is customised for 'live microphone' you can speak without holding the PTT button for a short period of time.

Make a Group call

WARNING! Do not hold the radio close to your ear. Press and hold the PTT button and speak into the top microphone. When you have finished speaking, release the PTT button to listen to the other radio users through the loudspeaker. To end the call, press the Red | key.

Make an individual half-duplex call

WARNING! Do not hold the radio close to your ear. From the Home screen, press the Menu context key or the Down navigation key. Select Phone > Contacts to open the contacts menu. Use the navigation keys to scroll to the *All Folder* and select your contact. Press the Open context key or the Green key, then choose the phone number and press the PTT button to make the call. To end the call, press the Red key.

Make an individual full-duplex call

From the Home screen, press any of the alphanumeric keys to launch the dial box, then enter the number required and press the **Green** key to initiate the call. Alternatively press the **Menu** context key or the **Down** navigation key, then select **Phone** > **Contacts** to open the contacts menu. Use the navigation keys to scroll to the **All Folder** and select your contact. Press the **Open** context key or the **Green** key, then choose the phone number. Press the **Dial** context key or the **Green** key to initiate the call. To end the call, press the **Clear** context key or the **Red** key.

Send a Status message

Press the **Mode** key 2 times. Use the navigation keys to scroll through the status messages. To send the message, press the **Send** context key or the **Green** key, then select the **Send to Default** option (or choose another destination such as your talkgroup, a contact in your phone book or dial the number). Press the **Select** context key or the **Green** key to send the message.

Send a text message

From the Home screen, press the **Menu** context key or the **Down** navigation key. Select **Messages > Create Message**. An empty message box appears. To send your message, press the **Green** (key, then select the **Send to Default** option. Press the **Select** context key or the **Green** (key to send the message.

Change the talkgroup

From the Home screen, press the **Mode** key to open the current folder and talkgroup in the selection box. Rotate the **Navi-knob** to scroll through the talkgroups in the current folder. If you want to change to a talkgroup in another folder, use the navigation keys to navigate through the folders (and sub-folders). Press the **Green** (key to attach to the talkgroup.

Change the talkgroup folder

From the Home screen, press the **Mode** key to open the current folder and talkgroup in the selection box. The Talkgroup Selection box appears showing the current selected talkgroup and folder.

Use the **Up** and **Down** navigation keys to scroll through the folder levels (sub-folders). Use the **Right** and **Left** navigation keys to scroll through more folders at the same level. Press the **Green** key to select the new folder. You must choose a talkgroup from that folder as your selected talkgroup.

LED indicators

Green: The radio is in a call and receiving.

Red: The radio is in a call and transmitting.

Red (flashing): You are receiving an Alarm call from another

radio user or the radio is attempting to connect

to the network or the battery charge level is .

low.

Orange (flashing): Incoming telephone call or SDS/Status

message.

Orange (intermittent four flashes):

Transmit Inhibit mode is active. The radio

cannot transmit.

Blue (flashing): You have missed a call or there are unread

messages in your Inbox or Bluetooth™ is

enabled.

Status Icons

9000 9100	9200	Description	9000 9100	9200	Description
4		Alarm call in progress		×	Missed DMO call
-	⊭	Outgoing TMO call in progress	X		New message in Inbox (unread)
*	He	Incoming TMO call in progress		*	Transmit Inhibit enabled
*	₩÷	Missed TMO call	M	ŗ	Keypad locked
	晶-围	Scanning enabled (TMO)	•	٠	Connector Protector enabled
	H←	Incoming DMO call in progress	M	¥	Connector Protector disabled
	⊯∻⊯	Outgoing DMO call		ŧ	Low battery warning