

# Contents

<b>1 SAFE USE AND CAUTIONS .....</b>	<b>3</b>
1.1 PLEASE COMPLY WITH THE FOLLOWING CAUTIONS WHEN USING THE PHONE.	3
1.2 PLEASE COMPLY WITH THE FOLLOWING CAUTIONS WHEN USING THE BATTERY.	4
1.3 PLEASE COMPLY WITH THE FOLLOWING CAUTIONS WHEN USING THE CHARGER.	6
<b>NOTICE BEFORE THE USE .....</b>	<b>6</b>
2.1 SIM CARD.....	6
2.2 BATTERY.....	7
2.2.2 Charge the Battery .....	9
2.3 T-FLASH CARD.....	9
2.4 USB CONNECTION CABLE.....	10
2.5 SECURITY PASSWORD .....	10
2.5.1 PIN Code (4 to 8 digits).....	10
2.5.2 PIN Code 2 (4 to 8 digits).....	10
2.5.3 PUK Code .....	10
2.5.4 Phone Password .....	11
<b>3 SUMMARY OF THE PHONE.....</b>	<b>11</b>
3.1 PHONE APPEARANCE.....	11
3.2 KEYSTROKE FUNCTION .....	11
3.3 ICON .....	11
<b>4 BRIEF INTRODUCTION TO MAIN FUNCTIONS OF THE PHONE</b>	<b>12</b>
<b>5 BASIC OPERATION OF THE PHONE .....</b>	<b>12</b>
5.1 POWER ON .....	12
5.1.1 Power on.....	12
5.1.2 Input pin code .....	13
5.2 POWER OFF.....	13
5.3 MAKE A PHONE CALL .....	13
5.3.1 Dial a Call .....	13
5.3.2 Emergency Call .....	14
5.3.3 Dial an International Call .....	15
5.3.4 Dial Recent Calls.....	15
5.3.5 Speed Dial.....	15
5.3.6 Call Receiving .....	15
5.3.7 Missed Call .....	16
5.3.8 Additional Function in the call.....	16

<b>5.4 TEXT INPUT .....</b>	<b>17</b>
<b>5.4.1 ABC/abc Input Method.....</b>	<b>17</b>
<b>5.4.2 Number Input Method .....</b>	<b>17</b>
<b>5.4.3 Handwritten input Method .....</b>	<b>17</b>
<b>6 MENU FUNCTION.....</b>	<b>17</b>
<b>6.1 PHONE BOOK .....</b>	<b>17</b>
<b>6.2 INFORMATION.....</b>	<b>19</b>
<b>6.3 SPEED DIAL .....</b>	<b>20</b>
<b>6.4 CALL LOG .....</b>	<b>21</b>
<b>6.5 SILENT MODE.....</b>	<b>22</b>
<b>6.6 BLUETOOTH .....</b>	<b>22</b>
<b>6.7 MMS .....</b>	<b>23</b>
<b>6.7.1 Mms.....</b>	<b>23</b>
<b>6.7.2 Voice Inbox.....</b>	<b>24</b>
<b>6.7.3 Cell Broadcast.....</b>	<b>24</b>
<b>6.8 MULTIMEDIA .....</b>	<b>25</b>
<b>6.8.1 Camera.....</b>	<b>25</b>
<b>6.8.2 Video Recorder.....</b>	<b>26</b>
<b>6.8.3 Audio Player.....</b>	<b>26</b>
<b>6.8.4 Video player.....</b>	<b>28</b>
<b>6.8.5 Sound recorder .....</b>	<b>28</b>
<b>6.8.6 Photo book .....</b>	<b>29</b>
<b>6.9 ORGANIZER.....</b>	<b>29</b>
<b>6.9.1 Calendar .....</b>	<b>29</b>
<b>6.9.2 Calculator .....</b>	<b>30</b>
<b>6.9.3 file manager.....</b>	<b>31</b>
<b>6.9.4 Alarm.....</b>	<b>31</b>
<b>6.9.5 Tasks .....</b>	<b>31</b>
<b>6.10 SCENE MODE .....</b>	<b>31</b>
<b>6.10.1 Activate .....</b>	<b>32</b>
<b>6.10.2 Personal Settings.....</b>	<b>32</b>
<b>6.11 SETTINGS.....</b>	<b>32</b>
<b>6.11.1 Pen calibration .....</b>	<b>32</b>
<b>6.11.2 Phone Settings .....</b>	<b>32</b>
<b>6.11.3 Network Settings .....</b>	<b>33</b>
<b>6.11.4 Security Settings .....</b>	<b>33</b>
<b>6.11.5 Restore Factory Settings .....</b>	<b>34</b>
<b>6.12 SERVICES .....</b>	<b>34</b>
<b>7 COMMON TROUBLESHOOTING .....</b>	<b>35</b>
<b>8 WARNING.....</b>	<b>39</b>

Notes: The company reserves the rights to revise the product without prior notice and reserves the final rights of performance specifications of the product.

IMEI: International Mobile Equipment Identification Number. Power off the phone and take out the battery to check the barcode label printed with the number on the back of the phone. The number is saved in the phone and can be shown after turning on the phone and inputting #06# in the standby mode. All the brands of mobile phones in the world must be printed with the identification number; all the IME of mobile phones are unique and will not be repeated with other mobile phones. It is suggested that you keep the number safe; the number can prevent the phone from being locked and unauthorized use of the third party, even if you are using different SIM cards.

## 1 Safe Use and Cautions

### 1.1 Please comply with the following cautions when using the phone.

- Please read the User's Manual carefully before the use.
- Please turn off the phone all the time in the plane. If the alarm, memo, and etc. of the phone have auto power-on function in power-off mode, please check and cancel the settings before boarding.
- Please keep away from heat source and high voltage environment when using the phone, for example, home appliances or electric heating cooking equipment. Please use the phone under normal temperature; the phone will be damaged under the temperature of higher than 55°C or lower than -10°C.
- Prevent from fire. Please turn off the phone nearby the chemicals plants, gas stations, fuel warehouses and other combustible articles.
- Please don't use the phone when driving. Please don't place the phone above the airbag or inside the area that can be touched after the expansion of airbag, for fear that the phone receives very strong external force and may cause severe damage to you when the airbag is expanded.
- Please only use the standard battery, charger and accessories authorized by the company.

The company will not take any responsibility for any aftereffect caused by using the third party's accessories.

- It is strictly prohibited to make bold to disassemble the phone.
- The phone will cause interference with other electronic equipments, please keep away from electronic equipments, for example, TV, radio, personal computer and other equipments. It is strictly prohibited to place the phone nearby the credit card or magnetic field.
- Please turn off the phone nearby the hospital or rest home; otherwise may interfere with medical electronic equipments, such as heart pacemaker, hearing aid, and etc. because of the phone use.
- It is strictly prohibited to make the phone receive the mechanical vibration or shaking. It is strictly prohibited to use the edge tool to knock on the screen.
- It may damage the coating of phone cover if phone bag or plastic phone bag is used.
- It is strictly prohibited to use the solute (such as benzene, thinner or alcohol) to clean the phone cover; it is strictly prohibited to contact the phone using corrosive chemicals and detergent. You only can gently clean the phone with clean soft cloth.
- It is strictly prohibited to expose the phone under the sunshine or the place with excessive fog and dust.
- Keep the phone dry; it is strictly prohibited to use the phone under the environment of high humidity, such as bathroom. The phone is not waterproof, so that it is strictly prohibited to expose the phone to rain or moisture.
- Please use the earphone and other accessories carefully. It is strictly prohibited to touch the antenna if not necessary. The phone only can use the original antenna; the phone may be damaged if the unauthorized antenna is used.
- When you pull out the charger interface from the phone, please hold the interface tightly and pull it outward. It is strictly prohibited to pull the power cord.
- Please don't only use the phone as the communication tool in emergency, such as medical rescue.
- Please keep the phone in the safe place that out reach of children for fear of danger.

## **1.2 Please comply with the following cautions when using the battery.**

- Please carefully read the operating instructions and battery surface identification carefully before the use.

- Please make sure the phone is turned off before taking out the battery from the phone.
- Please charge the battery in the cool and ventilated room; otherwise too high environment temperature may cause heating, smoking, burning or distortion, and even explosion of the battery.
- The inner battery is equipped with special protection circuit; it is strictly prohibited to make bold to disassemble the battery; otherwise will cause the damage of liquid crystal panel and leakage of liquid crystal. If liquid crystal enters the eyes, it may cause ablepsia. Please rinse eyes with clean water immediately (don't rub the eyes); come to the hospital and see a doctor immediately.
- It is strictly prohibited to extrude the battery; mechanical vibration or shaking of the battery is strictly prohibited; battery short circuit is strictly prohibited, for it may damage the battery or the connected components. Short circuit may cause by direct connection of positive electrode and negative electrode of battery using some metal articles, such as coins, pens, clips, and etc., so that it is strictly prohibited to place the battery and metal articles together.
- Please keep the metal contact and battery clean.
- It is strictly prohibited to use damaged or used up battery.
- Please replace the battery when it can't meet the performance requirements. The battery can be charged for hundreds of times until it needs to be replaced. The battery is a kind of consumable; although it can be charged and discharged for hundreds of times, the electrical quantity will be reduced slowly. When you find the usage of time (call time and standby time) is reduced, please replace one new battery immediately.
- It is strictly prohibited to expose the phone under the sunshine or the place with excessive fog and dust. Keep the phone dry; it is strictly prohibited to use the phone under the environment of high humidity, such as bathroom. The phone is not waterproof; it is strictly prohibited to expose the phone to rain or moisture.
- It is strictly prohibited to place the battery in the overheat or sub cooled place.
- It is strictly prohibited to throw the battery in the fire for fear of explosion.
- It is strictly prohibited to place the battery in water for fear of internal short circuit and then cause heating, smoking, distortion, damage and even explosion of the battery.
- Please treat the battery (such as recycle) according to regulations; don't treat the battery as life trash for fear of explosion and pollution.
- The battery only can be charged using special charger, and over 24 hours of continuous charge time is strictly prohibited.
- Please don't keep the phone in the safe place that out reach of children for fear of danger.

### **1.3 Please comply with the following cautions when using the charger.**

- Please carefully read the operating instructions and charger surface identification carefully before the use.
- Please don't disassemble or reconstruct the charger; it is strictly prohibited to use the charger if the power cord is damaged; otherwise it may cause electric shock, fire and charge damage.
- It is strictly prohibited to contact the charger with wet hands. If the charger contacts with water or other liquid, please cut off power supply immediately.
- Short circuit of charger, mechanical vibration or shaking of the battery and direct sunshine exposure is strictly prohibited; it is strictly prohibited to use the charger in the place with high humidity such as bathroom, and tec. The phone is not waterproof, so that it is strictly prohibited to expose the phone to rain or moisture.
- Please don't use the charger nearby TV, radio and other home appliances.
- Please hold the charger when pulling out the plug. Pulling the power cord will damage the electric wire.
- Please keep the charger in the safe place that out reach of children for fear of danger.

**Explanation:** The User's Manual is the operating instructions based on simple Chinse operating mode and may slightly different from English operating mode.

**Notes:** The phone has the function of taking photos and video recording. Please make sure to comply with the relevant laws and regulations and use these functions. According to the relevant regulations, make bold to take a photo for others or any personal characteristics, and then copying and distribution maybe deemed as invasion of privacy. The photos and video tapes recorded by using photo taking and video recording improperly may invade the right of copyright owners. Therefore, the user must take full responsibility for this. The company will not responsible for any damage caused by improper use of the phone.

## **Notice before the Use**

### **2.1 SIM CARD**

- When registering the mobile phone number, you will get one SIM card (Subscriber Identity Model) provided by network service provider. If you get one SIM card at the size of credit card, please take out the smaller part and remove other edges.

- With the SIM card, you can use all the functions of the phone. All the information relevant to the establishment of network connection is recorded in the chip of SIM card, personal data (including PIN code (Personal Identification Number), phone book, SMS and other additional system services) is also recorded in the card.
- Please use SIM card carefully, don't twist it by force or exert pressure on SIM card; try the best to avoid contacting with metal contact surface; place SIM card in the place far from electricity and magnetism. Don't make SIM card contact with dust and water. Once SIM card is damaged, you can't use the phone normally.

**Notes:** Please make sure to turn off the phone before taking out SIM card. It is absolutely prohibited to insert or take out SIM card when external power supply is connected to the phone; otherwise it may damage SIM card and the phone.

### Install and Take out SIM Card

#### Install SIM Card

- Make the back of the phone upward ; push the back cover outward to take out the back cover the phone.
- Make the metal surface of SIM card downward (face to the phone) ; insert SIM card in the card slot on the phone ; Make the metal surface of SIM card upward (back to the phone) ; insert SIM on the phone ;make sure bevel angle of SIM card aim at bevel angle of card slot.
- Push horizontally the SIM card inward until the end.
- Push the battery cover until hear "crack"; close the battery cover again. Battery cover should be closed tightly and make sure that there is no gap between the battery cover and the phone.

#### Take out SIM Card

- When taking out SIM card, you only need to push the edge of SIM card with hands ; glide slightly outward to take out SIM card. Other operations are the same as Install SIM Card.

## 2.2 BATTERY

The phone is using rechargeable battery. Only after two or three times of full charge and discharge cycles (charging time each time should be kept within 14-16 hours, but can't exceed 24 hours), the efficiency of new battery can be exerted fully. It is suggested that you use the phone normally until the electrical quantity of the battery is not sufficient and power off automatically, and then charge the battery.

- In order to keep the battery in good condition, we suggest you discharge the battery once per month, that is, use the phone all the time until the electrical quantity of the battery is used up

and power off automatically.

- The battery can be charged and discharged for hundreds of times, however, it will lose efficiency finally. When the standby time and call time of the phone is shortened obviously, please replace the battery.

- In the charging process, slight heating of the battery is normal. The phone can be protected automatically when the battery temperature is rising, so that control the temperature change.

- Only appointed battery and accessories can be used; otherwise it may damage the phone.

- Please make sure to turn off the phone before taking out the battery; otherwise it may lose the data saved in the phone and may affect the service life of the phone.

- When the charger is not used, please disconnect the charger from the phone, and pull out the charger plug from the power socket. Please don't connect fully charged battery to the charger for a long time, because overcharge will shorten the service life of the battery. If fully charged battery is laid up, the battery will be discharged after a period of time.

- Don't use the battery for other purposes. Don't use any damaged charger or battery. Don't make the battery short circuit. When some metal articles (such as coins, brooches or pens, and etc.) are directly connected the « + » to « - » accidentally (small metal bar on the battery), short circuit may occur. For example, when you place the standby battery in the pocket or handbag, this condition may occur. Short circuit may damage the battery or connection.

- Don't place the battery in the overheat or sub cooled place; if placing the battery in the closed car in summer or winter, the capacity, service life and charging ability of the battery will be reduced. Try the best to keep the battery temperature between 15°C and 25°C (59°F and 77°F). The phone may not work temporarily in the sub cooled or overheat place, even electrical quantity of the battery is sufficient. When the temperature is lower than freezing point, battery performance is especially restricted.

- Please don't throw the battery in the fire for fear of battery explosion. Damaged battery may explode. Please treat the battery according to the local regulations. Please recycle the battery if possible and don't treat the battery as life trash.

## **2.2.1 Install and Take out the Battery**

### **Install the Battery**

1. The face with metal contact of the battery is facing downward (face to the phone).
2. Insert the inserted handle on the edge of the battery in the jack along the upper edge of battery slot.
3. Press the lower part of the battery until you hear "crack", and then insert the battery in the

battery slot completely.

4. Close rear cover of the phone.

#### **Take out the Battery**

1. Make sure the phone is turned off; make sure that the charger or other equipments have been taken out from the phone.
2. Make the back of the phone upward ; push the rear cover outward to take out rear cover of the phone.
3. Find the release button at the bottom of the battery; press and pull upward the battery; take out the battery.

#### **2.2.2 Charge the Battery**

1. Make sure that the battery is installed in the phone.
2. Find the charger jack at the bottom of the phone. Connect the charger, and connect the charger to power supply.
3. After the charging is over, please firstly pull out the charger from power socket, and then press the release button on both sides of charger plug, take out the charger from the phone.
4. Don't insert and draw the charger plug by force ; otherwise may damage the phone or the charger.

#### **Display screen displays charging indication icon**

- In the charging process, indicator bar scrolls circularly.
- After the charging is over, indicator bar stops scrolling.

#### **Alarm to insufficient electrical quantity of the battery**

- When electrical quantity of the battery is too low, display screen will prompt insufficient electrical quantity of the battery. The phone will give an alarm, and then will be turned off automatically. Please fully charge the battery. If you receive an alarm of insufficient electrical quantity of the battery during a call, please end the call as soon as possible.

### **2.3 T-FLASH CARD**

1. Make the rear of the phone upward, push the rear cover outward to take out rear cover of the phone.

2. Make the metal surface of T-FLASH card (face to the phone), insert the card in the T-FLASH card slot of the phone. Make sure that bevel angle of T-FLASH card aim at bevel angle of card slot.

- Except for T-FLASH card, please don't insert any object in T-FLASH socket.
- Please don't stick the label and other objects on T-FLASH card; slight change in T-FLASH card thickness may cause the problems of insertion and taking out; otherwise may lose data or information.
- Be careful when inserting and taking out T-FLASH card; avoid scratching or bending and folding T-FLASH card and metal surface.

## 2.4 USB CONNECTION CABLE

1. Connect USB connector to USB interface of the computer (desk computer or laptop)
2. Connect the other end of USB connector to the charging interface of phone base.

- Through USB connection, **download** and **charging** can be used.
- When you connect the phone to the computer using USB connection cable, LCD of the phone will show "**storage device, Network camera and series interface**" in the power on state. If you just want to charge, according to hang up key directly from

## 2.5 SECURITY PASSWORD

### 2.5.1 PIN Code (4 to 8 digits)

This is personal identification number of your SIM card; PIN code is usually provided with SIM card by network service provider.

- If you input wrong PIN code for three times continuously, SIM card will be locked and need to input PUK code to unlock. Please contact with your network service provider for more details to unlock.

### 2.5.2 PIN Code 2 (4 to 8 digits)

Some SIM cards will provide PIN code 2 for visiting some functions, such as: notice of call charges and dial a fixed number. These functions can be used only with the support of SIM card.

### 2.5.3 PUK Code

To release locked PIN code, PUK code and SIM card should be provided together; otherwise please contact with your network service provider to get the password. If you lose the password, please also contact with your network service provider.

#### 2.5.4 Phone Password

Phone password can prevent others from using the phone without authorization (original phone password is 1122).

- To ensure the security of your personal information, please change the original phone password in time.

### 3 Summary of the Phone

#### 3.1 Phone Appearance

#### 3.2 Keystroke Function

Main functions of the function keys are listed in the following table.

Keystroke	Function
End	<ul style="list-style-type: none"><li>• Press and hold the key to power on or power off the phone.</li><li>• End a call or reject an incoming call.</li><li>• Return to standby mode.</li></ul>
OK Key	<ul style="list-style-type: none"><li>• In the standby mode: Press OK Key to enter menu.</li><li>• In the other mode, Press the OK key to confirm the selected functions.</li></ul>

#### 3.3 Icon

According to different functions you are using and different options, display screen will show different icons.

I con	Meanings	I con	Meanings
----------	----------	----------	----------

	In the state of electrical quantity of the battery. In the process of battery charging, indicator bar will scroll.		Ring mode
	Signal strength of network.		Vibration mode
	Receive new message.		Ring after vibration
	Missed calls.		Vibration and ring
	Keyboard is locked.		Alarm is set.
	GPRS available		

## 4 Brief Introduction to Main functions of the Phone

- **MMS:** your phone includes multimedia messaging services, so that you can include film, color picture and sound in the text message; and your photos can be sent by MMS too.
- **Camera/video recorder:** Record sound film using the phone; you can add an interesting photo frame when taking a photo.
- **Film player:** You can browse or process the video files saved in the player; play the recorded films and MP4 files downloaded from the internet.
- **Music player:** You can play MP3 music files saved in phone and T-FLASH card.
- **Bluetooth:** You can use Bluetooth transmission of documents directly. Search equipment to the transfer, in accordance with the onscreen instructions can operate, and accepts data, choose to receive the same, document will be automatically stored in the directory.

## 5 Basic Operation of the Phone

### 5.1 Power on

#### 5.1.1 Power on

In the normal condition, press and hold End to power on the phone.

### 5.1.2 Input pin code

- If the phone is not set up password or SIM card is not set up password protection, the phone will search the network automatically. When the phone is registered to the internet, the network name will be shown on the screen, and then you can dial or receive a call.
- If the phone is set up power-on password, the screen will prompt you to input power-on password, input correct password to power on the phone.
- In order to prevent SIM card from being used without permission, you can set up protection password (PIN code). After setting up PIN code, the phone will require you to input PIN code when turning on the power. Please input correct password, in the inputting process, the screen will show\* to replace input contents, and then press **ok** key to confirm. After being unlocked, the phone will show the name of registered network and signal strength.
- If you input wrong PIN code for three times continuously, SIM card will be locked. If this condition happens, please contact with network service provider.
- If you don't know PIN code, please contact with your network service provider.
- If the screen shows "Insert SIM Card" after the phone is powered on, please press End to power off, and check whether your SIM card is installed correctly or not installed yet.

## 5.2 Power off

If you want to power off the phone, please press and hold **End** in the standby mode. When the screen shows power off motion, the phone is powered off. Please don't power off the phone by removing the battery. If do like this, it may lose some information that haven't saved in SIM card or the phone.

## 5.3 Make a phone call

### 5.3.1 Dial a Call

- The function can be used only after network name is shown on the display screen.
- In the standby mode, input telephone number using keyboard, press SIM Call to dial a call by SIM, press SIM Call to dial a call by or press OK Key to select Save Number.
- You also can dial a call from phone book, press Right Function Key to enter Phone Book in the standby mode, select Speed Search, find the corresponding contact person and select the corresponding phone number, press Call to dial out.
- You also can dial a call through SMS. If the SMS you have received includes phone number, you can dial the number through SMS of inbox, also can dial a call to the sender of SMS.

- ◆ Select and open the information you need from inbox, press OK Key to enter the option, and then select Use Number to select the phone number or sender number that includes in SMS, press the option again to select Dialing or save the number.
- Delete Key is used to delete the last number, press and hold the key to clear away all the inputs.
- When the phone is put through, if you set up Call Time Display is on, you can see call counter on the screen.
- When the phone is put through, press Right Function Key to enter hands free mode. When open hands free mode, please remove the phone from your ears, because amplified volume may impair your hearing. Press Right Function Key again to close hands free and return to normal mode.
- If you can't dial a call, the possible reason is:
  - ◆ "The line is busy" means the called party is busy or the network is busy; if you have set up auto redial function, the phone will redial automatically at the time.
  - ◆ "Refused" means that the call is not allowed, for example, set up call barring function.
- If you set Auto Redial as on, the phone will redial automatically when the called party is busy or no answer.
- If the dialed number is saved, the corresponding name of the phone number will be shown on the screen.
- Press End to end a call. At the time, the screen will show the call time this time.
- Press End to cancel the call just dialed.

### 5.3.2 Emergency Call

Emergency call is the number that can be dialed out even the phone is locked and SIM card is not inserted (must be within the coverage of network).

- Different countries have different emergency numbers, so that emergency numbers of the phone will not take effect in all areas. Sometimes emergency call may not dial out because of the influence of network, environment or interference.
- 112 is standard GSM emergency number, any GSM network in the world can be used.

### 5.3.3 Dial an International Call

- When dialing an international call, replace “00” by “+”, press and hold \* to input “+”.
- Input the country code.
- Input the area code and phone number.
- Just like dialing an international call, take out “0” before the city area code when dialing.

**Notes:** Dialing a call between different areas of some countries and regions (for example, China mainland and the Hong Kong Special Administrative Region) is the same as dialing an international call.

### 5.3.4 Dial Recent Calls

No matter what the call is put through, the phone saves the list of incoming and outgoing phone number. The list is saved in the order of from new to old. After new number is saved, older number that exceeds the storage range will be deleted.

- In the standby state, press Call to display recent call numbers of SIM. Press Navigation Key to select required number, press Call to dial out the number.

### 5.3.5 Speed Dial

You can set up speed dial for the numbers that you often dial out, and then you only need to press two keys and dial the number.

- Use Number Key 2-9 to show different phone number. In the standby mode, press certain number of 2-9 Number Key to dial out the corresponding number, if the number key is not set number, it will show the prompt menu of « unsaved speed dial ».
- When setting up speed dial, select Speed Dial and enter Phone Settings of Setting Menu.
- After entering the setting interface of speed dial, set the status as on, you can use blank number key to edit new speed dial number, also can delete old speed dial.
- You can delete old number and set up new phone number.
- **Number Key 1** may be reserved for voice inbox number.

### 5.3.6 Call Receiving

- When there is an incoming call, according to the phone settings, it may prompt incoming call using **Ring, Vibration, Vibration and Ring, Ring after Vibration** and **Incoming Call Picture**.

◆To receive a call, press **Call**.

◆To refuse a call, press **End**.

- If you have opened Incoming Call Display, calling number and Location will be shown on the screen during a call. If the number is saved in the phone book, the corresponding name of the number will be shown on the screen.

- Press **End** to end a call.

### 5.3.7 Missed Call

When there is a missed call, main screen will show prompt box, you can press Read to enter the list and check the missed call.

- If you have selected Call Divert in Call Settings of Settings, the phone will divert the call to the designated phone number according to your settings.

### 5.3.8 Additional Function in the call

During a call, you can press **OK** Key to enter the option. Through the option, you can pause (restore) a call, end a call, open a new call, open phone book, enter SMS menu, mute, disable (enable) DTMF.

Option	Explanation
<b>Volume</b>	Set up volume of Ring and Key Tone.
<b>Keep down</b>	Keep down current call.
<b>End</b>	End current call.
<b>New Call</b>	Input phone number and make the other call. Select the switching between two calls.
<b>Phone Book</b>	After the selection, enter photo book function list, please refer to Menu Function SMS for specific function.
<b>SMS</b>	Please refer to Menu Function SMS for specific function.
<b>voice Recorder</b>	Calls for recording
<b>Mute/Recovery</b>	Select to enable mute or recovery; after enabling mute, the called party can't hear your voice, but you can hear voice of the called party.
<b>DTMF</b>	Whether to open DTMF. DTMF may your phone use automatic telephone exchange.

## 5.4 Text Input

It is Chinese and English phone. The phone can not only show Chinese and English on the menu interface, but also can edit Chinese and English SMS. Making use of Chinese and English input methods, you can write and edit Chinese and English phone book. The phone provides the following input modes, in the editing interface, press # to switch the input method, press \* to enter input punctuation interface. In the non-digital input method, press 0 number keys to enter a space.

### 5.4.1 ABC/abc Input Method

The phone provides capital letter and small letter input methods. The difference between ABC input method and smart English input method is no imagination function, you can input required letters by pressing the key many times. Input one corresponding character by pressing the key once. For example: Press Key 2 to input A, press Key 3 to input D, press Key 2 continuously to select 'A', 'B', 'C' or '2'.

### 5.4.2 Number Input Method

In the input method, press Number Key to input the corresponding numbers.

### 5.4.3 Handwritten input Method

The device supports handwriting recognition input, which can greatly enhance the speed of input

## 6 Menu Function

### 6.1 Phone Book

- The phone provides two phone book storages: SIM (Maximum capacity is 200) and the Phone can support 500.

• In the standby mode, input one series of numbers, press **OK** Key to save. After storage location is selected, editing interface is shown.

• You only can input **Name** and **Phone Number** in the phone book record that saves in SIM card.

• In the standby state, press **Right Function** Key to directly enter phone book interface.

- Enter phone book function list from the menu, you can select **Speed Search, Name Search, Add Numbers, Copy All, Delete, Incoming Call Group, Other Numbers, Settings, Incoming Call Photo, Incoming Call Ring tone** and other functions.

### Speed Search

Browse all the records in the phone book, also can input the contents to search rapidly.

- The small icon on the left side of phone book list shows that the record is in SIM card the phone, the right side is name information of the record.
- After selecting one record, press **Call** to dial a call, or press **OK** Key to conduct the following operation.

Option	Explanation
<b>view</b>	Check the detailed information of the record.
<b>Send SMS</b>	After inputting text, choose SIM, you can send SMS to the contact person.
<b>send MMS</b>	Finish input the copy and text can be sent by MMS directly. Can insert picture, voice, video, accessories in the text.
<b>call</b>	Select Direct-dial numbers
<b>SIM IP dial</b>	IP numbers have been set up and activated, can do IP dial by SIM.
<b>Edit</b>	It can edit the options of one phone book record.
<b>Delete</b>	Delete the record.
<b>Copy</b>	Copy one record from current storage to storage.
<b>Shift</b>	Shift the record from current storage to storage.
<b>Send contact</b>	send the records or save into file by SMS ,MMS, Bluetooth.
<b>Add to blacklist</b>	It is used to restrict the incoming call of somebody or certain phone number.
<b>Caller groups</b>	It was up to five call groups, you can choose one group, look up and edit the group date contain group name, pictures, ring and members.

<b>Phonebook settings</b>	Set the phonebook location , quick dial and so on.
-------------------------------	--

## 6.2 Information

The phone supports the function of sending SMS. SMS is sent to network SMS center, and then network send to the target user. If target user is not power on or can't receive SMS, network will save the message temporarily. The period of validity of saving SMS is commonly decided by the settings of sender and service operator.

- When you receive new SMS, display screen will show the prompt. Press **OK** Key to read SMS.
- If the opposing party has received SMS, he can hear alarm tone (**SMS Alarm Tone** and **Information Report** should be set as on).
- If information memory is full, at this time, you can't receive any new SMS. In the **Inbox**, select designated old SMS, use delete option, delete old SMS. Once there is space in memory, the SMS that has not sent will be received.

### SMS

	<b>Option</b>	<b>Explanation</b>
<b>Inbox</b>	<b>Check</b> : Check SMS received in inbox. <b>Reply</b> : Reply SMS directly. <b>Delete</b> : Delete current SMS. <b>Edit</b> : Enter the SMS edit box. <b>Forward</b> : Directly forward the SMS to others. <b>Copy to the phone</b> : Copy the SMS to the phone. <b>Shift to the phone</b> : Shift the SMS to the phone. <b>Delete all</b> : Delete all the SMS in the inbox. <b>Copy all</b> : Copy all SMS in the inbox from SIM card to the phone or from the phone to SIM card. <b>Shift all</b> : Shift all SMS in the inbox from SIM card to the phone or from the phone to SIM card. <b>Use the number</b> : Use the number information in SMS. <b>Use Connect</b> : use SMS for connected.	
<b>outbox</b>	Read or process the SMS saved in outbox.	
<b>Write</b>	<b>Create and edit new SMS in the menu.</b>	

<b>SMS</b>	<p><b>Completion of SIM:</b> After information edit is over, select the operation, you can select Send, Save and Send, Save, Send to Multi-party and Send to Group.</p> <p><b>Common phrase:</b> Enter common phrase entry and select one insert SMS.</p> <p><b>Insert object:</b> You can enter Insert Picture, My Pictures, Preset Motion, My Motion, Ring tone, My Ring tone and Preset Rhythm.</p> <p><b>Text format:</b> It can enter and select Text Size, Font, Align and Paragraph.</p> <p><b>Insert phone number:</b> Insert required number from SIM card or the phone.</p> <p><b>Insert phone book name:</b> Insert required number from SIM card or the phone.</p> <p><b>Input method:</b> Select input method.</p>
<b>Common Phrase</b>	<p>Edit and delete common phrases.</p>
<b>SMS Settings</b>	<p>Set up some parameters relevant to SMS.</p> <p><b>Mode settings:</b> There are two modes for your selection; you can set up Data Folder Name, SMS Center Number, Valid Period of SMS, Send Format and other basic formats.</p> <p><b>Status settings:</b> Enable and disable Information Report and Reply Path. If Information Report is set as On, when the receiving party receive the SMS you have sent or can't receive it due to certain reason; SMS center will reply the information report, you can easily see whether the receiving party has received the SMS (needs network support). If you set up the Reply Path as on, when the receiving party uses reply function, the SMS he has sent will automatically select SMS center that you have sent SMS just now.</p> <p><b>Capacity inquiry:</b> Check the memory state, includes memory state of SIM card and the phone.</p> <p><b>Storage location:</b> Check and revise default SMS storage place.</p>

### 6.3 Speed Dial

You can set up speed dial for the numbers that you often dial out, and then you only

need to press two keys and dial the number.

- Use Number Key 2-9 to show different phone number. In the standby mode, press certain number of 2-9 Number Key to dial out the corresponding number, if the number key is not set number, it will show the prompt menu of « unsaved speed dial ».
- When setting up speed dial, select Speed Dial and enter Phone Settings of Setting Menu.
- After entering the setting interface of speed dial, set the status as on, you can use blank number key to edit new speed dial number, also can delete old speed dial.
- You can delete old number and set up new phone number.

## 6.4 Call log

### Missed call

Display the list of all the missed calls, select one missed call to check the date, time, phone number and times of the last call. If one call is refused by you, it is also considered to be a missed call.

### Dialed Call

Display the list of all the dialed calls; select one dialed call to check the date, time, phone number and times of the last call.

### Received Call

Display the list of all the received calls; select one received call to check the date, time, phone number and times of the last call.

### Delete Call log

Select to delete missed call, dialed call, received call or all the call records.

### Call Time

From the last return-to-zero of timing, calculate Last Call Time, Total Dialed Calls and Total Received Calls, also can return all the timing to zero.

### Call Charge

Call timing and charging is one network function and needs the support of network operator.

Option	Explanation
Last Call Charge	Check the last call charge.
All Call Charge	Check all the call charges.
Call Charge Return-to-zero	Clean the call charge record.
Charge Limit	Check the maximum call charge.
Price and Rate	Check and set up call charge unit.

## 6.5 Silent mode

In the standby mode, press and hold the key to switch between current scene mode and mute mode.

## 6.6 Bluetooth

Option	Introduction
Active Bluetooth	Turn on/off the Bluetooth
Searching	Searching for the other unit
Further control	Further control the Bluetooth equipment
My equipment	Units has already been searched
connected	Unit in connecting.
Set-up	“unit can be searched”、“unit name”、“certification requirement”、“set the sounds path” and “file transport set-up”

My blue  
tooth Unit information

## 6.7 Mms

### 6.7.1 Mms

**MMS is a network service, you need apply for ISP firstly, to send and receive MMS.**

The handset support MMS function. MMS is the multi media short message which include, picture, sounds and text. The MMS you sent will first sent to MMS center then , the MMS center will send it to receiver, if the receiver not power on the handset or not possible to receive the MMS, the center will keep the MMS first, the time range will depends.

If the receiver of handset has no function of mms, then the service center of mms can develop the temporary mailbox for this user on special server to save the mms, and user will be informed to read it in network by the short message .If the user has not been able to read it in 48 hours, then the mms and the temporary mailbox could be deleted automatically.

Generally, mms saves in the handset memory. As SIM card cannot save mms.

If storage space of mms is already full, screen will appear a dialog box in the handset.

If opposite side already receives and reads mms, then the side will be able to receive the prompt (if the transmission of mms will repay and read repayment being open).

Option	Explanation
Input MMS	<b>Create a new MMS and operate.</b> <b>addressee:</b> Input the number and e-mail of addressee. <b>copy:</b> Input the number and e-mail of addressee. <b>confidential copy:</b> Input the phone no. and email add of receiver. <b>substance:</b> manage the tile of the MMS <b>content:</b> Manage the content of the MMS <b>Send:</b> Send the MMS to addressee by SIM . <b>Save&amp; send:</b> Save the MMS in outbox and send by SIM . <b>Save as draft:</b> save the MMS as draft <b>Send option:</b> Set up the relate option of sending <b>Quit:</b> quit to manage the MMS
Inbox	Check and manage the MMS received
Outbox	Check and save the MMS in outbox
draft	Check and manage the MMS for the draft.

Default MMS	Can be read and edit the default MMS, also can be generated from the model of MMS.
setting	Setting some files of MMS.

### 6.7.2 Voice Inbox

Voice inbox is a kind of service provided by network operator, you may apply for opening the service. You can divert the call to voice inbox service center, the caller can leave a voice message; you can dial the voice inbox service center number and listen to the message at any time.

- Voice inbox number is provided by your network operator; please consult your network operator for more details. The phone will not recognize the correctness of voice inbox number.
- Your voice inbox is provided by network operator so that will not miss any call. It is somewhat similar to answering machine, and you can check it at any time.
- The phone can set up two groups of voice inbox numbers.

Option	Explanation
Edit of SIM	Add or change voice inbox number.
Connect to Voice Inbox Number	Rapidly connect to current voice inbox number.

### 6.7.3 Cell Broadcast

Cell broadcast refers to the public information sent by network operator. Using cell broadcast service, you can receive the information relevant to all the subjects from network operator, such as weather forecast, traffic condition, hospital, and etc.

Option	Explanation
Receive Mode	Select to enable or disable cell broadcast.

Read SMS	Read the received cell broadcast.
Language	Select the language shown in cell broadcast.
Channel Settings	<p><b>Select:</b> Conduct switching operation on standby cell broadcast channel so that filtrate the cell broadcast that doesn't need to receive.</p> <p><b>Newly added:</b> Add cell broadcast channel, and then set up Channel Name and Numbering.</p> <p><b>Edit:</b> Set up current standby channel.</p> <p><b>Delete:</b> Delete cell broadcast channel.</p>

## 6.8 Multimedia

### 6.8.1 Camera

You can take a photo using the built-in camera and adjust the settings. The photo will be saved in the file system of the phone; the photo being taken is JPG format.

- **Take a photo:** Press Left Function Key in the photo preview interface to set up the camera, after completing the setting, save the camera settings. After you have selected the scenery, press Middle Key to confirm. At this time, shutter sound will ring; in order to ensure photo quality, please keep the camera still for a while. After the photo is taken, the screen will display the static scenery taken by the phone (it is called stop motion state at the time).
- You can select the option and enter the photo preview interface.

Option	Explanation
To Photo Book	You can check and set up your photo in photo book list.
Camera Settings	Set up the relevant parameters of the camera, such as <b>Shutter Sound</b> , <b>Exposure Compensation</b> , <b>Avoid Flicker</b> , <b>Shoot Delay</b> and <b>Continuous Shoot Settings</b> .
Photo Settings	Set up Photo Size and Photo Quality.
White Balance	It can select different light modes.
Situation	It can select Auto and Night Shot modes.

#### Mode

Special Effect Settings	Select special effect to conduct special effect processing on the photo.
Picture Box	Add different picture boxes to the photo.
Storage Path	Select to save to the phone or memory card.
Restore Settings	Restore the camera settings to default settings.

#### 6.8.2 Video Recorder

In the video recorder interface, press up and down navigation keys to adjust the focal length; press left and right navigation keys to adjust the exposure compensation, also can enter "Option" menu to set up the video recorder and save, press OK Key to record, press Left Function Key to pause playing during the video recording, press Right Function Key to stop playing.

Option	Explanation
Go player	To view the video files have saved.
Video Recorder Settings	Set up the relevant parameters of video recorder.
Movie Settings	Set up the relevant parameters of recorded film.
Special Effect Settings	Set up special effect of recorded film.
Storage Path	Set up the storage location of video file.
Restore Settings	Restore video settings to default settings.

#### 6.8.3 Audio Player

The built-in music player is used to play the music list and set the music to ringtone.

Notes: MP3 files should be placed in the directory of "Memory Card/ my music", and then can be shown in the music list.

- When listening to the music, please select moderate volume. It may impair your hearing if you use high volume continuously.
- In the music player interface, press Up Navigation Key to Play and pause; press Down Navigation Key to stop, press Left Navigation Key to previous song, press Right Navigation Key to next song.
- In the player interface, press Left Function Key to enter song list, you can select Play, Details, Add to Ring tone Database, Update Play List, Settings and other options.
- Set up Auto-generated List, Repeat, Random and Background Play, blue tooth output, blue tooth earphone and the equalizer.

Option	Explanation
<b>List</b>	When selecting "Enable", the phone will automatically check the music file saved in music player file folder, and then add to default song list. When the selection function is set as Off, you can add the music files in any directory manually.
<b>Repeat</b>	You can set up play repeat method; play current song or all the songs of song list repeatedly.
<b>shuffle</b>	Play the song in the song list in random order.
<b>Background Play</b>	When selecting "enable", you can make the phone in other operating interfaces (except for no relevant operations of sound or camera), also can play the music.
<b>Bluetooth stereo output</b>	You can choose put on /off this function.
<b>Bluetooth earphone</b>	It is can being setting to use Bluetooth earphone.

#### 6.8.4 Video player

The built-in video player is used to browse or process the video files saved in the player, including video, MP4 files, and etc. Notes: Video files can be played normally if placing in "Memory Card /video" file folder.

- When listening to video music, please select moderate volume. It may impair your hearing if you use too high volume continuously.
- In the video player interface, press **OK** Key to Play, press **OK** Key to Stop, press Left Navigation Key to Backward, press Right Navigation Key to Forward, press Up Navigation Key to Speed Play, press Down Navigation Key to Slow Play.
- In the play interface, press Left Function Key to pause playing, and then press again to continue to play.
- In the options, select Play, Rename, and Delete, Delete All Files, Sorting and Storage Path to revise the file.
- Press \* to make switch between full screen and windows.

#### 6.8.5 Sound recorder

The default path for records file is under "memory cards/audio"

Press option bottom to choose record, play, attach, rename, delete, delete all, setup and transform files.

Option	Introduction
<b>Record</b>	Start to record
<b>Play</b>	Play a selected record file
<b>attach</b>	Making attach record on one selected file.(the function will appear under a special option)
<b>rename</b>	Rename a selected record file. Caution : if the selected file has already been set as ring tone, the ring tone will change to default after rename.
<b>delete</b>	Delete a selected record file.
<b>Delete all</b>	Delete all record files.
<b>Option</b>	The path of saving and the format can be set here

Transport files	Make transport files to profiles .MMS and Bluetooth.
-----------------	--

#### 6.8.6 Photo book

Browse and set up your photos in photo list. You can select Check, Browse Mode, and Send, Rename, Delete, Delete All Files, Sorting, Storage Path and other operations.

Option	Explanation
Send	You can select to send the photo to <b>Wallpaper</b> , <b>Screen Saver</b> , <b>Power-on Motion</b> , <b>Power-off Motion</b> and <b>Phone Book</b> .
Storage Path	You can select to save to the <b>Phone</b> or <b>Memory Card</b> .

## 6.9 Organizer

### 6.9.1 Calendar

In calendar interface, press left function key to select Schedule, Skip to Designated Date and Lunar Calendar.

- In the calendar interface, the first row shows year, month, and etc., the second row shows week, the middle part displays the specific date of certain month; the last row displays the prompt information. In the calendar interface, press Up Navigation Key to move one week forward, press Down Navigation Key to move one week backward, press Left Navigation Key to move one day forward, press Right Navigation Key to move one day backward, selected date is displayed in deep color.
- Enter Phone Settings of Settings to change date, calendar information on the screen will be updated correspondingly.

Option	Explanation
Schedule	According to Left Function Key prompt, select to add or enter option menu, you can add to schedule arrangement at the same day. You also can enter option menu from calendar interface, select to skip to designated date, add to schedule arrangement, so that you can conveniently manage all the tasks in your work

	<p>and life, arrange and record the future proceedings. When time is arrived in the preset proceeding, the phone will give an alarm to remind you to complete the prearranged proceedings. When the current schedule is empty, you can add to increase the schedule arrangement; when the schedule is not empty, press Left Function Key to see the following menu options: Browse, Add, Edit, Delete Record, Delete All, Send Calendar.</p> <p>Browse: Check current selected schedule contents.</p> <p>Add: Create new schedule. You can edit date, time, remarks, alarm and method (set up alarm prompt repeat date of schedule) and other options.</p> <p>Edit: Edit and revise date, time, remarks, alarm, method and other contents of schedule records.</p> <p>Delete the record: Delete current schedule arrangement record.</p> <p>Delete all: Delete all the schedule arrangement records.</p> <p>Send calendar: Send calendar to the designated person.</p>
<b>Skip to Designated Date</b>	Input the designated date and press confirm, and then automatically skip to the calendar interface of the date.
<b>Lunar Calendar</b>	Through On or Off settings, enable and disable the display of lunar calendar and relevant solar term, custom, animal sign.

### 6.9.2 Calculator

You can use the phone to conduct simple calculation using the function.

In the calculator interface, press number key 0-9 and input the number to be calculated. Press Right Function Key to clean out recent inputs or results digit by digit.

Press Right Function Key to exit from the calculator, press Left Function Key to check the results.

### 6.9.3 file manager

Conduct the management on your files in the menu.

**Notes:** Video files, audio files and pictures should be saved in T-flash.

Option	Explanation
Open	Open one designated data folder.
Build Data Folder	Newly build one data folder.
Format	Format the file. Notes: After the format, you will lose all the data saved in the file system.
Remove	Remove the memory card.

### 6.9.4 Alarm

The phone can set up five alarm time. For each time, you can select whether to turn on alarm and set up the alarm sstime, alarm method and alarm cycle.

### 6.9.5 Tasks

Display all the schedule arrangements today and in the future. In the option menu, you can add new memo, browse, and edit, delete record, delete all, and send calendar and other operations. Please refer to Schedule for specific operations.

## 6.10 Scene Mode

The phone provides **Normal Mode**, **Conference Mode**, **Outdoor Mode**, **Indoor Mode**, **Earphone Mode** and **Bluetooth mode** to conduct the default settings. When you insert the earphone, the phone will enter the earphone mode automatically.

- In the standby mode, press # to switch between Mute Mode and current mode.
- For each scene mode, you can enter personal settings and conduct the settings on the following options:

### 6.10.1 Activate

Activate the mode you have setted.

### 6.10.2 Personal Settings

Option	Explanation
Ring Settings	Conduct the settings on Incoming Call of SIM , Alarm, Power on/Power Off, SMS of SIM and Key Tone.
Volume	Set up volume of Ring and Key Tone.
Ring Method	Provide Ring, Vibration, Vibration and Ring, Ring after Vibration and other incoming call prompt types for your selection.
Ring tone Type	Select Ring Once, Ascending and Ringing.
Prompt Tone	Select whether Give an Alarm, Error, Network Connection Tone and Call Connection (give an alarm when putting through a call).
Answer Mode	Select whether to press Any Key.

## 6.11 Settings

### 6.11.1 Pen calibration

If the touch panel does not respond accurately on the phone, it should be calibrated touch panel.

### 6.11.2 Phone Settings

Set up phone time, power on /power off timely, language, and other options.

Option	Explanation
Time and Date	Conduct the settings on City, Time and Time format.
Schedule Power on /Power off	Enable or disable Power on/Power off Timely. The phone provides four powers on/power off time. You can set up state and time for each time.

Language	Select the language shown on the phone.
Preferred Input Method	Defined default input method.
Display characteristic	Conduct the settings on Wallpaper, Screen Saver, and Power on Motion and whether to show date and time, the phone number and service operator, and download more standby pictures from the internet.
Auto Update Time	Enable or disable to control auto update time.
Sky menu setting	Define version 3D on the switching function of the main screen, program screen and sub-windows
Hand writing setting	Can be changed hand writing speed and changed the color.
Other settings	Set up phone brightness level and brightness display time.

Special reminder: In special regions that prohibit the use of the phone (such as inside the cabin), please make sure to confirm whether auto power-on function is off before entering the region for fear of abnormal accident.

### 6.11.3 Network Settings

You can set up the network in the menu.

Option	Explanation
Network Option	Set up the network search using automatic or manual methods.
Preferred Network	Set up the preferred network.

### 6.11.4 Security Settings

In the menu, you can set up security and secrecy of the phone.

Option	Explanation
security setup	When setting up the function is on, you must input PIN code when the phone is power on. Therefore, any person who doesn't know PIN code can't use the

	phone without your permission. When you close the function, you must input PIN code first.
<b>Phone Lock</b>	When the function is on, you must input phone security password when the phone is power on. Notes: Factory original password of the phone is 1122.
<b>Keyboard Lock</b>	Set up auto keyboard lock function, make sure to enter keyboard lock setting interface, you can select Close (keyboard lock function is valid), 5 Seconds, 30 Seconds, 60 Seconds and 5 Minutes, if the phone is not any operation, the keyboard will be locked automatically within the corresponding time.
<b>Dial ban</b>	Switch on the function "Dial ban" to avoid outgoing phone calls on certain number, user has to input the PIN 2 number to release this function, cell phone will not support this function if the SIM card not have PIN 2 number.
<b>Limitation call</b>	After this function available (need input PIN 2 number), user can only make phone calls on the number which show in the imitate dial list, meanwhile, the phone book will not available.
<b>Change Password</b>	Set up new passwords, includes PIN 1, PIN 2 and phone lock passwords. After changing the password, please keep new password in mind timely.

#### 6.11.5 Restore Factory Settings

After selecting the function, factory default settings of the phone will be restored. And need to input phone lock password, default password is "1122".

### 6.12 Services

#### WAP

Multi kinds of WAP (Wireless Application Protocol) services are available, eg : Banking, news, weather forcaste and airline timetable. These services are basically designed to the handset and maintaining by the service provider.

About the Availability, price and the tax of WAP, please make inquiries to your ISP or your service provider. The ISP will also provide you about the information of how to use the other services, if you use WAP service from CM, you have to make call to 1860 or log on

the local website to active the WAP and GPRS function before use.

Option	Introduction
<b>Homepage</b>	Go to home page you set.
<b>Book mark</b>	Run internet with your book mark
<b>History record</b>	Run internet with history record
<b>Save homepage</b>	Homepage you have save the phone .
<b>Input the address</b>	Input the web address.
<b>Service inbox</b>	You can get the newest news and setting from the service provider.
<b>Set-up</b>	Organize the files : the handset had make the right set-up as default setting. Exploration: Turn on/off the picture from the website Server infor: Turn on/off the message receiving from the server. Delete the cache: delete the cache Delete the personal info: delete cookies. Certification: check the trusted certification

\*Some data, picture and tones download by using the WAP service can cost purchased from the ISP, more intensive payment items please check with the website.

## 7 Common Troubleshooting

If any problem occurred when using the phone, please solve the problem according to the following articles. If the problem still exists, please contact the distributors or designated maintenance personnel.

### **The phone can't turn on**

- Press End until power-on menu is shown.
- Check electrical quantity of the battery.
- Check whether the battery is poor contact, remove the battery and install it again, and then

power on.

#### **The phone is not responded for several minutes**

- Press End.
- Take out the battery and install again, and then power on again.

#### **Phone menu is difficult to read**

- Clean the screen.
- Enable the backlight.
- Please use the phone according to the suggested using conditions.

#### **The phone will power off automatically**

- Please check whether the keyboard is locked when it is not used.
- Check electrical quantity of the battery.
- Please check whether the backlight is on all the time.

#### **The phone only can be used for a short time**

- Please make sure to use screen saver.
- Please make sure that the phone is charged for enough time (at least three hours).
- After partial charging, battery indicator may not correct. After pulling out the charger, please wait for twenty minutes to get the accurate indication.

#### **The phone can't be charged normally**

- Please check whether the battery can be used; the battery performance will be reduced after being used for several years.
- Please charge the battery in normal condition.
- Please make sure the battery is installed. It must be installed before the charger is charged.
- Please make sure to use the designated battery and charger.
- Before going abroad, please check whether the current is compatible.

#### **The phone can't connect to network**

- Please try again in another place.
- Please consult your network service provider and confirm the coverage area of network.
- Please consult your network service provider to confirm your SIM card is effective.
- Try to select network manually.
- Please try again later if network is too busy.

#### **SIM card error**

- Please make sure to insert SIM card correctly.
- Please consults your network service provider whether your SIM card is compatible 3V. Old 5V SIM card can't be used.
- Please make sure the crystal chip of SIM card is not polluted, damaged or scratched.

#### **Can't dial out a call**

- Please make sure to dial correct number and press Call.
- As for international call, please check the country code and area code.
- Please make sure the phone is connected to network, and network is not busy and available.
- Please make sure not outgoing call barring because of overdue payment.
- Please consult your network service provider about your registered conditions (rating, effectiveness of SIM card, and etc.).
- Please make sure that you don't set up outgoing call barring.
- Please check whether you have set up fixed dialing function.

#### **Can't receive an incoming call**

- Please make sure the phone is power on and connect to network (check whether the load is too heavy or no network).
- Please make sure not incoming call barring because of overdue payment.
- Please consult your network service provider about your registered conditions (rating, effectiveness of SIM card, and etc.).
- Please make sure that you don't set up call divert.

- Please make sure that you don't set up outgoing call barring.

#### **Caller name is not show when receiving an incoming call**

- Please consult your network service provider and check whether you have ordered the service.
- The phone has cancelled his /her phone number.

#### **Sound quality is not so good during a call**

- You can make an adjustment using the side key during a call.
- Check the wireless signal.

#### **Can't use the functions in the manual**

- Please consult your network service provider whether the registered contents include the service.
- Please check the function not need to use the accessory.

#### **Can't dial out when selecting a number from phone book**

- Please make sure the numbers recorded in the phone book are correct.
- Please make sure you have selected correct country code when dialing an international call.

#### **Can't newly build a record in the phone book**

- Please make sure your SIM card phone book is not full; otherwise, please delete some numbers or save the number in phone book of the phone, and vice versa.

#### **My caller can't leave me a message in my voice inbox**

- Please consult your network service provider whether they provide the service.

#### **Can't enter my voice inbox**

- Please input correct voice inbox number in the voice inbox option of SMS.
- Please try again later if the network is busy.

#### **Has input wrong PIN code for three times**

- Please consult your network service provider to get PUK password.

#### **Photo is too dark**

- Please check whether you set up too low photo brightness.
- Whether the ambient light is too dark.

#### **Photo is too blurred**

- Whether the object being taken is in motion.
- Whether the phone is slightly shaking at the instant of pressing the shutter.

#### **Distortion of the photo**

- It is possible that the main body camera of the photo being taken is too close.

#### **Can't Play Music**

- Please check whether the phone supports the song format or not (such as MMF format).
- Please check whether the downloaded song has been deleted, but the song name is still saved in the file folder. You can update the playlist to confirm.

## **8      WARNING**

When you start to use this phone, please pay attention to the following this information: for safety concerns, you should only wear the wrist watch on your wrist and the device should not be worn on the inside of the wrist(such as the palm side) or in any other configurations during transmission.

If damaged ,please do not attempt repair for yourself.

#### **FCC Caution:**

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

#### **IMPORTANT NOTE:**

#### **FCC Radiation Exposure Statement:**

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment . This equipment should be installed and operated with minimum distance 1.0 cm(speak mode)between the front of watchband and the rest of user body while it is transmitting.

Specific Absorption Rate (SAR) information

This watch phone has been tested and meets the FCC RF exposure.

The SAR limit set by the FCC is 1.6 W/Kg.

transmitter.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.