# WT8000 User Manual

# **Contents**

# **Getting started**

## Menus

- 1. Phonebook
- 1.1 Quick Search
- 1.2 Add a Contact
- 2. Information
- 2.1 Write information
- 2.2 Inbox
- 2.3 Drafts
- 2.4 Outbox
- 2.5 MMS
- 2.6 E-mail
- 2.7 Cell Broadcast
- 2.8 Template
- 2.9 SMS Settings
- 3. Call Center
- 3.1 Call History
- 3.2 Call settings
- 4. Set
- 4.1 Mode Setting
- 4.2 Touch screen calibration
- 4.3 Phone Settings
- 4.4 SMS Settings
- 4.5 Call settings
- 4.6 Data Accounts
- 4.7 Wallpaper
- 4.8 LCD backlight
- 4.9 Music Settings
- 4.10 Network settings
- 4.11 Security Settings
- 4.12 External links
- 4.13 Restore factory settings
- **4.14 Sound**
- 4.15 Sensor Set
- 5. Book
- 5.1 Open the e-book
- 5.2 Update
- 5.3 System Settings
- 5.4 Information
- 5.5 Remove
- 5.6 Delete all files
- 5.7 Sort

- 5.8 Execution System Settings
- 5.9 Help
- 6 Network Services
- 6.1STK
- 6.2 Internet Services
- 6.3 Baidu search
- 6.4UCWEB browser
- 7. Multimedia
- 7.1 Video Chat
- 7.2 Camera
- 7.2.1 Album
- 7.2.2 Camera Settings
- 7.2.3 Photo Settings
- 7.2.4 White Balance
- 7.2.5 Situational Model
- 7.2.6 Effects Set
- 7.2.7 Storage location
- 7.2.8 Restore Default
- 7.3 Album
- 7.4 video recording device
- 7.2 Video Player
- 7.3 Music Player
- 7.4 Recording
- 7.5 FM radio
- 7.6 Slide
- 7.7 TV
- 7.7.1 Add to my channel
- 7.7.2 Channel List
- 7.7.3 My Channel
- 7.7 4 channel search
- 7.7.5 Search Area
- 7.7.6 Display Settings
- 8. Toolbox
- 8.1 Calendar
- 8.2 Task
- 8.3 Alarm Clock
- 8.4 World Time
- 9. Scenarios
- 9.1 Standard Mode
- 9.2 Meeting mode
- 9.3 Outdoor Model
- 9.4 Indoor Model
- 9.5 Headset Mode
- 9.6 Bluetooth Mode

- 10. Exchange rate conversion
- 11. Document Management
- 11.1 Use function
- 11.2 Folders feature
- 12. Calculator
- 13. Stopwatch
- 13.1 General code table
- 13.2 Multi-oriented code table
- 14 Telephone
- 14.1 The phone features
- 14.2 Call Options
- 15. Bluetooth
- 15.1 Bluetooth menu, settings
- 15.2 to establish a Bluetooth connection
- 16. Fun & Games
- 16.1 Java
- 16.2 Java Set
- 16.3 Game
- 16.4 Dynamic Game
- 17. Wireless Network
- 18 calls Background Music
- 18.1 Choose to call
- 18.2 Play Set
- 18.3 Background Music List
- 19.MSN
- 20.Art Fonts

**Frequently Asked Questions** 

## **Know Before You Use**

# Phone keypad description

Power button (on \ off button): The bond length for the switch by machine; in the call or the caller interface Click button to hang up; Click button on any interface can be a direct return to the standby interface.

Side button: standby interface can be realized quickly adjust the function of the size of ring volume; in tone or MP3 player interface that enables adjustment , ringtone volume size or the size of features Rackball: You can use the trackball to navigate the various interfaces.

# Battery installation / removal

Exchange the battery, make sure you have closed the phone, at the same time disconnected from the charger links.

## SIM card installation / removal

Installation, make sure you have closed the phone and remove the battery.

If you do not properly insert the SIM card can only use the device in offline mode.

## T card installation / removal

Installation, make sure you have closed the phone and remove the battery.

## **Mobile Phone Charger**

In the charge before, make sure the battery has been correctly loaded mobile phones, and make sure the use of compatible charger.

- 1. will be compatible with cell phone charger jack into the port.
- 2. Connect the charger plug into the power socket on the device screen shows the battery charging icon was rolling.
- 3. If the battery is completely depleted or long-term unused lead to the battery voltage is too low, charging, you may need to wait some time before a charge screen.
- 4. Charging is complete, charge prompt the state to stop at full grid at this time, please disconnect the charger and the device link, and then unplug the charger from the electrical outlet.
- 5. Please completely exhausted after the first fully charged before use, so easy to achieve the best use of the battery condition.

Note: While charging, the circuit in order to avoid serious burning mobile phone, do not move or remove the battery.

Users not in a closed environment or in flammable and explosive environment charge.

## On / Off

- 1, long press the power button to open or close the phone.
- 2, if asked to enter mobile phone boot password, please enter the correct number, then select "Confirm", mobile phones default density

Code is "1122."

## **Input Method Description**

In the input interface, you can enter numbers, words or symbols, and more.

- 1, switching input method: enter the editing interface, the options menu select the input method into the input method list, and press OK key to select the desired input method, your cell phone to provide you with pinyin input, strokes input, uppercase English, lowercase English, digital input, punctuation input in the six input; also available on the editing interface, click the interface in the input region to switch input methods.
- 2, Pinyin input method: Click on the letter keys input alphabet, and then click on the text you want can be.
- 3, stroke input method: Click the needs of stroke, and then click on the text you want can be.

- 4, English case input method: Click the letter you need direct input.
- 5, digital input method: Click on the number you need direct input.
- 6, punctuation: In the punctuation list, click on the symbol you need a direct input.

## Menus

- 1. Telephone Directory
- 1.1 Quick Find

Click on a telephone book entry, which indicates that phone book browsing interface, the bottom of the window provides a search input box, you can enter the appropriate information to the telephone records of screening, select a record, enter the option, the menu is as follows:

- 1.1.1 View: See this article for details.
- 1.1.2 Send SMS: send SMS to this number.
- 1.1.3 to send MMS: Send MMS to this number.
- 1.1.4 Call: Call the current number.
- 1.1.5 IP Call: call this number to IP.
- 1.1.6 Edit: Edit this article entry.
- 1.1.7 Delete: delete the clause entry.
- 1.1.8 Copy: Copy this article entry.
- 1.1.9 Mobile: Mobile this article entry.
- 1.1.10 Send Contact Person:
- 1, text messages: Use SMS to send this article entry.
- 2, MMS: Using MMS for sending this article.
- 3, e-mail: Use e-mail this article entry.
- 4, through Bluetooth: using Bluetooth to send this article entry.
- 1.1.11 added to the blacklist: this article added to the blacklist, the other party could not inbound.
- 1.1.12 Caller Group: This mobile phone to provide you with five caller groups, you can for each group to group members, change the name, ring type, caller personalized picture settings.
- 1.1.13 Phone book settings:
- 1, the preferred storage location: You can set the preferred storage location for the SIM card 1, SIM card
- 2, mobile phone or all of the.
- 2, speed dial: set the quick dial, dial interface, click on the corresponding number keys can be set by calling the telephone number.
- 3, my numbers: numbers may be edited or send a
- 4, business card version: You can set the card version 2.1 or 3.0.

5 other numbers: You can right SIM card numbers to view the native and modified.

- \* Note: The SIM card needs to support service numbers.
- 6, storage condition: View the current storage state.
- 7, copy contact: For cell phone or SIM card to copy all the records.
- 8, mobile Contact: For cell phone or SIM card to move all the records.
- 9, delete all of the contacts: the mobile phone or SIM card to delete all records.
- 1.2 Add a Contact

To add a new telephone directory telephone records, you can select stored way SIM card 1, SIM card two or cell phone.

- \* Note: the two slightly different way in the storage.
- 2. Information

#### 2.1 Write Message

Into the editing interface for editing text messaging, SMS, content editing is completed by entering the following menu options:

2.1.1, send: send this message, select the Add a recipient to enter the menu, you can directly enter the number or

Select the number from the telephone book to add to send.

- 2.1.2, Input Method: Select the required input method.
- 2.1.3, insert a template: Select the contents of the template inserted into the editorial content.

#### 2.1.4, Advanced Options:

Insert object: you can insert pictures, animations and sound files.

Insert number: can be inserted in the phone book phone numbers to text messages.

Insert Name: the name can be inserted in the phone book to the text message.

Insert a bookmark: You can insert the URL.

Text format: You can right text size, font, alignment, set the paragraph.

- 2.1.5, save it to Drafts: The editorial content directly saved to the Drafts.
- \* Note: Some cities and regions of the short message center do not support more than 70 characters or more than 160 English characters), the length of the message.

#### 2.2 Inbox

Showing SIM card and SIM card one inbox inbox 2, respectively, view the received message, in the event of a short message inbox list, you can press OK to read the message details.

#### 2.3 Drafts

After the message if you do not send the editors choose to save, save here.

## 2.4 Outbox

Showing SIM card and an Outbox Outbox SIM card 2, view sent successfully or not to send a successful message. Outbox appears short message list, you can press OK to read the message details.

## 2.5 MMS

Include text, graphics and sound content. Via multimedia messaging (MMS) service (Multimedia Messaging Service, MMS), you can not only send or receive images and text, you can also receive information accompanying sound files.

Phone supports multi-page MMS, that is, the content of each page contains a picture, a music, and text content, while multimedia message contains pictures, phone will automatically adjust the picture zoom, display the phone screen.

\* Note: This feature requires network operators support.

## 2.5.1 Write Message

Into the set-up message in the multimedia message, a new one MMS, you can fill in the recipient, Cc, Bcc, themes, MMS content and accessories.

## 2.5.2 Inbox

View the received MMS. (To do the same text message in the inbox.)

# 2.5.3 Outbox

Send successful or unsuccessful store to send multimedia messages.

## 2.5.4 Draft

After the message editor can be saved if you do not send here.

# 2.5.5 Template

There information can be selected by default, but also save the information for the custom.

#### 2.5.6 MMS settings

To send and receive multimedia messages to set the relevant parameters.

\* Note: In the settings file must be set the correct parameters, or download the MMS failed.

#### 2 6 F-mail

This feature requires network support, the initial need to enter e-mail account to use the menu to set mailbox accounts.

#### Create a new account:

A, enter the correct e-mail account name, the options menu to enter the next step;

B, communication protocols: Select POP3 or IMAP4 (POP3 (Post Office Protocol 3) or Post Office Protocol version 3, which specifies how a personal computer connected to the Internet, mail server and download e-mail e-agreements; IMAP4 (Internet Message Access Protocol 4) or Internet Message Access Protocol version 4 of the first, is used to access e-mail from a remote server, the standard protocol; the difference please refer to the professional information) Options menu to enter the next step; C, Data Account: Options menu, select Always ask for editing in each use is to ask a choice SIM1, SIM2 or wireless local area network, in which choice SIM1, SIM2 need to select the specific data account, GSM data or GPRS (need to Open GPRS service), and choosing the right operator (such as: china mobile gprs (China Telecom), china Unicom gprs (China Unicom)), the Options menu to enter the next step;

D, the receiving server: Depending on your set up e-mail account to set up the receiving server (such as  $x \times x \otimes q$  qq.com is set to: pop3.qq.com or imap.qq.com and communication protocol setting corresponds to), Options menu to enter the next step;

E, the sending server: According to the mail account settings, outgoing server (such as  $\times \times \times \otimes$  qq.com generally set to: smtp.qq.com), the Options menu to enter the next step;

- F, user name: Edit the user name, the options menu to enter the next step;
- G, password: password, options menu to enter the next step;
- H, Account name: set up an account name, enter the completion of the Options menu to complete the account settings.

E-mail account settings is complete you can send and receive, edit, e-mail, Inbox, Outbox, Sent Items, Drafts, empty e-mail and other operations.

- 1, send and receive: A Good-mail account has been set up to send and receive operation.
- 2, edit the e-mail: Editor e-mail.
- 3, Inbox: See receive e-mail.
- 4, Outbox: View sent messages unsuccessful.
- 5, Sent Mail: View Sent Mail.
- 6, Draft: Editor If you do not send a good message can be stored here.
- 7, empty-mail: select all clear or all of the empty mailbox.
- 8, delete marked e-mail: The delete operation marks a good e-mail.
- 9, e-mail account: set up an e-mail accounts, accounts can be right there to start, edit, delete operations.
- 10, the template: It is the default e-mail content can be selected, but also save the information for the custom.

## 2.7 Cell Broadcast

SIM cards can enter a cell broadcast can also choose to enter the SIM card 2 Cell Broadcast. Cell broadcast receiving and reading the news of the following functions:

2.7.1 Receive Mode: on or off Cell Broadcast.

- 2.7.2 read the information: Read Cell Broadcast has been received.
- 2.7.3 Language: Select language.
- 2.7.4 Channel Settings: Cell Broadcast Channel settings. Including the selection, add, edit and delete.
- 2.19 Template

Information can be used to write some commonly used sentences in order to avoid sending duplicate messages one by one, when typing, can be edited or deleted.

2.9 SMS Settings

Using the short message function of time, you will first need to do the necessary settings.

- 2.9.1, the pattern is set: to provide four modes for you to set up, you can set the mode name, SMS center number, SMS is valid, send format.
- 2.9.2, voice mail: You can enter the SIM card a voice mail, you can also choose to enter SIM card two voice mail. Any voice mail, you can edit the voice mail on a call or edited.
- 2.9.3, status settings: open or closed to send a report, open or close the reply path, open or close the save sent messages
- 2.9.4, memory status: See mobile phones and SIM card memory status.
- 2.9.5, the preferred storage location: can be set to SIM card or mobile phone.
- 3. Call Center
- 3.1 Call History

Chose to enter call history menu, there is a phone SIM card records and phone records of two SIM cards two options, either a call record is as follows:

- 3.1.1, did not answer the phone: a record of 20 missed in different phone numbers.
- 3.1.2, has been making telephone calls: a record of 20 has been allocated a different phone number.
- 3.1.3, has to answer the phone: a record 20 different phone numbers have been received.

In the call history list interface, press OK to view the record details, including date, time of call, name (if the phone book there this record), number, and dial the number.

In the details interface, you can click Options on the currently selected phone records do the following.

- 1. Delete: Delete this record.
- 2. Save to Phonebook: this number stored in the SIM card or mobile phone.
- 3. Call: Call the telephone number.
- 4. Editor: Edit the phone number and phone book of the deposit.
- 5. Send SMS: send SMS to this number.
- 6. To send MMS: Send MMS to the number of
- 3.1.4, delete the call records: choose Empty the list of records to a call.
- 3.1.5, call timing: In the talk time, there are four sub-menu: At the last call, dialed calls, received calls and reset all.
- 1, last call: Check out the last time talk time.

Two have since been donated Phone: view the total time allocated telephone.

- 3, has to answer the phone: view the total time to answer the phone.
- 4, Reset All: All calls time zero.
- 3.1.6, call billing: Call costs can be accumulated for you to store phone billing.
- 1, the last call cost: Check out the last time call charges.
- 2, all call costs: See the accumulated call charges.
- 3, reset call cost: Enter PIN2 code may be cleared on the meter and re-start accounting.
- 4, cost restrictions: limit the cost to enter sub-menu, you can view, modify or cancel the feature.

Amendment and cancellation of these functions need to enter the PIN2 code.

5, prices and rates: Call rates to enter sub-menu, you can browse, modify or cancel the feature. Amendment and cancellation of these functions need to enter the PIN2 code.

Note: Some operations require that you enter the PIN2 code, contact your network vendor to obtain the password.

\* Note: the need for network support

3.1.7, SMS Counter

Sent: Record the number of sent SMS.

Have been received: Record the number of messages have been received.

The left soft key "Reset" to clear these two, respectively.

3.1.8, GPRS Traffic

Last delivery: Record the last number of bytes transmitted.

Last received: Record the last number of bytes received.

Total sent: Record total number of bytes transferred.

Total received: Record total number of bytes received.

Reset Counter: re-start counting.

3.2 Phone Setting

3.2.1 Call Settings

SIM card is displayed as a call to set up and SIM cards 2 call set up.

1, the machine number:

The system default: number of sending or not using the system default.

Hide number: call when the other party do not see numbers. (Requires carrier support)

Send number: call when the other party can see the numbers.

2, call waiting: the call waiting feature on or off. Select query to view the current status of call waiting.

3, call forwarding:

Forwarding all voice calls: Turn on forwarding all voice calls, will in any case the phone call to set up the transfer to your number.

Contact less than a transfer: the transfer can not open the contact, it will not contact you in the other case, shall be credited to set up calls to your number.

No Answer Transfer: Turn on the transfer of non-response, will be on your cell phone number does not answer case, will be paid calls to the number you set.

Busy Transfer: Open the busy transfer, will be on your phone is busy, it will be transferred to the dial telephone number you set.

Relay all data calls: When to open relay all the data calls, will be credited to all the calls to the number you set.

To cancel the transfer: cancel all call forwarding.

4, call restrictions: restrictions on phone calls.

Prohibition set aside: To restrict outgoing calls.

Prohibition of calls: The calls to restrict.

Start All: Start all the settings restrictions.

The abolition of all: the abolition of the restrictions set in (required to enter the PIN2 code).

Change Password: Change Password.

5, line switch: Select line 1 or line 2.

Note: This feature requires SIM card where the network operator support.

- 3.2.2 Advanced Settings
- 1, blacklist: You can edit the blacklist numbers, and the mode setting is turned on or off, black list numbers will be rejected in the number of connected.
- \* Note: Please enter the region fixed-line telephone number
- 2, automatic redialing: Open the automatic redial after the failure of each call will be automatically redial.
- 3, IP Dial-up: You can set the IP dial-up.
- 4, the background sound: You can set the background sound when making a call.
- 5, Call duration display: you can set whether to display talk time.
- 6, talk time tips: You can set whether to prompt, suggesting that cycle, and whether repeated prompts.
- 7, automatic time limit: set talk time, when the time is, the phone automatically hang up.
- 4. Set
- 4.1 Mode Setting
- 4.1.1 Dual-Mode Open: Turn dual card dual standby.
- 4.1.2 Only an open SIM card: SIM card one standby.
- 4.1.3 Only two open SIM card: SIM card two standby.
- 4.1.4 Flight Mode: Turn on flight mode, so that no cell phone service into the state.
- 4.2 touch screen calibration

Click the icon interface, the center of the screen calibration.

- 4.3 Phone Settings
- 4.3.1 Time and Date: Set the time and date.
- 1, set the City: The phone number of different cities around the world collected for you to choose.
- 2, time / date settings: set the current time and date.
- 3, the format settings: set the time format to 12-hour or 24 hour clock.
- 4.3.2 Timing Switch Machine: Set the time period in the boot or shut down.
- 4.3.3 Language: set the phone menu display language.
- 4.3.4 the preferred input method: Choose a default input method.
- 4.3.5 Caller attribution display: Set Caller attribution to display on or off.
- 4.3.6 Key vibration settings: Settings button vibration turned on or off.
- 4.3.7 touch screen vibration settings: set the touch screen vibration turned on or off.
- 4.3.8 encoding: set encoding to Big5 or GB2312.
- 4.3.9 Standby menu displays:
- 1, Wallpaper: Select standby interface wallpaper.
- 2, boot Animation: In order to boot select an animation.
- 3, shutdown animation: an animation for the shutdown option.
- 4, the screen switching effect: on or off the screen transitions.
- 4.3.10 greeting: Set to open, you can edit the boot display greeting.
- 4.3.11 Automatic Update: Automatic Updates turned on or off time function.
- 4.3.12 handwritten settings: Set the speed and handwriting handwritten pen color displayed when editing the contents of a handwritten set the display.
- 4.3.13 UART settings: SIM card can be set to 1 or SIM card 2.
- 4.3.14 Other settings:
- LCD backlight: Set up the phone LCD backlight brightness and time.
- 4.4 SMS Settings
  - With 2.9 in the SMS settings menu.

4.5 Phone Setting

With 3.3 in the call settings menu.

- 4.6 Data Account
- 4.6.1 GSM Data: For GSM data, editorial content is as follows:
- 1, Account name: the account name, select Edit to modify.
- 2, number: the account number.
- 3, the user name: dial-up server (not the WAP gateway) account name.
- 4, Password: dial-up server (not the WAP gateway) password.
- 5, line type: Select the line type, analog or digital.
- 6, Speed: Select the appropriate transmission speed.
- 7, the primary DNS address: Enter the primary DNS address.
- 8, Sub-DNS Address: Enter the second DNS addresses.
- 4.6.2 GPRS: right GPRS editorial reads as follows:
- 1, Account name: the account name, select Edit to modify.
- 2, GPRS connection point: Enter the APN (Access Point Name that "access point name).
- 3, the user name: dial-up server (not the WAP gateway) account name.
- 4, Password: dial-up server (not the WAP gateway) password.
- 5, authentication type: choose a general or encrypted.
- 6, the primary DNS address: Enter the primary DNS address.
- 7, Sub-DNS Address: Enter the second DNS addresses.
- 4.7 Wallpaper

Choose wallpaper standby interface.

4.8 LCD backlight

With 4.3.14.

- 4.9 Music Settings
- 4.9.1 Play Set:
- 1, repeat: Open the repeat play songs.
- 2, random: Turn on the playing randomly.
- 3, the background play: Open the the music does not stop with the withdrawal of the menu.
- 4.9.2 Audio settings:
- 1, sound effects: Set audio playback devices are horizontal, echo sound, stereo surround sound effects, sound effects turned on or off functions.
- 2, bass enhancement: Turn on or off the bass enhancements.
- 3, playback speed: Set playback speed: normal, fast, fastest, slow, slowest.
- 4.9.3 Bluetooth Settings:
- 1, Bluetooth stereo output: Turns on and off the Bluetooth stereo headphone output.
- 2, Bluetooth Stereo Headset: Select audio services need to be connected into the Bluetooth stereo headphones. (For support of Stereo

The Bluetooth headset when you want to turn this feature songs)

- 4.10 Network Settings
- 4.10.1 Network options:
- 1, re-search
- 2, select the network
- 3, select the mode

Automatic: Automatic search for the SIM card belongs network.

Manual: Search is now available to all networks, manual registration.

4, preferences settings: pre-existing number of your favorite network.

#### 4.10.2 Priority mode:

Can be set to use only mobile phone system, only using a wireless local area network, mobile phone systems give priority to, wireless local area network priority.

#### 4.11 Security Settings

## 4.11.1 Security Settings

Showing SIM card and SIM card security settings for a security settings 2.

#### 1, SIM card lock:

In this menu you can set the phone security options in order to avoid cell phone or SIM card is the illegal use. PIN code of your SIM card to prevent unauthorized use, if the current PIN is closed, select Open to open the PIN code protection, the next boot will ask you PIN code; if the current PIN code is already open, choose Close to close the PIN code protection, choose to change the PIN code you can set a new PIN code, please follow the prompts to enter the old PIN code followed by the new PIN code and repeat the new PIN code.

Note: PIN code three times, if mismatched, SIM card will be locked, when you need PUK code to unlock the SIM card. PIN code and PUK code may be provided with the SIM card to you, if not, contact your network vendor. The default PIN code is usually 1234, please change it as soon as possible to set their own password.

#### 2, fixed dial-up:

When this feature is turned on, only a fixed dial-up tables can call the phone number or a few figures in the table at the beginning of the phone (requires SIM card support).

Mode: on or off the fixed dialing function (required to enter the PIN2 code).

Fixed Dial list: Enter the fixed-dial phone number.

Note: Turn on or off fixed⇔ dialing function, requires you to enter the PIN2 code, contact your network vendor to obtain PIN2 code, open the regular dial-up, go to the phone book shows a fixed dial in number.

3, to prohibit dialing: This feature requires SIM card support.

## 4, change your password:

Change your password. Including the PIN, PIN2

# 4.11.2 Phone Lock:

In order to prevent the illegal use, your phone can set the phone password protected. Elected to use this feature, you each

Second boot, you must enter the phone password, so you can unlock the phone, and then send or receive calls. Users can eliminate phone password, in this case, the phone will not prevent illegal use. Enter the phone password, clear the input error to use the right soft key, press to confirm the end. For example, if the phone password is set to 1122, then make the following type: 1122.

Note: The default phone lock $\Leftrightarrow$  password is 1122, you should change it as soon as possible for their own password. If you forget your cell phone password, you must contact your retailer or local authorized repair service center contact in order to unlock your phone password.

## 4.11.3 Keyboard lock:

Set the keyboard lock waiting time. After setting, when the phone is not used within a specified period of time, the keyboard will automatically lock. Standby mode press the # key to unlock.

4.11.4 Change Password: password of the phone changes.

- \* Note: Some features require support for your network operator.
- 4.11.5 Certificate Management: View authorization certificates and user certificates.
- 4.12 External links

Need to connect external devices are: Bluetooth connection, connection management, data accounts.

Bluetooth connection: Same as 15. Connection management: with 17.

Data account: Same as 4.7. 4.13 Restore factory settings

Function to set the phone back to factory defaults, the password default value is: "1122."

4.14 Sound

Set audio playback devices are horizontal, echo sound, stereo sound effect ring Yang, turned on or off bass enhancements.

4.15 Sensor Set

When the sensor is turned around shaking the phone to switch songs, and calls to achieve the next turn when you switch cell phone ringing tone for the mute function.

- 1, MP3 sensor settings: on or off MP3 sensors.
- 2, call sensor settings: on or off call sensors.
- 5. Book
- 5.1 Open the e-book

Open the e-book file.

5.2 Update

Update e-bookcase.

- 5.3 System Settings
- 5.3.1 Font size: select large, medium and small fonts on the 3rd.
- 5.3.2 Volume page: Select line scrolling and page scrolling.
- 5.3.3 Auto scroll: on or off auto-scrolling.
- 5.3.4 scrolling speed: Select the auto-scrolling speed.
- 5.3.5 Full-screen: Turn on or off full-screen reading.
- 5.3.6 encoding: Set the e-book reading of the encoding. The default is: English (Windows).
- \* Note: Open the e-book when the encoding, needs and encoding of the file consistent with the way e-books, or e-book content is not displayed correctly.
- 5.3.7 Alignment: Alternative left-justified, right-aligned.
- 5.3.8 Select storage location: Choose the path to read e-books, memory card or mobile phone.
- 5.4 Information

View e-book format, size and other information.

5.5 Delete

Delete the e-book file.

5.6 Delete all files

Remove the list of all the e-book file.

5.7 Sort by

Choose by name, type, time, size of the sort.

5.8 implementation of the System Settings

To restore the default settings.

5.9 Help

Displays help information.

6 Network Services

6.1STK

This item is provided by the network provider. If the SIM card and network providers do not support the kinds of services, the functions will not be used. For more information, please contact with the network provider.

6.2 Internet Service

6.2.1 Menu function:

- 1, Home page: Log Home. Home page is your connection settings in the start set the WAP site. If you do not set, will use pre-set vendor sites.
- 2, bookmark: Show all existing bookmarks. Choice can be directly connected to the bookmark URL. Select the option to enter the following menu:

Enter: Link to the current bookmark URL.

Edit: Edit the current bookmark name and URL.

Send: the bookmark URL via SMS, MMS, e-mail sent.

Delete: Delete the current bookmark.

Delete All: Delete all the bookmarks list.

Add a new bookmark: edit the title and address information.

- 3, web history: The records you have previously viewed online by the web site.
- 4, has maintained website: displays a list of stored pages.
- 5, enter the URL: Select this you can enter any of a WAP or any other Internet sites.
- 6, Service inbox: receive the WAP PUSH message mailbox.
- 6.2.2 settings: settings for Internet browsing.
- 1, select the SIM card: can be set to Always ask, SIM card 1, SIM card 2.
- 2, edit the settings file: Select settings for the service group, there are eight set group to choose from. Choose a setting to the next one to set the menu to view the file information, as well as startup settings file.
- 3, browse options: browsing the web when the parameter settings. Including wait time and display pictures.
- 4, service information is set: to open or close the service information.
- 5, clear the cache: Select the Clear Cache.
- 6, clear the cookies: Select this item to remove personal data.
- 7, trust certificate: You can browse and select the trusted certificate.
- \* Note 1: GPRS network support service needs to be opened later and the GPRS network coverage in areas, in order to use GPRS services.
- \* Note 1: The system software of Netease, Baidu, google, Sina, Sohu, Yahoo and other menu, login features and functions the same as in this note.

# 6.3 Baidu search

Need to search the contents of the input, select the search that is into the web search the contents of the specific menu functions with 6.2.

## 6.4UCWEB browser

Your phone provides you with a UC browser, you can use the UC web browser. This feature requires network support. First entry into the browser, the system will automatically get initialization data to initialize.

In the UC browser interface to select menu items to enter the following menu:

6.4.1, open the

To open the home page, URL, bookmark, and Help menu.

- 1, Home Page: enter the home.
- 2, URL: enter the URL editing interface for editing site, editing, press OK to complete connection URL.
- 3, bookmark: Entering bookmark list select collection of bookmarks browsing. Select a menu item to enter the following menu:
- 4, to determine: a bookmark to connect to the current Web site;
- 5, mobile: You can select the bookmark to move to the top, bottom, top or one that already exists The directory.
- 6, Editor: edit the bookmark name into the editing interface, click OK to enter the path after the editing interface to edit the bookmark path, press OK to finish editing.
- 7, New: Can a new directory, the new label, selection into the editing interface for editing the directory name press OK to complete the new directory, edit the label name and press OK to enter the path editing interface, click OK to finish editing the completion of the new label.
- 8, delete: delete the current menu, choose to delete the selected bookmark, choose to delete all bookmarks menu to delete the list of all bookmarks.
- 9 Help: Display UcWeb6 details.
- 6.4.2, navigation

Includes forward, backward, refresh, the Favorites menu.

- 1, forward: When you select Back to return on a website, select the advance might return to the current page.
- 2, Back: return to the previous one website.
- 3, Refresh: Refresh the current page.
- 4, Collection: Save the current URL to the list of bookmarks.
- 6.4.3, the window: You can browse two windows, through the New Window menu to open a new window; a new window to open the menu and open a new focal point of a link; choose Window menu to switch to achieve switching between the two windows, select the Close Window menu Close the current window.
- 6.4.4, tools:
- 1, Save Target As: save the currently selected message, the default storage location for the memory card. Is saved in File Manager menu to view store information.
- 2, download management: access to download the list of tasks, menu under the following menu: Select the pause menu to suspend the current download to download the task; choose to download the menu continues to be suspended to download the task; choice can re-download the menu has been suspended or have been completed Download the task to re-download; the task menu displays the current task more detailed information; delete the current: Delete the current download tasks; removal is complete: Remove the download has completed the task; Exit management: Quit Download Manager menu.
- 3, the page attributes: display the current page path, select the menu item to open the path into the current editing interface, the path can be edited; select View to view the current path.
- 4, Clear: choose Clear history, cache, and fully realized historical information, cache information, all the information removed.
- 6.4.5, set: There are menus,
- 1, theme settings: Set your browser's theme elements available with either black, pink, night three models.

- 2, the system set up: You can set up networks and systems, respectively detailed information under the menu option to restore the default option, the system default network access point for: china mobile gprs, network access proxy way: agent (ask your operator to confirm whether the GPRS service has been opened); when the network access point is set to: wireless local area network, please set the network access to: Direct Connect (make sure there are available wireless local area network).
- 3, horizontal screen switch: You can switch the screen display horizontal or vertical display.
- 4, full-screen switch: You can switch to the browser interface, full screen.
- 7. Multimedia

Your mobile phone to provide you with a variety of third-party software (video chat, mobile TV U m, U m Internet radio, FLV partners), in order to provide you with better quality TV, Radio and video chat. Note: Some features require network support, the specific flow rate and tariff information, please consult your operator.

7.1 video chat

Specific operating instructions refer to the software interface.

7.2 Camera

Your phone offers camera features, select the menu entry of the camera, press OK key to take pictures. Options include:

- 7.2.1 Album: into the album.
- 7.2.2 Camera Settings: When I am photographing a number of related parameters settings.
- 7.2.3 Photo Settings: Photo size and photo quality settings.
- 7.2.4 White Balance: But when the light settings.
- 7.2.5 Preset Modes: Choose Auto or night shooting mode.
- 7.2.6 Effects settings: effects of different models of selected photos.
- 7.2.7 Storage Location: Set the default storage path for photographs.
- 7.2.8 Restore Default: Set to restore the factory default values.
- 7.3 Album

View photos stored in folders under the photos or pictures.

- 7.3.1 View: Zoom preview the selected photos.
- 7.3.2 Printing: Connect the network printer to print pictures.
- 7.3.3 View Mode: Change album photo view mode select "matrix" or "list" mode.
- 7.3.4 Send: Through MMS, e-mail, Bluetooth, a way to send photos.
- 7.3.5 for: the use of selected photos as wallpaper, switch machine animation.
- 7.3.6 Rename: Change the selected photo file name.
- 7.3.7 Delete: delete the selected photos.
- 7.3.8 Sort by: According to the piece name, type, time, or the size of the selected folder of photos to sort.
- 7.3.9 Delete all files: Remove all of the photos album.
- 7.3.10 Storage Location: Change and choice of reading and take photographs of the storage path.
- 7.4 Video Recording device

Your phone offers recording animated features, video recording device select menu entry, click the button for video recording.

Press Options to enter:

- 7.4.1 Video Settings: Select this menu, enter the recording device of some relevant parameters settings.
- 7.4.2 Video Settings: Video quality parameter settings.
- 7.4.3 White Balance: video-light settings.

- 7.4.4 Effects settings: you can choose your video of this one special effects.
- 7.4.2 Storage Location: Select stored in phone or memory card.
- 7.4.3 Restore Default value: all the settings to their factory default values.

## 7.5 Video Player

Play users have stored on film, to select the shortcut keys associated interface operations, the following functions:

- 7.5.1 Play: play the selected animation.
- 7.5.2, send: Through MMS, send e-mail and Bluetooth.
- 7.5.3, rename: change the file name of the selected animation.
- 7.5.4, delete: Delete the selected animation.
- 7.5.5, delete all the files: remove all save the animation.
- 7.5.6, Sort by: For the current folder in the animation sort by name, type, time, large Little or none.
- 7.5.7, storage location: Choose to read the file path, mobile phone or memory card.
- 7.6 music player

Select music player into the MP3 player interface, optional interface shortcut keys in the related operations.

Click the upper right corner of the icon into the album playlists, songs, after loading you can scroll search songs for playback.

Song list interface, and then point the left soft-option into the song some of the health-related settings.

- 7.6.1. The basic functions of
- 1, Play: Play the currently selected songs.
- 2, detailed information: see the song details.
- 3, Move: Move the cursor to the selected songs on a song.
- 4, down: Move the cursor to the selected song to the next song.
- 5, add: From the phone or memory card, select songs to the playlist.
- 6, remove: remove the selected songs.
- 7, send: Through MMS, send e-mail and Bluetooth.
- 8, for: to join the current profile song ringtones library.
- 7.6.2 Music Set

Music settings with the 4.9.

#### 7.7 Recording

Select this item can be recorded, click on the shortcut keys associated interface operations. Press the left soft-Jian entry options:

- 7.7.1, a new recording: record a new voice.
- 7.7.2 Play: Play the currently selected recording.
- 7.7.3, added: on the basis of the original recording and add new recordings. (For AMR, AWB format)
- 7.7.4, rename: change the name for the current audio file.
- 7.7.5, delete: delete the current recording file.
- 7.7.6, the list: Check out audio file list.
- 7.7.7, set: Set record repository, the file format and sound quality.
- 7.7.8 for: the current recording sent to the scene mode ringtones library.
- 7.7.9, send: current recording via MMS, e-mail, Bluetooth sent.

#### 7.8 FM

Your phone supports FM radio, you can click on the shortcut keys associated interface operations. Select "Options" button, proceed as follows:

- 7.8.1. Channel list: You can edit the channel name, frequency. Appear on this list;
- 7.8.2. Manual Input: Direct Input FM radio frequency, such as: 103.7;
- 7.8.3. Auto Search: Auto Search FM channel and automatically update the channel list;
- 7.8.4. Settings: Set the background player turned on or off, set the appearance style.

Slide 7.9

This paragraph phone supports slide show function, can select a folder that contains images to set into a slide file.

- 7.9.1. Play: Play the slide.
- 7.9.2. Setting: You can set up slide shows the relevant parameters:
- 1, Play mode: automatic (once), auto (repetition), Manual.
- 2, speed: slow, medium and fast.
- 3, Effects: No effects, progressive, segmentation, random.
- 4, the background music: choose to close or from a file selection.
- 5, the level of play: Turn on or off the level of playback functions,
- 6, sound: off, music 1, music 2, music 3.
- 7, Sort by: by name, by type, depending on the time, depending on size, or no sort.
- 7.10.3. Continue: to continue to slide.

7.10 TV

Analog TV playback, you can manually or automatically search to get the channel.

Note: This function must select the area corresponding to the channel format, and can be obtained by adjusting the antenna for better TV signal.

- 7.10.1 Add to my channel: Custom channel option, and can be its own common or preferred channel, save it to my list of channels to facilitate the playback channels.
- 7.10.2 Channel list: saved searches to the TV channel list.
- 7.10.3 My Channel: Save your favorite television channel list.
- 7.10 .. 4 Channel Search: Auto search station function, through all channels, the signal channel is saved to the list. For select Play.
- 7.10.5 Search area: to provide the various regions of the format options.
- 7.10.6 display settings:
- 1, Brightness: adjust the brightness when on television.
- 2, the signal strength display: You can choose to open or close the weak TV signals when prompted.
- 3, the signal weak Tip: to open or close the weak signals prompt.
- 8. Toolbox
- 8.1 Calendar

Access to the calendar management submenu.

Press Options to enter sub-menu

Create a new schedule is displayed as: conferences, courses and other matters. And have worked to add an alarm reminder. You can choose to once, daily, self-definition, weekly, monthly five options.

Once again: that the schedule is only to remind once.

Every day: that day, at all times in the set will remind.

Self-definition: set the alarm sounded in the week time.

Weekly: that the set time every week will be reminded.

Monthly:: said at a set time every month will be reminded.

- 1, view: view the current calendar date.
- 2, View all: View all schedules.
- 3, Add Event: Add schedule
- 4, delete events: remove unwanted events.
- 5, go to the specified date: The calendar of the current date is set to the specified date.
- 6 to Week / Month View: View a month or a week schedule.
- 7, Lunar New Year: on or off Lunar New Year show.
- \* Note: Due to storage space is limited, please user the best record store no more than 70. Otherwise be lost.

8.2 task

The list in the task to add appointments, telephone, anniversaries and other memo information.

8.2.1 Add

- 1, Date: memorandum prompt date.
- 2, time: memorandum prompt time.
- 3, topic: prompt displayed on the screen content.
- 4, alarm clock: alarm clock on or off.

As follows:

Once again: that the memorandum is only to remind once.

Every day: that day, at all times in the set will remind.

Self-definition: set the alarm sounded in the week time.

Weekly: just to remind once a week, said the memorandum.

Monthly: reminder once a month, said the memorandum.

- 5, location: Editor Memo location information displayed on the screen when prompted.
- 6, priority: Set the memo priority: high, medium and low.
- 7 Details: Edit the task details.
- 8.2.2 View: View of the memorandum has been saved.
- 8.2.3 Add: re-add the editor to another memo.
- 8.2.4 Editor: re-edit the saved aide-memoire.
- 8.2.5 Delete: Delete a single memo has been selected.
- 8.2.6 Delete expired tasks: (when the task list will be displayed when there is overdue reminder of the menu) to delete the reminder has expired.
- 8.2.7 Delete All: Delete all saved aide-memoire.
- 8.2.19 jump to the specified date: jump to the specified date of the memo list.
- 8.2.9 send the schedule: The selected memo via SMS, MMS, e-mail sent to other Bluetooth-enabled hand -

Machine.

- 8.2.10 saved as File: Save to local file management.
- 8.3 Alarm
- 8.3.1 Switch: Turn on and off the alarm clock.
- 8.3.2 Time: set the ringing time.

- 8.3.3 Ringing mode:
- 1, once again: indicates that the alarm clock just to remind once.
- 2 a day: that day, at all times in the set will remind.
- 8.3.4, self-definition: set the alarm clock ringing in the week time.
- 8.3.5 Ring Settings: Set ring tones or FM radio.
- 8.3.7 Snooze Time: Set 1 ~ 10 minutes, or the default value, the alarm time septal tips.
- 8.3.19 Ring mode: Set ringing, vibration, vibration and ringing.
- 8.4 World Time

You can set the world time.

- 9. Profile
- 9.1 Standard Mode
- 9.1.1 Start: Select the boot into standard mode.
- 9.1.2 Personal settings: Select your personal settings to enter the mode to customize it.

Functions as follows:

- 1, ring tones settings: change the call, switch machines, information, and key tone type of sound and so
- 2, volume: adjust sound volume of ring tones and keypad tones.
- 3, suggesting that type: Select a prompt type: ringing, vibration, vibration and ringing, vibrating ring post.
- 4, bell type: heard, repeated or crescendo.
- 5, suggesting that tone: set the tone of certain events: a warning, error, network connections or calls with sound

Access and so on.

- 6, response mode: Set any key answer.
- 9.2 Meeting mode:

With the standard mode of operation

9.3 Outdoor Mode

Operation with the standard model.

9.4 Indoor Model

Operation with the standard model.

9.5 Headset Mode

Plug in headphones, the phone automatically defaults to the headset mode, specific operations with the standard model.

9.6 Bluetooth Mode

After the success of the Bluetooth headset to connect the phone automatically defaults to the Bluetooth mode, specific operations with the standard model.

## 10. Exchange rate conversion

Any change in currency exchange rates between the conversion. Input rate, and then enter the national or foreign currency values, press the left soft key OK, in another edit box displays the values you need.

11. Document Management

11.1 use function

Open: Displays the contents of the folder.

New Folder: In this folder create a new information.

Format: Format the folder.

Rename: change the file or folder name.

Delete: delete the file or folder.

Sort by: The file or folder to be sorted.

Details: view a file or folder details.

Copy the files: Copy the file or folder to any location. Moving Files: Move the file or folder to any location.

11.2 Folders feature

Audio: The default save path of record. Images: Photo of the default save path.

My Music: store folder upload songs, music player, the default path.

Photos: photographs of the default save. Videos: shooting video of the default save.

#### 12. Calculator

Click Enter to calculate the number of 0-9.

Click the appropriate symbol can enter, -, \*, /, M, M-, MC, MR a total of eight operational symbol.

Click to clear the last bit can be input or results, click the "Back" opt-out calculator, click the "OK" calculations.

\* Note: This computer device has limited accuracy and rounding errors will be generated, especially in the divisible time.

#### 13. Stopwatch

The machine-oriented sub-general and multi-stopwatch stopwatch, this feature can accurately recording time, click OK, enter the Options menu:

### 13.1 General code table

Namely, two kinds of timing and in lap time. Time can be kept in view the record time to view, delete or delete all.

## 13.2 Multi-oriented code table

Click around and down time can be recorded separately, after a pause can be cleared by reset.

## 14 Telephone

Click to dial into the phone menu interface

# 14.1 phone features

## 14.1.1 Use the numeric keys to call:

1, click on the main menu of the dial-up menus, in the dial interface, click the digital input telephone number, to repair

To change the number on the screen, move the cursor, and then a short click the Clear icon to delete a character before the cursor, long click the Clear icon to clear all the characters.

- 2, enter the dial phone number, click to dial, can be dial-up card 1 or card 2.
- 3, click on different icons, can enter the number to save, call records, call center, phone book and voice mail menu.

#### 14.1.2 to use the telephone book to call:

Into the telephone book list, select the desired number, enter the option, and select Call.

# 14.1.3 the use of phone records to call:

Access to call records, select the desired number, enter the option, and select Call.

## 14.2 Call Options

Used in a variety of call features.

Mute: Turn off the microphone, so that the other party can not hear their own voice.

Dial pad: Open the dial pad, you can enter a number.

Hands-free: Open speaker, the sound from the speakers in the issue.

Add a call: You can enter numbers, create a new call (this feature requires the network operator support).

Reservations: call to suspend.

Phone book: You can enter the phonebook menu.

15. Bluetooth

The phone supports Bluetooth technology, support for headset mode, text mode of transmission patterns varied.

15.1 Bluetooth Settings menu

15.1.1 Activate Bluetooth: on / off the Bluetooth function

15.1.2 Search for hands-free devices: search the current Bluetooth hands-free devices

15.1.3 Remote control: via Bluetooth can control the computer desktop, slideshow, music player and so on.

15.1.4 My devices: has been seized and the establishment of the connection device list.

15.1.5 Connect the device: the current established connection equipment.

15.1.6 Setting: When using the Bluetooth function, you first need to do the necessary settings.

15.1.7 my Bluetooth: Bluetooth view the current situation.

15.2 to establish a Bluetooth connection

Bluetooth opens, select "Search-free device", or go to "My devices" - "Options" - "Search new device" to search for Bluetooth devices within the valid range. The importation of equipment identified in consultation with the Bluetooth password in order to create the pairing between devices, then you can transfer data.

After the Bluetooth connection device connected devices can do the following:

Online: Get connected device in the device name.

Delete: Delete all devices in the list records.

Service Records: to view the current can be of service.

Search for new devices: See Bluetooth device within a valid range.

Using Bluetooth technology to mobile phones within 15 meters with a compatible Bluetooth device to establish an unlimited connection. However, the Bluetooth wireless connection may be due to obstructions such as walls or other electronic equipment from interference.

Bluetooth wireless technology using the required functionality, or use other features to run in the background of these features, it will quickly consume phone battery power and shorten battery life. Do not recommend the Bluetooth technology off the feature.

To ensure mobile phones and other wireless technologies to support each other between the operation of the equipment, please use our equipment manufacturer recognized as applicable to this model phone accessories, on equipment manufacturers to determine whether their equipment is compatible with this phone.

## 16. Fun & Games

Your mobile phone to provide you with a variety of third-party entertainment software (U m game centers, excellent m sensual listening to the book, JAVA, JAVA settings):

16.1 Um game center

The game need to network and memory card support, the specific instructions detailed in the software help explain the menu.

16.2 Um sensual listening to the book

The software requires network support, for the first time will need to download and install the software directory, the software prompts the light of specific operations.

16.3 Java

Choose Opera Mini 4.2 can enter the following menu interface:

(Note: This feature requires network support, tariffs please consult your operator for the first time using the need to install the application software.)

Executive: Select this menu and entered the web interface.

Setting: You can set up the network access, self-executing, information, multimedia, reading the user data, write the user information, the local on-line manner is always asking permission, do not allow for each question, the first question, only ask once.

Details: Display game software for more information.

Network:

Set mode: can be set to the default value JAVA or user-defined, when the mode is set to the default value of JAVA to use the default value of the following menu: Select the SIM card, Java SIM card settings group.

Select SIM card: SIM card can choose one or the SIM card 2.

Java SIM card a set group, Java SIM card is set Group 2: 1 respectively for the SIM card and SIM card 2 set the appropriate network connection.

To restore the default settings: Select this option to restore default settings.

16.4Java Set

Java Sound: Set the sound size, there are seven levels to choose from.

Java backlight: backlight on or off.

Java vibration: vibration on or off.

SIM card options: select the desired SIM card to SIM card 1 or SIM card 2.

JAVA SIM card settings Group: setting need to use the network.

Implementation of the memory size: Set a value of 2.048 million bytes.

16.5 Games

Mahjong:

New Game: start a game.

Game Mode: Select the game difficulty. Best Ranking: This game record list.

Game Help: to enter the menu to see rules of the game.

Game Setting

Background Sound: Turn on or off the game background music.

Sound: Turn on or off the game sound effects.

Game vibration: vibration on or off the game tips.

Volume: adjust the volume size.

16.6 Dynamic Games

Dynamic Dice: Start: Start a game.

Game Setting: Event, sound, volume and other settings.

Event Settings: Add Event.

Help: to enter the menu to see rules of the game.

17. Wireless Network

- 1, enable wireless networks: enable and disable the wireless network.
- 2, wireless network status: Displays the wireless network status information. Such as: mobile phone MAC address, SSID, BSSID, channel, signal strength, speed, IP address.
- 3, the access point settings: enter the access point list, when the list is empty, select Options to enter the access point editing interface, when the list is not empty when you select the option to enter the following menu:

Connection: connect or disconnect the connection with the APN

Editor: enter the Edit menu to edit the current access point, as follows:

The link name: set the link name.

SSID: Set Service Set ID.

Set Network Type: Infrastructure construction, point to point wireless transmission.

TCP / IP settings: Set whether to use DHCP, set the IP address, set the subnet mask, set the default gateway, set the primary DNS address, set the second DNS address.

Set the security mode: Open network, sharing, IEEE 802.1X, WPA / WPA 2, WPA / WPA 2 PSK.

Encryption mode: Set encryption mode is turned off or WEP.

WEP key settings: (when WEP encryption mode is set to when you need to set the WEP key)

Set in the use of WEP keys: can be set to # 1, # 2, # 3, # 4.

WEP Encryption: can be set to 64-bit or 128-bit.

WEP key format: can be set to ASCII or hexadecimal.

WEP key: enter the editing interface for editing keys.

New access point: New and edit the access point.

Delete: delete the access point.

Change Priority: set the access point priority.

4, the search network: search for available wireless networks.

Connection: connect or disconnect the wireless network.

The definition of access point: the definition of the type of network access point and settings.

Details: Display the access point network status and other information.

Update: refresh the list of available wireless networks.

18 calls Background Music

Can be set to the background sound when making a call.

18.1 choose to call

When you call to set the background sound on or off.

18.2 Play Set

Set the background tone of the volume, play mode.

18.3 Background Music List

There are 10 kinds of background sounds to choose from.

19 MSN

Your mobile phone to provide you with MSN chat software, the software needs of network and memory card support.

19.1.1 Start:

For the first time will need to download the software, the software have been downloaded into the

sub-menu to select the MSN menu to enter

To the login screen, enter the account name and password, right-click login. Enter the login account interface, click Options menu

Enter the following menu:

- 1, log on: the current account login.
- 2, registration: enter the registration interface, enter the account number, password, press OK to send registration request.
- 3, log settings: can be set to save passwords so as to avoid the trouble of each log type can also set up automatic logon.
- 4, the connection settings: can be set to WAP connection, NET connection, WIFI.

More software instructions please refer to logon screen list of options under the Help menu.

19.1.2 Settings:

Update frequency can be set once a week once a month, or temporarily update; can set up the network connection WAP

Connection, NET connection, WIFI.

19.1.3, version upgrade: update software version.

19.1.4, on: release notes.

More tariff instructions, operating instructions, download the monthly flow of information, please refer to the software provided by the user help area (update the software before it can view it) 20 Art font

Three of the font for you to choose: Simple bold, amber body, Mao Zedong fonts, font selection will be the interface corresponding font, the system default is simple blackbody.

# **Frequently Asked Questions**

Network operator can set the feature does not support or need to sign up, please contact the network transport

**Business Contacts** 

PIN has been locked input network operators to provide, together with the SIM card PUK code to unlock the password, or contact your network operator.

PIN2 locked enter the network operator with the SIM card provided with the password or contact PUK2 code to unlock network operators.

Hua Fei did not transfer billing pulse counter is invalid, please contact your network operator.

SIM card SIM card error dirty, clean and SIM card

To re-install the SIM card

SIM card has been damaged, replace the SIM card.

The manufacturer has the final interpretation of this manual.

The manufacturer reserves the technical rules change without prior notice.

The manufacturer reserves the right to modify this manual without notice.

The manufacturer reserves without prior notice for technical product specifications, under the right to make changes.

#### FCC Notice:

- \*This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
- \*This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

  -Reorient or relocate the receiving antenna.
- -Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help.

#### Cautions:

Changes or modifications made in the radio phone, not expressly approved by Bestpower Direct Export Co. Ltd, will void the user's authority to operate the equipment.

Only use approved batteries, antennas and chargers. The use of any unauthorized accessories may be dangerous and void the phone warranty if said accessories cause damage or a defect to the phone.

#### SAR values:

The exposure guidelines for mobile devices employ a unit of measurement known as the Specific Absorption Rate or SAR. The Tests for SAR are conducted using standard operation positions with the device transmitting at certified power level in all tested frequency bands Your mobile device is also designed to meet the requirements for radio waves established by the Federal Communications Commission (USA). These requirements set a SAR limit of 1.6W/kg averaged over one gram of tissue. The highest SAR value reported under this standard during product certification for use at GSM 848 the ear is 0.239 W/kg and when properly body-worn is 1.110 W/kg, for use at PCS 1900 the ear is 0.302 W/kg and when properly body-worn is 1.050 W/kg.

Information about this device model can be found at <a href="http://www.fcc.gov/oet/fccid">http://www.fcc.gov/oet/fccid</a> by searching the equipment authorization system using FCC ID: YNFWT8000

Use of device accessories not approved for use with this device may result in different SAR values that exceed allowable limits. Any body worn accessory used with this device must NOT contain any metal. Use of an accessory that does contain metal may cause SAR values that exceed the allowable limit.