FCC INFORMATION

FCC ID: YRG4055427CF

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- •Increase the separation between the equipment and receiver.
- •Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution (Battery usage, handling, disposal)

Incorrect use of batteries can result in hazards such as leakage and bursting. Please observe the following:

- Do not mix old and new batteries.
- •Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries, or mix batteries with different brands, although they may look similar, different batteries may have different voltages.
- •Make sure that the plus and minus ends of each battery match the indications in the battery compartment.
- •Remove batteries from item that isn't going to be used for a month or more.
- Do not attempt to destroy or disassemble battery or remove any of its components.
- Batteries must be recycled or disposed of properly. Please consult your local waste authority for information regarding available recycling and/or disposal options/instructions.
- Keep batteries away from children and pets. Do not incinerate fire and/or serious injury could result from a failure to comply with these warnings.

Battery Replacement

When item does not function as intended, it may due to low battery voltage. Please follow the below steps to make battery replacement.

- •Open the Battery Compartment Cover.
- Remove the old batteries from the battery compartment.
- •Insert (3) AA size batteries into the battery compartment following the battery marking direction with correct polarity. (Suggest using Alkaline Batteries.)
- •Close the Battery Compartment Cover.

To Install Batteries in Small World Base

1. Turn base upside-down and open battery compartment.



2. Insert three (3) AA batteries in direction indicated in battery compartment. (Batteries not included.)



3. Close battery compartment.



To Activate Music with Small World Figurines

 Turn power switch located on bottom of base to the ON position.



2. Turn base right-side up and set on a flat surface.



3. Place any Small World figurine on top of the base to start music.



- 4. Additional Small World figurines can be added on the base. Once the music for the first figurine ends, the music for the additional figurines will be played consecutively in the order the figurines were placed on the base.
- Once all the music for the individual Small World figurines on the base has been played, the finale for "It's a Small World" will play.



6. To play the entire Small World song collection available in the base, turn the base over and press the small button located to the right of the battery compartment for four seconds. To stop the music, press the button again.



Note: To conserve battery life, this base comes with an automatic shut off function. If there is no activity for five minutes after the music has ended, the base will turn itself off. To re-active the base, re-set the power switch by turning it to the OFF position, then back to the ON position.