



User's Manual of Q970 Mobile Phone

TABLE OF CONTENT

TABLE OF CONTENT	2
CHAPTER 1 BASICS.....	3
1.1 INTRODUCTION	4
1.2 SAFETY NOTICE	4
1.3 GENERAL NOTES	5
1.4 NOTES ON USING MOBILE PHONES	5
1.5 NOTES ON BATTERIES	6
1.6 NOTES ON USING THE CHARGER	7
1.7 CLEANING AND MAINTENANCE.....	8
1.8 GENERAL NOTES	8
CHAPTER 2 BEFORE USING	8
2.1 THE PART OF THE NAME AND DESCRIPTION.....	8
2.1.1 TECHNICAL PARAMETERS	8
2.2 SIM CARD.....	9
2.3 BATTERY	9
2.3.1 BATTERY REMOVAL AND INSTALLATION.....	9
2.3.2 BATTERY CHARGING	9
2.4 BOOT	10
CHAPTER 3 BASIC DESCRIPTION	11
3.1 KEYBOARD DESCRIPTION	11
3.1.1 BASIC KEYS	11
3.2 PHONE FEATURES.....	11
3.2.1 DIAL CALLS	11
3.2.2 RECEIVE CALLS	12
3.2.3 REFUSE TO ANSWER CALL.....	12
3.3 USE	12
CHAPTER 4 MENU IN DETAIL	13
4.1 CONTACTS	13
4.2 MESSAGE.....	13
4.3 CALL LOG	16
4.4 SETTINGS	17
4.4.1 Call.....	17
4.4.2 Phone	19
4.4.3 Display	19
4.4.4 Security	19
4.5 GAMES	20
4.6 PROFILE	20
4.7 MULTIMEDIA	21
4.7.1 Camera.....	21
4.7.2 Handycan	21
4.7.3 MP3 Player	22

4.7.4 <i>Media Player</i>	23
4.7.5 <i>FM</i>	23
4.7.6 <i>Recorder</i>	24
4.7.7 <i>Image browser</i>	24
4.7.8 <i>E-book</i>	25
4.7.9 <i>File management</i>	25
4.8 TOOLS	25
4.8.1 <i>Bluetooth</i>	26
4.8.2 <i>Alarm</i>	26
4.8.3 <i>Calendar</i>	26
4.8.4 <i>Calculator</i>	26
4.8.5 <i>World Time</i>	26
4.8.6 <i>STK</i>	26
4.9 BROWSER	27

WARNING:

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The following are the suggested text on SAR information

Specific Absorption Rate (SAR) information

The SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of tissue. This model (FCC ID: YROQ970) has also been tested against this SAR limit. The highest SAR value reported under this standard during product certification for use at the ear is **0.225**.

Shielded cables must be used with this unit to ensure compliance with the Class B FCC limits, and the shielded cables is marketed with the mobile phone, don't use others.

Use of other accessories may not ensure compliance with FCC RF exposure guidelines

Chapter 1 Basics

1.1 Introduction

Thanks for selecting Q970 color screen GSM/GPRS digital mobile phone. Through reading the manual, you can fully know how to use Q970 mobile phone, appreciate its complete function and simple operating method.

Q970 color screen mobile phone is designed aiming at GSM/GPRS network environment; and it is Two Card Two Standby. Besides basic call functions, Q970 also provides many kinds of practical functions, such as Contacts, Profiles, message, Mp3 Player and Media player, TV, Fm, camera and video, E book, game, GPRS internet access, Bluetooth, alarm, Calculator, world clock, STK, time and date, auto power-on and shut-down, and etc. so that convenient for your work and leisure activities. In addition, Q970 adopts personalized human-computer interface designed, its complete function can meet your different requirements.

Q970 color screen mobile phone accords with GSM/GPRS criterion, has obtained the certification of competent authority.

The company reserves the rights to revise the contents of the manual without prior notice.

1.2 Safety Notice

- If your phone is lost or stolen, please immediately inform the telecom department or commission agents of forbidding the use of SIM card, so that avoid the economic loss caused by false calling of others.
- When you contact with telecom department or commission agents, they need to know your phone IMEI number (printed on the label on the back of the phone and can be found after taking down the battery). Please copy the number and keep it safe for future use.
- In order to use the phone more safely, please adopt preventive measures, for example: set up the PIN code of SIM card, PIN code can prevent your SIM card from being used by others without permission. When leaving the car, please don't place the phone in a place easy to be seen, you had better to carry with you or lock in the suitcase.

1.3 General Notes

- Your mobile phone can only use the specified battery and charger of the company. Other products use may cause battery leakage, overheating, bursting and fire.
- Do not bang, shock, or throw cell phones, in order to avoid failure and fire to the cell phone.
- Do not put batteries, cell phone, charger in the microwave oven or high pressure equipment, or may cause circuit damage and fire and other accidents.
- Do not place a cell phone in flammable or explosive gases, otherwise mobile phones may cause a malfunction and cause a fire.
- Do not use mobile phones in high-temperature, high humidity or where there is a lot of dust, or may cause malfunction.
- Place the phone from the children's reach to prevent their children playing it as a toy, causing personal injury.
- Do not use mobile phones on uneven or unstable on the counter, to prevent malfunction or damage caused by falling.

1.4 Notes on using mobile phones

- On the plane, hospitals and other places where use is prohibited, please turn off the phone. Phone may affect electronic equipment and medical devices work, use of mobile phones in these areas, please follow the relevant provisions of the place. Auto-boot feature phone with a timer, check your alarm clock set to confirm your phone during the flight will not automatically boot.
- Do not use the phone around weak signal or high-precision electronic devices.

Radio wave interference may lead to misuse of electronic equipment and other problems. Especially in the vicinity of the following devices require special attention: hearing aids, pacemakers and other medical electronic equipment, fire detectors, automatic doors and other control devices. Mobile phones on pacemakers and other medical electronic equipment of the device, please consult the manufacturer or local distributor.

- Do not force on the LCD screen or use it to beat other things, otherwise the damage caused by liquid crystal panels and liquid crystal liquid leakage. If the liquid crystal fluid into the eye may cause the danger of blind. Then flush the eyes immediately with water (do not rub the eye) and to the hospital.
- Without professional guidance, do not remove or modify cell phone, or cause damage to the phone, leakage and circuit failure.
- In rare cases, in some models of car phone use may adversely affect electronic equipment inside the vehicle. Then please do not use the phone in order to avoid loss of security guarantees.
- If your vehicle is equipped with air bag, do not put the phone after the air bag or air bag can hit the area, so that the air bag inflates, the phone is subject to strong external forces, may cause serious injury to vehicle owners. According to driving conditions, please leave the main road, stopping cars and then make or receive calls.
- Do not use needles and other sharp things to press keys, otherwise they will damage the phone or a miss-operations.
- If the antenna is damaged, please do not use the phone, or may cause personal injury.
- Avoid the phone too close to the magnetic card and other objects, mobile phone radiation may remove the floppy disk, savings card, credit card information stored.
- Please put thumbtacks and other small metal objects on the mobile handset away from the place. Work with the magnetic speaker, will attract small metal objects, which may cause personal injury or damage the device.
- Avoid the phone getting wet, or water or other liquids entering the mobile phone will result in overheating, leakage and failure.
- Do not allow children alone.

1.5 Notes on batteries

- Do not throw the battery into fire, otherwise it will cause the battery to fire and burst.
- Install the battery, do not force pressure, otherwise it will cause battery leakage, overheating, bursting and fire.
- Do not use wires, needles and other metal objects to short-circuit the battery, or to the battery with necklaces and other metal objects together, otherwise it will lead to battery leakage, overheating, bursting and fire.
- Do not solder the battery ends, otherwise they will cause leakage, overheating, bursting and fire.
- If the battery liquid fluid into the eye may cause the danger of blind, then

please do not rub the eyes, rinse with fresh water, and then immediately to the hospital.

- Do not disassemble or modify the battery, otherwise it will lead to battery leakage, overheating, bursting and fire.
- Do not let it around the fire or heater or other hot areas, otherwise it will lead to battery leakage, overheating, bursting and fire.
- If the battery is in use, charge or save in the process of heating, discoloration, deformation and abnormal, please stop using and replace the new battery.
- If the battery liquid touched the skin, clothing, which may cause skin burns, immediately rinse with water, if necessary, please seek medical treatment immediately.
- If the battery fluid leakage or strange odor issue, please take it from the fire next to the open, avoid fire and burst.
- Do not leave the battery wet, otherwise the battery overheating, smoke and corrosion.
- Do not leave the battery under direct sunlight or near high temperature of the car, otherwise it will lead to fluid leakage and overheating, may reduce performance and shorten service life.
- Do not charge for more than 24 hours.

1.6 Notes on using the charger

- Use 220V AC. Using other voltage can cause leakage, fire and damage to the cell phone and charger.
- Against short-circuit charger, otherwise it will cause electric shock, smoke and damage the charger.
- Please do not use the charger with the damaged power cord, otherwise it would lead to a fire and electric shock.
- Please clean product in the power outlet with the dust.
- Please do not leave the charge next to water storage containers, etc. to prevent overheating, leakage and failure caused by water spills.
- If the Chargers come into contact with water or other liquid, please Immediately disconnect the power from the outlet to prevent overheating, fire, electric shock and charger failure.
- Do not disassemble or modify the charger, otherwise it will lead to personal injury, electric shock, fire and damage the charger.
- Please do not use it in the bathroom where is high humidity, or may cause electric shock, fire and damage the charger.
- Please do not touch the charger with wet hands, wires and electrical outlets, or may cause electric shock.
- Do not place heavy objects on the power cord or modified wire, otherwise it will cause electric shock and fire.
- Before the cleaning and maintenance pull out the power plug from the socket.
- Unplugging the charger when you seize, pull the power cord may damage the wire, causing electric shock and fire.

1.7 Cleaning and maintenance

- Mobile phones, batteries and charger is not waterproof, do not use it in the bathroom with high humidity, the same you should also avoid it getting wet.
- Use a soft, dry cloth to clean the phone, battery and charger.
- Do not use alcohol, thinner or benzene solution to wipe phone.
- A dirt outlet will lead to poor contact and power-down, so it can no longer charge, periodically clean please.

1.8 General Notes

Mobile:

- Please use the phone in 5 °C ~ 40 °C temperature and 35% ~ 85% humidity environment.
- If possible, keep it away from the ordinary telephone, television, radio and office automation equipment, so as not to affect the use of these devices and mobile phones effect.

Battery:

- Keep the battery from direct sunlight, cool well ventilated place.
- Phone battery life is limited. Battery charging time reduced with the frequent gradually. The battery life has done after Multiple charge fails, it should be replaced by new battery type specified.
- Do not throw old batteries in the general garbage. Used batteries in a clearly defined place to deal with the prescribed instructions, please do.

Charger:

- Do not charge in the following areas: direct sunlight; the place with the outside temperature that is below 5 °C or higher than 40 °C; humidity, dust or large vibration areas (cause trouble); TV, radio and other electrical appliances nearby (in image, sound effects).

Chapter 2 before using

2.1 The part of the name and description

2.1.1 Technical parameters

Host

Model:

Dimensions (length × width × thickness):

Weight:

Lithium Battery

Model:

Nominal Voltage:

Charge limit voltage:

Rated capacity:

Continuous standby time:

Continuous call time:

Travel Charger

Model:

Input:

Output:

2.2 SIM card

- Before Use the phone you must first insert a valid SIM card. SIM card is your key to enter the digital GSM network.
- And a network connection with all the relevant information and your call records are recorded in the SIM card initialization metal surface area, besides your SIM card with phone book that stored the received name, phone number and short message. SIM cards can be removed from your phone and put it into any GSM phone (new mobile phone automatically read SIM card).
- In order to prevent losing and damaging card information, you should avoid touching the metal surface area, and keep the SIM card away from the electric, magnetic places. Once the SIM card is damaged, you will not have access to GSM networks.

* Note: be sure to remove the SIM card before the phone off. There is absolutely prohibited in the case of an external power supply connected to insert or remove a SIM card, or SIM card may be damaged.

2.2.1 SIM card insertion and removal

- SIM card in a card in general, before the assembly, you must carefully remove it.
- Power off the phone, remove the battery and other external power supply.
- Put the SIM card into the SIM card seat.

When you need to take out SIM card, firstly shut down, then remove its battery, open SIM card seat and last get the SIM card out.

2.3 Battery

The initial state of battery charge is about 50% of the electricity, opening them to use. New battery would be charged at least 14 hours, and be completely used up the first time (power consumption and fail to boot) and then fully charged before use; the second time is as the first one, so after three consecutive time cycles, the battery will be easy to achieve the best state of the use.

2.3.1 Battery removal and installation

- **Demolition by the following steps:**
- ① push downwards and take the back cover; ② Remove the battery by lifting upward.
- **Installation as the following steps:**
- ① the battery snaps into the battery bay; ② Push the back cover upwards to be jammed .

2.3.2 Battery charging

- Plug the charger.
- Insert the charger connector into the phone up side.
- At this time, the phone battery indicator on top right corner of the screen will flash cycle; If the phone is shutdown in the charging time , the charging indicator

will appear on the screen, show that the battery is charging. If the phone is still in the excessive use of low power, the charge may be required after the beginning of a period of time before the charging indicator appears on the screen.

- When the screen upper right corner of the battery indicator shows full, and no longer flashing, indicating that charge has been completed. This process usually takes 6 to 8 hours. During charging, batteries, cell phone and charger will get hot, this is normal.
- Charge after taking it out from the AC outlet and disconnect the phone and charger.

* Note:

– Charging must be doing in temperature +5 °C ~ +40 °C of the ventilation, and be sure to use the charger provided by manufacturer. Use of an unapproved charger may be dangerous and breach of the phone recognition and warranty.

– When the phone is automatically powered off, showing the warning of “LOW BATTERY” so that you should promptly charge the battery. If the battery does not run out before charging and the phone will automatically reduce the charging time.

– The standby and talk time that Mobile phone manufacturers provide is based on the ideal working environment. In actual use, the battery life is according to the network conditions, working conditions and patterns of use vary.

– Be sure that the battery has been installed When charging, please Do not remove the battery with charging.

– After the charge, you will disconnect the charger with phone and power.

– If you do not have disconnected the charger with power and phone, then after quite a long time (about 5 to 8 hours), battery power consumption is to a certain extent, and then cell phone still begin charging. We recommend that you do not do this operation because it will be of some impact with your battery performance and life.

2.4 Boot

- To start the phone, please press and hold the red button; power off the phone by pressing and holding the red button.
- If you firstly open the phone but do not insert the SIM card, the phone will prompt you to insert the SIM card. Insert the SIM card, the phone will automatically test whether the SIM card is available.
- Then the display will show the following tips:
 - Enter the PIN1 (if you set a SIM card password) (specific operations security settings refer to section 4.4.4)
 - Enter the phone password (if you set the phone lock code) (specific operations security settings refer to section 4.4.4)
- After SIM card decryption is successful, the phone automatically searches for available network (the screen will show “searching the network”). Once contacted, the network provider’s name will appear on screen. At this point that the phone has gotten into normal standby mode, then it can be properly used.

* Note: If the screen prompts “only emergency calls (EMERGENCY)”, means that you have gotten out of the normal network coverage (service area), but you can still send an emergency call according to signal strength

Chapter 3 Basic Description

3.1 Keyboard description

3.1.1 Basic keys

- **Arrow keys:** the arrow keys can browse up and down the menu or set options for selecting to Browse.
- **Dial key 1:** SIM card 1 could dial phone number and answer the call; the standby mode, adjust the SIM card 1 dialed.
- **Dial key 2:** SIM card 2 could dial the phone number and answer the call; the standby mode, adjust the SIM card 2 phone records.
- **FM key:** You can enter FM player interface directly by pressing this key.
- **Hang up key:** end or reject the call; press and hold this button to power off; in other cases, normally click this button for returning to standby mode.

*** Note:** This manual, “press a key” refers to the press the key then release it; “long pressing a button” refers to press the button and hold for 2 seconds or more than 2 seconds.

3.2 Phone features

When the network provider's logo appears on the display, you can make or receive calls. The signal bar on the top left corner displays network signal strength. The impact to voice quality is related with the relatively large obstacles, so the movement in a small area can improve call quality.

3.2.1 Dial Calls

➤ Own country Phone:

Enter the phone number using the number keypad, then press dial key to dial the call. If you need to change the phone number, press the right soft key to delete characters entered. The display shows the animation when dialing the call. After picking up the other screen will show the call status information, if you open a connect tone, there will be the tone (requires network support).

After the call, press red button to hang up.

Area code + phone number + dial keys

➤ Call fixed extension telephone:

Some fixed extension phone can not directly dial, you need to dial the host, then dial ext. If you enter a phone number, inserted the symbol pause character “P” between the host and the extensin, the machine will automatically complete all the dialing for you to dial ext. Enter “P” through pressing and holding * key (At this point the screen will display symbols “P”)

Area Code + host number + P + extension number + dial keys

➤ The use of suspended characters examples:

For example: If you have a number in the 8880000 ones with dial-up way of the voice mail system, mailbox number 6666, password is 8888. You can do as the following

ways:

8880000 P 6666 P 8888

The first part of this number on the voice mail system number is for dial-up.

After Phone is answered, then sent 6666 to select the mailbox.

Issued before the password 8888, the second pause symbol will have 5 seconds of delay (the first P suggests the waiting call is connected, the P next means 5 seconds delay).

➤ **International Phone:**

To make international calls, can long press 0 until the display shows the international call prefix symbol “+”, which will allow you to call from any one country without knowing the local international telephone prefix number (for example, in China is 00).

Enter the prefix number, then enter your county area code and complete phone number that you want. Country code according to usual practice, Germany 49, Britain 44, Sweden 46 and so on.

Make international telephone calls as normal, “0” should be removed in front of the city code when dialing.

For example: call service hotline from other countries, you should do this:

+86 21 114

+ Country code + the complete phone number + dial key

➤ **Emergency Call:**

If the phone is in coverage of the network (by checking the top left corner of the network signal strength bar on the screen), You should be able to call Emergency service (you also can do emergency calls even without SIM card). If your netowrk service operators do not provide roaming service in this areas, the display will show “only emergency calls (EMERGENCY)”, tell you that you can only do the call of this tye.

3.2.2 Receive Calls

- Under normal circumstances, pressing dial keys can answer a incoming call .
- If you set any key to answer, then press any key to answer the phone.
- If the headset has been plugged in, you can also use the button on the headset to answer calls.

3.2.3 Refuse to answer call

Press the red button to reject incoming calls.

3.3 Use

- Insert the data wire when the phone has been powered off, the phone will display USB status, this time the phone is off in the state of charge and can be used as a mobile hard drive.
- Insert the data wire after powering on, mobile phone displays a menu:
 - Storage devices: mobile phones get into the storage mode, you can read and write contents in memory card on the computer.

Chapter 4 Menu in Detail

4.1 Contacts

- **New:** new phonebook records to SIM card or phone.
- **Contacts Search:** Select this option to access the phonebook browsing interface, it provides a search input interface, you can enter the appropriate information to select the telephone records. Finding alternative ways: 1. Lowercase letters 2. Capital letter 3. EN 4. Figures
- **Write a message:** send SMS or MMS to the record.
- **Dial up:** direct dial or IP call the record.
- **Send Vcard:** send to others via SMS or Bluetooth to the record.
- **Delete:** Select the deletion of the phone records. Select to delete the record in the SIM card, or select to Delete phone record from the phone. and choosing to delete one by one so you can delete the records in the phone book one by one.
- **Mark:** You can mark single, multiple or all of the phone book records.
- **Copy to:** Copy the records to SIM card, cell phone, or memory card.
- **Others:** the other functions is Divided into four small items:
 - speed dial settings: in the standby interface, press and hold the number key that you have set to the record, then you can dial this record.
- **Prompt:** press and hold 1,2-key to enter the SIM card 1,2 voice mail on the idle interface.
 - **Own Number:** view or edit own phone number.
 - **Capacity check:** Check SIM card or phone storage capacity.
 - **Single \ double-line display:** Set the display way of record list .

* Note: This phone can store 500 phone numbers.

4.2 Message

- **Write Message**
- **New SMS**

You could write new message by using this function. When you have input the message, press middle key to send, and press left soft key to insert the templates, to add contact person information and symbol, and to save, etc.

—**Send:** Enter the interface of input number, you can dial the phone number directly, or press left soft key to enter the contacts and select the number to send.

—**Insert the templates:** Enter the templates interface and you could insert the template to the message.

—**Add the information of the contact person:** Enter the contacts interface and you could insert the contacts information to the message.

—**Add symbol:** Enter the symbol interface and add the symbols to the message.

—**Save:** Save this message to the drafts.

- **New MMS**

You could edit the MMS, and insert pictures or ringtones with this function. Select the “create MMS” and enter, you could edit the receiver, forwarder, confidential receiver, the title and content, and operate the functions of send, preview

and save.

—**Send:** Send the edited MMS.

—**Receiver:** Input the number you want to send directly, or enter the Contacts to choose the number, or choose group to add, after adding, the operation of deleting or modifying the receiver is also allowed.

—**Forwarder:** Input the number you want to send directly, or enter the Contacts to choose the number, or choose group to add, after adding, the operation of deleting or modifying the forwarder is also allowed.

—**Confidential receiver:** Input the number you want to send directly, or enter the Contacts to choose the number, or choose group to add, after adding, the operation of deleting or modifying the confidential receiver is also allowed.

—**Edit title:** Edit the theme of the MMS.

—**Edit content:** Under the edit content interface, press left soft key to edit the words, insert new page or picture, insert the sound, delete the current page and the playing time of the current page.

—**Preview:** Preview the edited MMS.

—**Save:** Save the edited MMS.

➤ Inbox

Store the SMS, MMS and Push message you've received. The SMS, MMS and Push message could be differentiated by different icons. The icons before the message list means whether this message is SMS, MMS or Push message and which is stored in SIM1, SIM2 or the phone.

Select one SMS or MMS and press left soft key, then you will do several operations, for example, reply, delete, dial, lock and mark. Press OK key directly you can read all the messages.

—**Reply:** You could choose to reply the addresser by SMS or MMS.

—**Delete:** Delete this message.

—**Dial:** IP Call/Call the addresser.

—**Lock/unlock:** Lock the message or unlock it.

—**Mark:** Choose one message or all messages, and choose message saved in SIM 1, SIM 2 or the Phone.

—**Sort:** Sort the messages in the inbox by time, contact person, theme or message type.

➤ Outbox

Store the SMS and MMS you've sent in failure. The SMS and MMS could be differentiated by different icons. The two icons before the message list means whether this message is SMS or MMS, and it is stored in SIM1, SIM2 or the phone.

Select one SMS or MMS and press left soft key, you could send, delete, lock, mark, sort, and so on.

—**Send:** Send this SMS or MMS.

—**Delete:** Delete this message.

—**Lock/unlock:** Lock the message or unlock it.

—**Mark:** Choose one message or all messages, and choose message saved in SIM 1, SIM 2 or the Phone.

—**Sort:** Sort the messages in the inbox by time, contact person, theme or message type.

➤ Draft box

Store the SMS and MMS you've edited. The SMS and MMS could be differentiated by different icons. The two icons before the message list means whether this message is

SMS or MMS, and it is stored in SIM1, SIM2 or the phone.

Select one SMS or MMS and press left soft key, you could delete, edit, lock, mark, sort, and so on.

—**Delete:** Delete this message.

—**Edit:** Edit this message.

—**Lock/unlock:** Lock the message or unlock it.

—**Mark:** Choose one message or all messages, and choose message saved in SIM 1 、 SIM 2 or the Phone.

—**Sort:** Sort the messages in the inbox by time, contact person, theme or message type.

➤ Sent box

Store the SMS and MMS you' ve sent successfully. The SMS and MMS could be differentiated by different icons. The two icons before the message list means whether this message is SMS or MMS, and it is stored in SIM1, SIM2 or the phone.

Select one SMS or MMS and press left soft key, you could delete, forward, lock, mark, sort, and so on.

—**Delete:** Delete this SMS or MMS.

—**Forward:** Forward this message to others.

—**Lock/unlock:** Lock the message or unlock it.

—**Mark:** Choose one message or all messages, and choose message saved in SIM 1 、 SIM 2 or the Phone.

—**Sort:** Sort the messages in the inbox by time, contact person, theme or message type.

➤ Template SMS

You could edit or delete the templates.

➤ Cell Broadcast

The area info services send different kinds of messages. Change the settings of this service and inquire the area info by using this function.

Read: Read the messages received.

Start up the broadcasting: Choose to start up/shut down the broadcasting.

Channel settings: Set the channel to receive the area message.

—**Add the channel:** Add the channel index and channel name.

—**Channel list:** Display the channel list.

Language settings: Set different languages.

➤ Voice Mail

This phone supports the function of the voice mailbox. You could choose either SIM1 or SIM2. When you receive the calls from others, they could give you a message in your voice mailbox. When you phone receives the message notice, you could listen to the messages. Under the voice mailbox interface you can edit and set the number of line 1, line 2, fax or data.

Listen to the message: Dial the number of the voice mailbox and listen to the message.

Number settings: Edit the number of the voice mailbox.

Prompt: The realization of the voice mailbox requires the support of the network operator and you may firstly apply for this service . For more information and the number of the voice mail, please inquire about your local network operator.

➤ Setting

➤ SMS Settings

There are seven options: SIM 1 service center, SIM2 service center, validity period,

delivery report, save sent message, preferential storage position, information statistics, etc.

—**SIM1 service center**: Display the SMS service center number in SIM1.

—**SIM2 service center**: Display the SMS service center number in SIM2.

—**Validity period**: You could set the validity period of the message for 1 hour, 6 hours, 24 hours, 72 hours, 1 week and the maximum value.

Prompt: This time is related with the services of the network operator.

—**Delivery report**: May choose to start up or shut down the delivery report. After switching this function as on, when the receiver gets the message or doesn't get for some reason, the SMS service center will give you a delivery report, so you will know whether your message sent successfully or not conveniently.

—**Save sent message**: There are three options: “Suggest to choosing”, “Save”, “Not save”.

—**Suggest to choosing**: Before sending the message, you will be suggested to choose “Send and Save” or “Send only”.

—**Save**: Save automatically your sent message.

—**Not save**: Not to save automatically the sent message.

—**Preferential storage position**: You could choose the preferential storage position at SIM card or phone.

—**Information Statistics**: Count the amount of the messages you've sent and received. You can re-set it by pressing left soft key.

➤ MMS Settings

—**MMS Account**: You could choose to set the MMS account of SIM1 or SIM2 in order to send or receive the MMS correctly.

—**Apply for delivery report**: When this function is on, after the MMS is successfully received, the user will receive a delivery report.

—**Send the reading report**: When this function is on, after the receiver reads the MMS, he would be inquired whether send the reading report or not.

—**Send anonymously**: When this function is on, after the receiver reads your MMS, the sender's name and number are hidden. This function requires the network support.

—**Priority**: Set the priority of the MMS as: High priority/common priority/low priority.

—**MMS receiving**: Manual receiving, automatic receiving. Start up the automatic receiving, then the MMS is received and return to the standby interface, the MMS will be loaded automatically.

—**Play sound**: When this function is started up, while viewing the MMS, the sound will be played automatically.

—**Accept advertisement**: If this function is on, the advertisements in MMS are allowed.

—**Validity period**: Set the validity period of the MMS: 12 hours, 1 day, 1 week and maximum period.

Prompt: This time is related with the services of the network operator.

—**Reset to default**: You could reset MMS settings to default by this function.

➤ Message Memory

You could view the capacity of SMS, MMS, WAP Push and OTA.

4.3 Call log

There are records in SIM1 and SIM2.

- **SIM card 1/2 dialed numbers:** the records of 20 different phone numbers dialed.
- **SIM card 1/2 received numbers:** the Records of 20 different received numbers.
- **SIM card 1/2 missed numbers:** the records of 20 different phone numbers missed
- **SIM card 1/2 rejected numbers:** the records of 20 different phone numbers rejected.

In the call log list interface, press OK to view the details of the record, including name, number, the date, call time, style and SIM name.

In the details interface, you can press option on the currently selected phone records and you can do as follows.

- **Delete:** Delete this record.
- **Save:** Save this number to the SIM card or mobile phone.
- **Call:** Call the phone number.
- **IP call:** IP dial this number.
- **Add to existing contact:** add this record to the existing contact.
- **Send message:** send SMS or MMS to this number.
- **Set as rejected number:** the number can not be received after setting.

- **Delete all:** you can delete all the records in SIM1 and SIM2.
- **Call time:** check the time of last call, received calls, dialed calls and all calls on SIM1 or SIM2, also you can reset them to zero.
- **Call costs:** you can check all costs, max costs ,cost rate of SIM1 or SIM2, and you can edit max calls ,cost rate and cost reset but it needs the network operators support.
- **GPRS Flow rate:** you can view the GPRS Flow rate of last sent, last receive, total sent and total receive on SIM1 or SIM2,besides you can set them to zero.

4.4 Settings

You can customize the settings, such as time and date, language, call settings etc.

4.4.1 Call

- **Dual SIM Settings**
 - SIM Enable Select:** You can choose standby mode as only SIM 1 standby, only SIM 2 standby or both cards standby.
 - SIM Setting:** You can set as dialing number, SMS, MMS, website browse, shortcut dialing, reply from the same card when both cards in use. After setting default card, select dialing number, sending SMS or MMS, connecting web page or reply from the same card will use the default SIM card. If you set as reminding selection, then whenever you do aforementioned work, you will be asked to choose SIM card.
 - Set SIM Name:** You can set any name you like as the name of SIM card slot.
- **Network Settings:** When your phone enjoys roaming service, the network can automatically or manually select network. The network roaming service can only be used when you subscribed the effective roaming service provided by the other network operator.
 - Auto Select:** Press left soft key, the phone will automatically search network. The operation will have the phone independently registered with the most proper network.
 - Manual Select:** Press left soft key, the phone will search available network, and select the compatible network from the network list.
- **Divert Calls:** When “call divert” function is started up, you can transfer the

incoming call to voice inbox or other phone number according to the scheduled “call divert” conditions.

—**Unconditional:** All incoming calls will be transferred to voice inbox or other phone number according to the setup.

—**If Busy:** When your number is busy, the incoming calls will be transferred to voice inbox or other phone number according to the setup.

—**If No Answer:** When there are missed calls in your phone, they will be transferred to voice inbox or other phone number according to the setup.

—**If Unreachable:** When your phone is power off or out of the service area, the incoming calls will be transferred to voice inbox or other phone number according to the setup.

—**Cancel All Diverts:** You can delete all settings of call divert.

➤ **Restrict Calls:** All outgoing calls, incoming calls, roaming incoming calls, international outgoing calls, roaming international outgoing calls are available.

—**All outgoing calls:** Start up the function will bar all outgoing calls.

—**All incoming calls:** Start up the function will bar all incoming calls.

—**Incoming When Roam:** Start up the function will bar all roaming incoming calls.

—**All Intl Outgoing:** Start up the function will bar all international outgoing calls.

—**Outgoing Intl Roam:** Start up the function will bar roaming international incoming calls.

—**Cancel all Barring:** Cancel all restrictions on the call.

—**Change Password :** You can consult your network operator about the call barring password.

Prompt: The above-mentioned function will have to need network support. To use the function, please contact your network service provider.

Call waiting: You can start up or shut down the function. When it is started up, even when you are making a call, you can also receive another income call.

➤ **Hide ID:** This function must be supported by network.

➤ **Line selection:** There are two lines can be selected: line 1 and line2 the default is line 1, and if you choose line 2, dialing will be limited.

➤ **Fly mode:** You can start up the function directly or choose when power on. It is used on flight. When fly mode is working all the functions connect with network, such as SMS, MMS, dialing back, WAP network, will be unavailable, to avoid interfering the signal of the flight you take.

➤ **Others:**

—**IP Number:** You can select different IP number or revise IP number.

—**50 Secs Warning:** If the function is on, when a call time is up to 50s, the reminder sound can be heard.

—**Connect prompt:** When the function is on, each time when a call is connected, the reminder sound can be heard.

—**Answer/ Reject Mode:**

1. **SMS reply After Reject:** When an incoming call is rejected, a reminder “reply SMS” will appear.

2. **Any key answer:** When this function is on, you can answer a call by press any key except power-off key and right soft key.

—**Auto Redial:** You can start up or shut down the function. When it is on, a failed

dialing will automatically redial.

4.4.2 Phone

- **Time and Date:** You can set up the date and time on the phone as well as their display mode.
- **Language:** You can select phone language.
- **Set shortcut:** You can set up and down left and right arrow keys on the shortcut menu.
- **Auto Power On/Off:** You can set the time and repeat mode of power-on and power-off.
- **Power management:** You can view the pair of battery power.
- **Restore factory settings:** You can restore part of the phone settings as factory settings.

The default code of restoring factory settings is: 1234.

- **Direction sensor:** Open this feature, as long as phones can achieve the corresponding rock features.

4.4.3 Display

- **Wallpaper settings:** You can set as default wallpaper image as well as more other wallpaper images.
- **Contrast:** On the screen backlight interface you can set different lightness of your phone by pressing the left/right direction key.
- **Backlight:** “Always on”, “30seconds”, “20seconds”, “15seconds”, “10seconds” and “5seconds” are available.
- **Keypad Light:** “20seconds”, “10seconds”, “5seconds”, “nighttime mode” and “shutdown” are available.

Prompt: When “nighttime” mode is turned on, the keypad light will not be on from 6:00 am to 6:00 pm.

4.4.4 Security

- **PIN:** You can start up, shut down or modify PIN code. Correct PIN code shall be input when you unlock or shut down PIN code. If PIN code verification is started up, each time when you switch on your phone, you will have to input PIN code. If you input mistaken PIN codes three times in a row, SIM card will be locked. You will have to get PUK1 code to unlock it. Please contact network operator to get PUK1 code when necessary.

The default PIN code is 1234.

- **PIN 2:** You can revise PIN2 code. For details, please contact network operator.
- **Privacy Protect:** You can revise privacy protection password. Besides, you can also set passwords for some menus, in this way, you will have to input password each time when you desire to open the menus.

The default password of privacy protection mode is 1234.

- **Automatic keypad lock:** You can choose to start up or shut down the function.
- **Darken screen by red key:** You can choose to start up or shut down the function. If the function is on, press red key in standby interface the screen will enter the state of backlight and locked keypad.
- **Power On Pwd:** You can start up or shut down “phone password” or revise it. When “phone password” is started up, you will have to input “password” each time when you use the phone.

Password default is : 1234.

- **Theftproof:** When “Theftproof” function is started up, you can only use your SIM card. If different SIM card is used, the phone will automatically check it when you switch it on, and the phone will require you to input protection password. If the password is correct, you can set up the SIM card so that it is compatible with the Theftproof function.

If three mistaken passwords are input, when you switch on the phone, it will send warning SMS to your original SIM card every 24 hours. If the phone is switched off, the warning messages will be sent when you switch on the phone. The warning messages will indicate the existing SIM card and the neighborhood number. To guarantee the safety of your phone, you are suggested to start up the function when you purchased the phone.

- **Activate:** Start up Theftproof function.
- **Deactivate:** To shut down Theftproof function, you will have to input the protection password you set for the phone.
- **Modify Pwd:** To revise protection password, you will have to input the protection password you set for the phone.

The default code is 123456.

4.5 Games

- **Box man**
 - **New game:** You can start a new Box man game.
 - **Continue:** You can continue to play the game you didn’t finish last time.
 - **Select Scene:** You can choose the level of the game.
- **MSN:** Your phone supports the function of mobile phone MSN, specific operation is the same as Microsoft MSN.

* **Note:** It needs GPRS network support while you use the function, also it will cause GPRS flow cost, please ask information for the network operator about GPRS service usability and cost.

4.6 Profile

- **Standard Mode**
 - **Active:** Select and start standard mode.
 - **Personal settings:** Select personal settings and enter the mode to customize. Functions as follows:
 - **Ring setting:** Change calls or message ringtone type.
 - **Adjust volume:** set the volume of incoming calls, messages, earpiece, keypad, alarm clock and power on/off tone.
 - **Call alert:** set as ring, vibration, silent, vibration then ring, ring and vibration.
 - **Message alert:** can set as ring, vibration, silent, ring and vibration.
 - **Alarm remind:** set as ring, vibration, silent, ring and vibration.
 - **Keypad tones:** silent, ringtone 1, ringtone 2.
 - **Battery low alert:** activate or deactivate.
 - **Power on/off tone:** activate or deactivate.
- **Silent mode**

Operations are the same as the standard mode.
- **Meeting mode**

Operations are the same as the standard mode.

➤ **Outdoor mode**

Operations are the same as the standard mode.

➤ **Beep-pager mode**

Operations are the same as the standard mode.

4.7 Multimedia

4.7.1 Camera

The mobile phone has been built-in HD camera, you can take pictures anytime, anywhere, and save the photo to memory card, it can be used as mobile phone wallpaper and you can send it via MMS and Bluetooth to others.

You can preview the image in the shoot interface, press ok key to shoot, and press the up/down arrow keys to adjust the zoom, press the left or right arrow keys to adjust menu

Settings:

- **shoot mode:** it can be set as digital camera or digital video mode.
- **Size:** size of the image can be set to take pictures.
- **Environment mode:** Image mode can be set as normal or night.
- **Light:** Totally there are 6 brightness levels for you to choose.
- **Contrast:** six contrast levels for you to choose.
- **Exposal:** six exposal levels for you to choose.
- **Burst:** can be set as forbidden and 3 photos.
- **White Balance:** You can set the effect of white balance according to your need.
- **Effect:** photo effects can be set according to need.

Pressing the left soft key interface in the camera preview can do the following:

- **View photos:** You can enter a list of photos, view the photographs, the specific operations refer to image browser.

Settings:

- **Image quality:** You can set image quality.
- **Avoid coruscate:** you can set it as 50Hz or 60Hz.
- **Shutter:** You can open or close the camera shutter.
- **Automatic save:** You can set auto-save as enable or disable.
- **Display parameters:** You can open or close the preview interface parameter display.

Help: Check relevant instructions of the camera.

*** Note:** The camera part of settings, after exiting the camera it will require you to reset when you enter it again.

4.7.2 Handycam

In the video preview interface, press OK key to enter shoot mode, and press left/right direction key can adjust menu settings below:

- **Shoot mode:** You can switch between “take photo” page and “Digital video” page.
- **Size:** You can set the video image size.
- **Light:** Six levels of brightness are available.
- **Contrast:** Six levels of contrast are available.
- **Effect:** The special effect can be classified into: normal, black and white, red, green, blue, yellow, negative and canvas.

In video preview interface press left soft key you can enter options menu as follows:

➤ **View video management:** You can view video list.

In video list interface press left soft key you can enter options menu as follows:

—**Create new folder:** Create a new folder.

—**Use video:** Set as screensaver, Power On or Power Off image.

—**Send:** Send the file to others via Bluetooth.

—**Delete:** Delete the file.

—**Details:** Check details of the file, name, date, size, position, resolution and so on.

—**Edit:** Rename or copy the folder.

—**Search:** Search the folder in the file.

—**Sort:** To sort according to name, date, size and type.

—**Mark:** Mark one or all the files in the list.

—**Memory Inquire:** View the service condition of the TF card. In this interface you can format iTF card by pressing left soft key, but this operation will cause the data in it lost forever.

➤ **Settings:**

—**Avoid Coruscate:** You can set as 50Hz or 60Hz. The default is 50Hz.

—**Audio:** You can set up audio as startup or shutdown. The default is startup.

—**Type:** You can set the mode of recording image as AVI or 3Gp.

—**Display Settings:** You can select Active or Deactive. The default is Active.

➤ **Help:** You can view the relevant operation instruction of the camera.

After shooting, you can press OK key to play the video you shot just now, and press return key to video preview interface, press left soft key to enter “options” menu, you can do as follows:

- **Shoot Again:** Choose the option, press left soft key you will enter video capture interface;
- **Delete:** Delete the video you took just now;
- **Send:** Send via Bluetooth;
- **Play:** Play the video;
- **Record Direct:** Enter the video list page.

4.7.3MP3 Player

In mp3 play interface , press number 2 or8 to adjust the volume of the mp3 and press power off key to the background play interface.

This phone could play the MP3 stored in the TF card and support the background play. On the audio player interface, press left/right or up/down direction key, you could rapidly operate the MP3 functions.

► Press Ok key can play the MP3;

► Press OK key and up direction key can make a pause;

► Press down direction key can stop playing;

► Press left/right direction key can choose previous one or next one.

Under the MP3 playing interface press left soft key you can do operations as follows:

➤ **Open:** Enter the TF card and open the MP3 stored in it.

➤ **Current Play List:** Display MP3 files list which are playing now.

Under the now playing list interface, press left soft key, then you can do operations as follows:

—**Play:** Play the MP3 you selected.

—**Add Music:** Choose new MP3 from the TF card and add it to play list.

—**Delete from list:** Delete the selected MP3 from play list.

—**Save list:** Save the current play list.

—**Clear current play:** Clear all the MP3 in play list.

—**All Play Lists:** Display all the MP3 or the play list you've saved.

Under the playing list interface, press left soft key, then you can do operations as follows:

—**Play:** Play the first music in playing list.

—**View:** View all the files in the list.

—**Delete:** Delete current list.

—**New list:** Create new list.

—**Rename:** Re-name the list.

—**Refresh :** Refresh the list.

➤ **Set call ring:** Set the selected MP3 as the ringtone of the incoming call.

➤ **Add to list:** Add the current MP3 file to an existing playlist.

➤ **Equalizer settings:** Set the music style as Regular, classical, odeum, jazz, rock or soft rock.

➤ **Settings:** Set lyric display as not displayed, display and backlight always display. And set play mode as looped play and random play.

4.7.4 Media Player

Enter the video play list interface, press left soft key, you could go on the following operations.

➤ **Play:** play the video file.

➤ **Add new Video:** Choose new video from the T card and add it to play list.

➤ **Refresh the list:** Refresh the play list.

➤ **Delete from list:** Delete the selected video from play list.

➤ **Details:** View the details of the video, name, date, time, resolution ratio, time span, size and so on.

➤ **Set as Power on:** Set the video as your startup image.

➤ **Set as Power off:** Set the video as your shutdown image.

➤ **Restore default startup/shutdown image:** Restore the startup/shutdown image as default one.

➤ **Mark:** Choose the video or all the video files.

4.7.5 FM

You can listen to Fm radio freely. Enter the radio interface, press up/down direction key can switch the frequency and pressing 2 or 8 can adjust the volume.

On the interface of the Radio playing, choose options you could enter the options menu and do operations as follows:

➤ **Auto search and save:** Search frequency available automatically and save it to broadcasting station list.

➤ **Channel List:** You can view all the broadcasting stations you saved and do the following operations:

—**Play:** Listen to the program of the frequency.

—**Edit:** Re-edit the frequency.

—**Delete:** Delete the frequency.

- Delete all:** Delete all the frequency.
- **Save:** Save the frequency you searched to the list.
- **Manual input:** Search the broadcasting station by input frequency manually.
- **Open speaker:** you can open or close speaker as your need.
- **Background play:** When the function is on, you can do other operations as well as listen to the radio.
- **Start to record:** Recording the current channel.

*Note: access to FM, you need to plug in your headphones.

4.7.6 Recorder

Use this function you can record or listen to your own record. You can also set the record as incoming call ring. The record file format: wav.

In recorder interface, press 2 or 8 can adjust the volume and move the cursor to the short-cut key on the screen and press OK key, then you can operate the functions of sound recorder swiftly.

-  Play the record.
-  Make a pause.
-  Stop recording.
-  Start recording.
-  Switch to previous record.
-  Switch to next record.

Enter “recorder” interface, press left soft key can do the following:

- **Audition:** Audition the tape you just recorded.
- **Delete:** Delete the tape you just recorded.
- **Send:** Send the tape to others via Bluetooth or MMS.
- **Record file list:** Enter the records list.

In record file list interface press left soft key you can do as follows:

- Create new folder:** Create a new folder under the catalog.
- Set as ringtone:** Set as incoming call tone.
- Send:** Send the file to others via MMS or Bluetooth.
- Delete:** Delete the file.
- Details:** Check details of the file, name, date, size, position and so on.
- Edit:** Re-name or copy the file.
- Look up:** Look up the file in the file.
- Sort:** To sort according to name, date, size and type.
- Mark:** Mark one or all the files in the list.
- Memory Inquire:** View the service condition of the TF card. In this interface you can format the storage by pressing left soft key, but this operation will cause the data in it lost forever.

4.7.7 Image browser

In the picture list interface press left soft key you can do operations as follows:

- **Change the folder:** Change the folder in which pictures are saved in memory card.
- **Send:** Send the pictures to others via MMS or Bluetooth.
- **Slide show:** Play the pictures in the list in a slide show manner.
- **Delete:** Delete the selected pictures.
- **Set as wallpaper:** Set the picture as standby wallpaper.
- **Re-name:** Rename the picture.
- **Mark:** Choose one or several or all of the pictures in the list.
- **Details:** View the details of the picture.

4.7.8 E-book

You can read e-book with txt format with the aid of this function. In e-book list interface, press left/right direction key to switch and look up the e-book in memory card .

In e-book list interface, Press OK key can open the book and press left soft key you can do the following.

- **Details:** View the details of the current e-book.
- **Recent reading:** Display the e-book list of recent reading.
- **Send via Bluetooth:** Send e-book to others via Bluetooth.
- **Delete:** Delete the selected e-book.
- **Mark:** Choose one or several or all of the e-books in the list.
- **Settings:** Set the mode of turning page, background font color.

In the interface of “read e-book”, press left soft key you can do the following.

—**Add bookmark:** You can save the existing page so that you can find it from bookmark next time.

- Check bookmarks:** You can read, delete and entirely delete bookmarks.
- Jump to first page:** Jump to homepage page of e-book.
- Jump to last page:** Jump to e-book Last Page.
- Jump pages:** You can edit the desired page.
- Turn off /turn on backlight always active:** Turn off or turn on the function of the backlight always active when you read.

4.7.9 File management

You can check the specific content and service condition of TF card with Left and Right Key. Meanwhile, you can format them too.

Choose one folder and press left soft key, then you can operate as follows:

- New folder:** Create a new folder.
- Delete:** Delete the folder.
- Details:** Check details of the folder, name, date, size, position and so on.
- Edit:** Rename or copy the folder.
- Search:** Search the file in the folder.
- Sort:** To sort according to name, date, size and type.
- Mark:** Mark one or all the folders in the list.

—**Capacity Enquiry:** View the service condition of TF card. In this interface you can format the storage device by pressing left soft key, but this operation will cause the data in it lost forever.

4.8 Tools

4.8.1 Bluetooth

➤ Start up/shut down Bluetooth

You can choose to “start up” or “shut down” Bluetooth.

➤ Device visible

You can choose “visible” or “invisible” Bluetooth. If the Bluetooth is invisible, others cannot search your phone.

➤ Paired device

You can search different Bluetooth equipments and find compatible ones (as long as the PIN codes of two Bluetooth equipments are identical with each other, the match will be successful. The PIN code of Bluetooth earphone is different due to different type, and you can find the code in operating manual of the Bluetooth earphone.).

➤ File share settings

—**Rights of shared directory:** You can choose “free access” or “read only” .

—**Shared directory:** The directory file you set as shared directory can be shared by others.

➤ My Bluetooth name

Change the name of the phone.

➤ Help

You can view the operating instruction of Bluetooth.

4.8.2 Alarm

➤ You can edit alarm, time, ring and repeated ring mode.

➤ In “alarm edit” mode, you can scroll up or down direction key, when the cursor goes to the desired option, press “OK”, then you can select desired settings.

4.8.3 Calendar

You can look up the calendar according to this function. Press left soft key on the Calendar interface, you can do the following.

➤ Calendar Setup: You can set up a calendar reminder.

➤ Check Calendar Reminder: You can check a calendar reminder of a certain date.

➤ All Calendar Reminders: You can check all calendar reminders.

➤ Clear Calendar Reminder: You can clear the calendar reminder of a certain date.

➤ Clear All Reminders: You can clear all reminders.

➤ Go to date: You can inquiry the information about date and calendar.

4.8.4 Calculator

The function will make your device a calculator with which you can carry out simple math calculation.

4.8.5 World Time

You can view the time of different location. If you travel to a country or city with different time zone, you can move the time zone graph by pressing navigation key to the country or city in world map, and you can find the local time then.

4.8.6 STK

Enter STK submenu, you can use the additional services that the network service operator provided.

The device has STK function. The service is provided by network operator. If SIM

card or network operator fails to provide the service, the function can not be available. Contact network service operator, if you want to have more information.

4.9 Browser

The device is compatible with WAP service. You can use the mobile internet business by the function. But before using it, you have to launch GPRS services, and it needs your SIM card's support.

➤ Url

Input website then visit it.

➤ Homepage

Enter homepage and visit it.

➤ Bookmarks

Enter bookmark page, you can add new bookmark. You can also do the following operations with the bookmark: Access, view, edit, delete, and delete all.

—**Access:** Get started to visit the selected web page.

—**View:** View the bookmark website.

—**Edit:** Edit the website and name of bookmark.

—**Delete:** Delete the bookmark.

—**Delete all:** Delete all bookmarks.

➤ Histories

— Record the websites you visited before. On the Histories interface you can also do the following operation with the visited web pages: get started, view, delete, and delete all.

1. **Access:** Get started to visit the web page in Histories.

2. **View:** View the web page in Histories.

3. **Delete:** Delete the Histories.

4. **Delete all:** Delete all the Histories.

➤ Snapshot

You can browse the websites when you are offline.

➤ WAP Settings

— Browser Setting:

1. **Clear temporary files:** Clear the temporary files you visited.

2. **Internet account:** Set your internet account of SIM card 1 or SIM card 2 in order to visit internet correctly.

3. **Download picture image:** You can shut down or start up “picture download” .

4. **Play background tone:** You can shut down or start up “play background tone” .

5. **Receive Push message:** You can shut down or start up “receive Push message” .

—**Storage position:** Memory card.

—**GPRS settings:**

You can set GPRS connection as “always connect” or “connect when need” .

—**Restore default:**

You can restore the default of WAP settings.

—**Internet account:**

Choose one account and press OK key you can view the default settings, and press left soft key to enter “Options” to do operations as follows:

Create a new connection: You can create a new connection, refer to the default settings in internet account you can create your own settings, and accord to the

webpage you want to connect you can set your home page.

1. **Add from listing:** You can add directly from the default listing.
2. **Search:** Search the connection.
3. **Delete:** Delete the connection.
4. **Edit:** Edit the connection.