

# Smart Seeker™ User's Guide

SECURE SMART TECHNOLOGY

This portable security system is great for traveling or just around and about.

Revolutionary patent-pending technology creates a secure "Safety Zone" around you making sure your tagged valued item is not forgotten or stolen. Your MONITOR alarms to let you know if your tagged item goes outside of your preset Safety Zone.



## ADJUSTABLE DISTANCE

Smart Seeker™ provides you the flexibility to determine the Safety Zone for your valued item by offering a choice of either a short (up to 9m or 30ft) or long (up to 30m or 100ft) range setting.

## SEARCH FEATURE

You can search for your TAGS with the press of SEARCH button on the MONITOR. TAG's loud audio alert goes on and beep when MONITOR is located within the range of 100 ft.

## LONG BATTERY LIFE

MONITOR runs over 1 year (2 x CR2032) and TAG runs over 6 months (1 x CR2032) on a single set of batteries. Batteries are included.

Smart Seeker™ User's Guide

## OPERATING INSTRUCTIONS


### MONITOR



1 To turn on TAG, slide switch to ON. The switch is located on the surface of TAG, close to battery compartment.




2 Slide switch on MONITOR to "SHORT" or "LONG" while TAG(s) are a few feet away. One beep will sound if one TAG was located or two beeps will sound if two TAGs are located. Every few seconds LED will blink once to indicate one TAG is being tracked, or blink twice if two TAGs are tracking.




3 If any of the TAG(s) exceed the selected range ("SHORT" or "LONG") your MONITOR will alarm.

### MONITOR DIAGRAM



### TAG DIAGRAM



STRAP ATTACHMENT  
(NEED TO USE ADHESION)

### ATTACHMENT OPTIONS


**Strap Option:** Peel off TAG adhesive seal **G** and snap Strap attachment  
**Direct Adhesive Option:** Peel off TAG adhesive seal **G** and stick to desired surface. **CAUTION: Adhesive is VERY STRONG. Make sure of location before sticking on TAG.**

## REDUCING FALSE ALARMS

Your Smart Seeker™ uses advanced Radio Frequency 'RF' technology that offers exceptional advantages by not requiring the MONITOR and TAG to have direct line of site to work.

However, operation may be affected by the manner in which the MONITOR and TAG are worn on the body or attached to an item. Under certain conditions the ALERT range may become shorter resulting in false alarms.

To Reduce False Alarms Try One or More of the Following Four (4) Suggestions:



1. Put setting on LONG

\*Slide switch is positioned to LONG setting, which is the preferred setting to prevent false alarms.

2. Using a strap to attach the TAG to an item is preferred over direct adhesion to some surfaces (like a cell phone or an IPOD).



3. Adjust location of MONITOR or TAG to be closer to each other. The body can greatly shorten the alert range so try to position the MONITOR and TAG on the same side of the body.

4. If false alarms persist, turn MONITOR off for 15 seconds and then turn back on.

## TESTING SYSTEM

(See MONITOR and TAG diagrams)

### ONE TAG OPERATION

Turn MONITOR to "SHORT" E setting while TAG F is about 30cm (1ft). After 10 seconds a single beep will sound and LED will start blinking. Holding MONITOR, begin walking away from TAG F. Note alarm goes off for your

"SHORT" setting. Turn MONITOR to "LONG" E setting and continue walking away. Note distance alarm goes off for your "LONG" setting.

### TWO TAGS OR MORE OPERATION

Turn MONITOR to "SHORT" E setting while TAGS F are about 30cm (1ft) away. Within 10 seconds, two short beeps will sound and LED will start blinking twice every few seconds to indicate both TAGS are being tracked. (If only a single beep sounds, only one tag was located. If you want two or more TAGS to be tracked, turn MONITOR off. Make sure all TAGS are close to MONITOR. Turn MONITOR on again. Holding MONITOR E, being walking away from TAGS F. Note distance alarm goes off for your "SHORT" E setting. Turn MONITOR to "LONG" E setting and continue walking away. Note alarm goes off for your "LONG" setting.

## GENERAL TIPS


1. The MONITOR performs best when worn or attached to a purse strap or clipped to a belt loop. Try to avoid attaching many keys to it and then putting it in the pocket of your pants.
2. To minimize false alarms, keep TAG as close as possible to the MONITOR at all times.
3. Metal objects, such as coins, may cause false alarms if they touch or are located very close to the MONITOR or TAG
4. Test the MONITOR and TAG in the manner they will be worn (example: MONITOR clipped to purse strap or pants belt and TAG on cell phone in pocket or belt holster).

## TROUBLESHOOTING GUIDE


PROBLEM	CAUSE	SOLUTION
<b>MONITOR</b> does not make a sound even when TAGS are out of range and LED never blinks	1. <b>MONITOR</b> needs to be reset. 2. <b>MONITOR</b> batteries are dead.	1. Reset <b>MONITOR</b> by removing and installing batteries again. 2. Replace <b>MONITOR</b> batteries.
<b>MONITOR</b> alarm always beeps when <b>MONITOR</b> is on	1. Both <b>TAGS</b> need to be reset. 2. Both <b>TAG</b> batteries are dead	1. Reset both <b>TAGS</b> by removing each battery, wait 10 minutes and install again. 2. Replace each <b>TAG</b> battery
<b>MONITOR</b> beeps once every 10 minutes	<b>MONITOR</b> batteries are getting low	Replace <b>MONITOR</b> and <b>TAG</b> batteries
<b>MONITOR</b> alarms when TAG is in close range (false alarm)	Method <b>MONITOR</b> and TAG are worn or used is not optimal	Review suggestions on other side "How to Wear Your SmartSeeker" to Reduce False Alarms
Not sure SmartSeeker system is working	Need verification SmartSeeker system is operating properly	Follow section "Testing System" to test unit
<b>MONITOR</b> does not track both TAGS	1. One <b>TAG</b> has poor battery contact. 2. One of the <b>TAGS</b> has a dead battery.	1. Reset bad <b>TAG</b> by removing battery, wait 10 minutes and install again. 2. Replace bad <b>TAG</b> battery
<b>MONITOR</b> never makes a sound and LED is blinking	Speaker may be damaged	Contact our Customer Support for help

## Changing Batteries

### REPLACING TAG BATTERY



### REPLACING MONITOR BATTERIES



### ! CAUTION

Check batteries regularly by observing the LED is still blinking. Replace batteries when needed to ensure proper operation. DO NOT use Smart Seeker™ system when batteries are low. DO NOT mix old and new batteries, it is best to replace both TAG and MONITOR batteries at the same time. DO NOT mix alkaline, standard (carbon zinc). DO NOT use rechargeable (nickel-cadmium) batteries.

### RETURNS

Do not return this product to the place of purchase. If any parts are missing, or if you are having difficulty using this product visit our website at [www.securesmarttech.com](http://www.securesmarttech.com).

### WARRANTY

Secure Smart Technologies (SST), warrants to the original purchaser that this product (Smart Seeker™), is free from material and workmanship defects when used under normal conditions for a period of one (1) year from the date of purchase. Should the product contain defects in material or workmanship Secure Smart Technologies (SST), Inc., will repair or replace the product, at our option, free of charge. Purchaser will be responsible for all costs associated with packaging and shipping the product to Secure Smart Technologies (SST) at the address noted on front page and all other freight or insurance costs associated with the return. Secure Smart Technologies (SST), will bear the cost of shipping the repaired or replaced product to the purchaser. Product should be returned in its original package accompanied by a proof of purchase, either a sales receipt or other proof that the product is within the warranty period. This warranty is void if the owner repairs or modifies the product or the product has been damaged as a result of misuse. This warranty excludes any liability other than that expressly stated previously, including but not limited to, any incidental or consequential damages.

**SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATION OR EXCLUSION MAY NOT APPLY TO YOU. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY ALSO HAVE OTHER RIGHTS THAT MAY VARY FROM STATE TO STATE.**  
Go to the Secure Smart Technologies (SST) website to register your Smart Seeker™ warranty.  
[www.securesmarttech.com](http://www.securesmarttech.com)

### ! WARNING

PLEASE READ THE FOLLOWING WARNINGS AND ALL ASSEMBLY AND USE INSTRUCTIONS CAREFULLY BEFORE USING SMART SEEKER™ KEEP THESE INSTRUCTIONS FOR FUTURE REFERENCE.

- The Smart Seeker™ system is not intended to replace responsible and proper supervision.
- Do not use Smart Seeker™ on board an airplane. You can turn off the TAG by removing the battery.
- Smart Seeker™ contains small parts not suitable for children.
- It is essential to check reception regularly. Please see the "Testing System" section for complete instructions.
- Check batteries regularly by observing the LED blinking. An audio tone will occur when batteries are low.
- RF distance measurements are not accurate and can vary from one locale to the next.
- This product should be serviced only by qualified service personnel at Secure Smart Technologies (SST), Inc. when:
  - The MONITOR or TAG have fallen.
  - Liquid has spilled into the MONITOR or TAG or either unit has fallen into water.
  - The MONITOR or TAG does not appear to operate normally or exhibit a marked change in performance.
- DO NOT attempt to service this product beyond that described in the Troubleshooting section. All other servicing should be referred to qualified personnel at Secure Smart Technologies (SST).

## FCC warning statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.