G'FIVE INTERNATIONAL LIMITED

Brand Name: G'FIVE

Model Name: N78 BT

FCC ID: Z3JN78BT

User Manual



-1-

1	General Information
1.1	Profile
1.2	Safety Information
1.3	Safety warning and Attentions
2	Your phone
2.1	Functions of Keys
3	Getting started
3.1	Installing the SIM Cards and the Battery
3.2	Installing T-Flash Card.
3.3	Charging the Battery
3.4	Powering On/Off the Mobile Phone
3.5	Linking to the Network
3.6	Dialing Calls
3.7	Using the Headset
4	Input method
4.1	Icons for Input Methods
4.2	To Shift Entry Methods.
4.3	Numeric Input
4.4	English input and numeric input:
4.5	Inserting a Symbol
5	Using the Menus.
5.1	Call center
5.2	Multimedia
5.3	Phonebook
5.4	User profiles
5.5	Messages
5.6	Organizer
5.7	Settings
5.8	Pastime
5.9	Service
6	Appendix

General Information
 Profile
 Please read this pamphlet carefully in order to make your phone in perfect condition.

Please read this pamphlet carefully in order to make your phone in perfect condition.

Perfectly combining humanized design and fine art, this mobile phone provides a streamlined outlook, comfortable hand-feeling, pleasant sounds and MP3 player which bring convenience and fun to your work.

Our company may change this mobile phone without prior written notice and reserves the final right to interpret the performance of this mobile phone.

Due to different software and network operators, display on your phone may be different, refer to your phone for details.

1.2 Safety Information

If your phone has lost or been stolen, notify the telecommunication office the SIM card is disabled (network support is required). This can avoid economic loss caused by unauthorized use.

Please take measures as following to avoid your phone being unauthorized use:

use: · Set PIN code of SIM card

Set PIN code of SIM card
Set phone password

1.3 Safety warning and Attentions
Safety warning
P ROAD SAFETY COMES FIRST
Do not use a hand-held phone while driving. Use hands-free fittings when calls are unavoidable while driving. Il some countries, dialing or receiving calls while driving is illegal!
P SWITCH OFF IN AIRCRAFT
Wireless devices can cause interference in aircraft. Using a mobile phone in flight is illegal and risky.
Please make sure that your mobile phone is powered off in flight.
P SWITCH OFF BEFORE ENTERING RISKY AREAS
Strictly observe the relevant laws, codes, and regulations on the use of mobile phones in risky areas. Turn off your mobile phone before entering

a place susceptible to explosion, such as an oil station, oil tank, chemical plant or a place where a blasting process is under way.

> OBSERVE ALL SPECIAL REGULATIONS
Follow any special regulations in force in any area such as hospitals and always switch off your phone whenever it is forbidden to use it or, when it may cause interference or danger. Properly use your mobile phone near medical apparatuses, such as pacemakers, hearing aids and some other electronic medical devices, as it may cause interference to such apparatuses.

electronic medical devices, as it may cause interference to such apparatuses.

> INTERFERENCE

The conversation quality of any mobile phone may be affected by radio interference. An antenna is built inside the mobile phone and located below the microphone. Do not touch the antenna area during a conversation, lest that the conversation quality deteriorate.

> QUALIFIED SERVICE

Only qualified personnel may install or repair phone equipment. Installing or repairing the mobile phone on your own may bring great danger and violates the warranty rules.

> ACCESSORIES AND BATTERIES

Use only approved accessories and batteries.

> USE SENSIBLY

Use only in a normal and proper manner.

> EMERGENCY CALLS

Ensure the phone is switched on and in service, enter the emergency number, e.g. 112, then press the Dial key. Give your location and state your situation briefly. Do not end the call until told to do so.

Note: Just like all other mobile phones, this mobile phone does not necessarily support all the features described in this manual due to not support the emergency call service. Therefore, do not rely solely on the mobile phone for retrical communications such as first aid. Please consult the local network operator.

Precautions
This mobile phone is well designed with fine art. Please exercise special care when using it. The following suggestions will help your mobile phone survive the warranty period and extend its service life:

> Keep the mobile phone and all its fittings beyond children's reach.
> Keep the mobile phone and all its fittings beyond children's reach.
> Keep the mobile phone and all its fittings beyond children's reach.
> Do not store the mobile phone in dusty places; lest that active parts of the mobile phone be damaged.
> Do not store the mobile phone in a high-temperature place. High temperature will shorten the life of electronic circuits and damage the battery and some plastic parts.
> Do not store the mobile phone to damage electronic circuits when the mobile phone is moved to a constant temperature place.
> Do not throw, knock or shock the mobile phone, as that will destroy the internal circuits and high-precision components of the mobile phone.

Find key
Press it to end a call being dialed or end an ongoing call; or press it to exit the menu and return to the standby state; or hold it for two or three seconds to power on or off the mobile phone.

Direction key
Press them to scroll the options when browsing a function list. In edit state, press direction keys to marke the desired function page. You can also customize direction keys to match the desired functions.

OK key
Press it to confirm your selection. In standby interface, pressing it will enter the main menu.

Flashlight
Long pressing OK key in idle screen to turn on or turn off flashlight.

FM shortcut key
Press it in the standby interface to enter into FM radio player interface.

Number keys, * key and # key
Press much the keys of through 9 to input or edit state to input numbers and characters;

The # key and the * key represent different functions in different states or different function menus.

Hold the # key up to 2s in standby state to activate or deactivate the silent

Hold the #key up to 2s in standby state to activate or deactivate the silent mode.

Press the # key in edit state to switch between input methods, or press it to unlock the keyboard when the keyboard is locked.

Pressing the * key in edit status to select a symbol.

Press and hold the * key up for 2s to input "+" in standby interface. "+" are used for dialing an international call.

3 Getting started

3.1 Installing the SIM Cards and the Battery

An SIM card carries useful information, including your mobile phone number, PIN (Personal Identification Number), PIN2, PUK (PIN Unlocking Key), IMSI (International Mobile Subscriber Identity), network information, contacts data, and short

messages data. SIM1 can not transmit with SIM2 simultaneously

Note:

After powering off your mobile phone, wait for a few seconds before removing or inserting an SIM card.

Exercise caution when operating an SIM card, as friction or bending will damage the SIM card.

Properly keep the mobile phone and its fittings such as the SIM cards beyond children's reach.

Installation

- Installation

 Hold the End key for a while to power off the mobile phone
 Push the back cover above the battery and remove it.
 Pull the left battery buckle outward and then lift the battery away.
 Insert the SIM card into the SIM card slot lightly with the corner cutting of the card aligning to the notch of the slot and the gold plate of the card facing download, till the SIM card cannot be further pushed in.
 Aim the positive pole and negative pole of the battery at the battery connector of the mobile phone, and press the left of the battery to install the battery into the battery tank.

 Usine code

 | Visine code | Visine code | Visine code | Visine code | Visine code | Visine code | Visine code | Visine code | Visine code | Visine code | Visine code | Visine code | Visine code | Visine code | Visine code | Visine code | Visine code | Visine code | Visine code | Visine code | Visine code | Visine code | Visine code | Visine code | Visine code | Visine code | Visine code | Visine code | Visine code | Visine code | Visine code | Visine code | Visine code | Visine code | Visine code | Visine code | Visine code | Visine code | Visine code | Visine code | Visine code | Visine code | Visine code | Visine code | Visine code | Visine code | Visine code | Visine code | Visine code | Visine code | Visine code | Visine code | Visine code | Visine code | Visine code | Visine code | Visine code | Visine code | Visine code | Visine code | Visine code | Visine code | Visine code | Visine code | Visine code | Visine code | Visine code | Visine code | Visine code | Visine code | Visine code | Visine code | Visine code | Visine code | Visine code | Visine code | Visine code | Visine code | Visine code | Visine code | Visine code | Visine code | Visine code | Visine code | Visine code | Visine code | Visine code | Visine code | Visine code | Visine code | Visine code | Visine code | Visine code | Visine code | Visine code | Visine code | Visine code | Visine code | Visine code | Visine code | Visine code | Visi

the battery into the battery tank.

Using code

The mobile phone and the SIM cards support sorts of passwords, in order to prevent the phone and the SIM cards from being misused. When you are prompted to input any of the codes mentioned below, just input the correct code and then press the OK key. If you input a wrong code, press the Right soft key to clear it and then input the correct code.

Phone lock code

Phone lock code is provided along with the mobile phone by the manufacturer. The initial phone lock code is set to 1234 by the manufacturer. The initial phone lock code is set, you need to input the phone lock code when powering on the mobile phone.

PIN

PIN

PIN (Personal identification number, 4 to 8 digits) code prevents your SIM card from being used by unauthorized people. In general, the PIN is supplied with SIM card by the network operator. If PIN check is enabled,

you need to input the PIN each time when you power on your mobile phone. The SIM card will be locked if you input wrong PIN code for three times.

phone. The SIM card will be locked if you input wrong PIN code for three times.

Unlocking methods as follows:
-Input the correct PUK according to the screen tips to unlock the SIM card.
-Then input the new PIN and press the OK key.
-Input the new PIN again and then press the OK key.
-Input the new PIN again and then press the OK key.
-If the input PUK is correct, the SIM card will be unlocked and the PIN will be reset.

Note: The SIM card will be locked if you input wrong PIN code for three times. To unlock the SIM card, you need to input the PUK. In general, the PUK can be obtained from the network operator.

◆ PUK
The PUK code (Personal Unlocking Key, 8 digits) is required to change a blocked PIN. It is supplied with SIM card. If not, contact your network operator. If you input wrong PUK code for 10 inseps, SIM card will be invalid. Please contact the network operator to replace the SIM card.

◆ Barring code
A barring code is required for setting the call barring function. You can obtain this code from the network operator to set the call barring function.

3.2 Installing T-Flash Card
The T-Flash card is a pluggable mobile storage card inside the mobile phone.
To install the T-Flash card, open its latch, place its indented side

The T-Flash card is a pluggable mobile storage card inside the mobile phone.

To install the T-Flash card, open its latch, place its indented side downward, insert the card into the card slot, and then close the latch.

To remove the T-flash card, open its latch and slightly press the card inward. The card will automatically pop out. Close the latch.

Note:

Note:

1. The mobile phone cannot automatically identify the T-flash card being inserted when the mobile phone is powered on. You must power off the mobile phone and then power it on, so that the phone can identify the T-Flash card.

2. The T-Flash card is a miniature object. Keep it out of the reach of

children for fear that children swallow it!

3.3 Charging the Battery
The lithium battery delivered with the mobile phone can be put into use immediately after being unpacked. A new battery will have maximum performance after the first three full charge/discharge cycles.

Battery level indication:

◆ Your mobile phone can monitor and display the battery state.

◆ Normally the remaining energy of the battery is indicated by the battery level icon at the upper right corner of the display screen.

◆ When the battery energy is insufficient, the mobile phone prompts "Battery low". If you have set an alert tone, an alert tone will be given off when the battery level is to low.

◆ A charging animation appears when the battery is being charged. When the charging is complete, the animation disappears.

Using a travel adapter:

◆ Install the battery into the mobile phone before charging the battery.

◆ Connect the adapter of the travel charger to an appropriate power outlet.

◆ During the charging, the battery level grids in the battery icon keep flickering till the battery is fully charged.

◆ It is normal when the battery is become hot during the charging period.

◆ The battery icon does no longer flicker when the charging process ends.

Note:

The battery icon does no longer flicker when the charging process ends.

Note:
Ensure that the plug of the charger, the plug of the earphone, and the plug of the USB cable are inserted in the right direction. Inserting them in a wrong direction may cause charging failure or other problems.

Before the charging, ensure that the standard voltage and frequency of the local mains supply match the rated voltage and power of the travel charger.

Using the Battery
The performance of a battery is subject to multiple factors: radio network

configuration, signal strength, ambient temperature, chosen functions or settings, phone fittings, and the voice, data or other application mode you choose to use.

- configuration, signal strength, ambient temperature, chosen functions or settings, phone fittings, and the voice, data or other application mode you choose to use.

 To guarantee the optimal performance of your battery, please stick to the following rules:

 Less only the battery provided by the vendor. Otherwise, damages or even injuries could be caused during the charging.

 Power off the mobile phone before removing the battery.

 The charging process lasts a longer time for a new battery or a battery not in use for long. If the battery voltage is too low to enable the mobile phone to be powered on, charge the battery for a longer time. In this case, the battery icon does not flicker until a long time after the battery enters the charge status.

 During the charging, ensure the battery is placed in a room temperature environment or in an environment close to room temperature.

 Immediately stop using the battery if the battery produces odor, overheats, cracks, distorts or has other damage, or if the electrolyte leaks.

 The battery wears out with use. A longer charging time is required as the battery is put into use for a long time. If the total conversation duration decreases but the charging time increases even though the battery is properly charged, purchase a standard battery from the OEM or use a battery approved by our company. Using any poor-quality fittings will cause harm to your mobile phone or even incur danger!

 Note: To guarantee your personal safety and protect the environment, do not litter the battery! Return the old battery to the mobile phone manufacturer or place it in specified battery may cause explosion, fire, personal injury or other severe consequences!

 3.4 Powering On/Off the Mobile Phone
 Hold the End key for a while to power on the mobile phone. A power-on animation appears on the display screen. Input the phone lock code and press the OK key if the mobile phone prompts you to input the phone lock code. The original code is 1234.

Input the PIN and press the OK key if the mobile phone prompts you to input the PIN. The PIN is provided by the network operator for new opening SIM card.

Enter the standby interface.
To power off the mobile phone, hold the End key for a while.

3.5 Linking to the Network

After the SIM card and the mobile phone are successfully unlocked, the mobile phone automatically searches for an available network. After finding a network, the mobile phone enters the standby state. When the mobile phone is registered in the network, the name of the network operator is displayed on the screen. Then you can dial or receive a call.

3.6 Dialing Calls
In the standby interface, press number keys to input the area code and the telephone number, and then press the Dial key to dial a call. To end the call, press the End key.

♦ Dialing an international call
Hold the *key and input *+.* Then input the country code, the area code, and the telephone number. Finally, press the Dial key.

♦ Dialing a call to a number in the phonebook
Enter the phonebook and use the upward and/or downward direction keys to find the telephone number you want to call.
Press the Dial key. The mobile phone automatically dials the chosen telephone number.

♦ Redialing the last number
In the standby interface, press the dial key to show the dialed calls.
Press the upward and/or downward direction keys to select a number you want to dial and then press the Dial key.

♦ Adapting volume

During a conversation, you can press the Up and/or Down direction keys to tue the sound volume.

♦ Answering incoming calls
Press the Dial key or the Left soft key to answer an incoming call.
Press the Dial key or the Left soft key to answer an incoming call.
Press the Dial key or the Left soft key to answer an incoming call.

-11-

Note: If the caller can be identified, the mobile phone will present the calling number. If the calling number exists in the phonebook, the mobile phone will present both the name and the phone number of the caller. If the caller cannot be identified, the mobile phone will present the calling number only. You can answer an incoming call when using a function list or browsing the phonebook.

◆ Using options during a conversation to pause, end the ongoing call, originate a new call, browse the phonebook, view information, set the mute, set the DTMF, or perform other operations. For details, refer to the menu guide.

3.7 Using the Headset
It would enter headset mode automatically when you insert headset to the slot. Make sure of inserting it at the bottom of the slot, or you can't use it normally.

4 Input method
This mobile phone provides multiple input methods, including English input and numeric input. You can use these input methods when editing the phonebook, short messages or the memorandum, an icon is displayed to indicate the current input method:
Numeric input: "123"
Smart English input: "sEng"
English input: "sEnglish input and numeric input are defined in the following table:

120-

Key	Character or Function	Remarks
Number key l	1	
Number key 2	ABCabc2]
Number key 3	DEFdef3]
Number key 4	GHIghi4	
Number key 5	JKLjkl5	
Number key 6	MNOmno6	
Number key 7	PQRSpqrs7]
Number key 8	TUVtuv8]
Number key 9	WXYZwxyz9]
Number key 0	0]
* key	Press it to input a symbol]
# key	Press it to switch between input methods	ĺ
Left direction key	Press it to move to the left	1

Right direction key	Press it to move to the right	
Left soft key	Equivalent to OK or Options	
Right soft key	Equivalent to Back or Clear	
End key	Press it to return to the standby interface	

- English input:

 Each key is used to represent multiple characters. Quickly and continuously press a key till the character you want appears. Input the next character after the cursor moves.

 Press the # key to switch between input methods
 To input a blank, switch to the English input mode (in upper or lower case) and then press number key 0.
 To clear wrong inputs, press the Right soft key.
 Linserting a Symbol
 Press the * key to enter the Select symbol interface, use direction keys to select a symbol you want.

5 Using the Menus

5.1 Call center
Dialed Calls
You can view the latest dialed calls. Choose dialed calls and then select a dialed call to delete, save, dial, or edit (or send a short message to it).
Received Calls
You can view the latest received calls. Choose received calls and then select a received call to delete, save, dial, or edit (or send a short message

to it).

Missed Calls

You can view a list of the latest missed calls.

Note: When the mobile phone indicates that some calls are missed, you can select Read to enter the missed calls list. Navigate to a missed call and then press the Dial key to dial the number that originated that call.

Rejected calls

A list of calls you've rejected.

Delete all

You can delete the latest call records. Choose Delete call and then select to delete all the numbers in the call history, or delete only the numbers in the missed calls list, the dialed calls list or the received calls list.

Call Timers

Choose call timer to view the last call time, the total time of all dialed calls, and the total time of all received calls, and or to reset all the time.

\$\int \text{ Last call: View the time duration of the last call.}\$

\$\int \text{ Dialed numbers: View the total time of all the received calls.}\$

\$\int \text{ Dialed numbers: View the total time of all the dialed calls.}\$

Call Costs

Choose call cost to view the cost of the last call and the cost of all calls, reset the call cost, modify the maximum cost allowed.

Note: The call cost function relates to the SIM card. Some SIM cards do not support this function. The PIN2 is provided by the network operator. To obtain the PIN2, contact the network operator.

GPRS flow rate

\$\int \text{ Last sent: Viewing the rate of last session senet}\$

Last receive: Viewing all of the rate of sessions received

\$\int \text{ Total receive: Viewing all of the rate of sessions received}\$

Total sent: Viewing all of the rate of sessions received

\$\int \text{ Total sent: Viewing all of the rate of sessions received}\$

Total receive: Viewing all of the rate of sessions received

\$\int \text{ Total sent: Viewing all of the rate of sessions received}\$

Total sent: Viewing all of the rate of sessions received

\$\int \text{ Total sent: Viewing all of the rate of sessions received}\$

the camera to the picture and then press OK key, which the picture will be

the camera to the picture and then press OK key, which the picture will be stored in the album. Select "option" and you can set some parameter of photo and camera, and scan the pictures you've taken in gallery and view the storage status. Video recorder

This function enables you to record dynamic pictures. Adapt the VCR to the scene or the figure, the press OK to start or pause recording. Press STOP to end recording, and the phone would save the file automatically. Video player

This function enables you play, delete, use a selected file as power on/off animation or save your video and movies.

Image viewer

This function enables you change folder, send, slide play, delete, set as wallapper, rename, mark, detail, and slide setting.

Audio Player

The audio player provides four buttons: Play or Pause, Back, and Forward which are corresponding to the OK key, down direction key, left direction key and right direction key. The audio player supports MP3, formats. Press up or down direction key to tune volume.

Recorder

up or down direction key to tune volume.

Recorder

The phone support WAV. The recording file you stopped would be stored in file list automatically. You can select storage location as needed. The path is Multimedia→recorder→option→storage location→Udisk/ Memory card.

FM Radio

Your phone is equipped with an FM radio. You can use the application as a traditional FM radio with automatic tuning and saved channels.

File manager

The phone provides a certain space for users to manage files and supports the T-Flash card. The capacity of the T-Flash card is selectable. You can use the file manager to conveniently manage various directories and files on the phone and the T-Flash card.

Choose File manager to enter the root directory of the memory. The root directory will list the default folders, new folders and user files. When the −16-

mobile phone is powered on for the first time or when you have not changed the directory, the root directory contains the default folders only. You can use this function to format all the data in the memory. The system will re-create a default folder. The formatted data cannot be recovered. Therefore, think twice before using the formatting function.

5.3 Phonebook

The mobile phone can store up to 500 telephone numbers. The number of telephone numbers that an SIM card can store depends on the storage capacity of the SIM card. The telephone numbers stored in the mobile phone and in the SIM cards form a phonebook.

The phonebook search function enables you to view contacts. You can search a contact as required from the phonebook. Select this option, in the delli interface, input the name of the contact you want to search or the first letter(s) of the name. All the contacts meeting the search condition are listed. Press the Up and Down direction keys to browse the contacts and select contact.

5.4 User profiles

The mobile phone provides multiple user profiles, so that you can customize some settings to adapt to the specific events and environments. Customize the user profiles according to your preference and then activate the user profiles. The user profiles fall into five scenarios: General, Meeting, Outdoor, Indoor and Silent.

Select option, and you can perform the following operations: Activate, Settings and Rename.

Note: In standby state, hold the # key to switch to the mute mode. To switch back to the original mode, hold the # key again.

5.5 Messages

If the destines and Rename.

The message memory is full, a blinking SMS icon appears on the top of the screen. To normally receive short messages, you need to delete some of the existing short messages.

If the destination user has received the short message you sent and the short message delivery report function is activated, the phone will give off a message report alet tone.

Note: When a short message is sent through the network, the mobile

phone may give a prompt message indicating that the short message has been sent. This indicates that the mobile phone has sent the short message strote short message service center number set in the mobile phone but does not imply that the destination user has received the short message. For further information, consult the service provider 5.5.1.1 Writing message From the main menu select "Messages" to create text message or MMS. You can type a message, and you're also able to insert a pre-defined message from "Templates." While writing a message, select "Options" to access all the messaging options. You can save your message start you send often to "Drafts." 5.5.1.2 Inbox If a new short message arrives, an icon will be displayed on the screen. If the short message sage strives, an icon will be displayed on the screen. To receive messages, delete some or all the existed messages. 5.5.1.3 Outbox
The message send failed are stored in this item.Choosing"outbox", the short message sin the Inbox are listed on the screen. A short message marked with an icon indicates that you have unread message. 5.5.1.4 Drafts
The messages you saved would be stored in this menu. 5.5.1.5 Sent box
The messages you saved would be stored in this menu. 5.5.1.5 Sent box
The message support the properties of the screen. A short message was used would be stored in this menu. 5.6.0 Organizer
Alarm
Three alarm clocks are set but deactivated by default. You can activate one,

Note that the content of the content

-18-







keep track of important appointments, etc. Days with events entered will be marked.

keep track of important appointments, etc. Days with events entered will be marked.

Bluetooth

> Open B-tooth: To activate or deactivate bluetooth as needed.

> Bluetooth visibility: To set Bluetooth visibility as show phone or Hidden.

> Paired device: To inquiry new devices automatically.

> My Bluetooth name: to set a name of your Bluetooth

> Bluetooth file location: It is storred in memory card only.

> Help: Provide some help information.

Ebook reader

Ebook enables you to read TXT file. Through the USB connecting line putting files to Ebook folder of phone and T-Flash card. Find the folder and you can open the Ebook to read text directly.

Calculator

Hold down the '*'key to get the decimal point, press # key to input a minus. Confirm with the OK key or the left soft key.

Note: This calculator provides limited precision and is only applicable to simple arithmetic calculation.

OSTIK

STK service is the tool kit of SIM card. This phone supports the service

0STK
STK service is the tool kit of SIM card. This phone supports the service function. The specific items are depended by SIM card and network. Service menu will be auto added to the phone menu when supported by network and SIM card.

5.7 Settings

The North and Save Card.

5.7 Settings

Dual SIM Settings

Dual SIM Settings

Dual SIM Settings

Dual SIM Settings

A Dual-SIM prefers to two SIM card slots, and the two cards can standby at the same time or set one of them to display on the idle screen.

Call Setup

A Network settings: Set Network selection mode to Automatic or Manual. Automatic is recommended. When Network selection mode is set to Automatic, the mobile phone will prefer the network where the SIM card is registered. When Network selection mode is set to Manual, you need to select the network operator's network where the SIM card is

19.

registered.

Divert calls: This network function enables you to forward incoming calls to another number you have previously specified.

Restrict calls
Call barring function enables you to bar calls as needed. When setting this function, you need to use a network barring code, which can be obtained from the network operator. If the code is wrong, an error message will be prompted on the screen. After selecting a call barring option, continue to select Activate or Deactivate. The mobile phone will prompt you to input the call barring code and then contact the network will make a response and send the operation results to the mobile phone.

Call waiting
Activate: After you choose Activate, the mobile phone will contact the network at moment later, the network will make a response and send a message to acknowledge your operation. If the call waiting function is activated, the network will alert you and the mobile phone screen will display the incoming call number if others are calling you while you are already in a conversation.

Deactivate: If you choose Deactivate, the network will not alert you whon others are calling you while you are already in a conversation.

Check status: Query the network to obtain the current call waiting status.

Hide ID: When you call someone, he or she can't find out your number if you enable this function.

Line selection: Switch to Line I or Line 2. By default, Line I is used. Note: If you choose Line 2, dialing may fail. This depends on the implementation of the network operator.

Flight mode: You can't communicate with others under this mode.

Others: It includes IP shortcut key, 50 seconds voice tone, connect prompt, answer/reject mode and auto redial.

Phone Settings

Time and date: Set time, date, time format and date display

-20-

type.

Language: Select the display language for the mobile phone.

Schedule power on/off: Set the time when the mobile phone will be automatically powered on or off.

Alert: Before entering an area where the use of mobile phones is forbidden, make sure that the scheduled power-on function is deactivated to avoid accidents.

Power management: Show the remaining battery level.

Display

Select images and set them as wallpaper and idle display. You can set duration of backlight and keypad light.

Security Settings

This function provides you with related settings about safety use. To set the SIMI lock, you need to input the PIN. You can set the SIMI lock, you need to input the PIN. You can set the SIMI lock, you need to input the PIN. To obtain the PIN, each time you power on the mobile phone. In the case you input a wrong PIN for three consecutive times, you need to input the PIN. To obtain the PUK, contact the network operator. Fixed dial requires the SIM cards support and the network operator's support. When the fixed dial function is activated, you can dial only the numbers in the fixed dial requires SIM cards you can dial only the numbers in the fixed dial requires SIM cards support and the network operator's support. When the fixed dial requires SIM cards support and the network operator's support. When the fixed dial function is activated, you can dial only the numbers in the fixed dial requires SIM cards support, you can activate or deactivate barring of some or all calls. Phone lock enables you to lock/unlock the phone. Input password to switch on or off the phone. Password is required when the phone is locked. The password is 4 to 8 digits. Keypad lock enables you to lock/unlock the keypad. Setting the auto locking time that 5s, 30s, 1 min or 5 min is available. The keypad will be auto locked with no operation during the period.

Restore factory settings
Choose Phone Settings > Restore settings to restore the factory settings. Input the phone lock code and then select OK or press the Left soft key. Note

5.8 Pastime
A game named Box man is embedded in the phone, you can refer to 'Help' option embedded in the phone for operation.
Games settings. You can turn on or turn off Audio or Vibration and modify volume as needed.
5.9 Service
This function enables you to view the internet. Your phone will ask you with existed way. You can start to view only by starting corresponding way. You can store a website of home page in each way. The home page will be first viewed when using WAP explore. And you can add, edit, delete or send bookmarks. The websites you've visited are usually stored in Histories. Moreover, you are able to set some parameter of WAP settings as needed.
6 Appendix
Appendix 1: Troubleshooting
If you find exceptions when operating the mobile phone, restore the factory settings and then refer to the following table to solve the problem. If the problem persists, contact the distributor or service provider.
Fault

Cause
Solution

Fault	Cause	Solution
	The SIM card is damaged.	Contact your network service provider
SIM card	The SIM card is not in position.	Check the SIM card
citoi	The metal face of the SIM card is polluted.	Clean the SIM card with a clean cloth
Poor received signal quality	Signals are obstructed. For instance, radio waves cannot	Move to a place where signals can be effectively transmitted

	be effectively transmitted nearby a high building or in a basement.	
	Line congestions occur when you use the mobile phone in high-traffic hours	Avoid using the mobile phone in high-traffic hours
The mobile phone cannot be powered on	The battery energy is exhausted.	Charge the battery
Calls cannot be dialed	Call barring is activated	Cancel call barring
The mobile phone cannot connect the	The SIM card is invalid	Contact your network service provider

network	The mobile phone is not in a service area of the GSM network	Move to the network operator's service area
	The signal is weak	Move to a place where the signal quality is high
The battery	The charging voltage does not match the voltage range indicated on the charger	Ensure the charging voltage matches the voltage range indicated on the charger
cannot be charged	An improper charger is used	Use the charger specially designed for the mobile phone
	Poor contact	Ensure the charger plug is in good contact with the mobile phone

Please use the phone under the environment with temperature of ~ 50

FCC RF EXPOSURE INFORMATION:

WARNING!! Read this information before using your phone

In August 1986 the Federal Communications Commission (FCC) of the United States with its action in Report and Outer FCC ZGRFLURRY adopted an updated safety standard for human exposure to radio frequency (RF) electromagnetic energy emitted by FCC regulated transmitters. Those guidelines are consistent with the safety standard previously set by both U.S. and international standards bodies. The design of this phone complies with the FCC guidelines and these international standards. Use only the supplied or an approved antenna. Unauthorized antennas modifications, or attachments could impair call quality, damage the phone, or result in violation of FCC regulations. Do not use the phone with a damaged antenna. If a damaged antenna comes into contact with the skin, a minor burn may result. Please contact your local dealer for replacement antenna.

BODY-WORN OPERATION:

This device was tested for typical body-worn operations with the back of the phone kept 1.5cm from the body. To comply with FCC RF exposure requirements, a minimum separation distance of 1.5cm must be maintained between the user's body and the back of the phone, including the antenna, whether extended or retracted. Third-party belt-clips, holsters and similar accessories containing metallic components shall not be used. Body-worn accessories that cannot maintain 1.5cm separation distance between the user's body and the back of the phone, and have not been tested for typical body-worn operations may not comply with FCC RF exposure limits and should be avoided.

For more information about RF exposure, please visit the FCC website at www.fcc.gov

Your wireless handheld portable telephone is a low power radio transmitter and receiver. When it is ON, it receives and also sends out radio frequency (RF) signals. In August, 1996, the Federal Communications Commissions (FCC) adopted RF exposure guidelines with safety levels for hand-held wireless phones. Those guidelines are consistent with the safety standards previously set by both U.S. and international standards bodies:

Those standards were based on comprehensive and periodic evaluations of the relevant scientific literature. For example, over 120 scientists, engineers, and physicians from universities, government health agencies, and industry reviewed the available body of research to develop the ANSI Standard (C95.1). Nevertheless, we recommend that you use a hands-free kit with your phone (such as an earpiece or headset) to avoid potential exposure to RF energy. The design of your phone complies with the FCC guidelines (and those standards).

Use only the supplied or an approved replacement antenna. Unauthorized antennas, modifications, or attachments could damage the phone and may violate FCC regulations.

NORMAL POSITION:

Hold the phone as you would any other telephone with the antenna pointed up and over your shoulder.

TIPS ON EFFICIENT OPERATION:

For your phone to operate most efficiently:

- Extend your antenna fully.
- Do not touch the antenna unnecessarily when the phone is in use. Contact with the antenna affects call quality and may cause the phone to operate at a higher power level than otherwise needed.

Vehicle mounted external antenna (Optional, if available))

A minimum separation distance of 7.9 inches (20cm) must be maintained between the user / by stander and the vehicle mounted external antenna to satisfy FCC RF exposure requirements.

RF Exposure Information:

FCC RF Exposure requirements: The highest SAR value reported under this standard during product certification for use next to the body with the minimum separation distance of 1.5cm is 0.710W/kg, next to the head is 0.632W/kg. This transmitter must not be collocated or operating in conjunction with any other antenna or transmitter.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help

Do not use the device with the environment which below minimum -10 $^{\circ}$ C , the device may not work.

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.