EQT Midstream Radio System Professional Installation Instruction Manual

FCC ID: Z3N-MDS-AMP

(DRAFT)

The transceiver system supplied by EQT Midstream requires custom configuration and assembly by the professional installer. This system must be installed by experienced professional installers who are familiar with radio frequency (RF) equipment operation as well as local building and safety codes. Failure to do so may void the Product Warranty, as well as expose the end user to legal and/or financial liabilities.

The following procedure must be followed by the professional installer in conjunction with the MDS radio's instructions detailing the transceiver interface setup.

- 1) The GE MDS radio supplied with this system must be set for a maximum radio output power of 20 dBm, to remain compatible with maximum permissible input power to L-COM amplifier used in the supplied radio system. Use the PWR command (described on Page 38 of the radio user's manual supplied) to set this power rating.
- 2) The professional installer must determine which amplifier and antenna have been included in the system, and use the following table to configure the system. Please note that the amplifiers employed in this system have fixed output power ratings. The maximum permissible transceiver EIRP is 36 dBm, and the type of antenna employed in each configuration cannot be changed.

| EQT Config. of MDS-AMP | Amplifier Included | Amplifier Output Power Rating (dBm) | Maximum Permissible System EIRP (dBm) | Only Permitted Antenna Type | Maximum Permitted Antenna Gain | Gain Limit Antenna Gain + Cable & Lightning Suppressor Loss (dB) |
|---------------------------------|-----------------------|---|--|--------------------------------------|---|--|
| А | HA901I-APC | 30 | 36 | Omni | 7 dBd (9.2 dBi) | 6 |
| В | HA900I- APC500 | 27 | 36 | Omni | 7 dBd (9.2 dBi) | 9 |
| С | HA900I- APC300 | 25 | 36 | Yagi | 10 dBd (12.2 dBi) | 11 |

To determine the minimum cable loss needed, perform the following step:

Determine the antenna gain (in dBi) and subtract that from the **Gain Limit** of your system tabulated above. For example, if you are employing a Yagi antenna with a gain

of 12.2 dBi under configuration C, then Gain Limit - Antenna Gain = 11 (dB) - 12.2 (dB) = -1.2 dB, so you must employ a length of cable + lightning suppressor (if desired) with an insertion loss of at least 1.2 dB.

If the Gain Limit – Antenna Gain is a positive number, then any length of cable may be used in the system.

Antennas of the same type as those dictated in each configuration, but with lower gain, may be employed when configuring the system. Note that antennas of a type not listed (e.g. Patch, Dish, etc...) may not be employed.

Health Hazard Statement

These devices must be installed in fixed-mount applications, and in such there is a minimum required separation distance of 23 cm between the antenna and all persons during normal operation. These systems are not authorized for use in mobile or portable applications.

Changes or modifications not expressively approved by the party responsible for compliance could void the user's authority to operate this equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

Microwave Data Systems Inc.

MDS TransNET 900[™] MDS TransNET 2400[™]



Spread Spectrum Data Transceiver

MDS 05-2708A01, Rev. D AUGUST 2006

industrial/wireless/performance




QUICK START GUIDE


1. Install and connect the antenna system to the transceiver

- Use a high-quality gain antenna, mounted in the clear.
- Use a low-loss feedline such as LMR 400.
- Preset directional antennas in the direction of desired transmission/reception.

2. Connect the data equipment to the radio's DB-9F DATA connector

- Connect only the required pins. EIA-232, shown below, typically uses only TXD, RXD and GND. (See Page 71 for EIA-485 interface connections.)
- Verify the connected data equipment is configured as DTE. The radio is DCE.





3. Apply DC power to the radio. Use the supplied 2-pin connector

• Input voltage is 6–30 Vdc. Observe proper polarity. The left pin is positive (+) and the right pin is negative (–). (See Page 17 for details.)

4. Configure with a PC terminal or TransNET Configuration Software

- Connect computer to radio's DIAG connector. See Page 69 for cable wiring.
- Set the Mode using the MODE M (Master), MODE R (Remote), or MODE X (Extension) command. (Note: Only one Master is permitted in a system.)
- Set a unique Network Address (1–65000) using **ADDR** command. Each radio in the system *must* have the same network address. *Tip: Use the last four digits of the Master's serial number to help avoid conflicts with other users.*
- Set the baud rate/data interface parameters. Default setting is 9600 bps, 8 data bits, no parity, 1 stop bit. If changes are required, use the BAUD xxxxx abc command where xxxxx equals the data rate (300–115200 bps) and abc equals the communication parameters as follows:
 - $\mathbf{a} = \text{Data Bits } (7 \text{ or } 8)$
 - **b** = Parity (N for None, O for Odd, E for Even
 - **c** = Stop Bits (1 or 2) **NOTE:** 7N1, 8E2 and 8O2 are not supported.

5. Verify proper operation by observing the LED display

- Refer to Table 6 on Page 20 for a description of the status LEDs.
- Refine directional antenna headings for maximum received signal strength using the RSSI command. (Remotes must be synchronized with the master.)



CONTENTS

| 1.0 | AB | OUT THIS MANUAL1 |
|-----|-----|---|
| 2.0 | PR | ODUCT DESCRIPTION1 |
| | 2.1 | Transceiver Features1 |
| | 2.2 | Model Number Codes2 |
| | 2.3 | Spread Spectrum Radios—How Are They Different?2 |
| | 2.4 | Typical Applications2 |
| | | Multiple Address Systems (MAS)2 |
| | | Point-to-Point System3 |
| | | Adding a Tail-End Link to an Existing Network3 |
| | | Extending a TransNET Network with a Repeater4 |
| | 2.5 | Accessories5 |
| 3.0 | INS | STALLATION PLANNING6 |
| | 3.1 | General Requirements6 |
| | 3.2 | Site Selection6 |
| | | Terrain and Signal Strength7 |
| | | Conducting a Site Survey7 |
| | 3.3 | A Word About Radio Interference8 |
| | 3.4 | Antenna & Feedline Selection9 |
| | | Antennas9 |
| | | Feedlines10 |
| | | Antenna System Ground11 |
| | 3.5 | How Much Output Power Can be Used?12 |
| 4.0 | INS | STALLATION14 |
| | 4.1 | Transceiver Installation14 |
| | 4.2 | Configuring Multiple Remote Units18 |
| | 4.3 | Tail-End Links18 |
| | 4.4 | Configuring a Network for Extensions19 |
| 5.0 | OF | PERATION19 |
| | 5.1 | Initial Start-up19 |



| | 5.2 | Performance Optimization Antenna Aiming Antenna SWR Check Data Buffer Setting—Modbus Protocol Hoptime Setting TotalFlow™ Protocol at 9600 with Sleep Mode Operation at 115200 bps Baud Rate Setting | 20 20 21 21 21 21 21 |
|-----|-----|--|--|
| 6.0 | RA | Radio Interference Checks | |
| | 6.1 | Radio Programming Methods Terminal Interface PC-Based Configuration Tool | 22 |
| | 6.2 | User Commands Entering Commands | |
| | 6.3 | Detailed Command Descriptions | 28 |
| | | AMASK [0000 0000–FFFF FFFF] | 29 |
| | | AT [ON, OFF] | 29 |
| | | ASENSE [HI/LO] | 29 |
| | | BAUD [xxxxx abc] Data Interface Port Baud Rate | 29 |
| | | BAND [A, B, C] | |
| | | BUFF [ON, OFF] | 30 |
| | | CODE [NONE, 1255] | 31 |
| | | CSADDR [1–65000, NONE] | 31 |
| | | CTS [0–255] | 31 |



| CTSHOLD [0–60000] Clear-to-Send Hold Time | 32 |
|--|----|
| DEVICE [DCE, CTS KEY] | 32 |
| DLINK [xxxxx/ON/OFF] InSite Diagnostics Link Support | 32 |
| DKEY | 33 |
| Turn Off Radio Transmitter 's Test Signal | |
| DTYPE [NODE/ROOT] | 33 |
| FEC [ON, OFF] Forward Error Correction | 33 |
| HOPTIME [7, 14, 28] Radio Transmitter Hop Timing | 34 |
| INIT Initialize; Restore to Factory Defaults | 34 |
| HREV Hardware Revision | 35 |
| KEY | 35 |
| Turn On Radio Transmitter Test Signal | |
| LED [ON, OFF] Enable/Disable PCB LEDs | 36 |
| LPM [1, 0] | 36 |
| LPMHOLD [0–1000] Low-Power Mode Sleep Time | 36 |
| MODE [M, R, X] Radio Operating Mode | 36 |
| MRSSI [NONE, -4090] | 37 |
| OT [ON, OFF] Output Trigger | 37 |
| OWM [xxxxx] "Owner's Message" | 37 |
| OWN [xxxxx] "Owner's Name" | 37 |



| PORT [RS232, RS485] | 7 |
|---|---|
| PWR [20–30]38 Radio Transmitter Power Level | 3 |
| REPEAT [0–10] | 3 |
| RETRY [0–10] | 3 |
| RSSI | 3 |
| RTU [ON, OFF, 0-80]39 Remote Terminal Unit Simulator | 9 |
| RX [xxxx] | 9 |
| RXD [0–235] / [ON/OFF] | 9 |
| RXTOT [NONE, 0–1440] |) |
| SAF [ON, OFF] |) |
| SETUP | C |
| SER |) |
| SHOW CON | 1 |
| SHOW PWR41 Show Measured RF Transmit Power | 1 |
| SHOW SYNC | 1 |
| SKIP [NONE, 18] | 1 |
| SLEEP [ON, OFF] | 2 |
| SREV | 2 |



| | STAT43 Alarm Status |
|------------|---|
| | TEMP43 |
| | Radio's Internal Temperature |
| | TX [xxxx]43 Radio Transmit Test Frequency |
| | UNIT [10000–65000] |
| | XADDR [0–31]44 Extended Address |
| | XMAP [00000000-FFFFFFFF]44 Map of Extension Addresses |
| | XPRI [0–31]44 Primary Extended Address |
| | XRSSI [NONE, -40120]44 Extension RSSI Level |
| | ZONE CLEAR44 Clear Zone Statistics Log |
| | ZONE DATA44 Read Zone Statistics Log |
| 7.0 TR | OUBLESHOOTING45 |
| 7.1 7.2 | LED Indicators |
| | Checking for Alarms—STAT command46 |
| | Major Alarms versus Minor Alarms46 |
| | Alarm Code Definitions47 |
| 7.3 | |
| 7.4 | Performing Network-Wide Remote Diagnostics49 |
| 7.5 | Internal Fuse Replacement50 |
| 8.0 RA | ADIO FIRMWARE UPGRADES51 |
| 8.1 | Obtaining New Firmware51 Saving a Web-Site Firmware File Onto Your PC51 |
| 8.2 | Installing Firmware Into Your Radio51 |
| 9.0 OF | PERATING PRINCIPLES AND CONFIGURATION52 |



| 9.1 | SAF Operation with Extension Radios |
|--------|---|
| | Extended SAF Network53 |
| | Retransmission and ARQ Operation53 |
| | SAF Configuration Example53 |
| 9.2 | Synchronizing Network Units54 |
| | Synchronization Messages55 |
| 9.3 | Using AT Commands55 |
| 9.4 | Configuration Parameters for Store-and-Forward Services |
| 9.5 | Using the Radio's Sleep Mode (Remote Units Only) 59 |
| 0.0 | Sleep Mode Example |
| 9.6 | Low-Power Mode (LPM)—Master Enabled |
| | Setup Commands |
| | Reading RSSI and Other Parameters |
| | with LPM Enabled61 |
| | Power Consumption Influence by |
| | HOPTIME and SAF Settings61 |
| 9.7 | Low-Power Mode versus Remote's Sleep Mode 62 |
| 9.8 | Mobile Operation Support62 |
| | Introduction |
| | Operational Influences—Hoptime & SAF63 |
| 9.9 | MIRRORED BITS™ Protocol Support63 |
| 9.10 | Seamless Mode Emulation63 |
| 9.11 | Full-Duplex Emulation63 |
| 9.12 | Co-Located and Close-Proximity Masters63 |
| | Master Station Configuration64 |
| | Antenna System for Co-Located Master Stations 64 |
| 9.13 | Security65 |
| 10.0 T | ECHNICAL REFERENCE |
| 10.1 | Product Specifications—900 MHz66 |
| 10.2 | |
| 10.3 | 5 |
| 10.4 | Data Interface Connections (DB-9F)69 |
| | Pin Descriptions—RS/EIA-232 Mode70 |
| | Pin Descriptions—RS/EIA-422/485 Mode71 |
| 10.5 | 3 · · · · · · · · · · · · · · · · · · · |
| | Using the I/O Points with InSite™ NMS Software73 |



| Application Example—Digital Input a | nd |
|---------------------------------------|----|
| Output at a Remote | 73 |
| 10.6 dBm-Watts-Volts Conversion Chart | 74 |

Copyright Notice

This Installation and Operation Guide and all software described herein are Copyright 2006 by Microwave Data Systems Inc. All rights reserved. Microwave Data Systems Inc. reserves its right to correct any errors and omissions in this manual.

MDS Quality Policy Statement

We, the employees of Microwave Data Systems, are committed to understanding and exceeding our customer's needs and expectations.

- We appreciate our customers' patronage. They are our business.
- We promise to serve them and anticipate their needs.
- We are committed to providing solutions that are cost effective, innovative and reliable, with consistently high levels of quality.

We are committed to the continuous improvement of all of our systems and processes, to improve product quality and increase customer satisfaction.

RF Exposure Notice



RF EXPOSURE Professional installation required. The radio equipment described in this guide emits radio frequency energy. Although the power level is low, the concentrated energy from a directional antenna may pose a health hazard. Do not allow people to come closer than 23 cm (9 inches) to the antenna when the transmitter is operating in indoor or outdoor environments in the 900 MHz band or 11.2 cm (4.4) inches) in the 2400 MHz band. More information on RF exposure is available on the Internet at www.fcc.gov/oet/info/documents/bulletins.

ISO 9001 Registration

Microwave Data Systems adheres to the internationally-accepted ISO 9001 quality system standard.

UL/CSA Notice

The MDS TransNET 900 is available for use in Class I, Division 2, Groups A, B, C & D Hazardous Locations. Such locations are defined in Article 500 of the National Fire Protection Association (NFPA) publication NFPA 70, otherwise known as the National Electrical Code. (Approval of the MDS TransNET 2400 is pending as of August 2006.)

The transceiver has been recognized for use in these hazardous locations by two independent agencies — Underwriters Laboratories (UL) and the Canadian Standards Association (CSA). The UL certification for the transceiver is as a Recognized Component for use in these hazardous locations, in accordance with UL Standard 1604, UL508. The CSA Certification is in accordance with CSA STD C22.2 No. 213-M1987.

UL/CSA Conditions of Approval: The transceiver is not acceptable as a stand-alone unit for use in the hazardous locations described above. It must either be mounted within another piece of equipment which is certified for hazardous locations, or installed within guidelines, or conditions of approval, as set forth by the approving agencies. These conditions of approval are as follows:

- 1. The transceiver must be mounted within a separate enclosure which is suitable for the intended application.
- 2. The coaxial antenna cable, power input cable and interface cables must be routed through conduit in accordance with Division 2 wiring methods as specified in the National Electrical Code, Article 501.4(B).
- 3. The transceiver must be used within its Recognized "Ratings".



- 4. Installation, operation and maintenance of the transceiver should be in accordance with the transceiver's installation manual, and the National Electrical Code.
- 5. Tampering or replacement with non-factory components may adversely affect the safe use of the transceiver in hazardous locations, and may void the approval.
- 6. A power connector with screw-type retaining screws as supplied by MDS must be used.

When installed in a Class I, Div. 2, Groups A, B, C or D hazardous location, observe the following: WARNING EXPLOSION HAZARD Do not disconnect equipment unless power has been switched off or the area is know to be non-hazardous.

Refer to Articles 500 through 502 of the National Electrical Code (NFPA 70) for further information on hazardous locations and approved Division 2 wiring methods.

FCC Part 15 Approval Notice

The MDS TransNET 900™ (FCC ID: E5MDS-EL805) and MDS TransNET 2400™ transceivers (Pending FCC ID: E5MDS-EL805-24) comply with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. This device is specifically designed to be used under Section 15.247 of the FCC Rules and Regulations. Any unauthorized modification or changes to this device without the express approval of Microwave Data Systems may void the user's authority to operate this device. Furthermore, this device is intended to be used only when installed in accordance with the instructions outlined in this manual. Failure to comply with these instructions may also void the user's authority to operate this device.

Manual Revision and Accuracy

While every reasonable effort has been made to ensure the accuracy of this manual, product improvements may result in minor differences between the manual and the product shipped to you. If you have additional questions or need an exact specification for a product, please contact our Customer Service Team using the information at the back of this guide. In addition, manual updates can often be found on the MDS Web site at www.microwavedata.com.

ESD Notice



To prevent malfunction or damage to this radio, which may be caused by Electrostatic Discharge (ESD), the radio should be properly grounded by connection to the ground stud on the rear panel. In addition, the installer or operator should follow proper ESD precautions, such as touching a grounded bare metal object to dissipate body charge, prior to adjusting front panel controls or connecting or disconnecting cables on the front or rear panels.

Environmental Information



The equipment that you purchased has required the extraction and use of natural resources for its production. Improper disposal may contaminate the environment and present a health risk due to hazardous substances contained within. To avoid dissemination of these substances into our environment, and to diminish the demand on nat-

ural resources, we encourage you to use the appropriate recycling systems for disposal. These systems will reuse or recycle most of the materials found in this equipment in a sound way. Please contact MDS or your supplier for more information on the proper disposal of this equipment.



1.0 ABOUT THIS MANUAL

This manual presents installation and operating instructions of the MDS TransNET 900TM and MDS TransNET 2400TM transceivers for use by a professional installer. This person is expected to install, operate, and perform basic system maintenance on the described radio. Following installation, we suggest keeping this manual near the equipment for future reference.

2.0 PRODUCT DESCRIPTION

The transceiver, shown in Figure 1, is a spread spectrum radio designed for license-free operation. These units employ Digital Signal Processing (DSP) technology to provide highly-reliable long-distance communications, even in the presence of weak signals or interference.

DSP technology also makes it possible to obtain information about radio operation and troubleshoot problems, without going to the Remote radio site. Using appropriate software at the Master station, diagnostic data can be obtained on any DSP radio in the system, even while payload data is being transmitted. (See "Performing Network-Wide Remote Diagnostics" on Page 49.)

The transceiver is housed in a compact and rugged die-cast enclosure that need only be protected from direct exposure to the weather. It contains a single printed circuit board with all necessary components for radio operation. No jumper settings or manual adjustments are required to configure the radio for operation.



2.1 Transceiver Features

Listed below are several key features of the transceiver. These are designed to ease the installation and configuration of the radio, while retaining the ability to make changes in the future.

- 902–928 MHz operation using the The TransNET 900
- 2406–2482 MHz ISM band operation with the TransNET 2400
- User-selectable option to skip sub-bands with constant interference



- 65.000 available network addresses
- Network-wide configuration from the Master station eliminates most trips to Remote sites
- Data transparency ensures compatibility with virtually all asynchronous SCADA system RTUs
- Peak-hold RSSI averaged over eight hop cycles
- Operation at up to 115,200 bps continuous data flow
- Store-and-Forward repeater operation
- Data latency typically less than 10 ms
- Same hardware for Master or Remote configuration
- Supports RS/EIA-232 and RS/EIA-485 user interface
- Low current consumption; typically less than 3 mA in "sleep" mode

NOTE: Some radio features may not be available on all models, or limited by the options purchased, or the applicable regulatory constraints for the region in which the radio will operate.

2.2 Model Number Codes

The radio model number is printed on the label on the end of the radio's enclosure. It provides key information about how the radio was configured when it was shipped from the factory. This number is subject to many variations depending on what options are installed and where (country) the product is used. Contact MDS is you have questions on the meaning of the code.

2.3 Spread Spectrum Radios— How Are They Different?

The main difference between a traditional (licensed) radio and the MDS TransNET transceiver is that this unit "hops" from channel to channel many times per second using a specific hop pattern applied to all radios in the network. A distinct hopping pattern is provided for each of the 65,000 available network addresses, thereby minimizing the chance of interference with other spread spectrum systems. In the USA, and some other countries, no license is required to install and operate this type of radio system, provided that RF power and antenna gain restrictions are observed.

2.4 Typical Applications

Multiple Address Systems (MAS)

This is the most common application of the transceiver. It consists of a central control station (Master) and two or more associated Remote units, as shown in Figure 2. An MAS network provides communications between a central host computer and remote terminal units (RTUs) or other data collection



devices. The operation of the radio system is transparent to the computer equipment. When used in this application, the transceiver provides an excellent alternative to traditional (licensed) MAS radio systems.




Figure 2. Typical MAS Network

Point-to-Point System

A point-to-point configuration (Figure 3) is a simple arrangement consisting of just two radios—a Master and a Remote. This provides a half-duplex communications link for the transfer of data between two locations.




Figure 3. Typical Point-to-Point Link

Adding a Tail-End Link to an Existing Network

A tail-end link can be used to extend the range of a traditional (licensed) MAS system. This might be required if an outlying site is blocked from the MAS Master station by a natural or man-made obstruction. In this arrangement, a



TransNET radio links the outlying Remote site into the rest of a licensed MAS system by sending data from that site to an associated TransNET installed at one of the licensed Remote sites (see Figure 4).

As the data from the outlying site is received at the licensed Remote site, it is transferred to the licensed radio (via a local cable connection) and is then transmitted to the MAS Master station in the usual manner. Additional details for tail-end links are given in Section 4.3 (Page 18).




Figure 4. Typical Tail-End Link Arrangement

Extending a TransNET Network with a Repeater

Similar to a Tail-End Link, Store-and-Forward (SAF) offers a way to physically extend the network range, but in a simple and economical manner. SAF works by dividing a network into a vertical hierarchy of two or more sub-networks. Extension radios (designated as **MODE X**) serve as single-radio repeaters that link adjacent sub-networks, and move data from one sub-network to the next one.




Figure 5. TransNET Repeater Network



2.5 Accessories

The transceiver can be used with one or more of the accessories listed in Table 1. Contact the factory for ordering details.

Table 1. Accessories

| Accessory | Description | MDS Part No. |
|--|---|-----------------------------|
| AC Power Adapter | Small power supply module designed for continuous service. UL approved. Input: 120/220 Vac Output: 12 Vdc @ 500 mA (20 Watts) | 01-3682A02 |
| 2-Pin DC Power Plug | Mates with power connector on the transceiver. Screw terminals are provided for wires. | 73-1194A39 |
| Fuse (Internal) | Fuse, 2A SMF Slo-Blo | 29-1784A03 |
| Omnidirectional Antennas | Rugged antennas suited for use at Master stations. Consult MDS for details. | Various; Consult factory |
| 900 MHz Yagi Antennas | Rugged directional antennas suited for use at Remote stations. Consult MDS for details. | Various; Consult factory |
| 2400 MHz Antennas | Rugged directional antennas suited for use at Remote stations. | Various; Consult factory |
| 900 MHz Bandpass Filter | Antenna system filter to aid in eliminating inter- ference from paging system transmissions. | 20-2822A02 |
| TNC-to-N Adapter Cable (3 ft./1 meter) | Coaxial cable used to connect the radio's TNC antenna connector to a Type-N style commonly used on large-diameter coaxial cables. | 97-1677A159 |
| TNC-to-N Adapter Cable (6 ft./1.8 meter) | Coaxial cable used to connect the radio's TNC antenna connector to a Type-N style commonly used on large-diameter coaxial cables. | 97-1677A160 |
| TNC-to-N RF Adaptor Plug | Adapts radio's antenna connector to Type-N style commonly used on large-diameter coaxial cables. | 97-1677A161 |
| RS/EIA-232 Cable | Shielded data cable fitted with DB-9 male and DB-9 female, 6 ft./1.8 meter. | 97-1971A03 |
| RJ-11 to DB-9 Adapter Cable | For connecting a PC terminal to the transceiver via the radio's DIAG(nostics) connector. Used for programming and diagnostics. | 03-3246A01 |
| Flat-Surface Mounting Brackets | Brackets: 2" x 3" plates designed to be screwed onto the bottom of the transceiver for surface-mounting the radio. | 82-1753-A01 |
| Mounting Bracket Screws | Screws: 6-32/1/4" with locking adhesive. (Industry Standard MS 51957-26) | 70-2620-A01 |
| 19-Inch Rail Mounting Brackets | Adaptor for mounting the radio in a standard 19-inch equipment rack. | Consult Factory |
| DIN Rail Mtg. Brackets | Adaptor for mounting the radio in a standard 19-inch equipment rack. | 03-4022A01 |



3.0 INSTALLATION PLANNING

The installation of the radio is not difficult, but it does require some planning to ensure station reliability and efficiency. This section provides tips for selecting an appropriate site, choosing an antenna system, and reducing the chance of harmful interference.

3.1 General Requirements

There are three main requirements for installing the radio—adequate and stable primary power, a good antenna system, and the compatible interface between the transceiver and the data device.

Figure 6 shows a typical Remote station arrangement. Master stations are similar, but an omni-directional antenna is normally used instead of a directional type, and a host computer replaces the data terminal equipment.




Figure 6. Typical Remote Station Arrangement

3.2 Site Selection

For a successful installation, careful thought must be given to selecting proper sites for the Master and Remote stations. Suitable sites should provide the following:

- Protection from direct weather exposure
- A source of adequate and stable primary power
- Suitable entrances for antenna, interface or other required cabling
- Antenna location that provides an unobstructed transmission path in the direction of the associated station(s)



These requirements can be quickly determined in most cases. A possible exception is the last item—verifying that an unobstructed transmission path exists. Radio signals travel primarily by line-of-sight, and obstructions between the sending and receiving stations will affect system performance. If you are not familiar with the effects of terrain and other obstructions on radio transmission, the discussion below will provide helpful background.

Terrain and Signal Strength

While the 900 and 2400 MHz bands offer many advantages over VHF and lower UHF frequencies for data transmission, they are more prone to signal attenuation from obstructions such as terrain, foliage or buildings in the transmission path.

A line-of-sight transmission path between the Master station and its associated Remote site(s) is highly desirable and provides the most reliable communications link. A line-of-sight path can often be achieved by mounting the station antenna on a tower or other elevated structure that raises it to a level sufficient to clear surrounding terrain and other obstructions.

The importance of a clear transmission path relates closely to the distance to be covered by the system. If the system is to cover only a limited geographic area, say up to 3 miles (4.8 km), then some obstructions in the communications path can usually be tolerated with minimal impact. For longer range systems, any substantial obstruction in the communications path could compromise the performance of the system, or block communications entirely.

Much depends on the minimum signal strength that can be tolerated in a given system. Fade margin for a TransNET system does not usually have to be as conservative as a licensed system. The nature of TransNET's frequency-hopping algorithm reduces the impact of frequency-selective fading.

Although the exact figure will differ from one system to another, a Received Signal Strength Indication (RSSI) of –100 dBm will often provide acceptable performance. A higher signal strength is generally desirable and may be needed in special cases—for example, urban deployment.

Conducting a Site Survey

If you are in doubt about the suitability of the radio sites in your system, it is best to evaluate them before a permanent installation is begun. This can be done with an on-the-air test (preferred method), or indirectly, using path-study software.

An on-the-air test is preferred because it allows you to see firsthand the factors involved at an installation site and to directly observe the quality of system operation. Even if a computer path study was conducted earlier, this test should be done to verify the predicted results.

The test can be performed by first installing a radio and antenna at the proposed Master station site and then visiting each Remote site with a transceiver and a hand-held antenna.



With the hand-held antenna positioned near the proposed mounting spot, a technician can check for synchronization with the Master station (shown by a lit SYNC lamp on the front panel) and measure the reported RSSI value. If adequate signal strength cannot be obtained, it may be necessary to mount the station antennas higher, use higher gain antennas, or select a different site. To prepare the equipment for an on-the-air test, follow the general installation procedures given in this guide and become familiar with the operating instructions given in Section 5.0, beginning on Page 19.

If time is short, and a site survey is impractical, a computer path study is a good alternative. Factors such as terrain, distance, transmitter power, receiver sensitivity, and other conditions are taken into account to predict the performance of a proposed system. Contact MDS' Technical Services Group for more information on path study services.

3.3 A Word About Radio Interference

The radio shares the frequency spectrum with other services and other Part 15 (unlicensed) devices in the USA. As such, near 100% error free communications may not be achieved in a given location, and some level of interference should be expected. However, the radio's flexible design and hopping techniques should allow adequate performance as long as care is taken in choosing station location, configuration of radio parameters and software/protocol techniques.

In general, keep the following points in mind when setting up your communications network:

- Systems installed in rural areas are least likely to encounter interference; those in suburban and urban environments are more likely to be affected by other devices operating in the license-free frequency band and by adjacent licensed services.
- 2. If possible, use a directional antenna at Remote sites. Although these antennas may be more costly than omnidirectional types, they confine the transmission and reception pattern to a comparatively narrow lobe, which minimizes interference to (and from) stations located outside the pattern.
- 3. If interference is suspected from a nearby licensed system (such as a paging transmitter), it may be helpful to use horizontal polarization of all antennas in the network. Because most other services use vertical polarization in these bands, an additional 20 dB of attenuation to interference can be achieved by using horizontal polarization.
- 4. Multiple transceiver systems can co-exist in proximity to each other with only very minor interference as long as they are each assigned a unique network address. Each network address has a different hop pattern.

Additional RF isolation can be achieved by using separate directional antennas with as much vertical or horizontal separation as is practical. Vertical separation of antennas is more effective per foot/meter than horizontal.



- 5. If constant interference is present in a particular frequency zone, it may be necessary to "lock out" that zone from the radio's hopping pattern. The radio includes built-in tools to help users remove blocked frequency zones. Refer to the discussion of the SKIP command (Page 41) for more information. In the USA, a maximum of four zones may be skipped, per FCC rules. Check the regulatory requirements for your region.
- 6. Interference can also come from out-of-band RF sources such as paging systems. Installation of a bandpass filter in the antenna system may bring relief. (Contact the MDS Customer Service Department for recommendations and sources of suitable filters.)
- 7. Proper use of the **RETRY** and **REPEAT** commands may be helpful in areas with heavy interference.

The **RETRY** command sets the maximum number of times (0 to 10) that a radio will re-transmit upstream data over the air. Values greater than 0 successively improve the chances of a message getting through when interference is a problem.

The **REPEAT** command sets a fixed number of unconditional retransmissions for downstream data.

8. The RF power output of all radios in a system should be set for the lowest level necessary for reliable communications. This lessens the chance of causing unnecessary interference to nearby systems.

3.4 Antenna & Feedline Selection

Antennas


The equipment can be used with a number of antennas. The exact style used depends on the physical size and layout of a system. Contact your MDS representative for specific recommendations on antenna types and hardware sources.

In general, an omnidirectional antenna (Figure 7 and Figure 8) is used at the Master station site in an MAS system. This provides equal coverage to all of the Remote sites.

NOTE: Antenna polarization is important. If the wrong polarization is used, a signal reduction of 20 dB or more will result. Most systems using a gain-type omnidirectional antenna at the Master station employ vertical polarization of the signal; therefore, the Remote antenna(s) must also be vertically polarized (elements oriented perpendicular to the horizon).

When required, horizontally polarized omnidirectional antennas are also available. Contact your MDS representative for details.





At Remote sites and point-to-point systems, a directional Yagi antenna (Figure 8), is generally recommended to minimize interference to and from other users. Antennas are available from a sources including MDS.




Figure 8. Typical Yagi Antenna mounted to a mast

Feedlines

The choice of feedline used with the antenna should be carefully considered. Poor-quality coaxial cables should be avoided, as they will degrade system performance for both transmission and reception. The cable should be kept as short as possible to minimize signal loss.

For cable runs of less than 20 feet (6 meters), or for short range transmission, an inexpensive type such as Type RG-8A/U may be acceptable. Otherwise, we recommend using a low-loss cable type suited for 900 MHz, such as Times Microwave LMR $400^{\$}$ or Andrew Heliax $^{\$}$.



Table 2 lists several types of feedlines and indicates the signal losses (in dB) that result when using various lengths of each cable at 900 MHz and Table 3 for 2.4 GHz. The choice of cable will depend on the required length, cost considerations, and the amount of signal loss that can be tolerated.

Table 2. Length vs. loss in coaxial cables at 900 MHz

| Cable Type | 10 Feet (3.05 Meters) | 50 Feet (15.24 Meters) | 100 Feet (30.48 Meters) | 300 Feet (91.44 Meters) |
|----------------------|--------------------------|---------------------------|----------------------------|----------------------------|
| LMR 400 | 0.39 dB | 1.95 dB | 3.9 dB | Unacceptable Loss |
| 1/2 inch HELIAX | 0.23 dB | 1.15 dB | 2.29 dB | 6.87 dB |
| 7/8 inch HELIAX | 0.13 dB | 0.64 dB | 1.28 dB | 3.84 dB |
| 1-1/4 inch HELIAX | 0.10 dB | 0.48 dB | 0.95 dB | 2.85 dB |
| 1-5/8 inch HELIAX | 0.08 dB | 0.40 dB | 0.80 dB | 2.4 dB |

Table 3. Length vs. loss in coaxial cables at 2400 MHz

| Cable Type | 10 Feet (3.05 Meters) | 50 Feet (15.24 Meters) | 100 Feet (30.48 Meters) | 300 Feet (91.44 Meters) |
|----------------------|--------------------------|---------------------------|----------------------------|----------------------------|
| LMR-400 | 0.70 dB | 3.50 dB | 6.61 dB | Unacceptable Loss |
| 1/2 inch HELIAX | 0.35 dB | 1.73 dB | 3.46 dB | 17.3 dB |
| 7/8 inch HELIAX | 0.20 dB | 0.99 dB | 1.97 dB | 9.85 dB |
| 1-1/4 inch HELIAX | 0.15 dB | 0.73 dB | 1.45 dB | 7.50 dB |

Antenna System Ground

Precautions should be taken to assure the antenna and its support structure are bonded to a good earth ground system to minimize the impact of voltages created by lightning and atmospheric charges.

CAUTION: Safety grounding systems are beyond the scope of this manual. Below you will find some elementary advice. These are generalities; every location and installation is unique and requires a unique safety grounding system design. Please consider consulting a radio system engineer or other professional for advice or ground system design. A well-designed ground system will minimize risk of electrical shock to personnel and the chances of equipment damage.



Antenna Selection—Choose an antenna that offers a "DC ground" or direct low-impedance ground connection for all metallic components. This will allow static charges on the antenna system to be safely dissipated to ground. It will also provide a low-impedance discharge path to an earth/safety ground in the event of a direct lightning strike.

Support Earth/Safety Ground—The structure that supports your antenna system should have a large-gauge ground wire that goes as directly as possible to an safety/earth ground system. If a tower is used, it should have its own ground system. Support structure grounds can be bonded to the electrical system ground for increased protection. Do not use the building's AC-power supply ground as a safety ground for lightning protection.

Chassis Ground—Connect a safety/earth ground to the ground post provided on the electronic/electrical equipment. If a ground terminal is present, bond the chassis to the safety ground at a point that is as close as possible to the antenna system and primary power entry points on the chassis.

3.5 How Much Output Power Can be Used?

The transceiver is normally supplied from the factory set for an RF power of +30 dBm (1 Watt) for 900 MHz and +27 dBm (0.5 Watt) for 2400 MHz; this is the maximum transmitter output power allowed under FCC rules. The power must be decreased from this level if the antenna system gain exceeds 6 dBi. The allowable level is dependent on the antenna gain, feedline loss, and the transmitter output power setting. Power considerations for the transceiver are discussed below.

NOTE: In some countries, the maximum allowable RF output may be limited to less than your model's peak output. Be sure to check for and comply with the requirements for your region.

To determine the maximum allowable power setting of the radio, perform the following steps:

- 1. Determine the antenna system gain by subtracting the feedline loss (in dB) from the antenna gain (in dBi). For example, if the antenna gain is 9.5 dBi, and the feedline loss is 1.5 dB, the antenna system gain would be 8 dB. (If the antenna system gain is 6 dB or less, no power adjustment is required.)
- 2. Subtract the antenna system gain from 36 dBm (the maximum allowable EIRP). The result indicates the maximum transmitter power (in dBm) allowed under the rules. In the example above, this is 28 dBm.
- 3. If the maximum transmitter power allowed in your region is less than 30 dBm, use the **PWR** command (described on Page 38) to set the power accordingly.



For convenience, Table 4 lists several antenna system gains and shows the maximum allowable power setting of the radio. Note that a gain of 6 dB or less entitles you to operate the radio at full power output—30 dBm (1 watt).

Table 4. Antenna system gain vs. power output setting (USA)

for 900 MHz models to achieve +36 dBm EIRP

| Antenna System Gain (Antenna Gain in dBi ^a minus Feedline Loss in dB ^b) | Maximum Power Setting (in dBm) | EIRP (in dBm) |
|--|--------------------------------------|------------------|
| 6 (or less) | 30 | 36 |
| 8 | 28 | 36 |
| 10 | 26 | 36 |
| 12 | 24 | 36 |
| 14 | 22 | 36 |
| 16 | 20 | 36 |

- a. Most antenna manufacturers rate antenna gain in dBd in their literature. To convert to dBi, add
 2.15 dB
- Feedline loss varies by cable type and length. To determine the loss for common lengths of feedline, see Table 2 on Page 11.

Table 5. Antenna system gain vs. power output setting (USA)

for 2400 MHz models to achieve +36 dBm EIRP

| Antenna System Gain (Antenna Gain in dBi ^a minus Feedline Loss in dB ^b | Maximum Power Setting (in dBm) | EIRP (in dBm) |
|--|--------------------------------------|------------------|
| 2 dB | 27 | 29 |
| 10 dB | 26 | 36 |

- a. Most antenna manufacturers rate antenna gain in dBd in their literature. To convert to dBi, add 2.15 dB.
- Feedline loss varies by cable type and length. To determine the loss for common lengths of feedline, see Table 2 on Page 11.



4.0 INSTALLATION

Figure 9 shows the contents of a typical transceiver shipment. Check the contents against the packing list secured to the outside of the shipping box. Accessories and spare parts kits, if any, are wrapped separately. Inspect all items for signs of damage and save all packing materials for possible re-shipment.




Figure 9. Typical Transceiver Shipment

User documentation will be provided as a paper manual and/or as a PDF on the "MDS TransNET Support Package CD" (P/N 03-2708A01). The CD includes:

- Installation & Operation Guide in PDF (Also known as Adobe AcrobatTM)
- TransNET Configuration Software

If a paper copy is required but not provided with your shipment, please contact MDS Customer Support Team.

4.1 Transceiver Installation

The following is an overview of a typical procedure for installing the transceiver. In most cases, these steps alone will be sufficient to complete the installation. Should further information be required, contact the factory using the information given on the inside back cover of this manual.

If you are installing a tail-end link system, you should also review Section 4.3 (Page 18) for important details on configuration.

NOTE: It is recommended that the Master station be installed first. In this way, it will be possible to quickly check the operation of each associated Remote station as it is placed on the air.

1. Mount the transceiver to a stable surface using the brackets supplied with the radio. (Fasteners/anchors are not supplied.) Figure 10 shows the dimensions of the transceiver case and its mounting brackets. If possible,



choose a mounting location that provides easy access to the connectors on the end of the radio and an unobstructed view of the LED status indicators.




Figure 10. Transceiver Mounting Dimensions

Figure 11 shows the four connectors on the transceiver and their functions.




Figure 11. Interface Connector Functions

2. Install the antenna and antenna feedline for the station. Antennas should be mounted in the clear and in accordance with the manufacturer's instructions. Additional information on antennas and feedlines is contained in Section 3.4 on Page 9.


NOTE: It is recommended to mount the antenna be at least 10 feet (>3 meters) from the radio, RTU, sensors and other components of the system to prevent RFI.

3. Connect the data equipment to the transceiver's DATA connector. Use only the required pins for the application.



Typical RS/EIA-232 applications require the use of Pin 2 (receive data—RXD and Pin 3 (transmit data—TXD). Some systems may require the use of Pin 7 (Request-to-send—RTS). Figure 13 shows connection details for the DATA connector for EIA/RS-232 and EIA/RS-485, respectively.

If hardware flow control is desired, Pin 7 (RTS) and Pin 8 (CTS) may also be connected. A more detailed discussion of pin functions is provided in see "Data Interface Connections (DB-9F)" on page 69.




Pin Function

- 1.....Data Carrier Detect (DCD)
- 2.....Receive Data (RXD)

- 3.....Transmit Data (TXD) 4.....Sleep (GND = Sleep) 5.....Signal Ground (GND)
- 6....Alarm Output (+5/-5 Vdc) 7....Ready-to-Send (RTS) 8....Clear-to-Send (CTS)
- 9.....Reserved for Special Uses (Do not connect)

Figure 12. DATA Connector Pin Functions, EIA/RS-232 Mode As viewed from outside the radio

NOTE: The data cabling between the transceiver and the connected device should be kept as short as possible. For EIA/RS-232 operation, the maximum recommended cable length is 50 feet/15 meters.



Pin Function

- 1.....Not Used (Open)
- 2.....TXD+/TXA, Non-inverted driver output. Supplies data to connected device.
- 3.....RXD+/RXA, Non-inverted receiver input.
- Accepts data from the connected device.
- 4.....Sleep Mode Input (GND = Sleep) 5.....Signal Ground (GND)
- 6.....Not Used (Open) 7.....RXD-/RXB, Inverting receiver input
- 8.....TXD-/TXB, Inverting driver output
- 9....Not Connected (User configureable via internal jumper)

Figure 13. DATA Connector Pin Functions, EIA/RS-485 Mode As viewed from outside the radio

4. Measure and install the primary power for the transceiver. It must be within 6–30 Vdc (including transients) and be capable of providing 7.5 watts over this voltage range. (Typical current draw is 400 mA @13.8 Vdc; 0.9 A @6 Vdc.) A power connector with screw-terminals is provided with each unit. Strip the wire leads to 0.25"/6 mm. Be sure to observe proper polarity. The left pin is the positive input; the right is negative. (See Figure 14.)



CAUTION

POSSIBLE EQUIPMENT DAMAGE The radio must be used only with negative-ground systems. Make sure the polarity of the power source is correct. The unit is protected from reverse polarity by an internal diode and fuse.



Figure 14. Power Connector (Polarity: Left +, Right –)

CAUTION

POSSIBLE EQUIPMENT DAMAGE The power connector used with the MDS TransNET transceiver is similar to that used by other MDS products, such as the MDS 9810 and MDS x710 family. The connectors are *not* equal and the use of the other style connector may provide unreliable connections and a spark may be created.

Only the power connector, shown in Figure 14 with screw terminals and two retainer screws should be used with this unit.

5. Set the radio's basic configuration with a PC terminal connected to the DIAG(nostics) connector via an RJ-11 to DB-9 adapter cable, MDS P/N 03-3246A01. (If necessary, a cable of this type may be constructed using the information shown in Figure 21 on Page 69.) For more information on connecting a PC terminal and preparing it for use, refer to Section 6.1 on Page 22.

The three essential settings for the Transceiver are as follows:

Mode—Master, Remote, or Extension
Network Address—a unique number from 1 to 65000
Data Interface Parameters—bps, data bits, parity, stop bits

a. Set the Mode using the MODE M (Master), MODE R (Remote), or MODE X (Extension) command. (Note: There can be only *one* Master radio in a system.)

If *any* MODE X radios are used in the network, SAF must be turned on at the Master station. The MODE X radio must be programmed with an Extended Address (XADDR). Units that need to hear the MODE X radio must be programmed with an appropriate XPRI and/or XMAP value. (See "SAF Operation with Extension Radios" on Page 52 for more information.)



- b. Set a unique Network Address (1–65000) using **ADDR** command. Each radio in the system *must* have the same network address. *Tip: Use the last four digits of the Master's serial number to help avoid conflicts with other users.*
- c. Set the baud rate/data interface parameters. Default setting is 9600 bps, 8 data bits, no parity, 1 stop bit. If changes are required, use the BAUD xxxxx abc command where xxxxx equals the data speed (300–115200 bps) and abc equals the communication parameters as follows:

 $\mathbf{a} = \text{Data bits } (7 \text{ or } 8)$

b = Parity (N for None, O for Odd, E for Even

 $\mathbf{c} = \text{Stop bits } (1 \text{ or } 2)$

NOTE: 7N1, 8E2 and 8O2 are invalid interface parameters.

4.2 Configuring Multiple Remote Units

In most installations, the Remote radios will be programmed with virtually the same set of parameters. This process can be streamlined by testing key pieces of equipment—such as the Master, any Extensions, and a typical Remote—on a benchtop setup prior to installation. This allows you to test various configurations in a controlled environment. Once the evaluation network is working satisfactorily, you can save the configuration of each unit in a data file on your PC's hard drive through the use of the *MDS TransNET Configuration Software* (included on the support CD shipped with the radio, MDS part number 03-2708A01).Most often, there are many Remote units that will need configuring. Using the *MDS TransNET Configuration Software*, you can save the sample unit's configuration, then open the configuration file with the program and install it in the next Remote. The software will prevent you from overwriting unit or mode-unique parameters.

4.3 Tail-End Links

A tail-end link is established by connecting an MDS TransNET Series radio "back-to-back" with another identical radio such as a licensed MDS x710B Series transceiver. This can be used to link an outlying Remote site into the rest of an MAS network. (Figure 4 on Page 4 shows a diagram of a typical tail-end link system.) The wiring connections between the two radios in a tail-end link system should be made as shown in Figure 15.






Figure 15. Data Interface Cable Wiring for Tail-End Links

Any device on the left that requires a keyline, as in this illustration, will require the bottom line (CTS to RTS) and the TransNET on the right will need **DEVICE** type set to **CTS KEY**. See **DEVICE**, on Page 32 for details.

4.4 Configuring a Network for Extensions

The installation and configuration of an Extension transceiver is straightforward with only a few unique parameters that need to be considered and set at each unit.

In every network there can be only one Master station. It will serve as the sole gateway to the outside world. The tables in "Configuration Parameters for Store-and-Forward Services" on Page 57 detail the parameters that need to be set on each type of radio in the network. For a detailed description of this network design, see "SAF Operation with Extension Radios" on page 52.

5.0 OPERATION

5.1 Initial Start-up

In-service operation of the transceiver is completely automatic. Once the unit has been properly installed and configured, operator actions are limited to observing the LED status indicators for proper operation.

If all parameters are correctly set, start operation of the radio as follows:

- 1. Apply primary power.
- 2. Observe the transceiver LED status panel for proper indications. Table 6 provides an explanation of the LED functions.

In a normally operating system, the following indications will be seen within 16 seconds of start-up:

- PWR lamp lit continuously
- SYNC lamp lit continuously



 Remote radio(s) transmitting data (TXD) and receiving data (RXD) with Master station

Table 6. LED indicator descriptions



| Name | Description |
|------|---|
| PWR | Continuous—Power is applied to the radio; no problems detected |
| | Flashing (5 times-per-second)—Fault indication See "TROUBLESHOOTING" on Page 45 |
| | Off—Radio is unpowered or in Sleep mode |
| | See also, "LED [ON, OFF]" on Page 36 |
| SYNC | Continuous—Radio is receiving/sending synchronization frames On within 10 seconds of power-up under normal conditions |
| TXD | Transmit data activity on the DB-9 DATA interface connector Payload data to connected device |
| RXD | Receive data activity on the DB-9 DATA interface connector. Payload data from the connected device |

5.2 Performance Optimization

After the basic operation of the radio has been checked, you may wish to optimize its performance using some of the suggestions given here. The effectiveness of these techniques will vary with the design of your system and the format of the data being sent.

Complete instructions for using the commands referenced in this manual are provided in "RADIO PROGRAMMING" on Page 22.

Antenna Aiming

For optimum performance, directional antennas must be accurately aimed in the direction of desired transmission. The easiest way to do this is to point the antenna in the approximate direction, then use the Remote radio's **RSSI** command (Received Signal Strength Indicator) to further refine the heading for maximum received signal strength.

In an MAS system, RSSI readings are only meaningful when initiated from a Remote station. This is because the Master station typically receives signals from several Remote sites, and the RSSI would be continually changing as the Master receives from each Remote in turn. Adjust the antenna for the highest (most positive) value to insure the greatest communication reliability.



Antenna SWR Check

It is necessary to briefly key the transmitter for this check by placing the radio in the **SETUP** mode (Page 40) and using the **KEY** command. (To unkey the radio, enter **DKEY**; to disable the **SETUP** mode and return the radio to normal operation, enter **Q** or **QUIT**.)

The SWR of the antenna system should be checked before the radio is put into regular service. For accurate readings, a wattmeter suited for 1000 MHz is required. One unit meeting this criteria is the Bird Model 43 directional wattmeter with a 5J element installed.

The reflected power should be less than 10% of the forward power (≈2:1 SWR). Higher readings usually indicate problems with the antenna, feedline or coaxial connectors.

Data Buffer Setting-Modbus Protocol

The default setting for the data buffer is **OFF**. This allows the radio to operate with the lowest possible latency and improves channel efficiency. MODBUS and its derivatives are the only protocols that should require the buffer to be turned on. See "BAND [A, B, C]" on Page 30 for details.

Hoptime Setting

The default hop-time setting is **7** (7 ms). Alternate settings of **14** and **28** milliseconds can be used to increase throughput, but at the cost of increased latency. A detailed explanation of the **HOPTIME** command can be found on Page 34.

TotalFlow™ Protocol at 9600 with Sleep Mode

For reliable operation with TotalFlow meters, use the default settings for 9600 with the following alterations:

HOPTIME 28—Allows large data packets

FEC OFF—Improves store-and-forward performance for a large continuous data stream

BUFF ON—Ensures "ungapped" 4-second polls if unit in sleep mode

Operation at 115200 bps

Burst throughput at 115200 bps is supported at all settings. The radio will always buffer at least 500 characters. Sustained throughput at 115200 bps is only possible when the data path is nearly error-free and the operating settings have been properly selected. For sustained operation at 115200 bps, use the following settings: SAF OFF, FEC OFF, REPEAT 0, RETRY 0, HOPTIME 28.



Baud Rate Setting

The default baud rate setting is 19200 bps to accommodate most systems. If your system will use a different data rate, you should change the radio's data interface speed using the **BAUD xxxxx abc** command (Page 29). It should be set to the highest speed that can be sent by the data equipment in the system. (The transceiver supports 300 to 115200 bps.)

Radio Interference Checks

The radio operates in eight frequency zones. If interference is found in one or more of these zones, the **SKIP** command (Page 41) can be used to omit them from the hop pattern. You should also review Section 3.3, *A Word About Radio Interference*, when dealing with interference problems.

6.0 RADIO PROGRAMMING

There are no manual adjustments on the radio. Programming and control is performed through a PC connected to the radio's DIAG connector.

6.1 Radio Programming Methods

Terminal Interface

A PC may be used by operating it in a basic terminal mode (for example, a HyperTerminal session) and entering the radio commands listed in the tables found in "*User Commands*" on Page 23. The PC must be connected to the radio's DIAG connector using an RJ-11 to DB-9 Adapter Cable (MDS P/N 03-3246A01). If desired, a cable of this type may be constructed using the information shown in Figure 21 on Page 69.

Once connected, communication (baud rate) is established through the command interface. To access the command interface, press the ESC key, followed by one or more ENTER keystrokes (delivered at about half-second intervals), until the ">" prompt is displayed.

NOTE: The DIAG port (RJ-11 connector) uses 8 data bits, 1 stop bit, and no parity. It can automatically configure itself to function at 1200, 2400, 4800, 9600, 19200, 38400, 57600, and 115200 bps. [Default: **BAUD** = 9600]

If the **DLINK** setting is **ON**, the DIAG port will start out in Diagnostic Link mode. This is a special protocol used to support Network-Wide Diagnostics. The process described in the paragraph above causes the radio to exit the diagnostic link mode and enter the command mode. If there is no input in command mode for 5 minutes, the DIAG port will revert back to diagnostic link mode.

PC-Based Configuration Tool

The MS WindowsTM-based *MDS TransNET Configuration Software* (P/N 06-4059A01) is designed for use with a PC connected to the radio's DIAG connector through an RJ-11 to DB-9 cable assembly (MDS Part No. 03-3246A01). A cable of this type may be constructed using the information shown in Figure 21 on Page 69.



The *TransNET Configuration Software* provides access to all of the radio's capabilities with the benefit of context-sensitive help. The program is shipped as part of the TransNET support CD included with every order (CD P/N 03-2708A02)

6.2 User Commands

A series of tables begin on the next page that provide reference charts of various user commands for the transceiver. See "Detailed Command Descriptions" on Page 28 for more details.

Entering Commands

The proper procedure for entering commands is to type the command, followed by an ENTER keystroke. For programming commands, the command is followed by SPACE, the appropriate information or values, and then ENTER.

Table 7. Network Configuration—Master Station

| COMMAND | DESCRIPTION |
|-------------------------------------|---|
| AT [ON, OFF] Details Page 29 | Enables Master station to emulate a modem and respond to AT commands |
| BUFF [ON, OFF] Details Page 30 | ON = Seamless data OFF = Fast byte throughput. |
| FEC [ON, OFF] Details Page 33 | Sets/disables FEC (Forward Error Correction) setting. |
| HOPTIME [7, 28] Details Page 34 | Displays hop-time or sets it to 7 or 28 ms. |
| LPM [1, 0] Details Page 36 | Used at Master to set all associated stations in an energy-conservation mode. |
| | 1 = Low-power mode enabled network-wide 0 = Disable low-power mode (Default) |
| REPEAT Details Page 38 | Sets/displays the fixed downstream re-send count. |
| RETRY [0–10] Details Page 38 | Sets/displays the maximum upstream re-send count for ARQ (Automatic Repeat Request) operation |
| SAF [ON, OFF] Details, page 40 | Enables/disables the store-and-forward function for the network controlled by this Master unit. |
| SKIP [NONE, 18] Details, page 41 | Skip one or more frequency zones |



Table 8. Network-Wide Diagnostics

| Command | Description |
|---------------------------------------|--|
| DLINK [xxxxx/ON/OFF] Details, page 32 | Controls operation of diagnostic link function. |
| DTYPE [NODE/ROOT] Details, page 33 | Set radio's operational characteristics for network-wide diagnostics |

Table 9. Operational Configuration—Set/Program

| Command | Description |
|---|---|
| ADDR [1–65000] <i>Details, page 29</i> | Program network address |
| AMASK [0000 0000–FFFF FFFF] Details, page 29 | Alarm response Default: FFFF FFFF |
| ASENSE [HI/LO] Details, page 29 | Sense of the alarm output on Pin 6 of the DATA interface connector in the EIA-232 mode. Default: Alarm present = HI |
| BAND [A, B, C] Details Page 30 | Selects one of three operating bands. (2.4 GHz Model Only) |
| BAUD [xxxxx abc] Details, page 29 | Data communication parameters |
| CODE [NONE, 1255] Details, page 31 | Select the security/encryption setting in the radio |
| CSADDR [1–65000, NONE] Details, page 31 | Used on a single Master/Remote network to support TDD-style simulated full-duplex. |
| CTS [0–255] Details, page 31 | CTS delay in milliseconds (A value of 0 returns CTS immediately) |
| CTSHOLD [0–60000] Details, page 32 | "Hold time" that CTS is present following last character from DATA port. |
| DEVICE [DCE, CTS KEY] Details, page 32 | Device behavior: DCE (normal) or CTS Key |
| MODE [M, R, X] Details, page 36 | Operating mode: M = Master, R = Remote, X = Extension |
| MRSSI [NONE, -4090] Details, page 37 | Minimum RSSI level required to preserve synchronization with a Master radio for Remotes in mobile service. |
| OT [ON, OFF] Details, page 37 | Enables a 1-second delay on delivery of RXD serial data. |



Table 9. Operational Configuration—Set/Program (Continued)

| Command | Description |
|---|---|
| OWN [xxxxx] Details, page 37 | Owner's name, or alternate message (30 characters maximum) |
| PORT [RS232, RS485] Details, page 37 | Data port (DATA connector) interface signaling mode: RS232 or RS485 |
| PWR [20–30] Details, page 38 | Power output in dBm (Figure 30 on Page 74) |
| RXD [0–235] / [ON/OFF] Details, page 39 | Set RXD delay time for virtual seamless mode with low latency |
| RXTOT [NONE, 0–1440] Details, page 40 | Maximum duration (in minutes) before time-out alarm. Default is OFF. |
| RTU [ON, OFF, 0-80] Details, page 39 | Enable or Disable unit's built-in RTU simulator. Default is OFF. Set RTU address between zero and 80. |
| SLEEP [ON, OFF] Details, page 42 | Enable or Disable the radio's energy-conservation Sleep mode function. |
| UNIT [10000–65000] <i>Details, page 43</i> | Unit address used for network-wide diagnostics. (Unique within associated network.) |
| XADDR [0–31] Details, page 44 | This unit's Extended address Typically, the Master is set to zero (0). |
| XMAP [00000000-FFFFFFF] Details, page 44 | Included Extended units in MODE X. (Extensions and Remotes only) |
| XPRI [0–31] Details, page 44 | Address of the primary Extended radio unit (Extension). |
| XRSSI [NONE, -40120] Details, page 44 | Minimum RSSI level required to preserve synchronization with a non-primary radio. (Only meaningful when XPRI is not NONE) |
| ZONE CLEAR Details, page 44 | Reset zone data statistics |

Table 10. Operating Status—Display Only

| Command | Description | |
|--------------------------|-----------------------|--|
| ADDR Details Page 29 | Network address | |
| AMASK Details Page 29 | Alarm mask (response) | |



Table 10. Operating Status—Display Only (Continued)

| Command | Description |
|----------------------------|--|
| ASENSE Details Page 29 | Current sense of the alarm output. |
| BAUD Details Page 29 | Data communication parameters. Example: BAUD 9600 8N1 |
| BUFF Details Page 30 | Data buffering mode: ON = seamless data, OFF = fast byte throughput |
| CODE Details Page 30 | Security/encryption operational status. "NONE" (Inactive), or "ACTIVE" |
| CTS Details Page 31 | CTS delay in milliseconds (0-255 ms) |
| CTSHOLD Details Page 32 | "Hold time" that CTS is present following last character from DATA port. |
| DEVICE Details Page 32 | Device behavior Alternatives: DCE and CTS KEY |
| HOPTIME Details Page 34 | Hop-time value in milliseconds (ms). |
| LPMHOLD Details Page 36 | Time (0-1000 ms) provided to give an RTU time to respond before the radio goes to sleep. |
| MODE Details Page 36 | Current operating mode: M = Master R = Remote X = Extension (Repeater) |
| MRSSI Details Page 37 | Minimum RSSI level required to preserve synchronization with a Master radio for Remotes in mobile service. |
| OWM Details Page 37 | Owner's message or site name |
| OT Details Page 37 | Status (ON/OFF) of the 1-second delay on delivery of RXD serial data. |
| OWN Details Page 37 | Owner's name or system name |
| PORT Details Page 37 | Current data port (DATA connector) interface signaling mode: RS232 or RS485 |
| PWR Details Page 38 | Forward power-output setting in dBm |



Table 10. Operating Status—Display Only (Continued)

| Command | Description |
|------------------------------|---|
| REPEAT Details Page 38 | The fixed downstream re-send count. |
| RETRY Details Page 38 | The maximum upstream re-send count for ARQ (Automatic Repeat Request) operation. |
| RSSI Details Page 38 | Received signal strength indicator (in dBm). Unavailable at Master unless SETUP is enabled. |
| RTU Details Page 39 | RTU simulator's operational status (ON/OFF) |
| RXTOT Details Page 40 | The amount of time (in seconds) to wait before issuing a time-out alarm. |
| SAF Details Page 40 | Store-and-forward mode status in this unit. (ON/OFF) |
| SER Details Page 40 | Serial number of radio |
| SHOW CON Details Page 41 | Display virtual modem connection status |
| SHOW PWR Details Page 41 | RF output power. Measured RF power in dBm. |
| SHOW SYNC Details Page 41 | Information on synchronization source |
| SKIP Details Page 41 | Frequency zones that are skipped |
| SLEEP Details Page 42 | Radio's Sleep Mode setting. (At Remotes Only) |
| SREV Details Page 42 | Transceiver firmware revision level |
| STAT Details Page 43 | Current alarm status |
| TEMP Details Page 43 | Transceiver's internal temperature (°C) |
| UNIT Details Page 43 | Programmed unit address for network-wide diagnostics |
| XADDR Details Page 44 | This unit's Extended address |



Table 10. Operating Status—Display Only (Continued)

| Command | Description |
|--------------------------|---|
| XPRI Details Page 44 | Address of the primary Extended radio unit (Extension). |
| XMAP Details Page 44 | Included Extended units in MODE X. (Extensions and Remotes only). |
| XRSSI Details Page 44 | Minimum RSSI level required to preserve synchronization with a non-primary radio. (Only meaningful when XPRI is not NONE) |

Table 11. Diagnostic and Test Functions

| Command | Description |
|-------------------------------|--|
| KEY Details Page 35 | Enables the transmitter test. (Must be in Setup mode. Details on page 40.) |
| DKEY Details Page 33 | Turns off the transmitter test. (Must be in Setup mode. Details on page 40.) |
| TX [xxxx] Details Page 43 | Set/display transmit test frequency. (Must be in Setup mode. Details on page 40.) |
| RX [xxxx] Details Page 39 | Set/display receive test frequency. (Must be in Setup mode. Details on page 40.) |
| SETUP Details Page 40 | Enables Setup mode. Times out after 10 minutes. Press "Q" to quit. |
| ZONE DATA Details Page 44 | Zone data statistics |
| ZONE CLEAR Details Page 44 | Clears the Zone Data log |

6.3 Detailed Command Descriptions

The essential commands for most applications are Network Address (ADDR), Mode (MODE), and Baud Rate (BAUD). However, proper use of the additional commands allows you to tailor the transceiver for a specific use, or to conduct basic diagnostics on the radio. This section gives more detailed information for the commands listed above in Section 6.2.

Most of the commands below can be used in two ways. First, you can type only the command name (for example, **ADDR**) to view the currently programmed data. Second, you can set or change the existing data by typing the command, followed by a space, and then the desired entry (for example, **ADDR 1234**). In the descriptions which follow, allowable programming variables, if any, are shown in brackets [] following the command name.



ADDR [1-65000]

Network Address

This command sets or displays the radio's network address. The network address can range from 1 to 65000.

A network address must be programmed at the time of installation and must be common across each radio in a given network. Radios are typically shipped with the network address unprogrammed, causing the address to display as **NONE**. If the address is not set (or is set to a wrong value) it leaves the system in an invalid state, preventing operation and generating an alarm.

NOTE: It is recommended that the last four digits of the Master radio's serial number be used for the network address. This helps avoid conflicts with other users.

AMASK [0000 0000-FFFF FFFF]

Alarm Mask

This command sets the alarm bits that cause the alarm output signal to be triggered. The PWR LED will still flash for all alarms, but the alarm output signal will only be activated for those alarms that have the corresponding mask bit set. The hex value for the mask aligns directly with the hex value for the ALARM command. The default is FFFF FFFF. Through proper use of the AMASK command, it is possible to tailor the alarm response of the radio. Contact the factory for more information on configuring the alarm mask.

AT [ON, OFF]

Hayes-Compatible AT Command Support

AT-style modem commands, also know as "Hayes-Compatible Commands", can be processed through the payload port. By setting **AT ON** at the Master (**MODE M**), individual Remotes can be accessed by using **ATDT** [Unit Address]. In this mode, RTUs designed only for dial-up access can be accessed through the Master station. For more details, see See "Using AT Commands" on Page 55 and "*OT [ON, OFF]*" on Page 37.

ASENSE [HI/LO]

Alarm Output Sense

This command is used to set the sense of the alarm output at Pin 6 of the DATA connector. The default is **HI** which means an alarm is present when an RS-232 high is on Pin 6.

BAUD [xxxxx abc]

Data Interface Port Baud Rate

This command sets or displays the communication attributes for the normal payload communications through the DATA port. The command has no effect on the RJ-11 DIAG(NOSTICS) port.



The first parameter (xxxxx) is baud rate. Baud rate is specified in bits-per-second and must be one of the following speeds: 300, 600, 1200, 1800, 2400, 4800, 9600, 19200, 38400, 57600, or 115200. At baud rates of 19200 bps or less, the radio can support unlimited continuous data transmission at any hop rate.

The second parameter of the **BAUD** command (**abc**) is a 3-character block indicating how the data is encoded. The following is a breakdown of each character's meaning:

 $\mathbf{a} = \text{Data bits } (\mathbf{7} \text{ or } \mathbf{8})$

b = Parity (**N** for None, **O** for Odd, **E** for Even)

 $\mathbf{c} = \text{Stop bits } (\mathbf{1} \text{ or } \mathbf{2})$

The factory default setting is 9600 baud, 8 data bits, no parity, 1 stop bit (Example: **9600 8N1**).

NOTE: 7N1, 8O2, and 8E2 are invalid communication settings and are not supported by the transceiver.

BAND [A, B, C]

Select Sub-Band (Normally used for 2.4 GHz model)

This command sets or displays the receiving and transmit operating band for the radio.

A = 2.4016 - 2.4270 GHz

B = 2.4272 - 2.4526 GHz

 $\mathbf{C} = 2.4528 - 2.478.2 \text{ GHz}$

NOTE: The same **BAND** must be programmed at the time of installation and must be common across each radio in a given network.

BUFF [ON, OFF]

Data Buffer Mode

This command sets or displays the received data handling mode of the radio. The command parameter is either **ON** or **OFF**. (The default is **OFF**.) The setting of this parameter affects the timing of received data sent out the DATA connector. Data transmitted over the air is unaffected by the **BUFF** setting.

If data buffering is set to **OFF**, the radio will operate with the lowest possible average latency. Data bytes are sent out the DATA port as soon as an incoming RF data frame is processed. Average and typical latency will both be below 10 ms, but idle character gaps may be introduced into the outgoing data flow.

If data buffering is **ON**, the radio will operate in a seamless mode. That is, data bytes will be sent over the air as quickly as possible, but the receiver will buffer the data until the entire packet has been collected. The delay introduced by data buffering is variable and depends on message size and the number of retransmissions required, but the radio will not create any gaps in the output data stream. This mode of operation is required for protocols such as MODBUSTM that do not allow gaps in their data transmission.



Seamless mode (**BUFF ON**) is intended only for applications where the message size is 256 characters or less. Enforcement of this rule is left up to the user. If more than 256 characters are transmitted data delivery will not be seamless and data may be lost.

Changes to the **BUFF** setting may only be made at the Master radio. This is because the Master radio broadcasts the buffer setting for the entire network. At Remote radios, the buffer setting may be read when the radio is in synchronization with the Master, but it cannot be changed.

CODE [NONE, 1...255]

Security Code

The **CODE** command is used to select or display the security/encryption setting in the radio.

The default is **CODE NONE**. Setting **CODE** to a value other than **NONE** provides an extra level of security beyond that provided by the Network Address (**ADDR**). The disadvantage is increased complexity in managing the network.

The **CODE** command takes an argument **1...255**, or **NONE**. Entering **CODE** without an argument will display either **NONE** or **ACTIVE**. **ACTIVE** means that security/encryption has been enabled, but the radio *will not* display the security argument.

When a **CODE** value is active, *all radios in the system must use the same code value*. If the code value is not properly programmed, a Remote radio will not synchronize with the Master.

CAUTION: Record the **CODE** value and store it in a safe place. If the code is later forgotten, and a unit is to be added to the system, all radios in the network must be set to **NONE** and then reprogrammed to a new value.

CSADDR [1-65000, NONE]

Clock-Synchronizing Master Address

Used to specify the network address of a "Clock-Sync" Master station to which this station will be synchronized. Also see "ADDR [1–65000]" on Page 29 and "Co-Located and Close-Proximity Masters" on Page 63 for further details.

CTS [0-255]

Clear-to-Send Delay

The CTS (clear-to-send) command sets or displays the timer value associated with the CTS line response. The command parameter ranges from 0 to 255 milliseconds.

For DCE operation, the timer specifies how long to wait after the RTS line goes high before asserting the CTS line. A timer value of zero means that the CTS line will be asserted immediately following the assertion of RTS.



For CTS Key operation (see the **DEVICE** command), the timer specifies how long to wait after asserting the CTS line before sending data out the DATA port. A timer value of zero means that data will be sent out the data port without imposing a key-up delay. (Other delays may be in effect from other radio operating parameters.)

CTSHOLD [0-60000]

Clear-to-Send Hold Time

Used in **DEVICE CTS KEY** mode, this command sets the amount of time in milliseconds that CTS remains present following transmission of the last character out the RXD pin of the DATA port. This "hold time" can be used to prevent squelch tail data corruption when communicating with other radios.

The **CTSHOLD** setting can range from 0 to 60000 (i.e., 60 seconds). The default value is 0, which means that CTS will drop immediately after the last character is transmitted. If the command is entered when the radio is in **DEVICE DCE** mode, the response **CTSHOLD N/A** will be displayed.

DEVICE [DCE, CTS KEY]

Radio-MODEM Behavior

The **DEVICE** command sets or displays the device behavior of the radio. The command parameter is either **DCE** or **CTS KEY**.

The default selection is **DCE**. In this mode, CTS will go high following RTS, subject to the CTS programmable delay time. Keying is stimulated by the input of characters at the data port. Hardware flow control is implemented by dropping the CTS line if data arrives faster than it can be transmitted.

If CTS KEY is selected, the radio is assumed to be controlling another radio, such as in a repeater or tail-end link system. The RTS line is ignored and the CTS line is used as a keyline control for the other radio. CTS is asserted immediately after the receipt of RF data, but data will not be sent out the DATA port until after the CTS programmable delay time has expired. (This gives the other radio time to key.)

Following transmission of the last byte of data, CTS will remain asserted for the duration specified by the **CTSHOLD** command. **CTSHOLD** should be set sufficiently high.

DLINK [xxxx/ON/OFF]

InSite Diagnostics Link Support

DLINK ON enables use of *Diagnostic Link* mode and establishes it as the default protocol on the RJ-11 DIAG port. *Diagnostic Link* mode is a special protocol used to support Network-Wide Diagnostics. **DLINK** must be set to **ON** to support connection to *InSite* or to support chained diagnostics between radio networks even while the radio is in sleep mode. **DLINK OFF** disables this feature. The default setting is **ON**.

The following **DLINK** baud rates selections are supported:

• 1200 • 4800 • 9600 • 19200 (default)



• 38400 • 57600 • 115200

Example: **DLINK 4800** sets the RJ-11 DIAG port to operate at 4800 bps when diagnostics is closed. This setting will not affect the port's autobaud operation. Use only of **DLINK ON**, will enable the use 19200 or the most recently programmed value. The default is **DLINK 19200** and **DLINK ON**.

- NOTE 1: The same baud rate must be entered into the InSite Equipment List's BAUD field.
- NOTE 2: The DLINK rate must match the rate of any connected device to the diagnostic port. This may be either another MDS radio's diagnostic port, InSite computer, or another data link device that eventually connects to the InSite computer.

DKEY

Turn Off Radio Transmitter 's Test Signal

Disables the transmitter when it is keyed. See also **KEY** command.

DTYPE [NODE/ROOT]

Network Diagnostics Mode

The **DTYPE** command specifies the radio's operational characteristics for network-wide diagnostics. The transceiver uses the following types:

- NODE—The most common setting, and the default. This is the basic system radio device-type. Typically, the radio network is comprised of nodes and one root. Intrusive diagnostics can originate from any node. However, non-intrusive diagnostics can only be conducted from the root node.
- ROOT—Always one, and only one, per network (including units associated through Extension units.) The root is the focal point of network-wide diagnostics information. Intrusive diagnostics can originate from any radio, including the root. However, the root is the only radio through which non-intrusive diagnostics can be conducted.

FEC [ON, OFF]

Forward Error Correction

This command is used to view the FEC setting, or turn it on or off. The default setting is **FEC ON**. (It needs to be turned off when throughputs exceed 57,600 bps.) FEC is set at the Master and is automatically passed on to all Remotes in a network.

Setting FEC to **ON** improves sensitivity at the cost of reduced throughput. Typical SCADA/telemetry applications use low data rates and, as such, the FEC setting is normally transparent to them.



HOPTIME [7, 14, 28]

Radio Transmitter Hop Timing

The **HOPTIME** command is used to set or display the hop-time setting. The command is a digit corresponding to the hop-time setting in milliseconds. The default **HOPTIME** setting is **7**. A setting of **28** must be used when throughputs exceed 57,600 bps and is recommended when data transmission sizes exceed 256 bytes.

Changes to the **HOPTIME** setting may only be made at the Master radio. (This is because the Master radio establishes the hop-time setting for the entire network.) At Remote radios, the hop-time setting may be read when the radio is in synchronization with the Master, but it cannot be changed.

INIT

Initialize; Restore to Factory Defaults

The **INIT** command is used to reset the radio's operating parameters to the factory defaults listed in Table 12 on Page 34. This may be helpful when trying to resolve configuration problems that resulted from the entry of one or more improper command settings. If you are unsure of which command setting caused the problem, this command allows you to get back to a known working state.

NOTE: Caution should be exercised when using the INIT command on radios in a system employing the Store-and-Forward feature. Settings relating to the use of Extension services will be lost and will need to be re-entered. Record the settings for XADDR, XPRI and XMAP before using the INIT command.

SPECIAL

NOTE: Installing firmware of Revision 3.0 or later into a radio with Revisions 1.x firmware will preserve the radio's compatibility with other radios running Revision 1.x firmware. If updating the radio's firmware is part of a system-wide upgrade, the last step should be to use the INIT command at the Master station. Use of the INIT command causes the changes shown in Table 12 to be applied.

Table 12. INIT Command Generated Defaults

| Parameter | Default Setting | Corresponding Command |
|---------------------|------------------------------------|--------------------------|
| For ALL radios | | |
| Alarm Mask | FFFF FFFF | AMASK |
| Alarm Output Sense | RS-232 High (+5.0 Vdc) | ASENSE |
| Device Operation | DCE | DEVICE DCE |
| DATA Interface Port | • 9600 baud | BAUD 9600 8N1 |
| | 8 data bits | |
| | none (no parity) | |
| | • 1 stop bit | |
| Data Port Setting | RS/EIA-232 | PORT RS232 |
| CTS Delay | 0 (CTS is continuously asserted) | CTS 0 |
| CTS Hold-Time | 0 | CTSHOLD 0 |



Table 12. INIT Command Generated Defaults (Continued)

| | | Corresponding |
|------------------------------------|---|---------------|
| Parameter | Default Setting | Command |
| LED Operation | OFF | LED |
| Low-Power Mode Hold | 0 | LPMHOLD |
| RX Time-Out-Timer | None/Disable | RXTOT |
| RF Output Power | 30 dBm (1 watt) | PWR 30 |
| Transmitter Test Frequency | 915.000 MHz or 2436.0 MHz (Model dependent) | TX xxx |
| Receiver Test Frequency | 915.000 MHz 2436.0 MHz (Model-dependent) | RX xxx |
| Sleep Mode | OFF | SLEEP OFF |
| Primary Extension Radio Address | 0 (Master) | XPRI 0 |
| Synchronization Source Map | None | XMAP 0 |
| Extended Address | 0 | XADDR 0 |
| For MASTER radios | | |
| AT Command Support | OFF | AT |
| Buffer Mode | OFF | BUFF OFF |
| Forward Error Correction | ON | FEC ON |
| Hop-Time | 7 ms | HOPTIME 7 |
| Low-Power Mode | 0 (Off) | LPM |
| Skipped Frequencies | None (radio will hop across all frequencies) | SKIP NONE |
| Retry Count | 10 (max. of 10 repeats for ARQ) | RETRY 10 |
| Repeat Count | 3 (downstream repeats) | REPEAT 3 |
| | | |

HREV

Hardware Revision

Shows the hardware revision of the radio.

KEY

Turn On Radio Transmitter Test Signal

Enables the transmitter. (Radio must be in Setup mode.) See also **DKEY** command (**DKEY** *Details*, *page 33*).



LED [ON, OFF]

Enable/Disable PCB LEDs

LED ON enables/disables the PCB board mounted LEDs seen only with the transceiver's covers removed. **LED** is normally **OFF**, it may be useful to have them on for testing the radio with the covers removed. Note: the *external* LEDs will be dimmer if the **LED** function is left **ON**.

The **LED** command also affects the operation of the LEDs in the "Low-Power Mode" (**LPM**). When **LED** is **OFF**, the radio keeps the PWR and SYNC LEDs extinguished.

LPM [1, 0]

Low-Power Mode—Masters Only

This feature trades increased latency to gain power savings. Low-power mode (LPM) automatically saves power at a Remote by instructing the Remote to shutdown for large periods of time in between **SYNC** messages. Master transmissions are automatically blocked while the Remotes are asleep. Note, both Masters and Remotes are adaptive and will suppress a normal sleep interval if data transmission or reception is in progress.

• LPM 1 at the Master enables low-power mode network-wide; all Remotes pick it up and start saving power by automatically sleeping.

LPM 1 can work in conjunction with the AT dialing feature. The dialed unit will be forced awake; all others will sleep.

• LPM 0 at the Master to disable low-power mode (Default setting).

The **SLEEP** command must be enabled for LPM to function. Further, when you enable LPM, the LEDs on the Remote radio dim even though the LPM function is not properly enabled by turning on **SLEEP**. For more information, see "Low-Power Mode (LPM)—Master Enabled" on Page 60, and "Low-Power Mode versus Remote's Sleep Mode" on Page 62.

LPMHOLD [0-1000]

Low-Power Mode Sleep Time

Used to give an RTU time (0-1000 ms) to respond before the radio goes to sleep. Value determines how long to suppress auto-sleep following reception of the last character sent out of the RXD serial data port.

NOTE: Any values entered will be rounded to the nearest multiple of 4 ms.

To verify the exact hold time, enter **LPMHOLD**, the response will give you the value currently being used.

MODE [M, R, X]

Radio Operating Mode

The **MODE** command sets or displays the operating mode of the radio. A Master radio is set by **MODE** M; a Remote set by **MODE** R, and an Extension is set by **MODE** X.



All units default to Remotes; other modes must be specifically programmed with the **MODE** command.

If **MODE X** is used, the **MODE X** radio should be programmed with an Extended Address (**XADDR**). Units that need to hear this **MODE X** radio must be programmed with an appropriate **XPRI** and/or **XMAP** value.

MRSSI [NONE, -40...-90]

Minimum RSSI for Mobile Operation

The MRRSSI command sets or displays the minimum RSSI level (dBm) of a Master station's signal to maintain synchronization. When the Master's signal falls below this level, the Remote will attempt to resynchronize with the next Master it can hear within the same network—same Network Address (ADDR)—and, meets the MRSSI level. See "Mobile Operation Support" on Page 62 for additional information.

OT [ON, OFF]

Output Trigger

The "output trigger" feature sets up a 1-second default delay on delivery of RXD serial data, however, a receipt of RTS causes cancellation of timer followed by immediate data delivery.

Hierarchy Rules:

- if **OT** = ON, RTS always cancels data delay and outputs immediately
- if OT = ON, DEVICE = DCE, and RXD = 0, data delay is 1 second or until RTS
- if **DEVICE** = DCE, and **RXD** = N, data delay is N ms
- if **DEVICE** = CTS KEY, and **CTS** = N, data delay is N ms or until RTS
- if **DEVICE** = CTS KEY overrides **RXD**. **RXD** overrides **OT** default.

OWM [xxxxx]

"Owner's Message"

The **OWM** command sets or displays an optional owner's message, such as the system name. The entry can contain up to 30 characters.

OWN [xxxxx]

"Owner's Name"

The **OWN** command sets or displays an optional owner's name, such as the site name. The entry can contain up to 30 characters.

PORT [RS232, RS485]

Data Interface Port Signaling Standard

Select or identify the current data port (DATA connector) interface signaling mode: RS232 or RS485. This is the port though which the payload data will



pass. Pin descriptions for EIA-232 are on page 69 and EIA-485 can be found on page 71.

PWR [20-30]

Radio Transmitter Power Level

This command displays or sets the desired RF power output of the radio. The **PWR** command parameter is specified in dBm and can be adjusted in 1 dBm steps. The default setting is 30 dBm (1 watt) for the 900 MHz model and 27 dBm (0.5 watt) for the 2400 MHz model. To read the actual (measured) power output of the radio, use the **SHOW PWR** command.

In the USA, maximum allowable power is governed by FCC limits on Effective Isotropic Radiated Power output (EIRP). The EIRP limit of +36 dBm on the 900 and 2400 MHz band, means that any user with a net antenna gain greater than 6 dBi on the 900 MHz band, or 9 dBi on the 2400 MHz band, must decrease the **PWR** setting accordingly. "How Much Output Power Can be Used?" on Page 12 contains a detailed discussion of this topic.

REPEAT [0-10]

Downstream Repeat Transmission Count

The **REPEAT** command affects "downstream" data. The command causes a Master or Extension to always repeat transmissions for the specified number of times (range is 0 to 10; default selection is 3). Unlike the **RETRY** command, there is no acknowledgment that a message has been received.

Use the **REPEAT** command without a value to display the current setting.

RETRY [0-10]

Upstream Repeat Transmission Count

The **RETRY** command affects upstream data. The command selects, or displays, the maximum number of times (0 to 10) that a Remote radio will re-transmit data. The default setting is 10.

This command is associated with ARQ (Automatic Repeat Request) operation of the radio and is intended for use in areas with heavy radio interference.

When the **RETRY** command is issued without parameters, the maximum retransmission count is shown. A value of 0 represents no retries, while values of 1 or greater successively improve the chance of data delivery in spectrally harsh environments (at the expense of possibly increased latency). The **RETRY** value is only setable at the Master. It is readable by a synchronized Remote.

RSSI

Received Signal Strength Indicator

This command displays the radio's Received Signal Strength Indication in dBm (decibels relative to 1 mW). The output can range from –40 dBm to –120 dBm. Command availability and results depend on the mode of operation (Master or Remote). The closer to 0 dBm, the stronger the signal, thus a reading of –70 dBm is stronger than –80 dBm.



For a Remote radio, under normal operation, RSSI is based on the average signal strength of the SYNC message received in each of the eight frequency zones. (RSSI is sampled each time a SYNC message is received.) When using the RSSI reading to align a directional antenna, it is important to make changes slowly so that the RSSI reading will provide meaningful results. It will take several seconds to indicate a change in signal level. The radio stays in RSSI mode until ENTER is pressed.

For a Master radio, under normal operation, entering the RSSI command causes the response **NOT AVAILABLE** to be returned. This is because a Master is normally receiving signals from several Remote stations and an RSSI reading would be continually changing. The only exception is when the **SETUP** command has been asserted. This disables hopping and allows reading a "raw" RSSI signal level in real time from a Master or Remote radio.

NOTE 1: RSSI readings will not accurately indicate signals stronger than -40 dBm.

NOTE 2: RSSI works for Dependent Masters. Command displays "NOT AVAILABLE" if the Dependent Master is not synchronized.

RTU [ON, OFF, 0-80]

Remote Terminal Unit Simulator

This command re-enables or disables the radio's internal RTU simulator, which runs with MDS' proprietary polling programs (poll.exe and rsim.exe). The internal RTU simulator is available whenever a radio has diagnostics enabled. This command also sets the RTU address to which the radio will respond.

The internal RTU can be used for testing system payload data or pseudo bit error rate (BER) testing. It can be helpful in isolating a problem to either the external RTU or the radio. The default RTU setting is **OFF**.

RX [xxxx]

Radio Receive Test Frequency

This command sets or displays the test receive frequency used in place of hopping when the radio is in **SETUP** mode. The test receive frequency can be reprogrammed to any value between 902.200 MHz and 927.800 MHz, inclusive. The factory default setting is 915.000 MHz.

RXD [0-235] / [ON/OFF]

RXD Delay

Used to set a delay, in milliseconds, of RXD data to emulate a seamless mode with much lower latency in applications where retries are not required. Use a delay of twice the value of the **HOPTIME** period (See page 34).

Entering a **RXD ON** (0 ms default) or **RXD XX** will enable the function. Entering **RXD OFF** will disable the function and erase any stored value.



RXTOT [NONE, 0-1440]

Receive Data Timeout-Timer

This command sets or displays the amount of time (in minutes) to wait for the next received data packet before issuing a receiver time-out alarm. The default setting is **NONE**.

SAF [ON, OFF]

Store-and-Forward Services Support

This command enables/disables the operation of the Store-and-Forward services. It can be set only at the network's Master station, but will effect all radios in the associated network. The default setting is OFF. See related commands: "XADDR [0–31]" on Page 44, "XPRI [0–31]" on Page 44, and "XMAP [00000000-FFFFFFFFFF]" on Page 44.

SETUP

Setup Radio Test

This command sets up the transceiver for checking antenna SWR or transmitter power with external measuring equipment. Do not use this mode during normal operation.

When the **SETUP** command is entered, the prompt changes to **SETUP>**, and:

- Hopping is disabled.
- Synthesizer frequencies are reset to the test frequencies specified by the TX and RX commands described earlier.
- The radio can be keyed using the KEY command. DKEY is used to unkey the radio. (If the radio is left in a keyed state it is automatically unkeyed after 10 minutes.)
- The RSSI is sampled in a raw, continuous fashion regardless of whether the unit is a Master or a Remote.

Entering **Q** or **QUIT** returns the system to normal operation.

A timer keeps the Setup mode from accidentally leaving the system disabled. After 10 minutes the system behaves as if **Q** or **QUIT** had been entered, returning the unit to normal operation.

NOTE: TransNET uses a automatic level control in normal operation to keep transmit power constant over time. This facility is disabled in Setup mode. To test 1 Watt power output in Setup mode, the user must enter **PWR 30** followed by **KEY**. The power output will only be valid for the first couple of seconds.

SER

Radio Serial Number

Displays the serial number of the radio.



SHOW CON

Show Virtual Connection Status

Shows virtual connection status established by the latest ATDT command sequence. (Works only with **AT ON**. See "AT [ON, OFF]" on Page 29)

If no connection is established, it displays **NONE**.

If a connection is active, it will display:

<Master unit address> TO <Remote ("dialed") unit address>.

SHOW PWR

Show Measured RF Transmit Power

The **SHOW PWR** command displays the actual (measured) RF power output in dBm. Unlike the **PWR** command, this command shows the actual level being measured, not the programmed RF power setting.

SHOW SYNC

Show Clock-Synchronization Master Network Address

When used at a Remote station, this command will display **Extended Address** and **Unit Address** of the Master or Extension radio to which the Remote is synchronized. The network depth at the Remote, defined as the number of downstream links from the Master, is displayed in parentheses.

SHOW SYNC works for Dependent Masters. A value of zero (0) means the station is a Master synchronized to a Clock-Sync Master. The **SHOW SYNC** command will display an asterisk (*) after depth value if the radio is operating with co-located Masters.

SKIP [NONE, 1...8]

Skip Radio Operating Zones

This command sets or displays which, if any, of the eight zones will be skipped from the radio's hopping sequence. Skipping zones is one way of dealing with constant interference on one or more frequencies in the radio's operating band. See "A Word About Radio Interference" on Page 8 for more information on dealing with interference.

Tables 13, 14, 15 and 16 show the frequency range covered by each zone. The command parameter is either the keyword **NONE** or an undelimited string of up to four digits where each digit 1...8 represents a corresponding zone to skip. (For zone parameter input, the digits can appear in any order and can be optionally separated by a blank space.) The **SKIP** command is display-only at Remote radios. (Remotes must be synchronized with the Master radio to display the skip status.)



In the USA, a maximum of *four* zones may be skipped for TransNET 900 and a maximum of *three* zones may skipped for TransNET 2400. Check the regulatory requirements for your region. The **SKIP** function may not be permitted in your country and the radio will not respond to the **SKIP** command.

Table 13. 900 MHz Frequency Skip Zones

| ZONE 1 | ZONE 2 | ZONE 3 | ZONE 4 | ZONE 5 | ZONE 6 | ZONE 7 | ZONE 8 |
|--------|--------|--------|--------|--------|--------|--------|--------|
| 902.2 | 905.4 | 908.6 | 911.8 | 915.0 | 918.2 | 921.4 | 924.6 |
| to |
| 905.2 | 908.4 | 911.6 | 914.8 | 918.0 | 921.2 | 924.4 | 927.6 |

Table 14. 2400 MHz, Band A, Frequency Skip Zones

| ZONE 1 | ZONE 2 | ZONE 3 | ZONE 4 | ZONE 5 | ZONE 6 | ZONE 7 | ZONE 8 |
|--------|--------|--------|--------|--------|--------|--------|--------|
| 2401.6 | 2404.8 | 2408.0 | 2411.2 | 2414.4 | 2417.6 | 2420.8 | 2424.0 |
| to |
| 2404.6 | 2407.8 | 2411.0 | 2414.2 | 2417. | 2420.6 | 2423.8 | 2427.0 |

Table 15. 2400 MHz, Band B, Frequency Skip Zones

| ZONE 1 | ZONE 2 | ZONE 3 | ZONE 4 | ZONE 5 | ZONE 6 | ZONE 7 | ZONE 8 |
|--------|--------|--------|---------|--------|--------|--------|--------|
| 2427.2 | 2430.4 | 2433.6 | 2436.80 | 2440.0 | 2443.2 | 2446.4 | 2449.6 |
| to | to | to | to | to | to | to | to |
| 2430.2 | 2433.4 | 2436.6 | 2439.8 | 2443.0 | 2446.2 | 2449.4 | 2452.6 |

Table 16. 2400 MHz, Band C, Frequency Skip Zones

| ZONE 1 | ZONE 2 | ZONE 3 | ZONE 4 | ZONE 5 | ZONE 6 | ZONE 7 | ZONE 8 |
|--------|--------|--------|--------|--------|--------|--------|--------|
| 2452.8 | 2456.0 | 2459.2 | 2462.4 | 2465.6 | 2468.8 | 2472.0 | 2475.2 |
| to |
| 2455.8 | 2459.0 | 2462.2 | 2465.4 | 2468.6 | 2471.8 | 2475.0 | 2478.2 |

SLEEP [ON, OFF]

Transceiver Sleep—Remotes Only

This command is used to set or display the radio's Sleep Mode setting. The default setting is **SLEEP OFF**. When this setting is **ON** (enabled) the Low-Power, or RTU-forced Sleep Mode, can be used. This function cannot be turned on for a Master or Extension radio unless the unit is in the Low-Power Mode. See "Using the Radio's Sleep Mode (Remote Units Only)" on Page 59 and "Low-Power Mode versus Remote's Sleep Mode" on Page 62 for more information.

SRFV

Firmware Revision Level

This command displays the version of the firmware currently loaded into the transceiver.



A display of **06-4040A01**, **3.6.1** is an example of the firmware version identifier—part number followed by release/version number.

STAT

Alarm Status

This command is used to check the alarm status of the radio. If no alarms exist, the message **NO ALARMS PRESENT** is returned.

If an alarm does exist, a two-digit alarm code (00–31) is displayed and the event is identified as a "Major" or "Minor" alarm. A brief description of the event is also given.

If more than one alarm exists, the word **MORE** appears, and additional alarms may be viewed by pressing the **ENTER** key. Detailed descriptions of the alarm codes are provided in Table 18 on Page 47.

TEMP

Radio's Internal Temperature

This command displays the internal temperature of the transceiver in degrees Celsius. (Note that the radio is specified to operate in an environment between -30° C and $+60^{\circ}$ C). This internal reading may be higher than the outside temperature by several degrees.

TX [xxxx]

Radio Transmit Test Frequency

This command sets or displays the test transmit frequency used in place of hopping whenever the radio is in Setup mode. The test transmit frequency for the 900 MHz radios can be reprogrammed to any value between 902.200 MHz and 927.800 MHz, inclusive. The factory default setting is 915.000 MHz.

For the 2400 MHz radios, the test frequency can be programmed to any frequency between 2400.6 MHz and 2482.0 MHz. The default value is 2436.0 MHz.

UNIT [10000-65000]

Unit Address

This command sets the unit addressing for network-wide diagnostics and AT-Command address. The unit address is factory programmed to the last four digits of the radio's serial number. If re-programmed in the field, the entry must consist of five digits between 10000 and 65000.



XADDR [0-31]

Extended Address

Used to display or program the Extended Address of this radio that will serve as a common address for the sub-network synchronized to this Master or Extension. This value can be listed in the **XPRI** parameter of associated Extension or Remote radios to allow them to synchronize to this radio. We recommend setting the Master to zero (0). It is easy to remember, and is the default address when the INIT command is used. (Programmed only in Master and Extension radios.)

XMAP [00000000-FFFFFFF]

Map of Extension Addresses

XMAP is a 32-bit hex entry where the least significant bit represents XADDR 0 and the most significant bit represents XADDR 31. The full 32-bit hex value represents the entire list of extensions with which the radio will be allowed to communicate. (Pertains to Remotes and Extensions only.)

This parameter is easily programmed through the MDS TransNET Configuration Software's Store-and-Forward Settings panel.

XPRI [0-31]

Primary Extended Address

Will display or program the extended address of the primary radio with which this radio will attempt to synchronize and communicate. A setting of **NONE** allows the unit to synchronize with any Master or Extension in the **XMAP** list. (Parameter only meaningful for Remote or Extension units.)

XRSSI [NONE, -40...-120]

Extension RSSI Level

The **XRSSI** command is used to set the RSSI minimum signal level required to preserve synchronization with a non-primary Extension radio. This parameter will be ignored if **XPRI** is set to **NONE**.

ZONE CLEAR

Clear Zone Statistics Log

The **ZONE CLEAR** command clears the zone data for *all* zones in the Zone Data Log, resetting the count to 0. (Zone data is also cleared automatically upon reboot.)

ZONE DATA

Read Zone Statistics Log

The transceiver divides its frequency operating spectrum into eight 3.0 MHz-wide zones or sub-bands. (These are the same zones referenced by the **SKIP** command described earlier.) Data frame statistics are maintained for each zone to indicate the transmission quality of data through the network. This information is useful for identifying zones where significant interference exists.



Historical information on the quality of each zone can be accessed using the **ZONE DATA** command. The report shows you the number of data frames sent, the number received, and the number received with errors. If an excessive number of errors are seen in one or more frequency zones, it may indicate interference, and you should consider "skipping" those zones using the **SKIP** command (See "SKIP [NONE, 1...8]" on Page 41).

Note: If a frequency zone has been skipped, all counts for that zone will be zeros.

The **ZONE DATA** format is displayed as follows:

All data is based on payload packets. Incoming network data may be divided into multiple packets for over-the-air transfers. The number before the colon represents the zone. **TX TOTAL** is the transmit packet total. **RX TOTAL** is the receive packet total. **RX ERROR** is the total number of received packets with CRC errors. All zone data is reset with the **ZONE CLEAR** command.

7.0 TROUBLESHOOTING

Successful troubleshooting of an MDS transceiver system is not difficult, but requires a logical approach. It is best to begin troubleshooting at the Master station, as the rest of the system depends on the Master for polling instructions and synchronization data. If the Master station has problems, the operation of the entire network will be affected.

When communication problems are found, it is good practice to begin by checking the basics. All radios in the network must meet these basic requirements:

- Adequate and stable primary power
- An efficient and properly aligned antenna system
- Secure connections (RF, data & power)
- Proper programming of the radio's operating parameters, especially Operating Mode (MODE), Network Address (ADDR), and interface Baud Rate (BAUD). For TransNET 2400 check the sub-band (BAND).
- The correct interface between the radio and the connected data equipment (proper cable wiring, data format and timing).
- In store-and-forward systems there are several areas that should be checked or evaluated:
 - Look for duplicate XADDR values on MODE M and MODE X radios.
 Duplicates will cause failures unless the radios are too far apart to hear each other.



- Check for errors in the synchronization qualifiers, XPRI and XMAP, on corresponding Remote radios.
- Verify **SAF** is enabled at the Master radio.

7.1 LED Indicators

The LED status indicators are an important troubleshooting tool and should be checked whenever a problem is suspected. Table 17 describes the function of each status LED.

Table 17. LED indicator descriptions



| Name | Description |
|------|---|
| PWR | Continuous—Power is applied to the radio; no problems detected Flashing (5 times-per-second)—Fault indication. See "TROUBLE-SHOOTING" on Page 45. Off—Radio is unpowered or in Sleep mode |
| SYNC | Continuous—Radio is receiving/sending synchronization frames On within 10 seconds of power-up under normal conditions |
| TXD | Transmit data activity on the DB-9 DATA interface connector |
| RXD | Receive data activity on the DB-9 DATA interface connector |

7.2 Alarm Codes

When an alarm condition exists, the transceiver creates an alarm code. These codes can be very helpful in resolving many system difficulties.

Checking for Alarms—STAT command

To check for the presence of alarms, enter **STAT**. If no alarms exist, the message **NO ALARMS PRESENT** appears at the top of the display.

If an alarm does exist, a two-digit alarm code (00–31) is displayed, and it is identified as a major or minor alarm. A brief description of the alarm is also given. Alarm codes and their meanings are listed in Table 18.

If more than one alarm exists, the word **MORE** appears at the bottom of the screen; additional alarms can be viewed by pressing **ENTER**.

Major Alarms versus Minor Alarms

Major alarms report serious conditions that generally indicate a hardware failure, or other abnormal condition that will prevent (or seriously hamper) further operation of the transceiver.



With the exception of alarm code 00 (network address not programmed), major alarms generally indicate the need for factory repair. Contact MDS for further assistance.

Minor alarms report conditions which, under most circumstances, will not prevent transceiver operation. This includes out-of-tolerance conditions, baud rate mismatches, etc. The cause of these alarms should be investigated and corrected to prevent system failure.

Alarm Code Definitions

Table 18 contains a listing of all event codes that may be reported by the transceiver. Additional alarm codes may be used in future firmware releases or are used by the factory.

Table 18. Alarm Codes

| Alarm Code | Alarm Type | Description |
|---------------|---------------|---|
| Coue | Type | Description |
| 00 | Major | The network address is not programmed. |
| 01 | Major | Improper firmware detected for this radio model. |
| 04 | Major | One or more of the programmable synthesizer loops is reporting an out-of-lock condition. |
| 08 | Major | The system is reporting that it has not been calibrated. Factory calibration is required for proper radio operation. |
| 10 | Major | The DSP was unable to properly program the system to the appropriate defaults. A hardware problem may exist. |
| 12 | Major | Receiver time-out alarm. |
| 16 | Minor | The unit address is not programmed. |
| 17 | Minor | A data parity fault has been detected on the DATA connector. This usually indicates a parity setting mismatch between the radio and the RTU. |
| 18 | Minor | A data framing error has been detected on the DATA connector. This may indicate a baud rate mismatch between the radio and the RTU. |
| 29 | Minor | RF output power fault detected. (Power differs by more than 2 dB from set level.) Often caused by high antenna system SWR. Check antenna, feedline and connectors. |
| 30 | Minor | The system is reporting an RSSI reading below –105 dBm. |
| 31 | Minor | The transceiver's internal temperature is approaching an out-of-tolerance condition. If the temperature drifts outside of the recommended operating range and the transceiver may fail. |



7.3 Troubleshooting Chart

Table 19 provides suggestions for resolving system difficulties that may be experienced in the radio system. If problems persist, contact the factory for further assistance. Refer to the inside back cover of this guide for contact information.

Table 19. Troubleshooting Guide

| Difficulty | Recommended System Checks |
|---|--|
| Unit is inoperative. | a. Check for the proper supply voltage at the power connector. |
| moperative. | b. The transceiver's internal fuse may have opened. Refer to Section 7.5 below for replacement instructions. |
| Interference is suspected. | a. Verify that the system has a unique network address. Nearby systems with the same address will cause interference. |
| | b. Check for interference by locking out affected zone(s) using the SKIP command (Page 41). |
| | c. If omnidirectional antennas are used on Remote stations, consider changing to directional antennas. This will often limit interference to and from other stations. |
| No synchroniza- tion with Master, | a. Check for secure interface connections at the radio and the connected device. |
| or poor overall performance. | b. Check the antenna, feedline and connectors. Reflected power should be less than 10% of the forward power reading (SWR ≈ 2:1 or lower). |
| | c. If the Remote radio is in synchronization, but performance is poor, check the received signal strength using the RSSI com- mand (Page 38). If RSSI is low, it may indicate antenna prob- lems, or misalignment of directional antenna headings. |
| | d. Verify proper programming of system parameters: mode, network address, data interface baud rate, transmitter power, CTS delay, etc. For store-and-forward applications, also verify the following: SAF is ON; extended address is properly programmed at each extension; Remotes are using the proper values for XPRI and XMAP. |
| | e.Check for alarms using the STAT command (Page 43) |
| BER is too high. Data throughput is spotty. | a. The RETRY and REPEAT commands may be increased to deal with interference, or decreased to increase throughput and reduce latency. |
| | b.Try turning on FEC. FEC on gives some coding gain, but comes at the cost of reduced throughput. |
| Latency is too | a. Reduce the REPEAT count. |
| high. | b.Turn BUFF OFF . BUFF ON ensures that no gaps occur in the data, but this comes at the cost of increased latency. |
| | c. Make sure HOPTIME is set to 7. |
| | |



7.4 Performing Network-Wide Remote Diagnostics

Diagnostics data from a Remote radio can be obtained by connecting a laptop or personal computer running *MDS InSite* diagnostics software (Version 6.6 or later) to any radio in the network.

NOTE: The diagnostics feature may not be available in all radios. The ability to query and configure a radio via Network-wide Diagnostics is based on the feature options purchased in the radio being polled.

If a PC is connected to any radio in the network, intrusive polling (polling which briefly interrupts payload data transmission) can be performed. To perform diagnostics without interrupting payload data transmission, connect the PC to a radio defined as the "root" radio. A radio is defined as a root radio using the **DTYPE ROOT** command locally, at the radio.

A complete explanation of Remote diagnostics can be found in MDS' *Network-Wide Diagnostics System Handbook* (MDS P/N 05-3467A01).

Table 20. Network-Wide Diagnostics Commands

| Command | Description |
|---------------------------------------|---|
| DLINK [xxxxx/ON/OFF] Details, page 32 | Set baud rate of diagnostics link |
| DTYPE [NODE/ROOT] Details, page 33 | Set radio's operational characteristics for net- work-wide diagnostics |

- Program one radio in the network as the root radio by entering the DTYPE ROOT command at the radio.
- 2. At the root radio, use the **DLINK ON** and **DLINK [***baud rate***]** commands to configure the diagnostic link protocol on the RJ-11 port.
- 3. Program all other radios in the network as nodes by entering the **DTYPE NODE** command at each radio.
- 4. Use the **DLINK ON** and **DLINK** [baud rate] commands to configure the diagnostic link protocol on the RJ-11 port of each node radio.
- 5. Connect a PC on which *MDS InSite* software is installed to the root radio, or to one of the nodes, at the radio's diagnostics port.
 - To connect a PC to the radio's DIAG port, an RJ-11 to DB-9 adapter (MDS P/N 03-3246A01) is required. If desired, an adapter cable may be constructed from scratch, using the information shown in Figure 21 on Page 69.
- 6. Launch the MDS InSite application at the PC. (Refer to the InSite user's manual for details.)



7.5 Internal Fuse Replacement

The radio is protected by an internal fuse. This fuse can be blown by an over-voltage transient or an internal failure. Follow the procedure below to remove and replace the fuse:

- 1. Disconnect the primary power cable and all other connections to the unit.
- 2. Place the radio on its back and remove the four Phillips screws at the corners of the bottom cover.
- 3. Carefully separate the top and bottom covers. There is a flat ribbon cable between the top cover's LED panel and the motherboard. You do *not* need to disconnect the ribbon cable.
- 4. Locate the fuse holder assembly behind the power connector. (See Figure 16).
- 5. Loosen the fuse from the holder using a very small flat-bladed screwdriver, then use a small pair of needle-nose pliers to pull the fuse straight up and out of the holder.
- 6. Use an ohmmeter or other continuity tester to verify that the fuse is blown.
- 7. Install a new fuse by reversing the process. Replacement fuse: Littelfuse #0454002; 452 Series, 2 Amp SMF Slo-Blo fuse (MDS Part No. 29-1784A03).
- 8. Re-install the covers, interface cables and check the radio for proper operation.



Figure 16. Internal Fuse and Holder Assembly Location



8.0 RADIO FIRMWARE UPGRADES

From time to time, Microwave Data Systems releases new firmware for its radio products. This file can be installed in existing radios to take advantage of engineering improvements or additional features.

8.1 Obtaining New Firmware

The latest firmware for each radio type may be obtained free from our Web site at:

www.MicrowaveData.com

Registration is required to access the downloads area of the MDS Web site.

Firmware is also available on disks from MDS that are bundled with an installation utility (MDS Radio Software Upgrade (upgrade.exe)) for transferring the firmware file on the disk to the radio.

Saving a Web-Site Firmware File Onto Your PC

MDS firmware upgrades are distributed as a plain-text (ASCII) file with a ".S28" extension. Browse the MDS Web site to find the desired ".S28" file for your radio. When you have found your selection, use the right mouse button to select a path on your computer on which to save the file. (If this isn't done, your browser may display the firmware file contents as text on the screen instead of downloading it to your local hard drive.)

After the ".S28" file has been saved to your computer, you may use either MDS TransNET Configuration Software or MDS Radio Software Upgrade programs to install this firmware in your radios.

8.2 Installing Firmware Into Your Radio

- 1. Connect the PC to the radio's DIAG port using an RJ-11 to DB-9 Adapter Cable (MDS Part No. 03-3246A01). If desired, a cable can be fabricated from the information shown in Figure 21 on Page 69.
- 2. Start the *MDS TransNET Configuration Software*. Open diagnostics port to the radio. The program will automatically read the radio's profile.
- 3. From the File menu, select Radio Firmware Upgrade and follow the prompts to install the new firmware into the radio. Do not press the Cancel button once the installation has started or it will leave the radio without any code. When the installation is complete, another radio may be connected to your PC and programmed.

NOTE: If a firmware installation fails, the radio is left unprogrammed and inoperative. This is indicated by the PWR LED flashing slowly (1 second on/1 second off). This condition is only likely to occur if there is a power failure to the computer or radio during the installation process. The installation should be attempted again.



9.0 OPERATING PRINCIPLES AND CONFIGURATION

9.1 SAF Operation with Extension Radios

The Store-and-Forward (SAF) capability operates by dividing a network into a vertical hierarchy of two or more sub-networks. (See Figure 5 on Page 4.) Adjacent sub-networks are connected via Extension radios operating in "**MODE X**" which move data from one sub-network to the next one.

The Store-and-Forward implementation adheres to the general polling principles used in most multiple-address systems (MAS). Polls originate from the Master station, broadcast to *all* radios within the network, and travel hierarchically downward. All Remotes will hear the same message, but only one Remote will respond. Messages within a hierarchy only travel in one direction at a time.

Using SAF will cut the overall data throughput in half, however, multiple networks can be inter-connected with no additional loss in network throughput.

Simple Extended SAF Network

The following example depicts a two-level network utilizing a single Master (M) and an Extension (X) radio. See Figure 17.




Figure 17. Simple Extended SAF Network
Networks: J and K

In this network, messages directed to Remotes in the "K" sub-network, will be relayed through Extension radio $X_{j,k}$ to the K-Remotes. Any response from a Remote in sub-network "K" will pass back through Extension radio $X_{j,k}$ to the Master M_j . Radios in sub-network "J" operate on the same set of frequencies and sub-network "K" but with a different radio-frequency hopping pattern.

In the SAF operation, the Extension radios are set to **MODE X** (*Details Page 36*) and operate with a "dual personality"—50% of the time it serves as a Remote station and 50% of the time as a Master for sub-network Remotes.



Extended SAF Network

Below is an example of a multilevel network utilizing two repeaters— $X_{J,K}$ and $X_{K,L}$. The example demonstrates the extensibility of the network. In this case, messages directed to Remotes in the sub-network L will be relayed through Extension radios $X_{J,K}$ and $X_{K,L}$. Like the previous example, the Extension radios will split their operating time equally between their Master and Remote "personalities." This multi-layered network can be extended indefinitely without degradation in throughput, beyond that initially incurred by placing the network in the SAF mode.




Figure 18. Extended SAF Network
Networks: J, K, L

Retransmission and ARQ Operation

Functionally, the sub-network side of an Extension behaves like a corresponding connection between a Master and a Remote.

When an Extension is using its "Master personality" it sends acknowledgments and performs unconditional retransmissions based on its **REPEAT** count.

When an Extension is using its "Remote personality," acknowledgments are processed and retransmissions occur as needed, up to the number of times specified by the **RETRY** count value.

If data arrives from a new source prior to completion of retransmissions, it is considered to be a violation of the polling model protocol. The new data takes precedence over the old data, and the old data is lost. In such a situation, new data is likely to be corrupted as it will have some old data mixed in with it.

SAF Configuration Example

Here is an outline for the configuration of a simple store-and-forward link.



- Mode X and M Radios—Can have direct reports (Mode R radios) outside of the chain.
- Data (Payload)—Travels from Master to Remote, and back from Remote to Master.
- 3. **Mode X and R Radios**—Extension links can be protected by mapping one or more fall-back paths in case of a failure. Add secondary extension addresses (XADDR) into the **XMAP** table. (See "*XMAP* [00000000-FFFFFFFF]" on Page 44.)

For example, as shown in Figure 19, Remote "D" could use Remote "C" as its extension primary, and Remote "B" (X ADDR = 1) as an alternative in case of a failure of Remote "C" (X ADDR = 2). This arrangement assumes a serviceable path between Remotes "D" and "B", and requires Remote "D" to be programmed with XMAP = 2 to correspond with the XADDR address of Remote "B."




Figure 19. SAF Configuration Example

This configuration is easily arranged through the use of the Extension Map in the MDS TransNET Configuration Software's "Store-and-Forward Settings."

9.2 Synchronizing Network Units

The Master controls the synchronization for a given network for all modes. Setting the Master to **SAF ON** broadcasts a command from the Master to all radio units in the associated network either directly or through an Extension radio. This command puts *all radios in the entire system* in a special time-division duplexing mode that alternates between two timeslots. One time slot for data communications upstream and the second for downstream communications.

The Extensions are single radios which serve as bridges between adjacent sub-network levels. Extensions will undertake a "Remote personality" in one timeslot, and a "Master personality" in the alternate timeslot and provide communications with associated Remotes downstream. Extensions behave like two radios with their data ports tied together, first synchronizing with their upstream Master during their Remote personality period, and then providing synchronization signals to dependent Remotes downstream during its Master personality period.



All Remotes synchronize to a corresponding Master. This can be the "real Master" (the **MODE M** unit), or it can be a repeater "Extension" that derives synchronization from the "real Master."

Payload polls/packets broadcast from the network Master will be repeated to all levels of the network, either directly to Remotes, or through network repeaters—the Extension station. The targeted Remote responds to the poll following the same path back to the Master.

Synchronization Messages

Remotes acquire synchronization and configuration information via **SYNC** messages. They can synchronize to the Master (the **MODE M** unit) or to any valid Extension (a **MODE X** unit).

The Master will always transmit **SYNC** messages. An Extension will only start sending **SYNC** messages after synchronization is achieved with its Master.

The ability to synchronize to a given radio is further qualified by the sender's Extended Address (**XADDR**) and by the receiver's Synchronization Qualifiers (**XMAP, XPRI**, and **XRSSI**).

When a primary is specified (**XPRI** is 0...31), a radio will always attempt to find the primary first. If 30 seconds elapses and the primary is not found, then the radio attempts to synchronize with any non-primary radio in the **XMAP** list.

Once every 30 minutes, if a primary is defined, the radio will check its synchronization source. If the radio is synchronized to a unit other than the primary, then the current RSSI value is compared to the XRSSI value. If RSSI is less than XRSSI (or if XRSSI is NONE) the radio will force a loss-of-synchronization, and hunt for the primary again (as described in the previous paragraph).

By default, Extensions (and the Master) begin with **XADDR 0**. Synchronization qualifiers are set to **XMAP 0**, **XPRI 0**, and **XRSSI NONE**, respectively. This default configuration allows any radio to hear the Master. When an Extension is added, *the extended address of the Extension radio must be set to a unique value*. All Remotes that need to hear that extension can specify this either by designating the extension as the primary (**XPRI**), or by including it in their list of valid synchronization sources (**XMAP**).

9.3 Using AT Commands

A TransNET network may be configured to support protocols employing Hayes-Compatible modem commands through the radio's AT Mode. In this mode, TransNET units can provide a communications replacement for dial-up modems where the RTUs and the protocol do not contain addressability, and the establishment of a direct-communications link is the only way to determine if the RTU has data ready to be sent. This requirement is common in many older SCADA systems which were developed for direct



connections where wire lines were the only communications link available at the time. Most of these older system implemented support for the AT commands needed in the host software, so TransNET units can be used without software modifications.

In this mode, the Master's DATA port is parsed for a subset of AT commands. (See *Supported Commands* below). When an **ATDTxxxxx** data sequence is detected, and **xxxxx** is a unit address of a radio in the network, the TransNET Master will establish a virtual link to that unit. It will remain in that state until either another **ATDTxxxxx** or **ATH** (hang-up/disconnect) is detected. (Note: Unaddressed Remotes in the network will not respond to user data. Data will only be exchanged between the equipment connected to the addressed Remote unit and the network or device connected to the Master's **DATA** port.

In order to use this mode, the command **AT ON** must be selected at the Master Radio. The acknowledgment to an ATDT command is simulated by the Master; there is no true verification that the far-end connection is valid.

Please consider the following additional information before using the AT commands:

- Radio commands and AT commands are independent with unique syntax and functional objectives.
- ATDT is not a radio command; it is part of the payload data input and follows the syntax for Hayes-compatible modems.
- TransNET commands are entered through the RJ11 DIAGNOSTIC port on Master and Remote radios. AT ON and UNIT are examples of TransNET commands.
- AT commands are only entered through the Master's DB-9 DATA port, and only when the TransNET command AT ON has been previously issued. The radio supports a *subset* of the Hayes-compatible modem AT set. Each command is *entered without spaces*, and always begins with AT, and *ends with a carriage return key press*.

Supported AT Commands

Supported modem commands on the payload port are:

AT <attention>

Replies with **OK** (Code 0).

ATDT[xxxxx] <dial>

The command **xxxxx** represents 5-digit unit address with a leading zero (0) if applicable. This command replies with **CONNECT** (Code 1). Once connected, all characters are passed through until a **+++** is seen.

ATH <hang up> or +++

This command replies with **OK** (Code 0) and deletes any virtual connection to the currently addressed Remote station.

ATV[x] <change verbosity>

x = 0, means use numeric messages

x = 1, means use text messages (Default)

Replies with **OK** (Code 0)



AT <command errors>

Replies with **ERROR** (Code 4)

Characters with <no AT command>

Modem will echo characters in data stream but will be ignored until a second "AT" is seen at which time the modem closes the virtual connection.

Operation Notes When AT Commands are ON

- Radios will not poll with the embedded RTU simulator unless a connection is established.
- Network-wide diagnostics are unaffected by the dialed unit connection status
- The use of the TransNET **OT** command (Output Trigger) can be of benefit in some configurations. See "OT [ON, OFF]" on Page 37 for configuration details.

9.4 Configuration Parameters for Store-and-Forward Services

The installation and configuration of a radio network with an Extension using SAF is straightforward with only a few unique parameters that need to be considered and set at each unit.

In every network there can be only one Master station. It will serve as the sole gateway to the outside world. The following three tables detail the parameters that will need to be set on each type of radio in the network.

- Network Master Radio—Table 21 on Page 57
- Extension Radio(s)—Table 22 on Page 58
- Remote Radio(s)—Table 23 on Page 59

Table 21. Configuration Parameters for SAF Services

Network Master Radio

| Parameter | Command | Description |
|-----------------|---------------------------|--|
| Operating Mode | MODE M Details Page 36 | Sets the radio to serve as a Master. |
| Network Address | ADDR Details Page 29 | A number between 1 and 65,000 that will serve as a common network address. All radios in the network use the same number. |



Table 21. Configuration Parameters for SAF Services
Network Master Radio (Continued)

| Parameter | Command | Description |
|---------------------------|---------------------------|---|
| Extended Address | XADDR Details Page 44 | A number between 0 and 31 that will serve as a common address for radios that synchronize directly to this Master. Typically, the Master is set to zero (0). |
| Store-and-Forward Mode | SAF ON Details Page 40 | Enables store-and-for- ward capability in the net- work. |

Table 22. Configuration Parameters for SAF Services Extension Radio(s)

| Parameter | Command | Description |
|--|---------------------------|---|
| Operating Mode | MODE X Details Page 36 | Sets the radio to serve as an Extension. |
| Network Address | ADDR Details Page 29 | A number between 1 and 65,000 that will serve as a common network address. All radios in the network use the same number. |
| Extended Address | XADDR Details Page 44 | A number between 0 and 31 that will serve as a common address for radios that synchronize directly to this Extension radio serving as Master for associated sub-network units. Zero (0) is recommended for the Master station. |
| Primary Extended Address | XPRI Details Page 44 | XADDR number of the pri- mary or preferred radio with which this radio will synchro- nize. |
| Extension Map | XMAP Details Page 44 | Lists all XADDR values with which this radio can synchronize, excluding the XPRI address. |
| Extension Received Signal Strength Indicator | XRSSI Details Page 44 | The minimum RSSI level required to preserve synchronization with a non-primary radio. (Ineffective when XPRI is NONE) |



Table 23. Configuration Parameters for SAF Services Remote Radio(s)

| Parameter | Command | Description |
|--|---------------------------|---|
| Operating Mode | MODE R Details Page 36 | Sets the radio to serve as a Remote station. |
| Network Address | ADDR Details Page 29 | A number between 1 and 65,000 that will serve as a common network address or name. |
| | | Same number for all units in the same network. |
| Primary Extended Address | XPRI Details Page 44 | XADDR number of the primary or preferred radio with which this radio will synchronize. |
| Extension Map | XMAP Details Page 44 | Lists all XADDR val- ues with which this ra- dio can synchronize, excluding the XPRI address. |
| Extension Received Signal Strength Indicator | XRSSI Details Page 44 | The minimum RSSI level required to preserve synchronization with a non-primary radio. (Ineffective when XPRI is NONE) |

9.5 Using the Radio's Sleep Mode (Remote Units Only)

In some installations, such as at solar-powered sites, it may be necessary to keep Remote transceivers' power consumption to an absolute minimum. This can be accomplished using the radio's Sleep Mode feature. Power consumption in the sleep mode will be less at higher voltages and more at lower voltages. Power in the Sleep Mode at 13.6 Vdc is approximately 3 mA.

Sleep Mode can be enabled under RTU control by asserting a ground (or EIA/RS-232 low) on Pin 4 of the radio's DATA connector. All normal functions are suspended until it is awakened. The radio stays in Sleep Mode until a built-in five-minute timer "awakens" it for resynchronization, or the low is removed from Pin 4.

When Pin 4 is opened (or an EIA/RS-232 high is asserted), the radio will be ready to receive data within 75 milliseconds or less. The radio can be awakened more often if desired, by your RTU.

NOTE: The **SLEEP** function must be set to **ON**; without this, a ground on Pin 4 will be ignored.



It is important to note that power consumption will increase somewhat as communication from the Master station degrades. This is because the radio will spend a greater period of time "awake" looking for synchronization messages from the Master radio.

In order for the radio to be controlled by Pin 4, the unit's Sleep Mode must be enabled through the **SLEEP [ON, OFF]** command. See "SLEEP [ON, OFF]" on Page 42 for more information.

NOTE: If INTRUSIVE polling is used in the MDS' InSite NMS software, it is necessary to select SLEEP MODE INHIBIT ON from the Polling Options menu, on the Network Wide Diagnostic Polling screen.

Sleep Mode Example

The following example describes Sleep Mode implementation in a typical system. Using this information, you should be able to configure a system that meets your own particular needs.

Suppose you need communications to each Remote site only once per hour. Program the RTU to raise an EIA/RS-232 line once each hour (DTR for example) and wait for a poll and response before lowering it again. Connect this line to Pin 4 of the radio's DATA connector. This will allow each RTU to be polled once per hour, with a dramatic reduction in power consumption.

9.6 Low-Power Mode (LPM)—Master Enabled

The Low-Power Mode (LPM) puts Remote radios into a configuration similar to Sleep, but with some important distinctions. The most important difference is the radio will automatically go to sleep in this mode, regardless of the condition of Pin 4 of the DATA interface connector.

This feature trades increased latency to gain power savings. The low-power mode (LPM) automatically saves power at a Remote by instructing the Remote to shutdown for long periods of time between SYNC messages. Master transmissions are automatically blocked while the Remotes are asleep. Note, both Masters and Remotes are adaptive and will suppress a normal sleep interval until after the end of a current data transmission or reception.

Setup Commands

These are the command options and their applications:

- LPM 1 at the Master enables low-power mode network-wide; all Remotes pick it up and start saving power by automatically sleeping.
 - **LPM 1** can work in conjunction with the AT dialing feature. The dialed unit will be forced awake; all others will sleep.
- **LPM 0** at the Master is used to disable low-power mode (LPM) (Default setting following an **INIT** or firmware upgrade.)

For **LPMHOLD 0** with **REPEAT 0** setting, a Remote with no data to send will consume about 1/4 of its normal power consumption. Note that the **SLEEP** command must be enabled for the LPM to function.



Reading RSSI and Other Parameters with LPM Enabled

It may be desired to perform tests and review operational settings of a Remote radio which has been programmed to operate in the low-power mode. Follow the abbreviated procedure below to interact with the radio through a local computer.

- Disconnect the Remote's antenna to force it to lose sync with the Master
- Power-down the radio
- Connect a computer running TransNET configuration software to the Remote's DIAG(nostic) port.
- · Power-up the radio
- · Reconnect the antenna
- Measure the RSSI or review and change any parameters you desire

Power Consumption Influence by HOPTIME and SAF Settings

Table 24 presents representative current consumption and data delay values for various settings of TransNET radios setup for Low Power Mode, LPM (See "LPM [1, 0]" on Page 36). It assumes the primary power voltage is 13.8 Vdc and the polling rate is minimized to yield best-case power consumption (current) values.

The more each RTU is polled and asked to transmit, the more current will be consumed. Therefore, these values are the lowest that can be expected. Power consumption (current) is inversely related to data delay as shown in the table. When a radio is sleeping (LPM) mode, it is also waiting longer to deliver the payload data.

Table 24. Power Consumption *versus* Hoptime and SAF Settings

| HOPTIME | SAF | Current (ma) | Data Delay |
|---------|-----|--------------|------------|
| 7 | OFF | 16 | 350 ms |
| 7 | ON | 10 | 780 ms |
| 28 | OFF | 7 | 1620 ms |
| 28 | ON | 4 | 3360 ms |

Note, the Store-and-Forward setting has a significant effect on power consumption, as it effectively doubles the HOPTIME to support LPM services. For the most power-efficient operation, turn on **SAF** even if you are not using repeaters.



9.7 Low-Power Mode versus Remote's Sleep Mode

The Low-Power Mode (LPM) puts Remote radios into an operational configuration similar to Sleep, but there are some important differences. Below is a comparison of the two modes.

Table 25. Power-Conservation Modes Comparison

| | Sleep Mode | Low-Power Mode | | | |
|----------|--|---|--|--|--|
| Features | Manual control by connected equipment Selective application of Sleep control User determines length and frequency of sleep periods | Automatic radio-controlled timing Automatic sleep during absence of directed traffic Network-wide implementation through Master station | | | |
| Benefits | Low latency Low standby power, ≤ 3 mA at 13.6 Vdc Greatest potential for power savings | Less complicated implementationSimple configuration | | | |

9.8 Mobile Operation Support

Introduction

Reliable mobile operation of Remotes is practical in areas covered by multiple Master Stations within the same network—Master stations with the same Network Address (ADDR). To make this type of service practical, the Remote must have several reliable Master stations with which to communicate

A "reliable" Master is defined as one, which consistently matches, or exceeds, the Remote's standard for Minimum RSSI (MRSSI).

Initially, the Remote will favor Masters with signal strengths 10 dB greater than the MRSSI threshold. This will allows for some signal degradation of the new Master as the Remote travels.

When the average signal level from the currently-associated Master falls below the user-defined **MRSSI** level, the Remote will become out-of-sync and seek an alternate Master with a reliable signal.



Operational Influences—Hoptime & SAF

The synchronization period is influenced by two parameters' values—**HOPTIME** and **SAF** (Store-and-Forward). Table 26 shows several configurations and the associated synchronization period value.

Table 26. Synchronization Period versus Hoptime and SAF Settings

| Sync Period | Hoptime Value | SAF | | |
|-------------|---------------|-----|--|--|
| 441 ms | 7 | OFF | | |
| 1.8 sec | 28 | OFF | | |
| 3.5 sec | 28 | ON | | |

9.9 MIRRORED BITS™ Protocol Support

TransNET radios are compatible with Schweitzer's Mirrored Bits MB8 protocol, provided complementary firmware (06-4045A01) is installed in *all* network radios. A detailed application guide (AG2003-07) is available from Schweitzer Engineering Labs Web site, www.SELinc.com/aglist.htm, or from Microwave Data Systems' Web site at www.microwavedata.com.

9.10 Seamless Mode Emulation

The **RXD** command *assumes* the payload message will be ready for transmission after the delay period has expired. If there is a chance the payload data may be delayed, it is recommended to use the **BUFF**(er) command to make sure the entire message is received before delivery is started. The **BUFF** command provides a highly-reliable seamless operating mode, but can be very slow to start, especially if it waits for the reception of long messages before passing on the message.

9.11 Full-Duplex Emulation

If your system design needs to support PTP or Point-to-Multipoint applications and your communications must appear to be full-duplex to the connected devices, set the Master to **CSADDR xxxxx** (where **xxxxx** is the Network Address (**ADDR**). This will place the system in a time-division duplex mode (TDD). The radio system will appear to be full-duplex to the connected devices, but actually operates half-duplex over the radio link. Data is buffered by the transmitting side until it is its turn to transmit. Throughput will be approximately 1/2 of the DATA interface rate.

9.12 Co-Located and Close-Proximity Masters

If your requirements call for multiple TransNET networks at the same location, you need to ensure that interference between the systems in minimized to prevent overload that will diminish the performance of the radios. Traditionally, vertical separation of the antennas of co-located radios was required



in order to reduce the interference to the point where overload of one network by the other will not occur. The **CSADDR** command will provide relief from this antenna separation requirement by operating the networks in a TDD mode and ensuring that one Master cannot transmit while the other (or multiple others) are trying to receive a signal from a distant radio.

Master Station Configuration

On all Masters for which you wish to synchronize transmissions, establish one Master as the "Clock-Sync Master by setting its **CSADDR** value to it own Network Address (**ADDR xxxxx**). Then, set all other dependent Masters **CSADDR** values to the Network Address (**ADDR**) of the Clock-Sync Master. Make sure that you use a different Network Address (**ADDR**) for each Master. This value will be used to identify all units associated with this Master's network.

Note that all Masters must be set to the same **CSADDR** setting, but only one where the **CSADDR** matches its own **ADDR**; this is the Clock-Sync Master.

CSADDR = ADDR—Unit serving as a Clock-Sync Master

CSADDR ≠ **ADDR**—Unit serves as a Dependent Master (Clock Slave)

CSADDR = NONE—Co-located Master feature disabled (default)

HOPTIME, **FEC** and **SAF** values are provided by the Clock-Sync Master to all dependent units.

NOTE: If a Dependent Master station is unable to find the Clock-Sync Master station, it will not be able to operate properly and the associated network will be out-of-service.

Antenna System for Co-Located Master Stations

Using this TDD (Clock-Sync) mode will prevent any two Masters from transmitting at the same time and greatly reduce the antenna separation requirements to near zero. Under this arrangement, the antennas of co-located Masters may be placed a few feet (less than a meter) apart horizontally, or just above or below vertically with no ill effects. There are two common antenna system arrangements:

Sharing a Common Antenna System

It is possible to share an antenna between multiple Masters using standard power dividers, as long as the extra loss associated with these devices is taken into account in your RF budgeting process. Masters in this configuration must be operating with Clock-Sync (CSADDR) enabled.

For example, the two Master stations shown in Figure 20 are connected to a common antenna system. They use a power-divider that will result in a signal loss of 3 dB, or one-half power level, on both transmit and receive signals.

The power divider, such as a Mini-Circuits ZAPD-1 or similar product, must be capable of handling 1 Watt and have >25 dB isolation between TX ports.






Figure 20. Co-Located Masters Sharing an Antenna

9.13 Security

Today, the operation and management of an enterprise is becoming increasing dependent on electronic information flow. An accompanying concern becomes the security of the communication infrastructure and the security of the data itself. MDS takes this matter seriously, and provides several means for protecting the data carried over its wireless products.

The radio addresses this issue primarily through the use of the following items:

- 1. **A proprietary modem/data link layer**—Data signals are processed using code and hardware specifically designed by MDS.
- 2. **A unique Network Address**—This provides a unique identifier for each radio in a network. A radio is not addressable unless this unique code is included in the data string.
- 3. An optional encryption value (code)—Setting an encryption code requires the use of the CODE command. This command scrambles the radio's hop pattern and encrypts payload data content. A radio requires the correct Network Address (ADDR) and CODE value in order to synchronize. When the CODE command is used, the same value must be programmed into all radios in the network. See "CODE [NONE, 1...255]" on Page 31 for more details.

The effective combination of **CODE** and **ADDR** discourage the use of an exhaustive search to gain access to a system.

The items described above provide sufficient security for a typical MAS system. For more highly-sensitive applications, system designers should consider employing application level encryption into their polling protocols to further protect their systems. Third party software tools are available for adding encryption, and these should be considered as part of any advanced encryption scheme.



10.0 TECHNICAL REFERENCE

10.1 Product Specifications - 900 MHz

GENERAL

Frequency Hopping Range: 902–928 MHz,

Subdivided into eight 3 MHz zones

Hop Pattern: Based on network address

Frequency Stability: ±1.5 ppm

Half-Duplex Operation: ±1.6 MHz TX/RX split

Network Addresses: 65,000

Temperature Range: -40° C to +70° C

Humidity: <95% at +40° C; non-condensing Primary Power: 13.8 Vdc, Nominal (6–30 Vdc range)

Current Draw

Weight:

(typical @ 30 dBm):

Agency Approvals:

Transmit: 510 mA @ 13.8 Vdc
Receive: 115 mA @ 13.8 Vdc
Sleep Mode: ≤ 3 mA @ 13.8 Vdc

Size: 5.30" W x 3.50" D x 1.40" H

(135 W x 89 D x 36 H mm):Weight:1

Lb/0.5 k w/o brackets; 1.15 Lb / 0.52 k w/brackets 1 Lb / 0.5 k w/o brackets;

1.15 Lb / 0.52 k w/brackets
Case: Die-cast aluminum

• FCC Part 15.247 (E5MDS-EL805)

• Industry Canada RSS-210 and RSS-139

(CAN 3738A 12122)

• UL/CSA Class 1, Div. 2: Groups A. B. C

and D hazardous locations

Contact MDS for information on availability of governmental approvals in other

countries

DATA CHARACTERISTICS (DB-9 Data Port

Data Interface: RS-232/422/485
Interface Connector: DB-9 female

Data Rate: 300, 600, 1200, 1800, 2400, 4800, 9600,

19200, 38400, 57600, 115200 bps asyn-

chronous

Data Latency: 7 ms typical Byte Length: 10 or 11 bits

Maximum Data Transmission: Continuous up to 115200 bps



RF CHARACTERISTICS (TNC RF Connector)

TRANSMITTER:

Power Output

(at antenna connector): 0.1 to 1.0 Watt (+20 dBm to +30 dBm),

set by user

Duty Cycle: Continuous
Modulation Type: Binary CPFSK

Output Impedance: 50 Ohms

Spurious: -49 dBm, 216 MHz-960 MHz -41 dBm above 960 MHz

RECEIVER:

Type: Double-conversion superheterodyne

Sensitivity: -108 dBm @ 10⁻⁶ BER Intermodulation: 54 dB minimum (EIA)

Desensitization: 75 dB

Spurious: 70 dB minimum

Bandwidth: 200 kHz

Interference Ratio

(SINAD degraded by 3dB): Co-channel: –10 dB

Adjacent channel: +30 dB Two channels away: +40 dB Three channels away: +48 dB

Time Required to Synchronize

with Master Radio: 0.5 seconds (typical)

10.2 Product Specifications — 2.4 GHz

GENERAL

Frequency Band: 2401.6–2477.8 MHz ISM band

A: 2401.6 MHz-2427.0 MHz B: 2427.2 MHz-2452.6 MHz C: 2452.8 MHz-2478.2 MHz

Subdivided into eight 3 MHz zones.

Hop Pattern: Based on network address

Frequency Stability: ±1.5 ppm

Half-Duplex Operation: ±1.6 MHz TX/RX split

Network Addresses: 65,000

Temperature Range: -40° C to +70° C

Humidity: <95% RH at +40° C; non-condensing Primary Power: 13.8 Vdc, Nominal (6–30 Vdc range)

Current Draw

(typical @ 27 dBm):

Transmit: 510 mA @ 13.8 Vdc Receive: 100 mA @ 13.8 Vdc Sleep Mode (typical): ≤ 3 mA @ 13.8 Vdc



Size: 5.30" W x 3.50" D x 1.40"H

(135 W x 89 D x 36 H mm). Weight: 1

Lb/0.5 k w/o brackets; 1.15 Lb / 0.52 k w/brackets

Weight: 1 Lb / 0.5 k w/o brackets;

1.15 Lb / 0.52 k w/brackets

Case: Die-cast aluminum

Agency Approvals. • FCC Part 15 Pending

(E5MDS-EL805-24)

• IC: Approved

 Contact MDS for information on availability of governmental approvals in

other countries

DATA CHARACTERISTICS (DB-9 Data Port)

Data Interface: RS-232/422/485 Interface Connector: DB-9 female

Data Rate. 300, 600, 1200, 1800, 2400, 4800, 9600,

19200, 38400, 57600, 115200 bps asyn-

chronous

Data Latency: 7 ms typical Byte Length: 10 or 11 bits

Maximum Data Transmission: Continuous up to 115200 bps

RF CHARACTERISTICS (TNC RF Connector)

TRANSMITTER:

Power Output

(at antenna connector): 0.1 to 0.5 watt (+20 dBm to +27 dBm),

set by user

Duty Cycle: Continuous
Modulation Type: Binary CPFSK
Output Impedance: 50 Ohms

Spurious: -49 dBm, 216 MHz-960 MHz

-41 dBm above 960 MHz

RECEIVER:

Type: Double-conversion superheterodyne

Sensitivity: -108 dBm @ 10⁻⁶ BER Intermodulation: 54 dB minimum (EIA)

Desensitization: 75 dB

Spurious: 70 dB minimum

Bandwidth: 200 kHz



10.3 Diagnostic Interface Connections (RJ-11)




Figure 21. RJ-11 to DB-9 Adapter Cable—Wiring Details

NOTE: Only wire pins 4, 5, and 6. Pins 1,2, and 3 are reserved for special functions and are not normally connected.

10.4 Data Interface Connections (DB-9F)

The DATA connector (Figure 22) is used to connect the radio to an external DTE data terminal that supports the EIA/RS-232 or EIA/RS-485 (balanced) format, depending on how the radio was configured at the factory. The radio supports data rates of 300, 600, 1200, 1800, 2400, 4800, 9600, 19200, 38400, 57600, and 115200 bps (asynchronous data only).

The DATA connector mates with a standard DB-9 plug that is available from many electronics parts distributors. Table 27 and Table 28 provide detailed pin descriptions for the DATA connector in RS/EIA-232 mode and RS/EIA-485 mode, respectively. Pin Descriptions—RS/EIA-232 Mode





Pin Descriptions—RS/EIA-232 Mode

Table 27 lists the DATA connector pin functions for radios configured to operate in RS/EIA-232 mode.

NOTE: The radio is hard-wired as a DCE in the EIA-232 mode.

Table 27. DATA connector pin descriptions—RS/EIA-232

| Pin Number | Input/ Output | Pin Description |
|---------------|------------------|--|
| 1 | OUT | DCD (Data Carrier Detect) A "high" indicates hopping synchronization. |
| 2 | OUT | RXD (Received Data) Supplies received data to the connected device. |
| 3 | IN | TXD (Transmitted Data) Accepts TX data from the connected device. |
| 4 | IN | Sleep—A ground on this pin turns off most circuits in a Remote radio, including transmit, receive, modem, and diagnostic functions. This allows for greatly reduced power consumption, yet preserves the radio's ability to be quickly brought on line. See "Using the Radio's Sleep Mode (Remote Units Only)" on Page 59 for details. |
| 5 | IN | Signal Ground— Connects to ground (negative supply potential) on the ra- dio's PC board and chassis. |
| 6 | OUT | Alarm Output—An RS-232 high/space (+5.0 Vdc) on this pin indicates an alarm condition. An RS-232 low/mark (-5.0 Vdc) indicates normal operation. This pin may be used as an alarm output. (See ASENSE [HI/LO] Details, page 29 for further information.) |
| 7 | IN | RTS (Request-to-Send) |
| 8 | OUT | CTS (Clear-to-Send)—Goes "high" after the programmed CTS delay time has elapsed (DCE), or keys an attached radio when RF data arrives (CTS KEY). |
| 9 | | Reserved for Special Uses (Do not connect) |



Pin Descriptions-RS/EIA-422/485 Mode

Table 28 lists the DATA connector pin functions for radios configured to operate in RS/EIA-422/485 mode. See Figure 23 for wiring schemes.

Table 28. DATA connector pin descriptions—RS/EIA-485 Mode

| Pin Number | Input/ Output | Pin Description |
|---------------|------------------|--|
| 1 | _ | Not Used—Do not connect |
| 2 | OUT | TXD+/TXA—Non-inverting driver output. Supplies data to the connected device. |
| 3 | IN | RXD+/RXA—Non-inverting receiver input. Accepts data from the connected device. |
| 4 | IN | Sleep—A ground on this pin turns off most circuits in a Remote radio, including transmit, receive, modem, and diagnostic functions. This allows for greatly reduced power consumption, yet preserves the radio's ability to be quickly brought on line. See "Using the Radio's Sleep Mode (Remote Units Only)" on Page 59 for details. |
| 5 | | Signal Ground (GND)—Connects to ground (negative supply potential) on the radio's PC board and chassis. |
| 6 | | Not Used—Do not connect |
| 7 | IN | RXD-/RXB-Inverting receiving input |
| 8 | OUT | TXD-/TXB—Inverting driver output. |
| 9 | | Open (User configurable via internal jumper. See "User Configurable I/O Connections" on Page 72) |
| | | |

NOTES:

- RXD+ / RXA and RXD- / RXB are data sent into the radio to be transmitted out
- RXD+ / RXA is positive with respect to RXD- / RXB when the line input is a "0"
- TXD+/TXA and TXD-/TXB are data received by the radio and sent to the connected device
- TXD+ / TXA is positive with respect to the TXD- / TXB when the line output is a "0"




Figure 23. EIA-422/485 Wiring Schemes (Left: EIA-422, Right: EIA-485)



10.5 User Configurable I/O Connections

Several connection points (eyelets) are provided within the transceiver near the DATA interface connector that allow the user to facilitate unique integration requirements.

By jumpering eyelets, external functions (unconditioned I/O) may be communicated within the TransNET network using a Network Management System (NMS) such as MDS' InSite or a user's custom application that uses the Network-Wide Diagnostics Protocol. Specifications for this protocol are open and are contained within the InSite distribution material on CD and on the MDS Web site.

One pin of the DB-9 Data Interface connector supports this function, as well as three pins of the RJ-11 Diagnostics connector. See Tables 27 and 28 on the previous pages for details.

CAUTION

POTENTIAL EQUIPMENT DAMAGE Care should be taken when soldering to the PCB eyelets due to their small size. For this reason, only qualified personnel should install the jumpers and external connections.

Installation of internal jumpers and connection to non-standard interface pins may void the product's warranty.

If you are uncertain of your interface design, please consult with the MDS Technical Services Department for a review of your design to assure maintenance of your warranty.



Figure 24. User Interface I/O Jumper Eyelets PCBs 03-4040A03/A04 and later

NOTE: If your PCB does not look like the one in the Figure 24, consult with the MDS Technical Services for assistance.

Each pin connected to user-designed equipment must be connected through a special cable constructed to breakout the User I/O pins.

Your interface can complement your unique requirements. The input signals and output interface must be within the radio's interface parameters as summarized in Table 29.



Table 29. TransNET User I/O Connection Resources

| Function or Service | Range | Available at eyelet: |
|---|---|----------------------|
| Filtered Receive Audio (For test purposes) | 0 – 5 Vac, 30–5 kHz | H2 |
| General Purpose I/O 1 (GPIO 1) ^a | TTL; External 10K to 3.3 V Vcc Recommended | НЗ |
| General Purpose I/O 2 (GPIO 2) ^b | TTL; External 10K to 3.3 V Vcc Recommended | H4 |
| Analog 1 ^c | 0 – 5 Vac, ≤ 60 HZ | H6 |
| Do not connect. Factory use only. | | H5 |
| Data Interface Pin | | Available at eyelet: |
| DB-9, Pin 9 | | H1 |
| RJ-11, Pin 1 | | H7 |
| RJ-11, Pin 2 | | H8 |
| RJ-11, Pin 3 | | H9 |

- a. Configuration and data retrievable via MDS InSite™ software as "I/O 1"
- b. Configuration and data retrievable via MDS InSite™ software as "I/O 2"
- c. Parameter retrievable via MDS InSite™ software

Using the I/O Points with InSite™ NMS Software

MDS' InSite has the ability to read the user analog input (Analog 1) and two user-configurable and independent I/O signals (VO 1 & VO 2). Each I/O connection can independently configured as input or output. If configured as an output, a *saved* default output value can be stored in the radio to ensure the radio boots to the desired state for this pin.

The values of **I/O** 1 & **I/O** 2 can be read and displayed by an InSite user to determine the current state. The values of **I/O** 1 & **I/O** 2 at the TransNET's DATA Interface connector will remain in a constant state until manually changed though the InSite **Configuration** screen.

Application Example—Digital Input and Output at a Remote

A typical application of the user I/O connections may require one digital input and one digital output to be controlled by network diagnostics. In this example, H3 could be jumpered to H7 (I/O 1 to RJ-11, Pin 1) and H4 jumpered to H8 (I/O 2 to RJ-11, Pin 2). Using InSite, I/O 1 could be configured as an output and I/O 2 as an input.



10.6 dBm-Watts-Volts Conversion Chart

Table 30 is provided as a convenience for determining the equivalent voltage or wattage of an RF power expressed in dBm with 50 Ohms load.

Table 30. dBm-Watts-Volts Conversion Chart

| dBm | V | Po | dBm | V | Po | dBm | mV | Ро | dBm | μV | Po |
|------------|--------------|----------------|------------|--------------|----------------|------------|--------------|----------|--------------|-------------|----------------|
| +53 | 100.0 | 200W | 0 | | | -49 | | FU | -98 | | го |
| +53 +50 | 70.7 | 100W | -1 | .225 .200 | 1.0mW .80mW | -49 -50 | 0.80 0.71 | .01µW | -98 | 2.9 2.51 | |
| +49 | 64.0 | 80W | -2 | .180 | .64mW | -51 | 0.64 | .01μνν | -100 | 2.25 | .1pW |
| +48 | 58.0 | 64W | -3 | .160 | .50mW | -52 | 0.57 | | -101 | 2.23 | . ipvv |
| +47 | 50.0 | 50W | -4 | .141 | .40mW | -53 | 0.50 | | -101 | 1.8 | |
| +46 | 44.5 | 40W | -5 | .125 | .32mW | -54 | 0.45 | | -103 | 1.6 | |
| +45 | 40.0 | 32W | -6 | .115 | .25mW | -55 | 0.40 | | -104 | 1.41 | |
| +44 | 32.5 | 25W | -7 | .100 | .20mW | -56 | 0.351 | | -105 | 1.27 | |
| +43 | 32.0 | 20W | -8 | .090 | .16mW | -57 | 0.32 | | -106 | 1.18 | |
| +42 | 28.0 | 16W | -9 | .080 | .125mW | -58 | 0.286 | | | | |
| +41 | 26.2 | 12.5W | -10 | .071 | .10mW | -59 | 0.251 | | dBm | nV | Po |
| +40 | 22.5 | 10W | -11 | .064 | | -60 | 0.225 | .001µW | -107 | 1000 | . • |
| +39 | 20.0 | 8W | -12 | .058 | | -61 | 0.200 | • | -108 | 900 | |
| +38 | 18.0 | 6.4W | -13 | .050 | | -62 | 0.180 | | -109 | 800 | |
| +37 | 16.0 | 5W | -14 | .045 | | -63 | 0.160 | | -110 | 710 | .01pW |
| +36 | 14.1 | 4W | -15 | .040 | | -64 | 0.141 | | -111 | 640 | .01011 |
| +35 | 12.5 | 3.2W | -16 | .0355 | | | | | -112 | 580 | |
| +34 | 11.5 | 2.5W | | | | dBm | μV | Po | -113 | 500 | |
| +33 | 10.0 | 2W | dBm | m۷ | Po | -65 | 128 | | -114 | 450 | |
| +32 | 9.0 | 1.6W | -17 | 31.5 | | -66 | 115 | | -115 | 400 | |
| +31 | 8.0 | 1.25W | -18 | 28.5 | | -67 | 100 | | -116 | 355 | |
| +30 | 7.10 | 1.0W | -19 | 25.1 | | -68 | 90 | | -117 | 325 | |
| +29 | 6.40 | 800mW | -20 | 22.5 | .01mW | -69 | 80 | | -118 | 285 | |
| +28 | 5.80 | 640mW | -21 | 20.0 | | -70 | 71 | .1nW | -119 | 251 | |
| +27 | 5.00 | 500mW | -22 | 17.9 | | -71 | 65 | | -120 | 225 | |
| +26 | 4.45 | 400mW | -23 | 15.9 | | -72 | 58 | | .001pV | V | |
| +25 | 4.00 | 320mW | -24 | 14.1 | | -73 | 50 | | -121 | 200 | |
| +24 | 3.55 | 250mW | -25 | 12.8 | | -74 | 45 | | -122 | 180 | |
| +23 | 3.20 | 200mW | -26 | 11.5 | | -75 | 40 | | -123 | 160 | |
| +22 | 2.80 | 160mW | -27 | 10.0 | | -76 | 35 | | -124 | 141 | |
| +21 +20 | 2.52 2.25 | 125mW 100mW | -28 | 8.9 | | -77 | 32 | | -125 | 128 | |
| +19 | 2.23 | 80mW | -29 | 8.0 | | -78 | 29 | | -126 | 117 | |
| +18 | 1.80 | 64mW | -30 | 7.1 | .001mW | -79 | 25 | 04.144 | -127 | 100 | |
| +17 | 1.60 | 50mW | -31 | 6.25 | | -80 | 22.5 | .01nW | -128 | 90 | 4 (14) |
| +16 | 1.41 | 40mW | -32 | 5.8 | | -81 | 20.0 | | -129 | 80 | .1 <i>f</i> W |
| +15 | 1.25 | 32mW | -33 | 5.0 | | -82 | 18.0 | | -130 | 71 | |
| +14 | 1.15 | 25mW | -34 -35 | 4.5 4.0 | | -83 -84 | 16.0 11.1 | | -131 -132 | 61 58 | |
| +13 | 1.00 | 20mW | -36 | 3.5 | | -85 | 12.9 | | -133 | 50 | |
| +12 | .90 | 16mW | -37 | 3.2 | | -86 | 11.5 | | -134 | 45 | |
| +11 | .80 | 12.5mW | -38 | 2.85 | | -87 | 10.0 | | -135 | 40 | |
| +10 | .71 | 10mW | -39 | 2.5 | | -88 | 9.0 | | -136 | 35 | |
| +9 | .64 | 8mW | -40 | 2.25 | .1µW | -89 | 8.0 | | -137 | 33 | |
| +8 | .58 | 6.4mW | -41 | 2.0 | . ιμνν | -90 | 7.1 | .001nW | -138 | 29 | |
| +7 | .500 | 5mW | -42 | 1.8 | | -91 | 6.1 | .0011111 | -139 | 25 | |
| +6 | .445 | 4mW | -43 | 1.6 | | -92 | 5.75 | | -140 | 23 | .01 <i>f</i> W |
| +5 | .400 | 3.2mW | -44 | 1.4 | | -93 | 5.0 | | | | , |
| +4 | .355 | 2.5mW | -45 | 1.25 | | -94 | 4.5 | | | | |
| +3 | .320 | 2.0mW | -46 | 1.18 | | -95 | 4.0 | | | | |
| +2 | .280 | 1.6mW | -47 | 1.00 | | -96 | 3.51 | | | | |
| +1 | .252 | 1.25mW | -48 | 0.90 | | -97 | 3.2 | | | | |
| | | | I | | | I | | | I | | |



INDEX



ADDR (set/display radio network address) 29

AMASK (configure alarm output signal) 29

ASENSE (set/display alarm output sense) 29

BAUD (set/display data interface port attributes) 29

BUFF (set/display received data handling mode) 30

CODE (set/display encryption value), See also Encryption 31

CTS (set/display CTS line response timer) 31

CTSHOLD (set/display CTS hold timer) 32

detailed descriptions 28-44

DEVICE (set/display DCE or CTS Key behavior) 32

display operating status 24

DKEY Command, Turn off radio transmitter test signal 33

DTYPE (set radio's diagnostics type) 33

FEC (Forward Error Correction) 33

FEC (Forward Error Correction) Command 33

HOPTIME (set/display hoptime setting) 34

how used 28

INIT (restore factory default settings) 34

LPM (low-power mode) 36

LPMHOLD (low-power mode sleep time) 36

MODE (display/set radio mode as master, remote, or extension) 36

MODE (radio operating mode) 36

most often used commands 28

network configuration 23

OWM (set/display optional owner's message) 37

OWN (set/display optional owner's name) 37

PORT (display/set current data port) 37

PWR (set/display RF forward output power) 38

Radio transmitter test frequency (TX) 43

RSSI (display received signal strength) 38

RTU (enable/disable internal RTU) 39

RX (set/display receiver test frequency) 39

RXD 39

RXTOT (set/display received data timeout value) 40

SAF (store-and-forward) 40

SER (radio serial number) 40

SETUP (enter testing and setup mode) 40

SHOW (display measured power output) 41

SHOW PWR (show power) 41

SHOW SYNC 41

SHOW SYNC (show Clock-Synchronization Master) 41

SKIP (set/display frequency zone to skip) 41

SLEEP (display/set radio's sleep mode setting) 42

SLEEP (transceiver sleep mode) 42

SREV (firmware/software revision level) 42

STAT (list alarms) 43

TEMP (display internal temperature) 43

UNIT (unit address) 43

XADDR (extended address) 44

XMAP (Map of Extension Addresses) 44



XPRI (display/program primary radio's extended address) 44

XRSSI (sets minimum signal level for sync. with non-primary extension unit) 44 Connectors

Diagnostic Interface, Connections 69

D

Data Baud Rate (BAUD) Command 29

Data Baud Rate (BUFF) Command 30

Data buffer setting 21, 30

DATA INTERFACE

cable wiring for tail-end links, illustrated 19

connections 69

connector pin descriptions, table 70

Data Port Signalling Standard (PORT) Command 37

Default settings

data interface baud rate 22

factory settings reset by INIT command (table) 34

restoring (INIT command) 34

See also individual command descriptions

DEVICE Command 32

DEVICE command (set/display DCE or CTS Key behavior) 32

Diagnostics

network-wide, performing 49

setup mode (SETUP command) 40

using InSite software for network-wide 49

Diagnostics Link (DLINK) 32

Display

alarm output sense (ASENSE command) 29

alarms (STAT command) 43

CTS hold timer value (CTSHOLD command) 32

CTS line response timer value (CTS command) 31

data interface baud rate (BAUD command) 29

device behavior (DEVICE command) 32

hoptime setting (HOPTIME command) 34

network address (ADDR command) 29

operating status commands 24

owner's message (OWM command) 37

owner's name (OWN command) 37

receive test frequency (RX command) 39

received data handling mode (BUFF command) 30

received data timeout value (RXTOT command) 40

received signal strength (RSSI command) 38

RF forward output power (PWR command) 38

RF power output, actual measured (SHOW command) 41

skipped frequency zones (SKIP command) 41

temperature, internal (TEMP command) 43

display/set radio mode as master, remote, or extension (see MODE command) 36

DKEY command (disable transmitter) 21, 40

DKEY, Disable Transmitter, Command 33

DLINK command (set/display baud rate of diagnostics link) 49



Downstream Repeat Transmission Count (REPEAT) Command 38 DSP (digital signal processing) 1, 47 DTYPE command (set radio's diagnostics type) 33, 49, 50

Ε

Enable
internal RTU (RTU command) 39
network-wide diagnostics, procedures 49
Setup mode (SETUP command) 40
skipped zone (SKIP command) 41
Sleep Mode
Enable/Disable LEDs (LED) Command 36
Encryption. See CODE command
Equipment List 33
Extended Address Command (XADDR) 44
Extension radio. See Store-and-Forward (SAF)

F

Feedline selection 9, 10 Firmware Revision Level Command (SREV) 42 Forward-Error Correction (FEC) Command 33 Fuse Replacement 50

G

Gate (radio diagnostics type) 33, 50

Н

Hardware Revision (HREV) Command 35
Hayes-Compatible AT Command (AT) 29
Hoptime
setting 21
HOPTIME Command (radio transmitter hop timing) 34
HOPTIME command (set/display hoptime setting) 34

ı

Illustrations
antenna, Yagi 10
data interface cable wiring for tail-end links 19
model configuration code 72
point-to-point link 3
remote station arrangement 6
tail-end link 4
typical MAS network 3
INIT command (restore factory default settings) 34
Initialize 34
InSite software 49
Installation
antenna 15
connecting transceiver to data equipment 15, 22



```
feedline selection 10
  performance optimization 20
  requirements 6
  site selection 6
  site survey 7
  tail-end links 18
  transmission path 7
Interference
  about 8
  checks 22
  troubleshooting 48
interference 8
K
Key
  set to CTS keying (DEVICE command) 32
  transmitter, for antenna SWR check 21
KEY command (key transmitter) 21, 40
L
LED status indicators
  table 20, 46
Low-Power Mode (LPM) Command 36
Low-Power Mode Sleep Time (LPMHOLD) Command 36
LPM Command (low-power mode) 36
LPMHOLD Command 36
M
Map 44
Map of Extension Addressses (XMAP) 44
Master Station
  default settings 34
MIRRORED BITS<sup>TM</sup> Protocol Support 62, 63
MODE Command 36
MODE command (display/set radio mode as master, remote, or extension) 36
MODE command (display/set radio's operating mode as master, remote, or
         extension) 36, 37
Model configuration code, illustrated 72
Modes
  Low-Power Mode versus Remote's Sleep 62
Mounting instructions/dimensions 14–15
Multiple Address System (MAS)
  network, illustrated 3
Multiple Address Systems (MAS) 2
Ν
Network Address (ADDR) Command 29
Network configuration commands 23
Network Diangnsotics Mode (DTYPE) Command 33
Network-wide diagnostics
```



procedures 49 Node (radio diagnostics type) 33, 50

0

LED 36 Modbus, BUFF 30 Operation 19–22 OWM command (set/display optional owner's message) 37 OWN command (set/display optional owner's name) 37 Owner's Message (OWM) Command 37 Owner's Name Command (OWN) 37

P

PC connecting to radio's diagnostic port 49 launching InSite application at 49 performing diagnostics using connected 49 Peer (radio diagnostics type) 33, 50 Performance optimization 20 Pins, DATA INTERFACE connector descriptions (table) 70 Point-to-point system link, illustrated 3 Point-to-Point System (P-P) 3 PORT command (set/display current data port) 37 Power Low-Power Mode versus Remote's Sleep 62 Power (RF) how much can be used 11 Measurement 41 set/display RF forward output (PWR command) 38 Power saving mode (see Sleep Mode) Primary Extension Address (XPRI) 44 Procedures antenna aiming 20 antenna and feedline selection 9 antenna SWR check 21

connecting data equipment to DATA INTERFACE connector 15, 22

connecting PC and radios for network-wide diagnostics 49

enabling sleep mode installation planning 6

installing the antenna and feedline 15

interference check 22

mounting the transceiver 14–15

network-wide diagnostics 49 performance optimization 20

performing network-wide diagnostics 49

programming radio for network-wide diagnostics 49

reading LED status indicators 19

site selection 6

troubleshooting 45-48



Programming radio 28–44 as root or node 49 PWR command (set/display RF forward output power) 38

R

Radio

inoperative (troubleshooting chart) 48 no synchronization with master (troubleshooting chart) 48 poor performance (troubleshooting chart) 48

Radio Operating Mode (MODE) Command 36, 37

Radio Receive Test Frequency Command (RX) 39

Radio Serial Number Command (SER) 40

Radio Transmit Test Frequency (TX) 43

Radio Transmitter Hop Timing (HOPTIME) 34

Radio Transmitter Power Level (PWR) Command 38

Radio's Internal Temperature Command (TEMP) 43

Radio-MODEM Behavior (DEVICE) Command 32

Receive Data Timeout-Timer Command (RXTOT) 40

Received Signal Strength Indicator Command (RSSI) 38

Remote radio

default settings 34

Remote station

typical arrangement, illustrated 6

Remote Terminal Unit Simulator Command (RTU) 39

Repeater Operation. See Store-and-Forward (SAF)

Restore to Factory Defaults (INIT) 34

RJ-11

Diagnostic Interface, Connection 69

Root (radio diagnostics type) 33, 50

RSSI command (display received signal strength) 38

RTU command (enable/disable internal RTU) 39

RX command (set/display test receive frequency) 39

RXD Command 39

RXD Delay Command (RXD) 39

RXTOT command (set/display received data timeout value) 40

S

SAF command (store-and-forward) 40

Security

Network Address 65

optional encryption value 65

Security Code (CODE) Command 31

Security, Data 65

SER Command 40

Set

alarm output sense (ASENSE command) 29

alarm output signal (AMASK command) 29

CTS hold timer (CTSHOLD command) 32

CTS line response timer (CTS command) 31

data interface baud rate (BAUD command) 29



```
DCE or CTS Key device behavior (DEVICE command) 32
  frequency zone to skip (SKIP command) 41
  hoptime (HOPTIME command) 34
  network address (ADDR command) 29
  owner's message (OWM command) 37
  owner's name (OWN command) 37
  radio mode (see MODE command) 36
  received data handling mode (BUFF command) 30
  received data timeout value (RXTOT command) 40
  receiver test frequency (RX command) 39
  testing mode (SETUP command) 40
SETUP command (enter testing and setup mode) 40
Setup Radio Test (SETUP) 40
Show Clock-Synchronization Master Network Address (SHOW SYNC) 41
SHOW command (display power output) 41
SHOW CON Command (show virtual connection status) 41
Show Measured RF Transmit Power (SHOW PWR) 41
SHOW SYNC Command 41
Show Virtual Connection Status Command (SHOW CON) 41
Site selection 6
SKIP command (set/display frequency zone to skip) 41
Skip Radio Operating Zones (SKIP) 41
SLEEP command (display/set radio's sleep setting) 42
SLEEP command (transceiver sleep ON/OFF) 42
Sleep Mode 59
Spread spectrum, basic principles of 2
SREV Command 42
STAT command (list alarms) 43
Store-and-Forward (SAF) 4, 23, 27, 34, 40, 45, 52, 57
Store-and-Forward Services (SAF) Support Command 40
SWR (Standing Wave Ratio)
  performance optimization 21
Synchronization qualifiers 46, 55
synchronization, check 8
т
Tables
  accessories 5
  alarm codes 47
  antenna system gain vs. power output setting 13
  DATA INTERFACE connector pin descriptions 70
  LED status indicators 20, 46
  troubleshooting 48
Tail-end link
  Adding to Existing Network 3
  cable wiring for, illustrated 19
  illustrated 4
  installation 18
Technical specifications 66-68
TEMP command (display internal temperature) 43
```



```
Temperature, display internal (TEMP command) 43
Terrain 7
Terrain and Signal Strength 7
Test, on-the-air 7
Transceiver
  connecting to data equipment 15, 22
  default settings 34
  mounting instructions/dimensions 14-15
  performance optimization 20
  sleep mode 59
Transceiver Sleep (SLEEP) 42
Troubleshooting 45–48
  performing network-wide diagnostics 49
  table 48
Turn Off Radio Transmitter Test Signal (DKEY) Command 33
Turn On Radio Transmitter Test Signal (KEY) Command 35
UNIT Command (unit address) 43
Upstream Repeat Transmission Count Command (RETRY) 38
X
XADDR (extended address command) 17, 27, 34, 35, 45, 55, 58
XADDR (extended address) Command 37
XPRI command (display/set extended address) 44
XRSSI command (sets minimum RSSI level to maintain sync. w/non-primary
        extension radio) 44
ZONE CLEAR (clear zone statistics log) 44
ZONE DATA Command (read zone statistics log) 44
Zone, Clear Statistics Log (ZONE CLEAR) 44
Zone, Read Statistics Log (ZONE DATA) 44
```

industrial/wireless/performance



N CASE OF DIFFICULTY...

MDS products are designed for long life and trouble-free operation. However, this equipment, as with all electronic equipment, may have an occasional component failure. The following information will assist you in the event that servicing becomes necessary.

TECHNICAL ASSISTANCE

Technical assistance for MDS products is available from our Technical Support Department during business hours (8:00 A.M.–5:30 P.M. Eastern Time). When calling, please give the complete model number of the radio, along with a description of the trouble/symptom(s) that you are experiencing. In many cases, problems can be resolved over the telephone, without the need for returning the unit to the factory. Please use one of the following means for product assistance:

Phone: 585 241-5510 E-Mail: TechSupport@microwavedata.com

FAX: 585 242-8369 Web: www.microwavedata.com

FACTORY SERVICE

Component level repair of radio equipment is not recommended in the field. Many components are installed using surface mount technology, which requires specialized training and equipment for proper servicing. For this reason, the equipment should be returned to the factory for any PC board repairs. The factory is best equipped to diagnose, repair and align your radio to its proper operating specifications.

If return of the equipment is necessary, you will be issued a Service Request Order (SRO) number. The SRO number will help expedite the repair so that the equipment can be repaired and returned to you as quickly as possible. Please be sure to include the SRO number on the outside of the shipping box, and on any correspondence relating to the repair. No equipment will be accepted for repair without an SRO number.

A statement should accompany the radio describing, in detail, the trouble symptom(s), and a description of any associated equipment normally connected to the radio. It is also important to include the name and telephone number of a person in your organization who can be contacted if additional information is required.

The radio must be properly packed for return to the factory. The original shipping container and packaging materials should be used whenever possible. All factory returns should be addressed to:

Microwave Data Systems Product Services Department (SRO No. XXXX) 175 Science Parkway Rochester, NY 14620 USA

When repairs have been completed, the equipment will be returned to you by the same shipping method used to send it to the factory. Please specify if you wish to make different shipping arrangements. To inquire about an in-process repair, you may contact our Product Services Group at 585-241-5540 (FAX: 585-242-8400), or via e-mail at ProductServices@microwavedata.com.

industrial/wireless/performance



Microwave Data Systems Inc. 175 Science Parkway Rochester, NY 14620 General Business: +1 585 242-9600 FAX: +1 585 242-9620 Web: www.microwavedata.com



A product of Microwave Data Systems Inc.