TROUBLE SHOOTING

Problems	Reasons	Solutions
Running Problems	The battery inside the radio controller is too weak.	Replace with new alkaline batteries.
	There is a weak or low reception to the radio controls.	
	The batteries inside the vehicle are too weak.	Recharge or replace with new batteries inside the RZR
Operating Problems	A small object obstructs movement of the tire of axle.	Use tweezers to remove obstruction.
	The RZR was driven on the carpet and has fabric threads caught in the axle.	Playing on the carpet is not recommended.
Other	The vehicle does not respond to the radio control.	Try playing at another location.
	The radio control's frequency is disrupted by something around the environment.	Some other equipment using the same radio wave could disrupt the radio control. Either play in another location or turn off the other equipment. If you are planning to race your vehicles with another friend, purchase vehicles with two different frequencies (49 MHz and 27 MHz) to avoid disruption.

The antenna provided is a unique antenna. By installation of unauthorized antenna to this equipment, such unauthorized installation could void the user's authority to operate the equipment.

PLEASE NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- · Connect the equipment into an outlet on a circuit different from
- that to which the receiver is needed.
- Consult the dealer or an experienced radio/TV technician for help.



CHOKING HAZARD Small parts not for children under 3 years

MADE IN CHINA



⚠ WARNING: CHOKING HAZARD-Small parts. Not for children under 3 years.

POLARIS

7//C)/(C)/(C)

* POLARIS

OF POLARIS INDUSTRIES INC. USED UNDER LICENSE.

FROM THE POLARIS HOMEPAGE AT WWW POLARISINDLISTRIES COM

*IMPORTANT:

AUTHORITY TO OPERATE THE EQUIPMENT.

user's authority to operate the equipment.

PLEASE DO NOT

RETURN TO STORE

For more information please

contact Customer Services:

help@bearriver.net

(580)-272-0022

1. This device may not cause harmful interference, and

POLARIS AND ITS VEHICLE BODY DESIGNS AND NAMES ARE REGISTERED TRADEMARKS

POLARIS DESIGNS, ENGINEERS, MANUFACTURES AND MARKETS SNOWMOBILES, ALL-TERRAIN

VEHICLES (ATVs), VICTORY MOTORCYCLES AND THE POLARIS RANGER FOR RECREATIONAL

AND UTILITY USE. INFORMATION ABOUT THE COMPLETE LINE OF POLARIS PRODUCTS. APPAREI

AND VEHICLE ACCESSORIES ARE AVAILABLE FROM ALITHORIZED POLARIS DEALERS OR ANYTIME

FULL FUNCTION RADIO CONTROL ALL TERRAIN VEHICLE

DO NOT MIX ALKALINE. STANDARD (CARBON ZINC) OR RECHARGEABLE (NICKEL CADMIUM) BATTERIES

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

INSTRUCTION MANUAL

** NOTE: THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the

2. This device must accept any interference received, including interference that may cause undesired operation.

UNAUTHORIZED MODIFICATIONS TO THIS EQUIPMENT. SUCH MODIFICATIONS COULD VOID THE USER'S

THE 2 X AA BATTERIES IN THE CONTROLLER.

IF RZR DOES NOT RESPOND PROPERLY, PLEASE RECHARGE OR

REPLACE THE 6V NI-MH BATTERY PACK IN THE RZR OR REPLACE

DO NOT MIX OLD AND NEW BATTERIES.

DO NOT DISPOSE OF BATTERIES IN FIRE, BATTERIES MAY EXPLODE OR LEAK.

REQUIRES 6V 500mAh RECHARGEABE NI-MH BATTERY IN RZR AND 2 AA **BATTERY IN CONTROLLER**

COLORS AND DECORATIONS MAY VARY, KEEP CONTENT DETAILS FOR FUTURE REFERENCE.

CONTENT LIST ITEM NO. B1426 AGE. AS WITH ALL ELECTRIC PRODUCTS, PRECAUTIO SHOULD BE OBSERVED DURING HANDLING AND USE O PREVENT ELECTRIC SHOCK INPUT: AC 120V 60Hz 100mA OUTPUT: DC 6V 250mA 8+

Manufactured & Distributed by

Frisco Texas 75033

All Rights Reserved

MADE IN CHINA

© 2015 Bear River Holdings, LLC

5000 Eldorado Parkway, Suite 150

6V Ni-MH Rechargeable Battery Pack

2 x AA Battery

o prevent damage, the contents of the package that are listed have been packed in the tray and may be out of plain sight. Please remove all contents from the tray.


! CAUTION:

DO NOT MODIFY TOY IN ANY WAY. ADULT SUPERVISION IS ADVISED!

∕ IMPORTANT

THE INCLUDED 6V NI-MH BATTERY PACK IS NOT CHARGED PRIOR TO SHIPMENT AND MUST BE CHARGED BEFORE USE.

GETTING TO KNOW YOUR RZR



BATTERY INSTALLATION

Diagram #2

- 1) Using a crosshead screwdriver, unscrew and remove the battery cover. 2) Insert 2 x AA battery into the controller. Replace
- battery cover and tighten screw. (Use Alkaline Batteries for the longest battery life,

and best performance).

PLEASE NOTE:

- A) Make sure the batteries have been inserted correctly (+ or -) into the controller.
- B) If the vehicle does not respond properly, please replace the Alkaline batteries in the controller or recharge battery.

Diagram #3

- 1) Unscrew and remove the battery cover.
- 2) Connect the battery cord to the cord from the RZR. 3) Place the connector and the battery pack into the battery compartment.
- 4) Replace the battery cover, tighten screws.
- DO NOT MIX ALKALINE, STANDARD (CARBON ZINC) OR RECHARGEABLE (NICKEL CADMIUM) BATTERIES. DO NOT MIX OLD AND NEW BATTERIES.
- DO NOT DISPOSE OF BATTERIES IN FIRE, BATTERIES MAY EXPLODE OR LEAK.



CHARGING THE BATTERY PACK


Diagram #4

To Charge the RZR Battery Pack:

- 1) First, plug the Charger into a standard 120V household electrical outlet
- 2) Plug the battery connector into the charger.
- 3) Charge the battery pack for only 5 hours. (Note: Failure to disconnect the battery after 5 hours may cause battery damage).
- 1) Unplug battery pack, and allow the battery pack to cool before placing inside the RZR.

NOTE:

PLEASE ALLOW THE BATTERY PACK TO COOL PRIOR TO RECHARGING. USING BEFORE DOING SO WILL GREATLY REDUCE THE LIFE OF THE



ATTENTION PARENTS: The battery charger and battery pack need to be periodically examined for potential hazards and any potentially hazardous parts to be repaired or replaced.

Cautions

- . Make sure you always use new or fully charged batteries in the controller. 2. Do not operate the RZR if it becomes damaged in any way.
- 3. Check that the infrared signal from the controller is making a connection with the RZR before operating.
- I. Try not to crash the RZR as this may cause damage. 5. Check that the area is clear of all obstacles before you operate.
- 6. Adult supervision is always recommended
- 7. Never operate near animals. Keep RZR a way from your
- fingers, hair, eyes and other body parts. Stay away from obstacles and electrical hazards

Warning 1.Non-rechargeable batteries are not to be recharged.


- 2.Rechargeable batteries are only to be charged under adult supervision. Rechargeable batteries are to be removed from the toy
- before being charged. 4.Different types of batteries or new and used batteries
- are not to be mixed 5.Batteries are to be inserted with the correct polarity.
- 6.Exhausted batteries are to be removed from the toy.
- 7. The supply terminals are not to be short-circuited.


USING YOUR RZR

Diagram #6

To use your RZR:

- 1) Flip the On/Off switch to the "On" position on the bottom of the RZR.
- 2) Flip the On/Off switch to the "On" position on the controller.
- 3) Place on the ground, and use the controller to maneuver the RZR. 4) If vehicle pulls to one side or the other, simply adjust the steering
- trim located on the bottom of the RZR. 5) After operating, return both the RZR and controller to the "Off" position.
- 6) When not being used for an extended amount of time, remove the
- batteries from the controller and RZR.





NEVER TOUCH THE WHEELS WHEN THEY ARE TURNING. NEVER INSERT ANY SHARP OBJECTS, PINS OR SCREWS INTO THE VEHICLE AS THIS MAY PUNCTURE THE MOTOR

Operating multiple RC's with the same frequency in close proximity will cause interference and poor performance. Two frequency bands are available to play two at the same time.

Works best away from electrical hazards and large obstacles.

Do not put objects or fingers near the front or rear of the wheels while it is turning.

RZR can run on various terrain, be sure objects do not get obstructed in the wheels.

Never give the RZR or controller to any child under the age of 3, as it contains small parts.

When not in use, remove batteries from compartments (RZR and controller).

Normal working distance is about 50 feet (15 meters).