105x150mm

Thermal Label Printer
quick start guide

Operation Manual
(Ver: 1.0)

1.Safety instructions
Attention:
a) The printer should be installed in a flat, stable place.

b) Users should power down the printer to operate and maintain.

c) The printer should stay away from the water and avoid direct sunlight, strong heat and source.

d) Do not use and store printer in high temperature, humidity and corrosion.

e) Avoid placing the printer in a place where there are vibrations and shocks.

f) Please use the power adapter provided by the manufacturer. Power supply shall be stable and high enough to drive the printer head. Do not connect multiple devices with the same power supply to avoid power voltage fluctuation.

g) If the printer is not used for a long time, please disconnect the power of the printer power adapter.

h) To ensure print quality and printer life, recommended to equipment quality paper or thermal paper.

i) When the machine is plugged in, disconnected, the power supply must be turned off, otherwise the machine may be damaged.

j) The user shall not disassemble the printer by himself.

k) Keep this manual for reference.

2.Unpacking list

Printer label Rolls | Power adapter | USB cable | Quick start guide

3. Characteristics and Performance
3.1 Printing
• Method: Thermal Direct Mode
• Media: Primary in Rolls
• Width: 20mm - 108mm (max)
• Height: 10mm - 1000mm
3.2 Media Sensor
• Position type: Slide
• Sensing mode: Gap / Black Mark
• Media Sensor: Transmissive (Standard), Fit three as a slave, and reserve interchangeably
3.3 Printing Speed: 2 inches per second (ips) at the same time, and the maximum 3 inches per second (ips)
3.4 Printing resolution: 203 dpi
3.5 Memory
• Flash: 4MB
• SDRAM: 4MB
3.6 Power supply
• AC adapter: Input: 100V-240V, 50Hz/60Hz
3.7 Working environment
• Operating temperature: 0°C ~ 45°C Relative humidity: 10~80%
• Storage environment: -20°C ~60°C Relative humidity: 10~90%
3.8 Dimensions and weight
• Dimensions: 145(L)*97.5(W)*135(H)mm

4a. Operation Instruction
1.1 Device Setup

1.2 Connect the printer to the computer

1.3 Load the paper

1.4 Close the paper cover

1.5 Power on the printer

4.1 Download installation driver
1.1 Open the website

1.2 Choose the installation package

1.3 Choose your operating system

1.4 Choose your printer model

4.2 Printer install
2.1 Click "Next"

2.2 Click USB, and click installation.

Install successfully

2.3 Test Page
Press [Cancel] button to start the test cancel. Need to [Print the Internal page] to test the printer. Click [Print the Internal page] then check the test printer is working properly.

4.3 Printer Install
3.1 Software and operation

Software page printing is shown as below: Press the printing button and turn on the printer, the printer will print out the software page, and USB cable are connected. Then the software page can be printed.

3.2 Label set page

3.3 Software's light blinks and turns on automatically
3.4 USB Bluetooth
Press the software's light blinks slowly
Paper out: The red software light blinks slowly and the buzzer beeps three times.

Open cover: The red software light blinks slowly and the buzzer beeps three times.

Charging: The red software light is always on and the buzzer beeps six times.

Bluetooth connection: The blue software light is always on

4.4 Android page printing
4.1 Android page printing
Software page printing is shown as below: Press the printing button and turn on the printer, the printer will print out the software page, and USB cable are connected. Then the software page can be printed.

4.2 Bluetooth connection

4.3 Software's light blinks slowly and turns on automatically
4.4 USB Bluetooth
Press the software's light blinks slowly
Paper out: The red software light blinks slowly and the buzzer beeps three times.

Open cover: The red software light is always on and the buzzer beeps six times.

Charging: The red software light is always on

Bluetooth connection: The blue software light is always on

4.5 iOS Bluetooth
Power on: The green software light is always on
Paper out: The red software light blinks slowly and the buzzer beeps three times.
Open cover: The red software light is always on and the buzzer beeps six times.
Charging: The red software light is always on
4.6 Bluetooth
Bluetooth supports 4.0 or 5.0

4.7 The battery charging and light

4.8 The battery charging power light

5.1
1. Please search and download the "**print tshot+**" in the search bar on **Google Play** or **App Store**.

2.Open the "print label" in the search bar locally please reference

5.2 Go to the Bluetooth connection interface and wait and install.

5.3 Open the Bluetooth connection interface

5.4. Create the template locally please reference below picture.

You can use one of label paper, and click Next

5.5 Connect the Bluetooth of TB41 to our printer locally please reference below picture

5.6 Label printing

6.1 Label common

6.1.1 The TP2X2X79 driver

6.1.2 The 3X5C driver

6.1.3 Electronic instruction manual

6.1.4 download and installation driver for guide video

6.2 Warning
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: The equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

6.3 Warning
This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your b

General Troubleshooting :

1. Printer can't be powered on (no light is on) when connecting to power supply.
Please check the power supply and make sure it is the one provided with the printer.

2. Printer does not print when the power is on.
Please check the connection between the printer and computer.

3. Printer is busy or pause.
Please check the printer driver to see if the printer is set to pause printing.

4. Printer is busy or pause.
Please check the printer driver to see if the printer is set to pause printing.

5. Printer is busy or pause.
Please check the printer driver to see if the printer is set to pause printing.

6. Printer is busy or pause.
Please check the printer driver to see if the printer is set to pause printing.

7. Printer is busy or pause.
Please check the printer driver to see if the printer is set to pause printing.

8. Printer is busy or pause.
Please check the printer driver to see if the printer is set to pause printing.

9. Printer is busy or pause.
Please check the printer driver to see if the printer is set to pause printing.

10. Printer is busy or pause.
Please check the printer driver to see if the printer is set to pause printing.

11. Printer is busy or pause.
Please check the printer driver to see if the printer is set to pause printing.

12. Printer is busy or pause.
Please check the printer driver to see if the printer is set to pause printing.

13. Printer is busy or pause.
Please check the printer driver to see if the printer is set to pause printing.

14. Printer is busy or pause.
Please check the printer driver to see if the printer is set to pause printing.

15. Printer is busy or pause.
Please check the printer driver to see if the printer is set to pause printing.

7.1 Set to work the printer via Bluetooth connection?
a) Please check the equipment "Bluetooth" function is powered on or not, and the communication is normal or not, and then try to plug the"Bluetooth adapter" the printer to connect, make it shift to on, please confirm it is the designated transmission mode or not.

b) The printer does not always shut the printer and prohibited.

c) Check to look at both ends are not clean or not, if yes, you please, the need to buy a new one problem, then to the machine which is about the paper, you need to clean.

Users do not need to open the printer to replace them can only problems prevented from it.

d) The connection status is white, please use youll finish to clean the sensor will be can not find the paper can affect printing phenomenal thanks for the designated maintenance point to clean.

7.2 Changes or modifications are expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: The equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

7.3 Warning
This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your b

printer drivers.Read.docx->Preparation->Don't or Select a Tablet->ALL TABLETS

a) Please check the equipment "Bluetooth" function is powered on or not, and the communication is normal or not, and then try to plug the"Bluetooth adapter" the printer to connect, make it shift to on, please confirm it is the designated transmission mode or not.

b) Any printer problems, please refer to the printer troubleshooting manual.

c) Check to look at both ends are not clean or not, if yes, you please, the need to buy a new one problem, then to the machine which is about the paper, you need to clean.

Users do not need to open the printer to replace them can only problems prevented from it.

d) The connection status is white, please use youll finish to clean the sensor will be can not find the paper can affect printing phenomenal thanks for the designated maintenance point to clean.

7.4 Changes or modifications are expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: The equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

7.5 Warning
This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your b

8.1 Add common
a) Choose the connect printers drivers.
b) Designing pages others causes when printing

8.2 Printer appears and appearing settings are common there between the printer and

check if the printer driver Settings are correct or not.

9. Daily maintenance of printer
(1) Usage: Keep away corrosive, or other substances that adhere to the printhead or printer may damage the printhead and shorten its lifetime.
(2) Cleaning printhead:
• Turn off the printer and disconnect the power cord.
• The printhead you can use has a opening. Therefore, if you want to clean the printhead, turn off the printer and wait for the printhead to cool down.
• Use a cotton swab moistened with ethanol to clean the heating line of the print head. Do not scratch the heating line with any other hard objects.
• Wait until the ink is dried or damage the printhead.
(3) Cleaning the platen roller:
• Turn off the printer and disconnect the power cord, and rotate platen roller manually.
• Use a cotton swab moistened with ethanol to wipe off any dirt on the platen roller.
• Rotate the platen roller manually and repeat the above steps until the entire roller is cleaned.
(4) Cleaning the paper path:
• Remove any paper dust or torn paper from the paper path.
(5) Cleaning the sensor:
• If the sensor is dirty or dusty, it may detect errors. Clean the sensor if necessary.
• Clean the sensor with a cotton swab moistened with ethanol.
(6) Cleaning the outside of the printer:
• Use a soft cloth moistened with a small amount of neutral detergent to clean the printer housing. Avoid using volatile solvents such as thinner or benzene, as they can damage the printer's surface.

9.1 Printer problems and solutions

Problem	Solution
Printer power indicator is off	Check the power cord connection.
Printer power indicator is red	Check if the printer is out of paper.
Printer power indicator is green but nothing is printed	Check if the printer is out of paper.
Printer power indicator is green but nothing is printed	Check if the printer is out of paper.
Printer power indicator is green but nothing is printed	Check if the printer is out of paper.
Printer power indicator is green but nothing is printed	Check if the printer is out of paper.
Printer power indicator is green but nothing is printed	Check if the printer is out of paper.
Printer power indicator is green but nothing is printed	Check if the printer is out of paper.
Printer power indicator is green but nothing is printed	Check if the printer is out of paper.
Printer power indicator is green but nothing is printed	Check if the printer is out of paper.