


Support Switch/Switch Lite/PC/IOS/Android Platform

WIRELESS CONTROLLER



手柄说明书

Instructions



- | | | |
|-------------|-------------------------|-----------------|
| ① 截屏键 | ① Screen capture key | ① スクリーンキャプチャボタン |
| ② +音量键 | ② volume button | ② ボリュームボタン |
| ③ L功能键 | ③ L function key | ③ Lボタン |
| ④ 左摇杆L3键 | ④ Left joystick L3 key | ④ L3左スティック |
| ⑤ 方向键 | ⑤ Arrow key | ⑤ 十字ボタン |
| ⑥ TURBO键 | ⑥ TURBO key | ⑥ TURBOボタン |
| ⑦ HOME键 | ⑦ HOME button | ⑦ ホームボタン |
| ⑧ +音量键 | ⑧ + volume keys | ⑧ +ボリュームボタン |
| ⑨ R功能键 | ⑨ R function key | ⑨ Rボタン |
| ⑩ A,B,X,Y键 | ⑩ A,B,X,Y keys | ⑩ A,B,X,Yボタン |
| ⑪ RGB灯控制键 | ⑪ RGB light control key | ⑪ RGBライトボタン |
| ⑫ 右摇杆R3键 | ⑫ Right joystick R3 key | ⑫ R3右スティック |
| ⑬ TYPE C充电口 | ⑬ TYPE C charging port | ⑬ TYPE Cポート |
| ⑭ ZR 功能键 | ⑭ ZR function key | ⑭ Zボタン |
| ⑮ MR 编程键 | ⑮ MR programming key | ⑮ MRプログラミングボタン |
| ⑯ 指示灯 | ⑯ Indicator light | ⑯ インジケータ |
| ⑰ 对码键 | ⑰ Pair key | ⑰ ペ어링ボタン |
| ⑱ ZL 功能键 | ⑱ ZL function key | ⑱ Lボタン |
| ⑲ ML 编程键 | ⑲ ML programming keys | ⑲ MLプログラミングボタン |
| ⑳ 编程开关键 | ⑳ Programming switch | ⑳ プログラムスイッチ |

产品特性

1. 支持switch/switch lite/PC/IOS安卓多平台操作；
2. 一键唤醒主机，快速回连；
3. 内置六轴陀螺仪，丰富方向、跳跃、压感等体感玩法；
4. 内置震动马达自动连发，连发快慢三档可调节；
5. 支持手动连发和自动连发，连发快慢三档可调节；
6. 支持宏编程按键；
7. A/B/X/Y灯设计，多种模式灯光呈现；
8. 支持APP空中升级，APP前置管理 可视化编程。

操作指引

- 1.模式与连接设置**
Switch/Switch Lite/Switch OLED主机连接：长按对码键 3～5秒，手柄LED通速灯闪烁进入蓝牙搜索模式，连接成功后对应的通速指示灯常亮。
注意：手柄进入同步模式后，2.5分钟之内没有同步成功则自动休眠。



1. 以下下载进入手柄设置页面
2. 进入手柄设置模式
3. 长按对码键使用蓝牙连接，进入连接模式。

- 安全连接提示：**长按HOME+X 3～5秒，LED1通速灯闪烁，进入蓝牙搜索模式，连接成功LED1常亮。
注意：长按HOME+A 3～5秒，LED2+LED3通速灯闪烁，进入宏编程模式，连接成功LED2+LED3常亮，支持MP的游戏使用。

2.模式与连接

- 回连：手柄休眠状态，短按HOME（A,B,X,Y,A+O,T/L+R+T）任意一个按键，LED1~LED4渐马闪烁，自动回连主机。
唤醒：主机休眠状态，短按手柄HOME键LED1~LED4渐马闪烁，即可唤醒主机，手柄自动开机连接。

3.体感与唤醒

- 手柄屏幕关闭，手柄自动休眠。
5分钟之内没有按键按下则自动休眠(包括感传震动)。
在连接状态下，按HOME键3秒，即可唤醒主机，即开与主机连接。

4.充电提示

- 充电提示：充电时LED1~LED4慢闪，充满LED亮；
连接状态下充电，当前通速指示灯闪烁（慢闪），充满当前指示灯常亮；
配对后通速充电时，以配对后LED1通速灯常亮。

1


2

- 8.RGB colorful lights**
1. Click the RGB light button to turn on the RGB light, the default is blue light, press once to change the color (blue, red, green, yellow, cyan, orange, purple, pink);
2. Double-click the RGB light button to turn on the monochrome breathing mode, press once to change the color (blue, red, green, yellow, cyan, orange, purple, pink);
3. Double-click the RGB light button again, the RGB light will turn on the breathing mode;
4. Double-click the RGB light button again to turn off the RGB light;

- 9.Adjustment of motor vibration speed (only available to SWITCH)**
In the connected state, press and hold the four keys L, R, L2, R2 at the same time to adjust the motor strength (the handle will vibrate once when you adjust it once); the motor vibration is divided into three levels: strong, medium and weak, and the default is Medium; then strong, weak in this way.

- 10.M key function programming**
M key=MR, ML, programmable keys T/L+R+T/A/B/X/Y/L/R/ZL/ZR/L3/R3; Programming mode:
(1). Default MR mapping RZ, ML mapping LZ;
(2). Setting method: press and hold the M key, then press the programming switch, the indicator light flashes and then release it to enter programming, and then arbitrarily press one or several keys you want to set (T/L+R+T/A/B/X/Y/L/R/ZL/ZR/L3/R3), and then press the M key to save the setting.
For example: press and hold the MR key, then press the programming switch key to enter the programming setting (the indicator light is flashing), then press the A key, and then press the MR key to save the setting. At this time, the MR key corresponds to the A key function.
(3). Press and hold the MR key, the ML key, and the programming key at the same time, and the three keys flash once for 3 seconds to clear the programming.
Note: When entering programming, if you do not press the key that can be programmed, the originally set function will be cleared.

- 11.Handle hardware reset**
When the handle is abnormal, press and hold the HOME button for more than 10 seconds to reset the handle hardware.



6

Handle upgrade (used when the handle is abnormal or when the software is updated)

- 1.Software upgrade**
(1) Double-click the upgrade software to open the interface.
(2) When the handle is turned off, press and hold the left joystick (L3), and connect the handle to the computer through the USB to TYPE-C interface cable.
(3) After the connection is successful, release the left joystick (L3) and lay the handle flat. At this time, the button "Update Firmware" in the update software window changes from gray to operable.
Click "Update Firmware" on the upgrade interface, the handle will be automatically upgraded. After the upgrade is completed, the handle LED1 and LED4 will flash, and the upgrade is successful.

- 2.The way to upgrade APP**
(1) Support KeyLinker APP for air upgrade (APP can be downloaded through the official website or QR code)
(2) APP can modify buttons, adjust joystick sensitivity, Turbo speed adjustment, motor vibration adjustment, macro programming, etc.
(3) This QR code is available for both general Android and IOS systems



- Product parameters**
Working voltage: DC 3.7V
Working current: 25mA~150mA
Sleep current: ≤27uA
Built-in lithium battery: 850mAh
Input charging voltage: 5V
Charging current: ≈350mA
Bluetooth version: 2.1+EDR
Transmission distance: 10M
Port TYPE C interface
Battery life about 10H

商品について

1. Switch / Switch Lite / Switch OLED / Android / IOS 13.0+ / PC に対応
2. フックでスリープを解除，Bluetoothで簡単に接続できます。
3. 6軸ジャイロセンサー搭載，重力感应，ジャンプ，エイムショットなど様々な機能があります。
4. 三段階H20二重振動調整可能です。
5. 三段階調整可能，手動連射モードと自動連射モード二種類の連射モードが搭載しております。
6. マクロプログラミング機能があります。
7. 8色のLEDディスプレイデザイン，複数色照明モードがあります。
8. APPエアアップグレード，APPプリセット，管理およびビジュアルプログラミングをサポートします。

7

操作ガイド

- Switch / Switch Lite / Switch OLEDペアリングボタンを3～5秒間押しすると，コントローラーのLEDチャンネルライトがすばやく点滅しBluetooth検索モードに入り，接続が成功した後は対応するチャンネルライトが常時に点灯します。
注：コントローラーがペアリングモードに入ったら，2.5分以内に接続が成功しなかった場合，コントローラーは自動的にスリープします。



2. コントローラーをオンにして，初期設定の画面に従って接続モードに入ります。最終的に接続すると，通電モードで使用できます。
3. コントローラーをオンにして，初期設定の画面に従って接続モードに入ります。最終的に接続すると，通電モードで使用できます。

- Android:HOME+ X 3～5秒間押し続けると，LED1チャンネルライトがすばやく点滅し，Bluetooth 検索モードに入ります。
接続が成功すると，LED1は常時に点灯します。
APPLE IOS 13.0+:HOME+A 3～5秒間押し続けると，LED2+ 点滅し，Bluetooth検索モードになります。
接続が成功すると，LED2+ LED3が常時に点灯し，MRゲームの使用がサポートされます。

- 2.再接続とホストスリープを解除**
OLED:ペアリングボタンを短く押し続けると，HOME (A,B,X,Y,A+O,T/L+R+T) のいずれかのボタンを短く押すと，LED1~LED4が点滅し，自動的にホストに接続します。
ホストスリープを解除:ホストはスリープ状態にあるコントローラーのHOMEボタンを短く押すと，LED1~LED4が点滅し，ホストスリープを解除でき，ハンドルが自動的にホストに接続します。

- 3.スリープと接続を解除する**
ホストスリープになり，コントローラーが自動的に接続を解除します。
2.フックでスリープを解除，Bluetoothで簡単に接続できます。
3.6軸ジャイロセンサー搭載，重力感应，ジャンプ，エイムショットなど様々な機能があります。
4.三段階H20二重振動調整可能です。
5.三段階調整可能，手動連射モードと自動連射モード二種類の連射モードが搭載しております。
6.マクロプログラミング機能があります。
7.8色のLEDディスプレイデザイン，複数色照明モードがあります。
8.APPエアアップグレード，APPプリセット，管理およびビジュアルプログラミングをサポートします。

8

- 5.低电压提醒**
电池电压低于3.35V±0.1V时当前通速灯闪烁提示电压；
电池电压低于3.45V±0.1V时自动休眠；
低电压提醒：当前通速指示灯闪烁(快闪)

- 6.Turbo功能**
a.手动连发设置：（第一次）任意按（A/B/X/Y/L/ZL/R/ZR）一个或几个动作键，再按TURBO键，开启手动连发功能；
b.自动连发设置：（第二次）再次按下已开启手动连发功能的动作键，并再按TURBO键，开启自动连发功能；
c.清除连发设置：（第三次）再次按下已开启自动连发功能的动作键，并再按TURBO键，清除连发功能；
清除连发后，先按住TURBO键3秒以上再按“-”号键，清除所有按键的TURBO功能。
TURBO速度调节：T键与十字键上（UP）是加快速度；T键与十字键下（DOWN）是减慢速度；速度为8Hz,12Hz,15Hz,默认12Hz。

- 7.有线连接**
PC主机连接：请使用USB数据线将手柄连接，然后插入电脑连接后手柄LED3通速常亮。（注意：手柄在PC端默认X-INPUT模式）
Switch/Switch Lite/Switch OLED主机连接：请使用USB数据线连接手柄和Switch Switch Lite主机，连接后手柄上对应的LED灯常亮

- 8.RGB炫彩灯**
1. 单击RGB灯按键，开启RGB灯，按一次变一次颜色（蓝，红，绿，黄，青，橙，紫，粉）；
2. 双击RGB灯按键，开启单色呼吸模式，按一次变一次颜色（蓝，红，绿，黄，青，橙，紫，粉）；
3. 再次双击RGB灯按键，RGB灯灯开呼吸模式；
4. 再次双击RGB灯按键，RGB灯关闭；

- 9.马达震动速度的调整（仅针对SWITCH可用）**
在连接状态下，同时按住L,R,L2,RZ四个键，进行马达速度调节（调节一次手柄会震动一次）；
此速度调节分为强、中、弱三个级别，每次上电都默认为中，然后最强，弱这样的方式进行循环。

- 10.M键自定义编程**
M键=MR, ML；可设定编程的按键 T/L+R+T/A/B/X/Y/L/R/ZL/ZR/L3/R3；编程模式：
(1) 默认MR键映射RZ, ML映射LZ；
(2) 设置方法：按住MR不放，再按编程开关指示灯闪烁后进入编程，再任意按一个或多个想要设置的按键（T/L+R+T/A/B/X/Y/L/R/ZL/ZR/L3/R3），再按M键保存设置完成。

- 例如：按住MR键不放，再按编程开关键进入编程设置（指示灯闪烁），再按下A键，再按MR键保存设置完成。此时MR键对应的功能就是A键功能。

- 11.手柄硬件复位**
当手柄出现异常时，长按HOME键超过10秒，手柄硬件复位。



手柄升级（手柄出现异常时或软件更新时使用）

- 一.软件方式升级**
(1) 双击升级按钮，打开界面。
(2) 手柄关机状态下，按住左摇杆（L3）不放，通过USB转TYPEC接口线连接手柄至电脑。
(3) 连接成功后，松开左摇杆（L3），手柄激活，此时升级软件窗口出现"Update Firmware"由灰色变为可操作。
点击升级界面"Update Firmware"手柄会自动升级，升级完成后手柄LED1,LED4闪烁，升级成功。

- 二.APP方式升级**
(1) 支持KeyLinker APP升级（APP可通过官网或二维码下载）
(2) APP可以进行修改按键，调节摇杆灵敏度，Turbo速度调节，马达震动调节，宏编程等
(3) 此二维码为通用型安卓及IOS系统都可



产品参数

- 工作电压: DC 3.7V
工作电流: 25mA~150mA
休眠电流: ≤27uA
内置锂电池: 850mAh
输入充电电压: 5V

- 充电电流: ≈350mA
蓝牙版本: 2.1+EDR
传输距离: 10M
接口: TYPE C接口
续航时长: 约10小时


Product Features

1. Support switch/switch lite/PC/IOS/Android multi-platform operation;
2. One key to wake up the host and quickly connect back;
3. Built-in six-axis gyroscope, rich in direction, jumping, gun pressing and other somatosensory gameplay;
4. Built-in asymmetric motor vibration, three gears adjustable;
5. Support manual burst and automatic burst, the burst speed can be adjusted in three gears;
6. Support macro programming back key;
7. Eight-color LED breathing light design, multi-mode lighting presentation;
8. Support APP air upgrade, APP preset management and visual programming.

Operation guide

- 1. Mode and connection instructions**
Switch / Switch Lite / Switch OLED host connection: Long press the pairing key for 3-5 seconds, the LED channel light of the handle flashes will quickly enter the Bluetooth search mode, and the corresponding channel light is always on after the connection is successful.

- Note:** After the controller enters the sync mode, it will automatically sleep if it is not successfully synced within 2.5 minutes.



- Android handle connection:** long press HOME+A for 3-5 seconds, the LED1 channel light flashes quickly to indicate that the voltage is low; When the battery voltage is lower than 3.45V±0.1V, it will automatically sleep; Low voltage alarm: the current on indicator flashes (fast flashing)

- Apple IOS 13 and above mode connection:** long press HOME+A for 3-5 seconds, LED2+LED3 channel light flashes quickly, enter the Bluetooth search mode, after the connection is successful, LED2+LED3 is always on, supporting MP game use.

- Android handle connection:** Please use a USB data cable to connect to the handle, and then plug it into the computer to connect, and the handle LED3 channel is always on. (Note: The handle defaults to X-INPUT mode on the PC side)
Switch / Switch Lite / Switch OLED host connection: Please use a USB data cable to connect the handle and the Switch / Switch Lite host, the corresponding LED light on the handle is always on after connection

4

- FCC Statement**
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
• Reorient or relocate the receiving antenna.
• Increase the separation between the equipment and receiver.
• Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
• Consult the dealer or an experienced radio/TV technician for help.
Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

- RF Exposure Information**
The device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure condition without restriction.

コントローラーソフトウェアのアップグレード（ハンドルが異常な場合、またはソフトウェアが更新された場合に使用）

- コントローラーのアップグレード**
(1) アップグレードソフトウェアをダブルクリックし、インタフェースを開きます。
(2) コントローラーがシャットダウンした状態で、左ジョイスティック(L3)を押したまま、USB-TYPE C インターフェイスケーブルでコントローラーをコンピュータに接続します。
(3) 接続が成功した後、左ジョイスティック(L3)を放して、コントローラーを完全に充電し、アップグレードソフトウェアウィンドウを開きます。Update Firmware がグレーから操作可能となります。アップグレードインターフェースは Update Firmware をクリックするとコントローラーが自動的にアップグレードされ、アップグレードが完了するとコントローラー LED1, LED4 が点滅し、アップグレードに成功します。

- 二.APPでコントローラーソフトウェアのアップグレード**
(1) エアアップグレード用のKeyLinkerAPPをサポートします (APPは公式WebサイトまたはQRコードからダウンロードできます)
(2) APPは、ボタンの変更、ジョイスティックの感度の調整、TURBO連射速度的調整、振動モーターの強弱の調整、マクロプログラミングなどを行うことができます。
(3) 以下のQRコードは、一般的なAndroidおよびIOSシステムで使用できます



製品パラメータ

- 動作电压:DC 3.7V
動作電流:25mA~150mA
充電電流: ≈350mA
充電電圧: 5V
充電電圧: 5V

- 充電電流: 約350mA
Bluetoothバージョン:2.1+EDR
伝送距離: 10M
TYPE C 充電ポート
バッテリーは約10時間使用

10

EN

- 2. Reconnect and wake up**
Reconnection: In the sleep state of the handle, short press HOME (A,B,X,Y,A+O,T/L+R+T) any button LED1~LED4 will flash and automatically return to the host.
Wake up: The host is in hibernation state, short press the handle HOME button LED1~LED4 to flash, you can wake up the host, and the handle is automatically connected to the host.

- 3. Sleep and disconnect**
The host screen is turned off, and the handle automatically sleeps.
If no button is pressed within 5 minutes, it will automatically sleep (including the sensor does not move).
In the wireless connection state, press the HOME button for 5 seconds to disconnect from the host.

- 4. Charging indication**
When the handle is turned off, LED1~LED4 will flash slowly when charging, and the LED will be off when fully charged;
When charging in the connected state, the current channel indicator flashes (slowly flashing), and the current indicator is always on when fully charged;
When pairing, reconnecting to charging or low power, the pairing, reconnecting LED indication takes priority.

- 5. Low voltage alarm**
When the battery voltage is lower than 3.65V±0.1V, the current channel light flashes quickly to indicate that the voltage is low;
When the battery voltage is lower than 3.45V±0.1V, it will automatically sleep; Low voltage alarm: the current on indicator flashes (fast flashing)

- 6. Turbo function**
A. Manual burst setting: (for the first time) press one or more action keys (A/B/X/Y/L/ZL/R/ZR), and then press the TURBO button to enable the manual burst function;
B. Automatic burst setting: (for the second time) press the action key that has turned on the manual burst function again, and press the TURBO button again to turn on the automatic burst function;
C. Clear burst settings: (for the third time) press the action key that has turned on the automatic burst function again, and press the TURBO button again to clear the burst function;
Clear all bursts: first press and hold the TURBO button for more than 3 seconds and then press the " " button to clear the TURBO function of all buttons.
TURBO speed adjustment: the T key and the cross key up (UP) are to increase the speed; the T key and the cross key down (DOWN) are to slow down the speed; the speed is divided into 8Hz, 12Hz, 15Hz; the default is 12Hz.

- 7. Wired connection**
PC host connection: Please use a USB data cable to connect to the handle, and then plug it into the computer to connect, and the handle LED3 channel is always on. (Note: The handle defaults to X-INPUT mode on the PC side)
Switch / Switch Lite / Switch OLED host connection: Please use a USB data cable to connect the handle and the Switch / Switch Lite host, the corresponding LED light on the handle is always on after connection

5