RK ROYAL KLUDGE

USER MANUAL

English / Español / Русский / Deutsch
Français / 한국어 / Türkçe / ภาษาไทย

CONTENTS

English 1
Español 2
Русский 3
Deutsch 4
Français 5
한국어 6
Türkçe 7
ภาษาไทย 8

Package list

Keyboard

1	Keyboard
2	Keycap puller
3	Switch puller
4	Type-C cable
5	User manual

Quick start

1. Power on/off
Slide the red key to green side ▶.

Disconnect ☒

Fn + Esc

Slide the red key to green side ▶.

Quick Start

Hello!
Thank you for using your ROYAL KLUDGE keyboard. Before using, please read this manual carefully to ensure you can use the keyboard correctly.

Connecting

Wired mode
Connect the keyboard to the computer with the Type-C cable.

Bluetooth mode
Step 1: Turn on the keyboard and switch to Bluetooth mode.
Step 2: Search for "RK ROYAL KLUDGE" on the device you want to connect.
Step 3: Click to connect.

Connecting

Wired mode
Connect the keyboard to the computer with the Type-C cable.

Bluetooth mode
Step 1: Turn on the keyboard and switch to Bluetooth mode.
Step 2: Search for "RK ROYAL KLUDGE" on the device you want to connect.
Step 3: Click to connect.

Switch Bluetooth device

Fn+1	Switch to Bluetooth device 1
Fn+2	Switch to Bluetooth device 2
Fn+3	Switch to Bluetooth device 3
Fn+4	Switch to 2.4G mode

Switch operating system

Fn+Left Win	Switch to Windows system
Fn+Right Win	Switch to Mac system

Switch Bluetooth device

Fn+1	Switch Bluetooth device 1
Fn+2	Switch Bluetooth device 2
Fn+3	Switch Bluetooth device 3
Fn+4	Switch to 2.4G mode

Switch operating system

Fn+Left Win	Switch to Windows system
Fn+Right Win	Switch to Mac system

Wireless connection

Wired connection: Use the Type-C cable to connect the keyboard to the computer.

Charging

Charging
Use the Type-C cable to connect the keyboard to the computer for charging.

Battery level
Press Fn + Home to check the battery level.

Low battery
When the battery is low, the Caps Lock indicator will flash red.

Charging

Charging
Use the Type-C cable to connect the keyboard to the computer for charging.

Battery level
Press Fn + Home to check the battery level.

Low battery
When the battery is low, the Caps Lock indicator will flash red.

Backlight

Backlight mode
Press Fn + Insert to switch backlight mode.

Backlight brightness
Press Fn + ↑ to increase backlight brightness.
Press Fn + ↓ to decrease backlight brightness.

Backlight speed
Press Fn + → to increase backlight speed.
Press Fn + ← to decrease backlight speed.

Backlight

Backlight mode
Press Fn + Insert to switch backlight mode.

Backlight brightness
Press Fn + ↑ to increase backlight brightness.
Press Fn + ↓ to decrease backlight brightness.

Backlight speed
Press Fn + → to increase backlight speed.
Press Fn + ← to decrease backlight speed.

Backlight mode list

Fn+1	Static backlight
Fn+2	Breathing backlight
Fn+3	Neon backlight
Fn+4	Wave backlight
Fn+5	Ripple backlight
Fn+6	Raindrop backlight
Fn+7	Snake backlight
Fn+8	Reactive backlight
Fn+9	Converge backlight
Fn+0	Sunny backlight
Fn+-	Rain backlight
Fn+=	Custom backlight

Backlight mode list

Fn+1	Static backlight
Fn+2	Breathing backlight
Fn+3	Neon backlight
Fn+4	Wave backlight
Fn+5	Ripple backlight
Fn+6	Raindrop backlight
Fn+7	Snake backlight
Fn+8	Reactive backlight
Fn+9	Converge backlight
Fn+0	Sunny backlight
Fn+-	Rain backlight
Fn+=	Custom backlight

Backlight list (Windows system)

Fn+F1	Screenshot
Fn+F2	Calculator
Fn+F3	Explorer
Fn+F4	Lock PC
Fn+F5	Email
Fn+F6	Settings
Fn+F7	Media
Fn+F8	Previous
Fn+F9	Play/Pause
Fn+F10	Next
Fn+F11	Mute
Fn+F12	Volume-
Fn+Del	Volume+

Backlight list (Windows system)

Fn+F1	Screenshot
Fn+F2	Calculator
Fn+F3	Explorer
Fn+F4	Lock PC
Fn+F5	Email
Fn+F6	Settings
Fn+F7	Media
Fn+F8	Previous
Fn+F9	Play/Pause
Fn+F10	Next
Fn+F11	Mute
Fn+F12	Volume-
Fn+Del	Volume+

Backlight list (Mac system)

Fn+F1	Brightness-
Fn+F2	Brightness+
Fn+F3	Mission Control
Fn+F4	Launchpad
Fn+F5	Backlight-
Fn+F6	Backlight+
Fn+F7	Previous
Fn+F8	Play/Pause
Fn+F9	Next
Fn+F10	Mute
Fn+F11	Volume-
Fn+F12	Volume+

Backlight list (Mac system)

Fn+F1	Brightness-
Fn+F2	Brightness+
Fn+F3	Mission Control
Fn+F4	Launchpad
Fn+F5	Backlight-
Fn+F6	Backlight+
Fn+F7	Previous
Fn+F8	Play/Pause
Fn+F9	Next
Fn+F10	Mute
Fn+F11	Volume-
Fn+F12	Volume+

Macro recording and playback (Windows system)

Start recording: Press Fn + Left Win + Record key (F1-F12) to start recording.
Stop recording: Press Fn + Left Win + Record key (F1-F12) to stop recording.
Playback: Press Record key (F1-F12) to play back the recorded macro.
Clear: Press Fn + Left Win + Record key (F1-F12) to clear the recorded macro.

Macro recording and playback (Windows system)

Start recording: Press Fn + Left Win + Record key (F1-F12) to start recording.
Stop recording: Press Fn + Left Win + Record key (F1-F12) to stop recording.
Playback: Press Record key (F1-F12) to play back the recorded macro.
Clear: Press Fn + Left Win + Record key (F1-F12) to clear the recorded macro.

Macro recording and playback (Mac system)

Start recording: Press Fn + Option + Record key (F1-F12) to start recording.
Stop recording: Press Fn + Option + Record key (F1-F12) to stop recording.
Playback: Press Record key (F1-F12) to play back the recorded macro.
Clear: Press Fn + Option + Record key (F1-F12) to clear the recorded macro.

Macro recording and playback (Mac system)

Start recording: Press Fn + Option + Record key (F1-F12) to start recording.
Stop recording: Press Fn + Option + Record key (F1-F12) to stop recording.
Playback: Press Record key (F1-F12) to play back the recorded macro.
Clear: Press Fn + Option + Record key (F1-F12) to clear the recorded macro.

Factory reset

Press Fn + Esc + Backspace for 3 seconds to restore factory settings.

Factory reset

Press Fn + Esc + Backspace for 3 seconds to restore factory settings.

Factory reset list

Fn+Left Win	Switch to Windows system
Fn+Right Win	Switch to Mac system
Fn+1	Switch Bluetooth device 1
Fn+2	Switch Bluetooth device 2
Fn+3	Switch Bluetooth device 3
Fn+4	Switch to 2.4G mode
Fn+Esc+Backspace	Factory reset

Factory reset list

Fn+Left Win	Switch to Windows system
Fn+Right Win	Switch to Mac system
Fn+1	Switch Bluetooth device 1
Fn+2	Switch Bluetooth device 2
Fn+3	Switch Bluetooth device 3
Fn+4	Switch to 2.4G mode
Fn+Esc+Backspace	Factory reset

Software

Software download
Visit the official website to download the software.

Software features
Customize keyboard backlight, macros, and more.

Software

Software download
Visit the official website to download the software.

Software features
Customize keyboard backlight, macros, and more.

Troubleshooting

Keyboard not responding
Check if the battery is low.
Check if the connection is normal.
Restart the keyboard.

Bluetooth connection failed
Check if Bluetooth is enabled.
Delete the old pairing record and reconnect.
Restart the keyboard.

Troubleshooting

Keyboard not responding
Check if the battery is low.
Check if the connection is normal.
Restart the keyboard.

Bluetooth connection failed
Check if Bluetooth is enabled.
Delete the old pairing record and reconnect.
Restart the keyboard.

Warranty

Thank you for choosing ROYAL KLUDGE keyboard. We provide a 2-year limited warranty for this product.

Warranty Coverage
- Manufacturing defects
- Non-human damage

Warranty Exclusions
- Damage caused by improper use
- Damage caused by disassembly
- Damage caused by liquid
- Damage caused by natural disasters

Warranty

Thank you for choosing ROYAL KLUDGE keyboard. We provide a 2-year limited warranty for this product.

Warranty Coverage
- Manufacturing defects
- Non-human damage

Warranty Exclusions
- Damage caused by improper use
- Damage caused by disassembly
- Damage caused by liquid
- Damage caused by natural disasters

Contact us

Email: support@royalkludge.com
Website: www.royalkludge.com

Contact us

Email: support@royalkludge.com
Website: www.royalkludge.com

RK ROYAL KLUDGE

Model: RK84 / RK84 Pro / RK84 Wireless
Size: 312.8*109.5*38.5mm
Weight: 0.8kg (without cable)
Battery: 4000mAh Li-ion
Connectivity: Bluetooth 5.1 / 2.4G / Wired
Backlight: RGB
Switch: Hot-swappable
Keycaps: PBT Double-shot
Compatibility: Windows / Mac / Android / iOS