

72.23 mm

129.83 mm

PORTABLE GENERATOR

Type: MP330

Battery capacity: 11.1V, 26Ah, 288.6Wh

DC input: 12V~24V=3A

DC output×2: 12.0V=5A

Cigarette lighter output: 12.0V=10A

USB-A output x3: 5V=2.5A, 9V=2A, 12V=1.5A

Type-C output: 5V~3A, 9V~3A, 12V~3A
15V~3A, 20V~3A(60W max.)

AC output: pure sine wave, 110V~60Hz, 330W

Wireless charge: 5W

Production date:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC ID : 2A4UPMP330MV1000



Made in China
株式会社 奉成商事
TaSeiyouji Co.,Ltd

WARNING!

1. Do not short-circuit the unit. To avoid short-circuiting, keep the unit away from all metal objects (e.g. coins, hair-pins, keys, etc.)
2. Do not heat the unit, or dispose of it in fire, water or other liquids. Keep away from high temperatures. Do not expose the unit to direct sunlight.
3. Keep away from high humidity, dusty places.
4. Do not disassemble or reassemble.
5. Do not place heavy objects on, or allow strong impact to this unit.
6. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
7. Children should be supervised to ensure that they do not play with the appliance.
8. The temperature of the internal battery is normal. Use caution when handling.
9. Use the unit properly to avoid electronic shock.
10. The product is only used for emergency power station. It can not replace the standard DC or AC power of household appliances or digital products.
11. Do not overcharge the internal battery. See Instruction Manual.

AVERTISSEMENT!

1. Ne court-circuitez pas l'appareil. Pour éviter tout court-circuit, éloignez l'appareil de tout objet métallique (par exemple, pièces de monnaie, épingle à cheveux, clés, etc.).
2. Ne chauffez pas l'appareil, ne le jetez pas dans l'eau ou d'autres liquides. Tenir à l'écart des températures élevées. N'exposez pas l'appareil à la lumière directe du soleil.
3. Tenir à l'écart des endroits humides et poussiéreux.
4. Ne démontez pas et ne reassemblez pas cet appareil.
5. Ne placez pas d'objets lourds sur cet appareil et ne laissez pas de chocs violents sur cet appareil.
6. Cet appareil est destiné à être utilisé par des personnes (y compris des enfants) ayant des capacités physiques, sensorielles ou mentales réduites, ou un manque d'expérience et de connaissances, à moins qu'elles n'aient reçu une supervision ou des instructions concernant
7. Utilisez l'appareil correctement pour une personne responsable de leur sécurité.
8. Les enfants doivent être surveillés pour s'assurer qu'ils ne jouent pas avec l'appareil.
9. L'appareil peut devenir chaud pendant la charge. C'est normal. Soyez prudent lors de la manipulation de l'appareil.
10. Utilisez l'appareil correctement pour éviter les chocs électriques. Le produit n'est utilisé que pour la centrale électrique de secours. Il ne peut pas remplacer la puissance DC ou CA standard des appareils ménagers ou des produits numériques.
11. Ne pas surcharger la batterie interne. Consulter le manuel d'utilisation.

Label positions

