


Vibrator



Material: ABS + Silikon
 Feature: 7 Schlagmodi und 10 Vibrationsmodi
 Ladezeit: ca. 90 Minuten
 Arbeitszeit: ca. 60 Minuten
 Rauschen: 50 - 52 DBS
 Produktgröße: 128 mm (L) * 78 mm (B) * 41,5 mm (H)
 Remote-Größe: 66 mm (L) * 46 mm (B)
 Wasserdichtes Niveau: IPX7 wasserdicht
 Paketliste: Vibrator * 1, Ladekabel * 1, Instructions * 1

 Halten Sie die Taste 1,5 Sekunden lang gedrückt, um den Vibrator ein- und auszuschalten. (Blaues Licht ein / aus)

 Kurz drücken, um den Vibration & Impact-Modus zu wechseln. (Insgesamt 10 verschiedene Vibrationsfrequenzen und Schlagmodi)

- ⌚ Halten Sie die Taste 1,5 Sekunden lang gedrückt, um die Fernbedienung ein- und auszuschalten. (Weißes Licht ein / aus)
- ➕ Kurz drücken, um die Vibrationsmodi einzuschalten und zu steuern.
- ⌚ Halten Sie die Taste 1,5 Sekunden lang gedrückt, um die Vibrationsmodi auszuschalten.
- ➖ Kurz drücken, um die Impact-Modi einzuschalten und zu steuern.
- ⌚ Halten Sie die Taste 1,5 Sekunden lang gedrückt, um die Impact-Modi auszuschalten.

- ◆ Bitte vor Gebrauch voll aufladen.
- ◆ Bitte desinfizieren Sie das Produkt vor und nach jedem Gebrauch, waschen Sie es mit warmem Wasser und antibakterieller Seife und trocknen Sie es vorsichtig mit einem Handtuch oder einem weichen Tuch ab.
- ◆ Bitte verwenden Sie kein Massageöl, Handcreme, Waschmittel, Benzin oder Aceton als Gleitmittel.
- ◆ (Es wird nicht empfohlen, lange Zeit Alkohol zu verwenden, da Alkohol die Oberfläche des Produkts angreift und das Altern des Spielzeugs beschleunigt.).

- ◆ Bitte teilen Sie dieses Produkt nicht mit anderen, um Ihre Gesundheit zu schützen.
- ◆ Wenn Sie sich unwohl und allergisch fühlen, stellen Sie die Anwendung sofort ein.
- ◆ Es wird empfohlen, mit Schmiermittel zu verwenden.
- ◆ Wenn der Kopf des Produkts nicht glatt genug ist oder scharfe Ecken aufweist, verwenden Sie das Produkt sofort nicht mehr und setzen Sie sich mit uns in Verbindung.
- ◆ Bitte halten Sie das Produkt von Kindern und Haustieren fern.

Es ist unsere oberste Priorität, unseren Kunden den besten Service zu bieten.

Sollten Sie ein defektes Produkt erhalten oder Fragen oder Anregungen haben, setzen Sie sich bitte umgehend mit uns in Verbindung.

Wir bieten Rückerstattung / ersatz Service.

(Nachricht Antwort innerhalb von 24 Stunden)

Vielen Dank für Ihren Einkauf und Ihre Unterstützung!
Sie erhalten von uns ein kostenloses Geschenk.
Wenn Sie an diesem Geschenk interessiert sind,
Bitte kontaktieren Sie uns über die folgende E-Mail:
E-Mail: support@outaole.com

材質：ABS+シリカゲル

製品性能：7つ衝撃モードと10種類振動モード

充電時間：約90分


使用時間：約60分

ノイズ：50-52 D

製品サイズ：161 mm(L)X 141 mm(W)X 39 mm(H)4

防水グレード：IPX 7 防水

パッケージ内容：マッサージ器、充電ケーブル、説明書、
リモコン



Gスポットとクリトリスの 刺激バイブレーター

🔌 バイブレータのオン/オフを切り替えるには、1.5秒押し
続けます。(ブルーライトのオン/オフ)

🔌 短く押すと、振動モードと衝撃モードが切り替わります。
(合計10種類の振動周波数と衝撃モード)

- 1.5秒押し続けます。(白色光のオン/オフ)
- ➔ 短く押して、振動モードをオンにして制御します。
- ➔ 振動モードをオフにするには、1.5秒押し続けます。
- ➔ 短押しでインパクトモードをオンにして制御します。
- ➔ インパクトモードをオフにするには、1.5秒押し続けます。

- ◆ 注意事項使用前に充電してください。
- ◆ 使用するたびに製品を消毒処理し、温水と抗菌石鹸で洗う、タオルや敷布で軽く乾かしてください。
- ◆ マッサージオイル、ハンドクリーム、クリーナー、ガソリンまたはプロパンガスなどを潤滑油とすることは禁止されています。
- ◆ 洗浄時には、ぬるま湯や石鹸で拭くことができます。大人のおもちゃの専用洗剤、消毒液または75%アルコールを配合して消毒することをお勧めします(アルコールの長期使用はお勧めできません)。アルコールはおもちゃの表面を腐食させ、おもちゃの老化を加速させます)。
- ◆ ほこりのないところに保存して他の材質のものに触れないようにしてください。

- ◆本製品は個人用品で、あなたの健康のために、多くの人を混用しないでください。
- ◆このマッサージ器は異なる頻度の振動があり、ユーザーによって求められ、不快感やアレルギーを感じた場合は、すぐに使用を停止してください。
- ◆潤滑剤を使用することをお勧めします。
- ◆使用中に不快感を感じた場合は、直ちに使用を停止してください。
- ◆製品を子供やペットから遠ざけてください。


お客様に最高のサービスを提供することが第一の任務です。
何か問題やアドバイスがありましたら、いつでもご連絡ください。
払い戻し/交換サービスを提供しています。(24時間以内のメッセージ返信)

ご購入ありがとうございます！
あなたは私たちから無料の贈り物を受け取ります。
この贈り物に興味があるなら、
以下のメールでお問い合わせください：
メール：support@outaole.com

Please take a few minutes to read this manual carefully before using this product.

Vibrator

Material: ABS + Silicone
 Feature: 7 Impact Modes & 10 Vibration Modes
 Charging Time: About 90 Minutes
 Working Time: About 60 Minutes
 Noise: 50 - 52 DBS
 Product Size: 128mm(L) * 78mm(W) * 41.5mm(H)
 Remote Size: 66mm(L) * 46mm(W)
 Waterproof Level: IPX7 Waterproof
 Package List: Vibrator * 1, Charging cable * 1, Instructions * 1



🔊 Press and hold for 1.5S to turn on / off the Vibrator.
(Blue light on / off)

🔊 Short press to switch the Vibration & Impact Modes.
(Totally 10 different vibration frequencies & Impact modes)

- Press and hold for 1.5S to turn on / off the Remote control.
(White light on / off)
- + Short press to turn on & control the Vibration modes.
- + Press and hold for 1.5S to turn off the Vibration modes.
- Short press to turn on & control the Impact modes.
- Press and hold for 1.5S to turn off the Impact modes.

- ◆ Please fully charged before using
- ◆ Please disinfect the product before and after each use, and wash the product with warm water and antibacterial soap, and dry gently with a towel or a soft cloth.
- ◆ Please do not use massage oil, hand cream, detergent, gasoline or acetone as lubricant.
- ◆ It can be washed with warm water and soap. It is recommended to use the special cleaning detergent for sex toys, disinfectant or 75° alcohol for disinfection.
(It is not recommended to use alcohol for a long time because alcohol will corrode the surface of the product and accelerate the aging of the toy).
- ◆ Please keep the product in a dust-free place and do not touch objects of other materials.

- ◆ Please do not share the product with others in order for your health.
- ◆ This product has different vibration & Impact modes for different user needs. If you feel unwell and allergic, please stop using it immediately.
- ◆ It is recommended to use with lubricant.
- ◆ If the head of the product is not smooth enough or has sharp corners, please stop using the product immediately and contact us.
- ◆ Please keep the product away from children and pets.

It is our top priority to give our customers the best service.
In case, if you receive a defective product or have any questions
or suggestions, please contact us immediately.
We offer refund / replacement Service.
(Message reply within 24 Hours)

Thank you for your purchase and supporting!
You will receive a free gift from us.
If you are interested in this gift,
please contact us via below Email:
Email: support@outaole.com

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement.