FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device and its antenna must not be co-located or operating in conjunction with any other antenna or transmitter.

萨克斯无线系统

用户手册/指南

IMP-130Plus

Guangzhou DK Electronic Technology Co., Ltd.
Address: Room 1201, Building 1, No. 1, Jinxiu Road, Yuexiu District, Guangzhou, Guangdong, China
Tel: +86 020-38104001
Fax: +86 020-38104000

Made in China

广州市数码科技有限公司
Guangzhou DK Electronic Technology Co., Ltd.
地址：广州市越秀区环市东路338号之一
电话：+86 020-38104001 传真：+86 020-38104000
网址：www.dk-music.cn

产品介绍

- 立体声
- 内置锂电池（可充电）
- 5.8GHz 无线数字传输技术
- 自动配对技术
- 5一对一无干扰
- 无延迟（≤3ms）
- 27pcs CR2 纽扣电池

Product Specifications

Product Name: DK Saxophone Wireless System
Model: IMP-130Plus
Transmitter Frequency: 2.4GHz ISM band (2401.5MHz~2481.5MHz)
Transmitter Power: ≤10dBm
Receiver Sensitivity: ≤-90dBm
Transmitter Range: ≤ 100m (Open area)
Latency: ≤3ms
Battery: Li-ion
Charging Time: 2.5H
Working Time: 6H
Charging Port: Type-C
Dimensions: 70.5*30.5*19.5mm
Weight: 30g

Transmitter Battery Capacity: 3.7V 80mAh
Receiver Battery Capacity: 3.7V 80mAh
Battery Life: 27pcs CR2 coin cell batteries
Operating Temperature: -10°C ~ 45°C
Storage Temperature: -20°C ~ 60°C
Humidity: 10% ~ 90%

Safety Guidelines

1. Before installation, please read this manual carefully and keep it properly for future reference.
2. Please use the power supply and battery specified in this manual. It needs to be charged and maintained according to the method.
3. Please do not disassemble, repair, or modify the product by yourself. Please contact our after-sales personnel, otherwise, the warranty will be void.
4. Store the product in a cool and ventilated place, avoid direct sunlight, and keep away from heat sources and flammable and explosive materials.
5. Please do not use the product in a humid environment. Avoid exposure to rain, moisture, and liquid splashes.
6. Please do not use the product in a dusty environment. Dust may cause damage to the product's electronic components.
7. Please do not use the product in extreme temperature environments. The ideal operating temperature is between 0°C and 40°C (32°F and 104°F). Extreme temperatures can affect the performance of the battery and electronic components.
8. Please do not drop, hit, or shake the product violently, as this may damage the internal circuit boards and components.
9. Please do not use the product near strong electromagnetic interference sources, such as microwave ovens, high-power radio transmitters, etc., to avoid affecting the product's signal transmission.
10. Please do not use the product for a long time at high volume, as this may cause hearing damage. It is recommended to take breaks and control the volume appropriately.
11. Please do not use the product while driving or operating machinery, to ensure safety.
12. Please do not use the product near children or pets to prevent accidental swallowing or damage to the product.
13. Please do not use the product in environments with strong vibrations, such as engine compartments or construction sites, to avoid damage to the product's internal components.
14. Please do not use the product in environments with strong magnetic fields, such as near magnets or magnetic devices, to avoid affecting the product's performance.
15. If the product is damaged, deformed, or malfunctioning, please stop using it immediately and contact our after-sales service for repair or replacement.

Quality Assurance

Dear User,

Thank you for purchasing our product. We provide a one-year quality assurance service for this product. If any quality issues occur during normal use within the warranty period, please contact our after-sales service. We will repair or replace the product for you free of charge.

Please note that the following situations are not covered by the warranty:

- Damage caused by improper use, such as dropping, impact, or exposure to water.
- Damage caused by unauthorized disassembly, repair, or modification.
- Damage caused by natural disasters, accidents, or force majeure.
- Damage caused by normal wear and tear.

We appreciate your understanding and support. If you have any questions or need assistance, please feel free to contact us.

Sincerely,
Guangzhou DK Electronic Technology Co., Ltd.

Certificate of Quality

Product Name: Saxophone Wireless System
Model: IMP-130Plus
Inspector:
Date:

安装图解及方法

1.拆开包装盒，将发射器和接收器从包装盒中取出。

2.将发射器插入萨克斯乐器的出音口，确保连接稳固。

3.将接收器插入音箱或调音台的输入接口，确保连接稳固。

4.将发射器和接收器的开关拨至“ON”位置，开启设备。

5.调节音量至合适水平，即可开始演奏。

质量保证

亲爱的用户：

感谢您购买我们的产品。我们为该产品提供一年的质量保证服务。在正常使用过程中，如果在保修期内出现任何质量问题，请联系我们的售后服务。我们将为您免费维修或更换产品。

请注意，以下情况不在保修范围内：

- 因不当使用（如摔落、撞击、接触水）造成的损坏。
- 因未经授权的拆卸、维修或改装造成的损坏。
- 因自然灾害、意外事故或不可抗力造成的损坏。
- 因正常磨损造成的损坏。

感谢您的理解与支持。如有任何疑问或需要帮助，请随时与我们联系。

此致，
敬礼！

广州市数码科技有限公司

质量合格证

产品名称：萨克斯无线系统
型号：IMP-130Plus
检验员：
日期：

产品介绍

- 立体声
- 内置锂电池（可充电）
- 5.8GHz 无线数字传输技术
- 自动配对技术
- 5一对一无干扰
- 无延迟（≤3ms）
- 27pcs CR2 纽扣电池

产品规格

产品名称：萨克斯无线系统
型号：IMP-130Plus
发射器频率：2.4GHz ISM 频段（2401.5MHz~2481.5MHz）
发射器功率：≤10dBm
接收器灵敏度：≤-90dBm
发射距离：≤ 100m（开阔区域）
延迟时间：≤3ms
电池类型：锂电池
充电时间：2.5H
续航时间：6H
充电接口：Type-C
尺寸：70.5*30.5*19.5mm
重量：30g

发射器电池容量：3.7V 80mAh
接收器电池容量：3.7V 80mAh
电池寿命：27pcs CR2 纽扣电池
工作温度：-10°C ~ 45°C
存储温度：-20°C ~ 60°C
湿度：10% ~ 90%

安全指南

1. 安装前请仔细阅读本手册，并妥善保存以备将来参考。
2. 请使用本手册中指定的电源和电池。按照规定的方法进行充电和维护。
3. 请勿自行拆卸、维修或改装产品。请联系我们的售后人员，否则保修将失效。
4. 将产品存放在阴凉通风处，避免阳光直射，远离热源和易燃易爆物品。
5. 请勿在潮湿环境中使用产品。避免雨水、湿气和液体飞溅。
6. 请勿在多尘环境中使用产品。灰尘可能会损坏产品的电子元件。
7. 请勿在极端温度环境中使用产品。理想的工作温度为 0°C 至 40°C（32°F 至 104°F）。极端温度会影响电池和电子元件的性能。
8. 请勿剧烈摔落、撞击或摇晃产品，这可能会损坏内部电路板和元件。
9. 请勿在强电磁干扰源附近使用产品，如微波炉、大功率无线电发射器等，以免影响产品的信号传输。
10. 请勿长时间大音量使用产品，这可能会导致听力损伤。建议适当休息并控制音量。
11. 为确保安全，请勿在驾驶或操作机械时使用产品。
12. 请勿在儿童或宠物附近使用产品，以防误吞或损坏产品。
13. 请勿在强振动环境中使用产品，如发动机舱或施工现场，以免损坏产品内部元件。
14. 请勿在强磁场环境中使用产品，如靠近磁铁或磁性设备，以免影响产品性能。
15. 如产品损坏、变形或出现故障，请立即停止使用并联系我们的售后服务进行维修或更换。

质保承诺

亲爱的用户：

感谢您购买我们的产品。我们为该产品提供一年的质量保证服务。在正常使用过程中，如果在保修期内出现任何质量问题，请联系我们的售后服务。我们将为您免费维修或更换产品。

请注意，以下情况不在保修范围内：

- 因不当使用（如摔落、撞击、接触水）造成的损坏。
- 因未经授权的拆卸、维修或改装造成的损坏。
- 因自然灾害、意外事故或不可抗力造成的损坏。
- 因正常磨损造成的损坏。

感谢您的理解与支持。如有任何疑问或需要帮助，请随时与我们联系。

此致，
敬礼！

广州市数码科技有限公司

质量合格证

产品名称：萨克斯无线系统
型号：IMP-130Plus
检验员：
日期：

Product Introduction

- Stereo
- Built-in Lithium Battery (Rechargeable)
- 5.8GHz Digital Wireless Transmission Technology
- Automatic Pairing Technology
- 5 Channels, 1-to-1 Interference-Free
- Ultra-Low Latency (≤3ms)
- 27pcs CR2 Coin Cell Batteries

Product Specifications

Product Name: DK Saxophone Wireless System
Model: IMP-130Plus
Transmitter Frequency: 2.4GHz ISM band (2401.5MHz~2481.5MHz)
Transmitter Power: ≤10dBm
Receiver Sensitivity: ≤-90dBm
Transmitter Range: ≤ 100m (Open area)
Latency: ≤3ms
Battery: Li-ion
Charging Time: 2.5H
Working Time: 6H
Charging Port: Type-C
Dimensions: 70.5*30.5*19.5mm
Weight: 30g

Transmitter Battery Capacity: 3.7V 80mAh
Receiver Battery Capacity: 3.7V 80mAh
Battery Life: 27pcs CR2 coin cell batteries
Operating Temperature: -10°C ~ 45°C
Storage Temperature: -20°C ~ 60°C
Humidity: 10% ~ 90%

Safety Guidelines

1. Before installation, please read this manual carefully and keep it properly for future reference.
2. Please use the power supply and battery specified in this manual. It needs to be charged and maintained according to the method.
3. Please do not disassemble, repair, or modify the product by yourself. Please contact our after-sales personnel, otherwise, the warranty will be void.
4. Store the product in a cool and ventilated place, avoid direct sunlight, and keep away from heat sources and flammable and explosive materials.
5. Please do not use the product in a humid environment. Avoid exposure to rain, moisture, and liquid splashes.
6. Please do not use the product in a dusty environment. Dust may cause damage to the product's electronic components.
7. Please do not use the product in extreme temperature environments. The ideal operating temperature is between 0°C and 40°C (32°F and 104°F). Extreme temperatures can affect the performance of the battery and electronic components.
8. Please do not drop, hit, or shake the product violently, as this may damage the internal circuit boards and components.
9. Please do not use the product near strong electromagnetic interference sources, such as microwave ovens, high-power radio transmitters, etc., to avoid affecting the product's signal transmission.
10. Please do not use the product for a long time at high volume, as this may cause hearing damage. It is recommended to take breaks and control the volume appropriately.
11. Please do not use the product while driving or operating machinery, to ensure safety.
12. Please do not use the product near children or pets to prevent accidental swallowing or damage to the product.
13. Please do not use the product in environments with strong vibrations, such as engine compartments or construction sites, to avoid damage to the product's internal components.
14. Please do not use the product in environments with strong magnetic fields, such as near magnets or magnetic devices, to avoid affecting the product's performance.
15. If the product is damaged, deformed, or malfunctioning, please stop using it immediately and contact our after-sales service for repair or replacement.

Quality Assurance

Dear User,

Thank you for purchasing our product. We provide a one-year quality assurance service for this product. If any quality issues occur during normal use within the warranty period, please contact our after-sales service. We will repair or replace the product for you free of charge.

Please note that the following situations are not covered by the warranty:

- Damage caused by improper use, such as dropping, impact, or exposure to water.
- Damage caused by unauthorized disassembly, repair, or modification.
- Damage caused by natural disasters, accidents, or force majeure.
- Damage caused by normal wear and tear.

We appreciate your understanding and support. If you have any questions or need assistance, please feel free to contact us.

Sincerely,
Guangzhou DK Electronic Technology Co., Ltd.

Certificate of Quality

Product Name: Saxophone Wireless System
Model: IMP-130Plus
Inspector:
Date:

Installation Diagram and Method

1. Take out the transmitter and receiver from the packaging box.
2. Insert the transmitter into the saxophone's output jack, ensuring a secure connection.
3. Insert the receiver into the audio input jack of the speaker or mixing console, ensuring a secure connection.
4. Set the power switches of the transmitter and receiver to the "ON" position to turn on the devices.
5. Adjust the volume to the appropriate level, and you can start playing.

Charging Instructions

1. Connect the Type-C charging cable to the charging port of the transmitter or receiver.
2. Connect the other end of the charging cable to a power source (such as a USB charger or computer).
3. The indicator light will turn red during charging and will turn off when fully charged.
4. Charging time is approximately 2.5 hours, and the working time is approximately 6 hours.

Operation Instructions

Function	Operation Instruction
Power On/Off	Set the power switch to the "ON" position to turn on the device; set it to the "OFF" position to turn off the device.
Volume Adjustment	Rotate the volume knob on the receiver to adjust the volume to the desired level.
Pairing	The transmitter and receiver are pre-paired from the factory and usually do not require manual pairing. If pairing is needed, refer to the pairing instructions in the manual.
Channel Selection	This device supports multiple channels. Select the channel that suits your needs.

Quality Assurance

Dear User,

Thank you for purchasing our product. We provide a one-year quality assurance service for this product. If any quality issues occur during normal use within the warranty period, please contact our after-sales service. We will repair or replace the product for you free of charge.

Please note that the following situations are not covered by the warranty:

- Damage caused by improper use, such as dropping, impact, or exposure to water.
- Damage caused by unauthorized disassembly, repair, or modification.
- Damage caused by natural disasters, accidents, or force majeure.
- Damage caused by normal wear and tear.

We appreciate your understanding and support. If you have any questions or need assistance, please feel free to contact us.

Sincerely,
Guangzhou DK Electronic Technology Co., Ltd.

Certificate of Quality

Product Name: Saxophone Wireless System
Model: IMP-130Plus
Inspector:
Date:

Installation Diagram and Method

1. Take out the transmitter and receiver from the packaging box.
2. Insert the transmitter into the saxophone's output jack, ensuring a secure connection.
3. Insert the receiver into the audio input jack of the speaker or mixing console, ensuring a secure connection.
4. Set the power switches of the transmitter and receiver to the "ON" position to turn on the devices.
5. Adjust the volume to the appropriate level, and you can start playing.

Charging Instructions

1. Connect the Type-C charging cable to the charging port of the transmitter or receiver.
2. Connect the other end of the charging cable to a power source (such as a USB charger or computer).
3. The indicator light will turn red during charging and will turn off when fully charged.
4. Charging time is approximately 2.5 hours, and the working time is approximately 6 hours.

Operation Instructions

Function	Operation Instruction
Power On/Off	Set the power switch to the "ON" position to turn on the device; set it to the "OFF" position to turn off the device.
Volume Adjustment	Rotate the volume knob on the receiver to adjust the volume to the desired level.
Pairing	The transmitter and receiver are pre-paired from the factory and usually do not require manual pairing. If pairing is needed, refer to the pairing instructions in the manual.
Channel Selection	This device supports multiple channels. Select the channel that suits your needs.

Quality Assurance

Dear User,

Thank you for purchasing our product. We provide a one-year quality assurance service for this product. If any quality issues occur during normal use within the warranty period, please contact our after-sales service. We will repair or replace the product for you free of charge.

Please note that the following situations are not covered by the warranty:

- Damage caused by improper use, such as dropping, impact, or exposure to water.
- Damage caused by unauthorized disassembly, repair, or modification.
- Damage caused by natural disasters, accidents, or force majeure.
- Damage caused by normal wear and tear.

We appreciate your understanding and support. If you have any questions or need assistance, please feel free to contact us.

Sincerely,
Guangzhou DK Electronic Technology Co., Ltd.

Certificate of Quality

Product Name: Saxophone Wireless System
Model: IMP-130Plus
Inspector:
Date:

Components of the product

- 1*Transmitter
- 1*Receiver (Dual-channel)
- 1*Charging cable (can also be used as a portable power bank)
- 1*Saxophone clip
- 1*Carrying case
- 1*Manual (including quick start guide)
- 1*Warranty card

Product Introduction

Transmitter

Receiver

Function	Transmitter	Receiver
Power Button	Press and hold for 3 seconds to turn on/off	Press and hold for 3 seconds to turn on/off
Volume Control	/	Rotate to adjust volume
Pairing Button	Press and hold for 3 seconds to enter pairing mode	Press and hold for 3 seconds to enter pairing mode
Charging Port	Type-C	Type-C
Indicator Light	Red: Charging Off: Fully charged	Red: Charging Off: Fully charged

Specifications

Item	Parameter
Transmitter Frequency	2.4GHz ISM band (2401.5MHz~2481.5MHz)
Transmitter Power	≤10dBm
Receiver Sensitivity	≤-90dBm
Transmitter Range	≤ 100m (Open area)
Latency	≤3ms
Battery	Li-ion
Charging Time	2.5H
Working Time	6H
Charging Port	Type-C
Dimensions	70.5*30.5*19.5mm
Weight	30g
Transmitter Battery Capacity	3.7V 80mAh
Receiver Battery Capacity	3.7V 80mAh
Battery Life	27pcs CR2 coin cell batteries
Operating Temperature	-10°C ~ 45°C
Storage Temperature	-20°C ~ 60°C
Humidity	10% ~ 90%

Safety Guidelines

1. Before installation, please read this manual carefully and keep it properly for future reference.
2. Please use the power supply and battery specified in this manual. It needs to be charged and maintained according to the method.
3. Please do not disassemble, repair, or modify the product by yourself. Please contact our after-sales personnel, otherwise, the warranty will be void.
4. Store the product in a cool and ventilated place, avoid direct sunlight, and keep away from heat sources and flammable and explosive materials.
5. Please do not use the product in a humid environment. Avoid exposure to rain, moisture, and liquid splashes.
6. Please do not use the product in a dusty environment. Dust may cause damage to the product's electronic components.
7. Please do not use the product in extreme temperature environments. The ideal operating temperature is between 0°C and 40°C (32°F and 104°F). Extreme temperatures can affect the performance of the battery and electronic components.
8. Please do not drop, hit, or shake the product violently, as this may damage the internal circuit boards and components.
9. Please do not use the product near strong electromagnetic interference sources, such as microwave ovens, high-power radio transmitters, etc., to avoid affecting the product's signal transmission.
10. Please do not use the product for a long time at high volume, as this may cause hearing damage. It is recommended to take breaks and control the volume appropriately.
11. Please do not use the product while driving or operating machinery, to ensure safety.
12. Please do not use the product near children or pets to prevent accidental swallowing or damage to the product.
13. Please do not use the product in environments with strong vibrations, such as engine compartments or construction sites, to avoid damage to the product's internal components.
14. Please do not use the product in environments with strong magnetic fields, such as near magnets or magnetic devices, to avoid affecting the product's performance.
15. If the product is damaged, deformed, or malfunctioning, please stop using it immediately and contact our after-sales service for repair or replacement.

Quality Assurance

Dear User,

Thank you for purchasing our product. We provide a one-year quality assurance service for this product. If any quality issues occur during normal use within the warranty period, please contact our after-sales service. We will repair or replace the product for you free of charge.

Please note that the following situations are not covered by the warranty:

- Damage caused by improper use, such as dropping, impact, or exposure to water.
- Damage caused by unauthorized disassembly, repair, or modification.
- Damage caused by natural disasters, accidents, or force majeure.
- Damage caused by normal wear and tear.

We appreciate your understanding and support. If you have any questions or need assistance, please feel free to contact us.

Sincerely,
Guangzhou DK Electronic Technology Co., Ltd.

Certificate of Quality

Product Name: Saxophone Wireless System
Model: IMP-130Plus
Inspector:
Date:

Installation Diagram and Method

1. Take out the transmitter and receiver from the packaging box.
2. Insert the transmitter into the saxophone's output jack, ensuring a secure connection.
3. Insert the receiver into the audio input jack of the speaker or mixing console, ensuring a secure connection.
4. Set the power switches of the transmitter and receiver to the "ON" position to turn on the devices.
5. Adjust the volume to the appropriate level, and you can start playing.

Charging Instructions

1. Connect the Type-C charging cable to the charging port of the transmitter or receiver.
2. Connect the other end of the charging cable to a power source (such as a USB charger or computer).
3. The indicator light will turn red during charging and will turn off when fully charged.
4. Charging time is approximately 2.5 hours, and the working time is approximately 6 hours.

Operation Instructions

Function	Operation Instruction
Power On/Off	Set the power switch to the "ON" position to turn on the device; set it to the "OFF" position to turn off the device.
Volume Adjustment	Rotate the volume knob on the receiver to adjust the volume to the desired level.
Pairing	The transmitter and receiver are pre-paired from the factory and usually do not require manual pairing. If pairing is needed, refer to the pairing instructions in the manual.
Channel Selection	This device supports multiple channels. Select the channel that suits your needs.

Quality Assurance

Dear User,

Thank you for purchasing our product. We provide a one-year quality assurance service for this product. If any quality issues occur during normal use within the warranty period, please contact our after-sales service. We will repair or replace the product for you free of charge.

Please note that the following situations are not covered by the warranty:

- Damage caused by improper use, such as dropping, impact, or exposure to water.
- Damage caused by unauthorized disassembly, repair, or modification.
- Damage caused by natural disasters, accidents, or force majeure.
- Damage caused by normal wear and tear.

We appreciate your understanding and support. If you have any questions or need assistance, please feel free to contact us.

Sincerely,
Guangzhou DK Electronic Technology Co., Ltd.

Certificate of Quality

Product Name: Saxophone Wireless System
Model: IMP-130Plus
Inspector:
Date:

Installation Diagram and Method

1. Take out the transmitter and receiver from the packaging box.
2. Insert the transmitter into the saxophone's output jack, ensuring a secure connection.
3. Insert the receiver into the audio input jack of the speaker or mixing console, ensuring a secure connection.
4. Set the power switches of the transmitter and receiver to the "ON" position to turn on the devices.
5. Adjust the volume to the appropriate level, and you can start playing.

Charging Instructions

1. Connect the Type-C charging cable to the charging port of the transmitter or receiver.
2. Connect the other end of the charging cable to a power source (such as a USB charger or computer).
3. The indicator light will turn red during charging and will turn off when fully charged.
4. Charging time is approximately 2.5 hours, and the working time is approximately 6 hours.

Operation Instructions

Function	Operation Instruction
Power On/Off	Set the power switch to the "ON" position to turn on the device; set it to the "OFF" position to turn off the device.
Volume Adjustment	Rotate the volume knob on the receiver to adjust the volume to the desired level.
Pairing	The transmitter and receiver are pre-paired from the factory and usually do not require manual pairing. If pairing is needed, refer to the pairing instructions in the manual.
Channel Selection	This device supports multiple channels. Select the channel that suits your needs.

Quality Assurance

Dear User,

Thank you for purchasing our product. We provide a one-year quality assurance service for this product. If any quality issues occur during normal use within the warranty period, please contact our after-sales service. We will repair or replace the product for you free of charge.

Please note that the following situations are not covered by the warranty:

- Damage caused by improper use, such as dropping, impact, or exposure to water.
- Damage caused by unauthorized disassembly, repair, or modification.
- Damage caused by natural disasters, accidents, or force majeure.
- Damage caused by normal wear and tear.

We appreciate your understanding and support. If you have any questions or need assistance, please feel free to contact us.

Sincerely,
Guangzhou DK Electronic Technology Co., Ltd.

Certificate of Quality

Product Name: Saxophone Wireless System
Model: IMP-130Plus
Inspector:
Date: