**Leme**

User Manual

## Introduction

Thanks for buying and using Leme Wireless Bluetooth Headphone. This manual will help you to learn how to use the Bluetooth headphone. Before using , you must understand and know how to use the Bluetooth function of your Super TV or other Bluetooth active devices (such as mobile phone) firstly.

## Security Rules

. To ensure safety, please abide by the rules mentioned in this manual. Before using the Bluetooth headphone, we strongly recommend you to read this manual.
. Please be ware sharp edges, uneven surfaces, metal parts, accessories and package, to avoid any possible injury.
. Please do not dismantle, repair the product as it may cause fire, electrical breakdown or even destroy the product completely as these are not in the warranty.

## Package Contents

1x Bluetooth Headphone EB30A
1x USB Charging line
1x User Manual / Warranty Certificate

## Connection Diagram

MFB Button
Power On / Off
Enter the Match Mode
Play / Pause
Answer Phone / End Call
Reject Call / Voice Switch
Tail Number Replay

Previous Song
Volume Up
LED Light
Next Song
Volume Down
Charging Interface
Microphone

## Instructions

| | |
|---|---|
| Power On | In the off state, press the "MFB" button for 3 seconds (red LED lights, and with a "beep" sound) |
| Power Off | In the on or play state, press the "MFB" button for 3 seconds and power off (prompt "beep" sound and LED off) |
| Enter the Match Mode | In the off state, press the multifunction button for 5 seconds. (prompt twice "beep"sound, the red LED and blue LED flashes alternately) |
| Match | Using Super TV or Bluetooth active devices (such as mobile phones) to match with the Bluetooth headset in the match mode. |
| Volume UP | long  press the volume "+" button to increase the volume |
| Volume Down | long  press the volume "-" button to decrease the volume |
| Music Play | In the connected state, click the "MFB" button to play music or pause music |
| Previous Song | Click the "<" button to play the previous song |
| Next song | Click the ">" button to play the next song |
| Low Battery Alarm | Red LED flashes |
| Charging | Insert the DC port into the USB port, the red LED light normally on. |

---

Dear Customer:
To protect your legal rights and relieve your worries, Leme commitment to Warranty Services. If your product has quality problems, please contact the distributor with product warranty voucher and bill, distributors will provide services for customers and Leme will provide support services todistributors.

For your convenience to understand and protect the rights of funds better, please consult and read the following terms:
1. Please keep the purchase bills issued by store after purchase the product.
2. The manufacturer promise 1 year quality arrurance from the purchase date.
3. Product quality principles:
a. normal use, non man-made damage, without overhaul.
b. Man-made damage, unauthorized overhaul or beyond the warranty period, maintenance product need to charge nominal fee.
4. Please fill in the product warranty certificate information in detail, so we can serve you better..
5. If product in need of repair, Please provide product warranty certificate and invoice.
6. If product and accessories used improperly or man-made damage is not covered under warranty.

Room 1006, Building 3, 9th Floor, No.105, Yaojiayuan Road,Chaoyang District, Beijing, China.
Postal Code: 100025
Phone: 10109000
Mail: kefu@letv.com
Twitter: http://weibo.com/letvservice
For more after-sale service information, please view the website:
http: //www.lemall.com

| | |
|---|---|
| Answer Phone | Click the "MFB" button to answer an incoming call |
| Reject Call | Press the "MFB" for 1 second |
| End Call | Click the"MFB" button while a call or outgoing call |
| Voice Switch | Double-click the "MFB" button while a call and you can switch the sound between the headphone and the mobile phone |
| Tail Number Replay | Double-click the "MFB" button in the connected state |
| One with Two Functions | In the match state click the "MFB" button to open one with two functions, double-click the "MFB" button to close the one with two functions. |
| Reset Factory | In the match mode, press the  volume "+"button and volume "-" button for 5 seconds to reset. |

## Match and Use with Super TV

. Connect Bluetooth headphone:
Open the Super TV, enter the TV screen, and use the set key of remote control to enter the setting interface, open the Bluetooth settings, turn on the Bluetooth, confirm the Bluetooth headphone name after it is displayed, wait for the system prompt the Bluetooth headphone already connected and then use.
. Cancel Match:
Select the Bluetooth device name in the Bluetooth settings interface and then cancel the Bluetooth match by menu button.

## Match with Mobile Phone or Other Devices

Open the Bluetooth headphone; enter the Bluetooth function of mobile phone or other devices select Leme EB30A until matched sucefully. If the Bluetooth headphone and the mobile phone already matched, Bluetooth headphone and mobile phone will automatically matched within effective distance.
. If mobile phone prompts to set the match code, please enter "0000" as match code.

## Bluetooth Headphone Charging

Connect the USB cable with the Bluetooth headphone, and connect the other port to the 5V DC adapter or other 5V (DC) port(such as computer USB port), then you can charge the Bluetooth headphone. LED displays red when not fully charged,; when fully charged, LED displays blue. Please make sure that charging Bluetooth headphone at least 2 hours for the first time

## Warning

You must choose the certified charger by the regular manufacturer, if the product do not be used for a long time (more than 1 year), please charge it.

## Technical Specifications

| | |
|---|---|
| Bluetooth Specification | Bluetooth V4.1 |
| Bluetooth Protocol | A2DP1.2 AVRCP1.4 HSP1.2 HFP1.6 |
| DSP | CVC6.0 Noise and Echo reduction |
| Communication Distance | 10M (under open condition) |
| Frequency Response | 20Hz-20KHz |
| Speaker Output Power | 20mW |
| SNR | ≥90dB |
| THD | ≤3.0% |
| Play Time | about 11 hours |
| Charging Time | about 2 hours |
| Dimention | 180x176.8x62.8mm |
| Weight | about 240g |

## Service and Support

. If your product with problem but not man-made damage, please return to us or dealer for warranty.

## Simple Q & A

1. Why my headphone with no sound when power on?
Ensure that charging 2 hours for the first time, it may power off without electricity
2. Headphone with no sound?
Check whether the playback device is connected with a Bluetooth headphone. If not connected, please reconnect. While ensuring the playback device you connect is what you need.
3. How to identify two mobile phones?
Set the headphone to match mode, click the "MFB" button to open the multi-point connection function, using mobile phone A to connect, then swith off the mobile phone and restart after successful connection, reset the headset in match mode, using a mobile phone B to connect, using the match list of mobile phone A to connect headphone again after mobile phone B successfully connected.

## FCC Compliance

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1)  This device may not cause harmful interference, and
(2)  This device must accept any interference received, including interference that may cause undesired operation.
Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user' s authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device,

pursuant to Part 15 of the FCC Rules.These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.
Increase the separation between the equipment and receiver.
Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
Consult the dealer or an experienced radio/TV technician for help.
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

**Leme**