

	1	2	3	4	5	6	7
A							
B							
C							
D							
E							
	1	2	3	4	5	6	7

EN

Let's get started.

Need help? Scan the QR code for video tutorials and user guide.

<https://link.gi-net.com/fgb-01-userguide-support>

FGB-01 FingerBot

PACKAGE CONTENTS

SETTING UP

Remove the plastic battery isolation tab.

1

Remove the cover from the notch on the side of the device.

2

Take out the USB dongle. (FGB-01-g)

3

Insert the USB dongle into the Comet (GL-RM1).

4

The FingerBot can be controlled through the GLKVM app.

INSTALLATION

1

Clean the surface of the device before installation.

2

Peel off the protective sticker from the adhesive on the bottom of the FingerBot.

3

Stick the FingerBot near the control button of the device.

4

Testing pressure levels

The FingerBot features two different pressing levels. You can adjust the level at any time through the GLKVM App.
1. **Light Press Mode:** Use for shorter key.
2. **Hard Press Mode:** Use for longer key.

5

Operation mode

The FingerBot features two different operation modes. You can adjust the modes at any time through the GLKVM App.
Press Mode: Pressing buttons or controlling on-way switches. Ideal for tasks like powering on a PC.

6

Installation on the laptop

Note: Only for laptops with edge-mounted power buttons.
1. Secure the bracket in the desired position and tighten it.
2. Attach the FingerBot to the bracket and test its alignment.

7

Test button

Use the test button to find your preferred pressing level.
1. **First press** – FingerBot extends to Light Press.
2. **Second press** – FingerBot extends to Hard Press.
3. **Third press** – FingerBot retracts.

REPLACE BATTERY

How to replace your battery:

1. Prepare a CR2 battery.
2. Remove the cover from the notch on the side of the device.
3. Replace the battery.
4. Put the cover back on the device.

SUPPORT

Setup video and FAQs

For more detailed and updated instructions, please visit our website <https://link.gi-net.com/fgb-01-userguide-support>

Hang Kong Office
GL Technology (Hong Kong) Limited
Unit 101, Building 101, Hong Kong Science Park,
Sha Tin, N.T., Hong Kong

Shenzhen Office
Shenzhen Guanglian Zhongtong Tech Co., Ltd.
Room 201, 10th, Shenzhen Jigang Building, Shuang Street,
Baoan District, Shenzhen, China, 518107
+86 13700466133

ver. 20250110

ES

Empecemos

¿Necesitas ayuda? Escanee el código QR para ver tutoriales en video y la guía del usuario.

<https://link.gi-net.com/fgb-01-userguide-support>

FGB-01 FingerBot

CONTENIDO DEL PAQUETE

CONFIGURACIÓN INICIAL

Retira la pantalla plástica de aislamiento de la batería.

1

Quita la tapa desde la ranura lateral del dispositivo.

2

Extrae el dongle USB. (FGB-01-g)

3

Inserta el dongle USB en el Comet (GL-RM1).

4

El FingerBot puede controlarse a través de la aplicación GLKVM.

INSTALACIÓN

1

Limpia la superficie del dispositivo antes de la instalación.

2

Retira la etiqueta protectora del adhesivo en la parte interior del FingerBot.

3

Pega el FingerBot cerca del botón de control del dispositivo.

4

Prueba el nivel adecuado

El FingerBot cuenta con dos modos de funcionamiento diferentes. Puedes ajustar el nivel en cualquier momento desde la aplicación GLKVM.
1. **Modo de presión ligera:** Usado para teclas más cortas.
2. **Modo de presión fuerte:** Usado para teclas más largas.

5

Modo de funcionamiento

El FingerBot cuenta con dos modos de funcionamiento diferentes. Puedes ajustar los modos en cualquier momento desde la aplicación GLKVM.
Modo de presión: Para presionar botones o controlar interruptores de una sola dirección. Ideal para tareas como encender una PC.

6

Instalación en laptop

Note: Solo usable in laptops that have the button on the side.
1. Asegura el soporte en la posición deseada y ajústalo.
2. Coloca el FingerBot en el soporte y prueba su alineación.

7

Botón de prueba

Usa el botón de prueba para encontrar tu nivel de presión preferido.
1. **Primera pulsación** – El FingerBot se extiende en Modo de Presión Ligera.
2. **Segunda pulsación** – El FingerBot se extiende en Modo de Presión Fuerte.
3. **Tercera pulsación** – El FingerBot se retracts.

CAMBIAR LA PILA

Cómo reemplazar la batería:

1. Prepara una batería CR2.
2. Quita la tapa desde la ranura lateral del dispositivo.
3. Reemplaza la batería.
4. Vuelve a colocar la tapa en el dispositivo.

APOYO

Video de instalación y preguntas frecuentes

Para obtener instrucciones más detalladas y actualizadas, visite nuestro sitio web <https://link.gi-net.com/fgb-01-userguide-support>

Si tiene más preguntas, póngase en contacto con nosotros por los siguientes medios:

Como electrónico: support@gi-net.com

Disco: link.gi-net.com/website-discord-support

Redes: link.gi-net.com/website-reddit-support

Foro: forum.gi-net.com

Hang Kong Office
GL Technology (Hong Kong) Limited
Unit 101, Building 101, Hong Kong Science Park,
Sha Tin, N.T., Hong Kong

Shenzhen Office
Shenzhen Guanglian Zhongtong Tech Co., Ltd.
Room 201, 10th, Shenzhen Jigang Building, Shuang Street,
Baoan District, Shenzhen, China, 518107
+86 13700466133

ver. 20250110

GL·iNet 深圳市广联智通科技有限公司	产品名称	英西双语说明书	
	物料编码	505-0384	
设计	朱志豪	单位/比例	mm/1:1
审核	朱哲宇/何丰	尺寸	单页78*95mm 整体390*190mm±1mm
标准化	叶彩霞	材质	128g铜版纸/双面单色印刷/用于手指机器人FGB-01
批准	邓珊珊	日期	ver.2025/06/10