hohem

HRT-03
All-in-one Remote Control

Black ● ○ white

*Please see the actual selection for product color

Specifications

Product Model	HRT-03	Notice
Product Name	All-in-one Remote Control	The remote control is built with a button battery. When the battery is low or power off, the indicator light will not light up. Please open the back cover of the remote control to replace the battery.
Size	38*27*8mm	
Weight	10g	
Remote Control Transmission Distance (Straight line without stuck)	10m	

*Remove the cover, and the user manual is on the back

CE RoHS

EC REP AMZLAB GmbH Laubenhof 23,45326 Essen

Web: Www.hohem.com
E-mail: Service@hohem.com

MADE IN CHINA

Pairing the remote control with the gimbal:

Please press the function button of the gimbal 7 times once the gimbal is turned on, the bluetooth light will flash alternately in yellow and green and enter the pairing mode.

⚠️

Make sure the gimbal is on the pairing mode before turning on the remote control to connect.

During the pairing process:

a. The pairing can be completed in 3 seconds, after the gimbal bluetooth light stop flashing alternately in yellow and green;

b. If the remote control is not paired within 30 seconds, the pairing will be cancelled;

c. Click the function button to cancel pairing;

d. Double-click the function button to clear the paired remote control and cancel pairing;

(And the paired remote control will be unavailable and need to be repaired)

① **Power Button**
ON: Power On
OFF: Power Off

③ **Function Button**

Single Press: Switch the landscape and portrait modes
Double Press: Recenter the gimbal
Triple Press: Inception (Auto rotation)

② **Shutter Button**
(Make sure the app connect to the gimbal successful)

Single Press: Take photo, Start/End video
Double Press: Switch the photo and video modes
Triple Press: Switch the front and rear cameras
(Only available in the app)

④ **M Button (Gimbal Working Mode)**

Single Press: Pan&Tilt Follow
Double Press: Pan Follow
Triple Press: All Lock
Quartic Press: POV (All Follow)
Long Press: Switch the zoom in/out mode and gimbal tilt control mode
(Zoom in/out mode only available in the app)

⑤ **Navigation Buttons: Up/Down/Left/Right**

Up/Down:
- Tilt Control (Indicator light shows green)
- Control the image zoom in/out
(Indicator light shows blue and only available in the app)

Left/Right: Pan Control

⑥ **Indicator Light**

The indicator light shows green or blue in button operation. If no light shows, it means the remote control is not turned on or no battery.

Green light: Gimbal controlling
Blue light: Phone camera controlling

FCC Statement:

Federal Communication Commission (FCC) Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement, The device can be used in portable exposure condition without restriction

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications or changes to this equipment. Such modifications or changes could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

 - Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help.

FCC ID:2AIB7RT