

142mm

Quick Start Guide
快速入門指南
快速入門指南
Schnellstartanleitung
Guide de Démarrage Rapide
Guide Rapido
Guia de Inicio Rápido
クイックスタートガイド
빠른 시작 가이드
Инструкция по началу рабо



CPU	Intel Xeon E5-2680
内存	LPDDR4 = 32GB/6GB
硬盘	M.2 NVMe SSD=M.2 SATA SSD固态硬盘

Informazioni di Configurazione	
CPU	Intel Xeon Lake R5308
RAM	LPDDR4 x 8GB/16GB
Archiviazione	Intel ZNVe 2280 + M.2 SATA 2242 (ogni riga)

Фабрикация	total Acoustic Lake N1500
Пульт	EP0354 = 8 FB / 16 FS
Назначение	для установки дрели M.2 NVMe 2280 + M.2 SATA

Verbinden Sie das Kabel mit dem Adapter des
Anzeigegeräts mit dem angeschlossenen HD-Display.
Verwenden Sie den passenden Adapter, um sich mit
dem Gerät zu verbinden, und stecken Sie den Adapter in
den Steckplatz.
Verbinden Sie das Kabel mit dem Adapter mit
und Maat, die an die USB-Schnittstelle angeschlossen
Drücken Sie den Netzschalter, um das System zu starten.

使用説明書

Do not try to open the case or perform repairs. If a malfunction occurs, please contact customer service. When cleaning electronic equipment, please pay attention to waterproof and be careful of electric shock. Check the wires or plugs for any fraying or damage. Pay attention to protect the environment, do not throw away the product when it is not in use.
Working environment: 5°C-35°C, humidity 20%-90%
Storage environment: -20°C-60°C, humidity 10%-90%

10	
----	--
