

INSTRUCTION MANUAL

使用說明 / 使用说明

momax

PinGuard

Camera Scanning Find My Locator

鏡頭掃描 Find My 全球定位器

鏡頭掃描 Find My 全球定位器



BR13

Apple, Apple Find My, Apple Watch, Find My, iPhone, iPad, iPods, Mac, macOS and watchOS are trademarks of Apple Inc. iOS is a trademark or registered trademark of Cisco in the U.S. and other countries and is used under license.

INSTRUCTION FOR USE

操作/操作

a. Find my Locator

- Press the button once and it will sound once. When you click to play the sound in Find My App, it will sound 5 times.
- When the anti-tracking detects that the anti-lost device has been moving, it will automatically play a sound.
- When unpairing in the Find app, it will sound twice.
- Press and hold the button for 3 seconds and let go when you hear a beep. The anti-lost device will enter sleep mode and will not send any signals. Pairing is not possible at this time.
- After entering sleep mode, short press the button once and you will hear a beep. The anti-lost device is awakened.
- Short press the button once, then press and hold the button for 5 seconds within two seconds and let go when you hear a long beep. When you hear a beep, it means the reset is successful and the anti-lost device can be paired.
- Under normal circumstances, there will be a sound when you short press the button at any time, and one short press will sound once.
- When the Find app plays a sound, short press the button once and it will sound once, and the sound will stop playing.
- For the firmware version, please check the "Firmware" item on the product details page of Find My app.

b. Camera Scanner

- The red light flashes when powered on, and the green light stays on when fully charged.
- Long press the switch, short circuit and cycle between the first gear (red light is always on) and the second gear (red light flashing).
- When the voltage reaches 3.3V±0.1V, the small red LED light flashes twice, and the low power reminder turns off. The red visitor light cannot be turned on, but the anti-lost part functions normally until the battery is lower than 2.5V, the whole machine turns off, and the product needs to be charged for normal use.
- Charging current 100mA±10 charging small red LED light is always on.
- When the battery is fully charged at 4.2V, the small green LED light is always on.

c. Protection characteristics

- When the battery voltage is lower than 3.3V±0.2V, the camera detector is turned off and cannot be used, but the anti-lost device can continue to work.
- When the battery voltage is lower than 2.5V±0.1V, the whole device will shut down due to low battery and needs to be recharged before use.

a. Find My 全球定位器

- 按鍵按一次響一聲。
- Find My App點擊播放聲音時，響5次。

3. 防追蹤偵測到防丟器一直在移動時會自動播放聲音。

- 在尋找應用程式中解除配對時，響2響。
- 長按按3秒聽到滴聲響，這時候防丟器進入休眠模式，不發送訊號，此時無法進行配對。
- 進入休眠模式後，短按按鍵一次，會聽到一聲滴響聲，此時防丟器被喚醒。
- 短按按鍵一次，然後兩秒中內按住按鍵5秒聽到滴滴滴聲，表示復位成功，防丟器可以進行配對。
- 正常情況下，任何時候短按按鍵都是有聲音的，短按一次響一聲。
- 尋找應用程式播放聲音時，短按按鍵一次響一聲，此時停止播放聲音。
- 解除版本，請在Find My app該產品詳細頁面「軟體」項目查看。

b. 鏡頭掃描

- 上電紅色小燈閃爍，充滿電 綠色小燈常亮
- 長按開關機，短按在一檔（紅光常亮），二檔（紅光閃爍）間循環。
- 電壓到達3.3V±0.1V時小紅色LED燈快閃，低電提醒閃爍，無法打開紅色夜視燈，但防丟器部分功能正常，直到電池低於2.5V，整機關機，產品需充電才能正常使用。
- 充電電流100mA±10 充電中小紅色LED燈慢閃
- 電池滿電狀態4.2V 小綠色LED燈常亮。

c. 保護特性

- 電池電壓低於 3.3V±0.2V，攝影機檢測器關機不可用，但防丟器還可以繼續工作。
- 電池電壓低於 2.5V±0.1V，整機低電量關機，需重新充電再使用。

a. Find My 全球定位器

- 按鍵按一次响一聲。
- Find My App点击播放声音时，响5次。
- 防跟踪检测到防丢器一直在移动时会自动播放声音。
- 在查找应用中解除配对时，响2响。
- 长按按键3秒听到滴声松手，这时候防丢器进入休眠模式，不发送信号，此时无法进行配对。
- 进入休眠模式后，短按按键一次，会听到一声滴声，此时防丢器被唤醒。
- 短按按键一次，然后两秒中内按住按键5秒听到滴滴滴声，表示复位成功，防丢器可以运行配对。
- 正常情况下，任何时候短按按键都是有声音的，短按一次响一声。
- 查找应用播放声音时，短按按键一次响一声，此时停止播放声音。
- 固件版本，请在Find My app该产品详细页面“固件”项查看。

b. 镜头扫描器

- 上电红色小灯闪烁，充满电 绿色小灯常亮。
- 长按开关机，短按在一档（红光常亮），二档（红光闪烁）间循环。
- 当电压到达3.3V±0.1V时，小红色LED灯快闪，低电提醒关机，无法打开红色夜视灯，但防丢器部分功能正常，直到电池低于2.5V，整机关机，产品需充电才能正常使用。
- 充电电流100mA±10 充电中小红色LED灯慢闪
- 电池满电状态4.2V 小绿色LED灯常亮。

c. 保护特性

- 电池电压低于 3.3V±0.2V，摄像头检测器关机不可用，但防丢器还可以继续工作。
- 电池电压低于 2.5V±0.1V，整机低电量关机，需要重新充电再使用。

Find and bind your product

- ※Please make sure that you have an iPhone, iPad, or iPod touch with iOS 14.5 or iPadOS 14.5 or later and two-factor authentication enabled.
- Turn on [Bluetooth] on your Apple device, and go to [Settings] - [Privacy & Security] - Turn on [Location Services] and swipe down and tap [Find My] to allow access to the location and turn on [Precise Location] .
 - Goes back to main screen of the apple device, click the [Find My] app, and then select the [Items] tab.
 - Click [+], and then click [Add Other Item] .
 - Find the item name "MOMAX BR13", click [Connect], fill in the "Name Item" custom product name, and click [Continue] . "Choose an Emoji" click to Continue to show "This item is linked to your Apple ID", please check that the email address and mobile phone number are correct, then tap [Agree], and then tap [Finish] to add successfully.

【Precise Location】.

- Goes back to main screen of the apple device, click the [Find My] app, and then select the [Items] tab.
- Click [+], and then click [Add Other Item] .
- Find the item name "MOMAX BR13", click [Connect], fill in the "Name Item" custom product name, and click [Continue] . "Choose an Emoji" click to Continue to show "This item is linked to your Apple ID", please check that the email address and mobile phone number are correct, then tap [Agree], and then tap [Finish] to add successfully.

查找并綁定產品

- ※請確認裝有iOS14.5或iPadOS 14.5或以上版本，并已啟用雙重認證的Phone、iPad或iPod touch。
- 在蘋果設備上打開【藍牙】，並且前往【設置】-【私隱】-開啟【定位服務】向下滑動點一下【查找】，允許取用位置就開啟【精確位置】。
 - 點擊【+】，再點擊【添加其他物品】。
 - 找到物品名為“MOMAX BR13”後點擊【連接】，填寫“表情符號”，點擊繼續顯示。此物品已連接到你的Apple ID，請核對電子郵件和移動電話號碼是否正確，隨即點擊【同意】，點擊【完成】添加成功。

查找并綁定產品

- ※請確認裝有iOS14.5或iPadOS 14.5或以上版本，并已啟用雙重認證的Phone、iPad或iPod touch。
- 在蘋果設備上打開【藍牙】，並且前往【設置】-【私隱】-開啟【定位服務】，并下滑动并点一下【查找】，允许取用位置就开启【精确定位】。
 - 如果设备处于桌面状态，点击【查找】应用程序，然后选择【物品】分页。
 - 点击【+】，再点击【添加其他物品】。
 - 找到物品名为“MOMAX BR13”后点击【连接】，填写表情符号，点击继续显示。此物品已连接到你的Apple ID，请核对电子邮箱和移动电话号码是否正确，随即点击【同意】，点击【完成】添加成功。

SETUP THE LOST MODE

- When the base station is a certain distance away from the console, you need to turn on the lost mode to mark the item as lost. Tap item at the bottom of the screen, then tap the name of the missing item. Under Lost Mode, tap Enable.
- Follow the on-screen instructions and enter a phone number where you can be contacted, or if you want to mark the item as lost, tap Item at the bottom of the screen, then tap the name of the missing item. Under Lost Mode, tap Enable.

開啟【遺失模式】

- 當定位器離開主機一定的距離時，要將物品標記為遺失。

- 失，你需要遺失模式。點一下屏幕底部的【物品】，然後點一下遺失物品名稱。在【遺失模式】下方，點一下【啟用】。
- 依照屏幕上方的指示操作，輸入可以與你聯絡的電話號碼。若要改為輸入電子郵件地址，請點一下【使用電子郵件地址】。然後按下【啟用】。
 - 注意：請先確定允許【查找】App的通知。

开启【丢失模式】

- 当定位器离开主机一定的距离时，要将物品标记为丢失，你需要开启丢失模式。点一下屏幕底部的【物品】，然后点一下丢失物品名称。在【丢失模式】下方，按一下【启用】。
- 依照屏幕上的指示操作，输入可以与你联络的电话号码。若要改为输入电子邮件地址，请点击一下【使用电子邮件地址】。然后按下【启用】。
- 注意：请先确定允许【查找】App的通知。

在地图查看定位器位置

- 打开【查找】应用程序，然后点按【物品】分页。在【物品】清单中选择您要定位的定位器。如果定位器位于你设置的覆盖范围或最近侦测到定位器的【查找】范围内，你便可在地图上看到。其名稱下方會顯示更新的位置時間。
- 如果定位器不在你装置或【查找】网络的任何装置之覆盖范围内，你可见到其最后已知位置和时间。如果定位器进入你装置范围人或可由【查找】网络侦测到时接收通知，请开启【通知】下的【找到时通知我】。

[Notifications].

在地圖查看定位器位置

- 打開【查找】應用程序，然後點按【物品】分页。在【物品】清單中選擇您要定位的定位器。如果定位器位於你裝置的覆蓋範圍或最近偵測到定位器的【查找】網絡範圍內，你便可在地圖看到。其名稱下方會顯示更新的位置時間。
- 如果定位器不在你裝置或【查找】網絡的任何裝置之覆蓋範圍內，你可见到其最后已知位置和时间。如果定位器进入你装置范围人或可由【查找】网络侦测到时接收通知，请開啟【通知】下的【找到时通知我】。

在地图查看定位器位置

- Open the Find My app, then click the Items tab. Select the locator you want to locate in the Items list. If the locator is within the coverage area of your device or the Find My network where the locator was recently detected, you can see it on the map. Below its name, you'll see the location and time of the update. Then press Enable.
- If the base station is not within range of your device or any device on the Find My network, you can see its last known location and time. If you want to receive notifications when the tracker comes within range of your device or can be detected by the Find My network, please turn on [Notify when found] under

PLAY A SOUND

- Open the [Find My] app, select the [Items] tab, click the product you need to use, the mobile phone interface will display the [Play Sound] button, click the [Play Sound] button, and then you will hear a piece of music, indicating that the product can be used normally.
- When the device and the product are out of the distance, the [Find My] app cannot connect to the product and the product cannot play sound normally.

播放聲音

- 打開【查找】應用程序，選取【物品】分页，點擊您要使用的產品，手機界面會顯示【播放聲音】的按鈕，點擊【播放聲音】按鈕，隨即聽見一段音樂，表示產品可以正常使用。
- ※當設備與產品超出使用距離後，【查找】應用程序無法連接到產品並且產品無法正常播放聲音。

播放聲音

- 打開【查找】应用程序，选取【物品】分页，点击您要使用的产品，手机界面会显示【播放声音】的按钮，点击【播放声音】按钮，随即听见一段音乐，表示产品可以正常使用。
- ※当设备与产品超出使用距离后，【查找】应用程序无法连接到产品并且产品无法正常播放声音。

Prevent unauthor ized tracking

- If any of the locators and other Find My network accessory products leave their owners and move with you for a period of time, you can send a notification to your Apple through the Find My app device, and be able to observe the walking path as you move and in time.
- These features are designed to prevent people from trying to track you without your knowledge, so if you feel your safety is at risk, contact your local law enforcement officer.

※This product has a function to prevent unauthorized tracking, and should not be used to track others, nor should it be used to track property that does not belong to you. In many countries and regions around the world, it is an offence to use these products to track someone without their consent.

防止擅自追蹤

- 如果任何定位器或其他【查找】網絡配件產品離開了其擁有者，并隨你移動一段時間，你可以透過【查找】應用程序通知到您的Apple設備，並能夠觀察到隨您移動的行走路徑及時間。
- 這些功能為特意製作，旨在防止他人在你不知道的情況下試圖追蹤您，如果您感到安全受到威脅，請聯絡當地執法人員。

※本產品加入了防止他人擅自追蹤的功能，不應用來追蹤他人，亦不應用來追蹤不屬於您的財物。在全球很多國家和地區，未經他人同意使用這些產品追蹤別人



產品重置

需要更換/解綁設備綁定產品時，在【查找】應用程序中，【物品】分页，找到需要解綁的產品，滑動頁面至最底部，點擊【移除物品】，點擊【移除】，再次點擊【移除】，確認【物品】分页中已經沒有該產品。

※若在未解綁前操作物理方式重置該產品，蘋果設備移除產品時間會較長。

產品重置

需要更換/解綁設備綁定產品時，在【查找】應用程序中，【物品】分页，找到需要解綁的產品，滑動頁面至最底部，點擊【移除物品】，點擊【移除】，再次點擊【移除】，確認【物品】分页中已經沒有該產品。

※若在未解綁前操作物理方式重置該產品，蘋果設備移除產品時間會較長。

PRODUCT RESET

- When you need to replace/unbind the product bound to your Apple device, in the [Find My] app, in the [Items] tab, find the product that needs to be unbound, slide to the bottom of the page, click [Remove item], click [Remove], and click [Remove] again to confirm that the product is no longer available in the [Items] tab.

※If you physically reset the product before unbinding, it will take longer for the Apple device to remove the product.

SPECIFICATION

產品規格 / 产品规格

MODEL: BR13

Battery Capacity : 3.7V 80mAh

Input : 5V = 100mA

Material : PC+ABS

Size : 65x38x11.5mm

Weigh : 18g

Compatible with Apple Find My App

Remarks: Please check your iOS / IPADOS / macOS version in iPhone series, iPad Touch series, iPad series, iMac & Macbook series of the iOS / IPADOS / macOS 版本。

CONTAINS:

- Camera Scanning Find My Locator
- Snap Hook
- USB-A to USB-C cable
- Adhesive sticker x 10pcs
- Instruction manual and warranty card

型號: BR13

電池容量 : 3.7V 80mAh

輸入 : 5V = 100mA

材質 : PC+ABS

尺寸 : 65x38x11.5mm

重量 : 18g

兼容 Apple Find MY 應用程式

備註：請檢查您的 iPhone 系列、iPad Touch 系列、iPad 系列、iMac & Macbook 系列中的 iOS / IPADOS / macOS 版本。

包裝內容：

- 鏡頭掃描 Find My 全球定位器
- 彈簧鉤
- USB-A 到 USB-C 充電線
- 產品標籤貼紙 x 10pcs
- 使用說明書及保用證

型號: BR13

電池容量 : 3.7V 80mAh

輸入 : 5V = 100mA

材質 : PC+ABS

尺寸 : 65x38x11.5mm

重量 : 18g

兼容 Apple Find MY 應用程式

備註：請檢查您的 iPhone 系列、iPad Touch 系列、iPad 系列、iMac & Macbook 系列中的 iOS / IPADOS / macOS 版本。

包裝內容：

- 鏡頭掃描 Find My 全球定位器
- 彈簧鉤
- USB-A 到 USB-C 充電線
- 產品標籤貼紙 x 10pcs
- 使用說明書及保用證

WARNING

- Do not dismantle or modify the product;
- Do not store the product in wet conditions;
- Do not keep or use the product near heat sources;
- Do not let water or any other liquid flows into the inside part of the product's interface. This would cause damages to the product;
- Avoid direct sunlight. Keep away from heat source;
- Avoid high processor load in long running loops or while charging;
- Ensure good ventilation while using;
- In case of overheating, stop using the product.

DISPOSAL OF ELECTRONIC PRODUCTS

- Do not place the product as household waste;
- Please dispose of discarded electronic products properly according to local regulations.
- MOMAX encourages you to participate in electronics recycling program.

WARRANTY CONDITIONS

- For any defect, in the judgment of our technician, caused under normal use, we are responsible for repairing free of charges 12 months commencing from the date of purchase at the discretion of our company;
- A valid warranty card and original purchase invoice must be presented upon request of warranty service;
- This warranty card shall not apply to the product if: (a) it has explicitly modified or repaired in any way by persons other than technicians of this company, or; (b) it has been damaged through misuse, malicious acts, negligence, inflow of any liquid, or; (c) losses or damages are caused by force majeure or natural disasters.
- No alteration to this warranty card will be allowed;

- The warranty terms and conditions are subject to change without prior notice;
- Please retain your proof of purchase for warranty service;
- Please consult the dealer about the product compatibility with your cell phone/ PDA before purchase. Product specifications are subject to change without prior notice;
- Please visit www.momax.net for latest product information.

警告

- 請勿自行拆開或改裝本產品；
- 請勿將產品存放在潮濕環境中；
- 請勿將產品靠近熱源或於熱源附近充電；
- MOMAX 鼓勵您積極參與電子產品回收計劃。

如何處理廢棄電子產品

- 請勿將電子產品當成家庭廢棄物丟棄；
- 請依當地的法例規定處理廢棄的電子產品；
- MOMAX 鼓勵您積極參與電子產品回收計劃。

保養條款

- 由購買日期起12個月內，如產品有損壞或故障，經本公司技術人員證實為在正常使用之情況下發生，本公司將提供免費維修服務。
- 維修時必須出示本保用證及購買商號之發票正本，如果用戶不能提供，本公司有權不提供維修服務。
- 保用期內，出現以下條款產品保用證自動失效：

- 非本公司人員任意拆解或 維修產品之任何部分；
- 錯誤的操作如：非法接取電源，以及水、污穢物等；
- 不可抗拒意外事件或天然災害導致產品損壞；
- 此保用證如經塗改，保用證自動失效；
- 本公司有權增冊任何維修及保用條款而不作通知；
- 如因錯誤使用本公司產品而導致手提電話或其他電子產品有任何損壞，本公司不會承擔任何責任；
- 有關 MOMAX 原裝產品和您的手機或電子產品的相容性，請在購買時向經銷商確認。此產品規格隨時可能變更，恕不另行通知；
- 請瀏覽 www.momax.net 瞭解最新產品資訊。

警告

- 請勿自行拆開或改裝本產品；
- 請勿將產品存放在潮濕環境中；
- 請勿將產品靠近熱源或于熱源附近充電；
- 請勿將產品或其它液体流入本产品介面内部，导致本产品损坏；
- 避免阳光直射照射；
- 使用或充电期间避免长时间运行高耗能的程式；
- 請於通風良好的地方使用；
- 如出現過熱，請停止使用。

如何處理廢棄電子產品

- 請勿將電子產品當成家庭廢棄物丟棄；
- 請依當地的法例規定處理廢棄的電子產品；
- MOMAX 鼓勵您積極參與電子產品回收計劃。

保養條款

- 由購買日期起12個月內，如產品有損壞或故障，經本公司技術人員證實為在正常使用之情況下發生，本公司將提供免費維修服務。
- 維修時必須出示本保用證及購買商號之發票正本，如果用戶不能提供，本公司有權不提供維修服務。
- 保用期內，出現以下條款產品保用證自動失效：

- 用戶可能需要支付相關維修費用；
- 保用期內，出現以下條款產品保用證自動失效：
- 非本公司人員任意拆解或 維修產品之任何部分；
- 錯誤的操作如：非法接取電源，以及水、污穢物等；
- 不可抗拒意外事件或天然災害導致產品損壞；
- 此保用證如經塗改，保用證自動失效；
- 本公司有權增冊任何維修及保用條款而不作通知；
- 如因錯誤使用本公司產品而導致手提電話或其他電子產品有任何損壞，本公司不會承擔任何責任；
- 有關 MOMAX 原裝產品和您的手機或電子產品的相容性，請在購買時向經銷商確認。此產品規格隨時可能變更，恕不另行通知；
- 請瀏覽 www.momax.net 了解最新產品資訊。

有害有毒物質或元素列表									
部件名稱	鉛 (Pb)	鎘 (Cd)	鉻 (Cr)	多環芳烴 (PAHs)	多環芳烴 (PbDE)	多環芳烴 (PbDE)	多環芳烴 (PbDE)	多環芳烴 (PbDE)	多環芳烴 (PbDE)
電池	X	0	0	0	0	0	0	0	0
其他	0	0	0	0	0	0	0	0	0

0: 表示含有害物質含量在法部標準和材料科學的標準在 GB/T 26572 中規定的限量以下。
X: 表示含有害物質含量在法部標準和材料科學的標準在 GB/T 26572 中規定的限量以上。
注: 本產品符合“X”的要求是，從設計和技術上可避免使用有害物質。

CE FC RoHS

momax

WARRANTY/保用證/保用证

Model/型號/型号:

Date of Purchase/購買日期/购买日期:

Remarks/備註/备注:

Customer Service/客戶服務中心/客户服务中心

Hong Kong and Macau:

Unit A, 4/F., Cheung Lung Ind. Bldg.,

Lai Chi Kok, Kowloon, Hong Kong/10 Cheung Yee Street,

Hong Kong: 852-2402 3186 E-Mail: info@momax.net

香港及澳門:

香港九龍慈雲角長興街10號昌隆大廈4樓A室

服務熱線: 852-2402 3186 電郵: info@momax.net

中国内地:

摩米士科技(深圳)有限公司

廣東省深圳市龍崗區坂田街道南區社區營業路2016號威

字庫布吉商場四層

郵編: 518000 全國服務熱線: 86-400-880-0010

電話: info@momax.net

Copyright© 2024 MOMAX Technology Ltd. All rights reserved.

MOMAX is registered trademark of MOMAX Technology Ltd.

All other trademarks are the property of their respective owners.

版權所有 ©2024 MOMAX Technology Ltd.，保留所有權利。

MOMAX是 MOMAX Technology Ltd. 的註冊商標。

所有其他商標均為其各自擁有者的財產。

版權所有 ©2024 MOMAX Technology Ltd.，保留所有權利。

MOMAX是 MOMAX Technology Ltd. 的註冊商標，所有其他商標均為其各自擁有者的財產。

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.