PANTONE color as below:

Pantone 306C   Pantone 1375C

材质：105G哑粉　80*80MM

80mm

80mm

blurams

Outdoor Lite 4 - A22C

User Manual

Packing List

1 × Camera   1 × Power Cord   1 × Screws Accessories Kit   1 x Waterproof Case

1 × Positioning Paper   1 × Bracket   1 × User Manual

1

Get to know your camera

Speaker
Reset Button
Micro SD Card Slot

Power Port

LAN Port

Antenna
Microphone
Spotlight
Lens
Indicator Light

2

---

1. Power up your camera

For the normal operation of the camera, please use the provided power cord to charge it.

Power Port

LAN Port

3

4

The camera has a power port and a LAN port. Waterproofing must be done on both of these ports.
1. Wrap the power port with waterproofing tape (self-provided) as shown below.
2. Wrap the LAN port with the waterproofing tape (self-provided) or the waterproofing case.

Wrapping with the waterproof tape

Wrap the power port with waterproofing tape.

Wrap the LAN port with waterproofing tape.

Wrapping with the waterproof tube

5

---

2. Download blurams App

Download the App by searching "blurams" in the App Store or Google Play. Alternatively, you can open a QR scanner App and scan the blurams App QR code below to install the App.

blurams App QR code

GET IT ON Google Play   Download on the App Store

6

---

3. Add your camera to App

Enter the blurams App, sign up for a free blurams account and log in. Go to the home page, click the "+" icon on the top right corner and select the model of your camera. Then follow the instructions to finish the device configuration.

7

FAQs

Why can't I add the camera to the App?
1. Please charge the camera first, and when seeing the red flashing indicator light, the camera is ready to pair.
2. Connect your smartphone and the camera to the same 2.4GHz Wi-Fi network (5GHz network is not supported currently).
3. Keep the camera, phone, and Wi-Fi router as close as possible during pairing.

Why can't the camera scan the QR code?
1. Remove the lens protective film and make sure there is no dust on the lens.
2. Adjust the smartphone screen brightness to high.
3. Tap the QR code picture to enlarge it.
4. Adjust the distance between the lens and screen, the optimal distance is 3-5 inches.

8

Can't hear sound from camera?
1. Check "Preferences" to turn "Microphone" option on.
2. Remove the protective film, and try talk closer and louder to the camera.
3. Restart the camera.

Why is the captured video black and white?
1. Position the camera in a well-lit environment during the daytime.
2. Check "Preferences" to see if the night vision is ON.
3. Restart the camera and re-add it to the App.
4. If you continue seeing black and white or other abnormal colors after trying all the above solutions, please contact the support team for help.

Why is the picture upside down?
In the blurams App, go to the device's "Preferences" and tap "Rotate 180°". If you encounter any other problems in Product Information, Product Installation and Use, please refer to the "Mine > Help And Feedback" in the blurams App or email support@blurams.com.

9

How to turn the spotlight on?
In the blurams App, please go to the device's "Preferences" and tap "Night vision", then you can choose to turn on or off the spotlight.

Do I have to use an Ethernet cable when I add the camera for the first time?
No, you can also scan the QR code to connect under 2.4Ghz Wi-Fi, or use an Ethernet cable for a more stable connection.

Look forward to your feedback
blurams strives for offering high-quality products and thoughtful user experience, and we're eager to hear your feedback or suggestions. Feel free to send your feedback through the App or email at support@blurams.com.

10

Notes:
1. We recommend using an Ethernet cable to get a better and more stable network connection.
2. Do not use the camera in any extreme weather environments such as extremely high, low temperatures, direct strong sunlight, or heavy rain for long periods of time. The suitable temperature for the product and accessories is -20℃ to 50℃.
3. If you use a third-party charger, the recommended output voltage/current of the adaptor is DC 12V/1A, and the adapter should be CE approval type.
4. RF Exposure Information: The Maximum Permissible Exposure (MPE) level has been calculated based on a distance of d=20cm between the device and the human body. To maintain compliance with RF exposure requirements, use products that maintain a 20cm distance between the device and the human body.
5. Operating Frequency Range: 2412 MHz ~ 2472 MHz
   Max Output Power: 20dBm
6. This product can be used across EU member states.

11

Congratulations!

Your camera is ready to use. Thank you for choosing blurams.

blurams Facebook   blurams Instagram

support@blurams.com
www.blurams.com