


规格4.72x3.5cm
10g净重量
重量1.2g 宽度15mm
15号

LISEN 2E789	Product accessory list & image are for reference only. Actual accessories may vary slightly from the image. PRODUCT ACCESSORY LIST 	PRODUCT STRUCTURE 	PRODUCT PARAMETERS PRODUCT MODEL: 2E789 NET WEIGHT: 10g LENGTH: 4.72cm WIDTH: 3.5cm THICKNESS: 1.2mm COMPATIBLE DEVICES: All smartphones and tablets with a standard USB-C port.	COMPATIBLE DEVICES 1. Smartphones: All smartphones with a standard USB-C port. 2. Tablets: All tablets with a standard USB-C port. 3. Smart TVs: All smart TVs with a standard USB-C port. 4. Smart Home Appliances: All smart home appliances with a standard USB-C port. 5. Smart Wearables: All smart wearables with a standard USB-C port.	INSTALLATION STEPS FOR THE BRACKET 1. Before installation, please check the device is turned off and the screen is locked. 2. Clean the back of the device with a soft cloth to remove any dust or oil. 3. Peel off the protective film from the back of the device. 4. Align the bracket with the back of the device and press it firmly into place. 5. Check the bracket is secure and the device is properly aligned.	GUIDE DISK INSTALLATION PROCEDURE 1. Turn on the device and go to the settings menu. 2. Select the 'About' option and then the 'Software Update' option. 3. Check for updates and download the latest version of the operating system. 4. Follow the on-screen instructions to complete the update process. 5. Once the update is complete, restart the device.	NOTES 1. Read the user manual carefully before using the device. 2. Do not use the device in wet or humid environments. 3. Do not use the device near fire or other heat sources. 4. Do not use the device while driving or operating machinery. 5. Do not use the device for extended periods of time without taking breaks.	FCC WARNING STATEMENT This equipment complies with the FCC rules for Class B digital devices. It does not cause harmful interference. However, if it does cause interference, the user may need to take certain measures to eliminate the interference.	AFTER SALE SERVICE For more information, please contact our customer service team at 1-800-123-4567. Our service team is available 24/7 to assist you with any issues you may have.


LISEN
2E789

Product accessory list & image are for reference only. Actual accessories may vary slightly from the image.

ZUBEHÖRLISTE



PRODUKTSTRUKTUR



PRODUKTPARAMETER

PRODUKTMODEL: 2E789

NETZGEWICHT: 10g

LÄNGE: 4.72cm

BREITE: 3.5cm

DÜCKE: 1.2mm

KOMPATIBILE GERÄTE: Alle Smartphones und Tablets mit einem standardisierten USB-C-Anschluss.

KOMPATIBILE GERÄTE

1. Smartphones: Alle Smartphones mit einem standardisierten USB-C-Anschluss.

2. Tablets: Alle Tablets mit einem standardisierten USB-C-Anschluss.

3. Smart TVs: Alle Smart TVs mit einem standardisierten USB-C-Anschluss.

4. Smart Home Appliances: Alle Smart Home Appliances mit einem standardisierten USB-C-Anschluss.

5. Smart Wearables: Alle Smart Wearables mit einem standardisierten USB-C-Anschluss.

MONTAGESCHRITTE FÜR DIE HALTERUNG

1. Vor der Installation, bitte überprüfen Sie, ob das Gerät ausgeschaltet ist und der Bildschirm gesperrt ist.

2. Reinigen Sie den Rückseite des Geräts mit einem weichen Tuch, um Staub und Öle zu entfernen.

3. Entfernen Sie den Schutzfilm von der Rückseite des Geräts.

4. Alignieren Sie die Klammer mit der Rückseite des Geräts und drücken Sie sie fest an.

5. Überprüfen Sie, ob die Klammer sicher sitzt und das Gerät richtig ausgerichtet ist.

INSTALLATIONSANLEITUNG FÜR DEN MAGNETSTREIFEN

1. Schalten Sie das Magnetstreifen an und gehen Sie zu den Einstellungen.

2. Wählen Sie die Option 'Einstellungen' und dann 'Softwareaktualisierung'.

3. Überprüfen Sie, ob eine Aktualisierung verfügbar ist und laden Sie die neueste Version des Betriebssystems herunter.

4. Folgen Sie den Anweisungen auf dem Bildschirm, um die Aktualisierung zu beenden.

5. Nach der Aktualisierung, starten Sie das Gerät neu.

VORSICHTSMAßNAHMEN

1. Lesen Sie das Benutzerhandbuch sorgfältig durch, bevor Sie das Gerät verwenden.

2. Vermeiden Sie das Gerät in feuchten oder kalten Umgebungen zu verwenden.

3. Vermeiden Sie das Gerät in der Nähe von Feuer oder anderen Wärmequellen zu verwenden.

4. Vermeiden Sie das Gerät während der Fahrt oder beim Bedienen von Maschinen zu verwenden.

5. Vermeiden Sie das Gerät für längere Zeiträume ohne Unterbrechung zu verwenden.

FCC WARNING

This equipment complies with the FCC rules for Class B digital devices. It does not cause harmful interference. However, if it does cause interference, the user may need to take certain measures to eliminate the interference.

AFTER SALE SERVICE

For more information, please contact our customer service team at 1-800-123-4567.

Our service team is available 24/7 to assist you with any issues you may have.

RECEIVED

1-800-123-4567