



Notice
d'utilisation

EarCITY
Modèle C

Avant-propos

Ce mode d'emploi vous indique les informations nécessaires liées au produit et à son utilisation. Nous vous recommandons de le lire soigneusement avant toute utilisation.

Ce produit est conforme aux normes européennes en vigueur et certifié CE par un organisme notifié. Nous espérons qu'il vous donnera entière satisfaction.

N'hésitez pas à nous envoyer vos commentaires et remarques à :

contact@earsquared.com

Présentation



1 - Bouton +

2 - Bouton -

3 - Bouton multifonction Power

4 - Port de chargement

Caractéristiques

Modèle:EarCITY C

Technologie : Ecoute aérienne directionnelle

Mode : stéréo

Intensité sonore : 85dB

Gamme de fréquences : 20Hz à 20KHz

Bluetooth

Version : 5,1

Type : QCC3034

Fréquence d'émission : 2402 à 2480 Mhz

Portée : 10 à 15 m

Codecs pris en charge : APtx, A2DP1.3, AVRCP1.6, HFP1.7, HID1.1, AVCTP1.4, AVDTP1.3, SPP1.2

Micro

4015 anti-interférence, haute sensibilité

Batterie

Capacité : 210 mAh

Autonomie en fonctionnement : 6h

Autonomie en veille : 360h

Temps de charge : 1h30

Installation



Appairage

Assurez-vous que votre téléphone portable soit allumé, sa fonction Bluetooth activée et situé à moins de 1m du casque.

Appuyez et maintenez enfoncé le bouton power pendant 3 à 5s jusqu'à ce que le témoin lumineux clignote alternativement en rouge et bleu ou que vous entendiez le message vocal "pairing".

Lancez une recherche Bluetooth à partir de votre téléphone. Sélectionnez "EarCITY C". Lorsque votre téléphone est correctement connecté, un message vocal "connected" se fait entendre.



FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

www.earsquared.com





Utilisation

Commandes d'allumage	
Allumer/Eteindre	Appuyez 3s sur Power
Commandes de musique	
Lire ou suspendre la musique	Appuyez 1 fois sur Power
Augmenter le volume	Appuyez sur le bouton +
Baisser le volume	Appuyez sur le bouton -
Plage précédente	Appuyer 2 fois sur le bouton +
Plage suivante	Appuyer 2 fois sur le bouton -
Commandes d'appel	
Décrocher/Raccrocher	Appuyez 1 fois sur Power
Rejeter un appel	Appuyez 2 fois Power
Commandes d'assistance vocale	
Siri/Google now	Appuyez 2 fois sur Power
Batterie faible	
Lorsque la batterie atteint 10% de sa capacité, le témoin lumineux rouge clignote 3 fois toutes les 30s et un message vocal d'alerte « low battery, please charge » se fait entendre	

Entretien et maintenance

Gardez le produit au sec. L'humidité et tous les types de liquides peuvent endommager les circuits électroniques.

Ne pas utiliser ou ranger ce produit dans un milieu poussiéreux ou sale.

Ne pas laisser ce produit dans un lieu froid ou un lieu exposé à une forte chaleur.

Le produit doit être utilisé à une température comprise entre 0 et 40°C et une humidité comprise entre 0 et 85%.

Ne pas utiliser de produits chimiques, de solvants de nettoyage, ou de détergents pour nettoyer le produit.

Si un nettoyage est nécessaire, utilisez un chiffon doux en l'humidifiant si besoin avec de l'eau et du savon.

Si vous n'utilisez pas le produit pendant une longue période, veillez à le recharger au moins 1 fois par mois pour ne pas dégrader les performances de la batterie.

Consignes de sécurité

L'écoute prolongée à un volume élevé peut endommager votre audition. Plus le volume est élevé, plus le temps d'écoute est limité.

Pour une écoute sans risque, réglez le volume à un niveau raisonnable et pendant une durée raisonnable.

L'utilisation des écouteurs sur la voie publique peut distraire. Veuillez à toujours rester attentif à votre environnement et faites preuve de prudence dans des situations potentiellement dangereuses.

N'essayez pas de démonter le casque, cela pourrait causer un court-circuit de la batterie.

Ne plongez pas le casque dans de l'eau.

Gardez le produit à l'écart du feu ou d'un équipement à haute pression.

Ne laissez pas le produit à la portée d'un enfant agé de moins de 3 ans.

Ne jetez pas le produit à la poubelle, déposez-le à un point de collecte pour les produits électroniques.

Garantie

Earsquared garantit le remplacement sans frais des pièces défectueuses du produits ou des défauts ayant pu survenir en raison de problèmes lors de la fabrication pour une période de deux ans à compter de la date d'achat initiale.

Earsquared n'est pas responsable des pertes, blessures aux personnes ou pertes de propriétés qui pourraient résulter de l'utilisation du produit en dehors des pièces défectueuses ou des défauts survenus lors de la fabrication.

Pour plus d'informations ou si vous rencontrez un problème avec ce produit, merci de nouscontacter à : contact@earsquared.com en nous indiquant votre nom, adresse et numéro de commande.



User
Manual

EarCITY
Model C

Foreword

This user manual gives you the main informations about this product and how to use it. We recommend you to read it carefully before use.

This product complies with European standards and is CE certified by a notified office.

Don't hesitate to send us your comments and experiences to :

contact@earsquared.com

Présentation



1 + button

2 - button

3 Multifunction button

4 USB charging port

Technical data

Modèle:EarCITYC

Technology : Aerial directionnal

Mode : stereo

Sound intensity : 85dB

Frequency range : 20Hz à20KHz

Bluetooth

Version : 5.1

Type : QCC3034

Emission frequencies : 2402 à 2480 Mhz

Operating range : 10 à 15 m

support:APtx,A2DP1.3,AVRCP1.6,HFP1.7, HID1.1, AVCTP1.4, AVDTP1.3, SPP1.2

Microphone

4015 anti-interference, high sensibility

Batterie

Capacity:210mAh

Play time : 6h

Standby time : 360h

Charging time : 1h30

Installation



Pairing method

Make sure your mobile phone is switched on, the bluetooth function is activated and within 1m off the headset.

Press and hold the power button for 3 to 5s until the indicator light alternately flashed in red and blue. A voice message says "pairing"

Start a Bluetooth search from your mobil phone. Select "EarCITY C". When your phone is connected, a voice message "connected" is heard.



FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

www.earsquared.com





Using

Switch operations	
Power on/Power off	Press 3s on power button
Music operations	
Play/pause music	Press once on power button
Increase the volume	Press on + button
Decrease the volume	Press on - button
Previous song	Press twice on + button
Next song	Press twice on - button
Call operations	
Pick up/Hang	Press once on power button
Reject a call	Press twice on power button
Voice assistance operation	
Siri/Google now	Press twice on power button
Low battery	
When the battery power is lower than 10%, the red light flashes 3 times every 30s and there is a low battery warning sound « low battery, please charge »	

General informationsSafety instructions

Keep the product dry. Humidity and all types of liquids can damage the electronic circuits.

Do not use or store this product in a dusty or dirty environment.

Do not leave this product in a cold place or exposed at high temperature.

The operate temperature range is between 0 and 40°C with a humidity between 0 to 85%.

Do not use chemicals, cleaning solvants or detergents to clean the product.

If a cleaning is necessary, use a soft cloth with little soap and water.

If you don't use the product for a long time, please recharge it at least once in order to prevent the deterioration of the battery performances.

warranty

Earsquared guarantees the replacement for free of the defective parts of the product or the defects which may occur during manufacturing process for a period of two years from the initial purchase date.

Earsquared is not responsible for anyloss, injury to persons or loss of property which may result from the use of the product.

For more information or if you have any problem with this product, please contact us at : contact@earsquared.com indicating your name, adress and order number.