

K30

产品介绍

Operation Manual  
使用说明书

WWW.SAINTLARK.COM

规格参数

输出功率	<60W	频率范围	60HZ~20KHZ
电池规格	7.4V/4000mAh	防水等级	4级
充电电压	DC5V=2A	蓝牙传输	约10米
充电时间	约5小时	放电时间	约3.5小时

操作说明

项目	操作说明	LED状态
开机	关机状态下长按电源键3-4秒	蓝色LED亮
关机	开机状态下长按电源键3-4秒	蓝色LED灭
蓝牙配对	开机自动进入蓝芽配对模式，其它模式长按切换。	蓝灯闪烁，显示配对成功。
断开蓝牙配对	长按播放/暂停键3秒	蓝色LED闪烁
模式切换	按M键可以在BT/AUXS/TF/AUX/M模式间切换	相应模式点亮
无线模式	按M键切换	/
无线配对	按M键切换到无线模式，长按M键进行配对	蓝色LED闪烁
AUX模式	插入AUX线并自动切换，其它模式按M键切换	/
TF卡模式	插入TF卡并自动切换，其它模式按M键切换	/
U盘模式	插入U盘并自动切换，其它模式按M键切换	/
耳机模式	/	/
播放/暂停	短按播放/暂停键	/
上一曲	短按“-”键	/
下一曲	短按“+”键	/
音量加	长按“+”键	/
音量减	长按“-”键	/
暂停/播放/静音	短按播放/暂停键(AUX模式是静音功能)	/
充电中	插入Type-C充电线(5V-2A)	红色LED长亮
充电完成	充满后自动完成	充满LED灯灭

注意事项

- 为了达到扩音最佳效果，请将喇叭放置离正面前方1-2cm处对准耳朵发音。若有啸叫，可适当调小音量或将机器与喇叭的距离稍微拉开，以防互相干扰；
- 尽量避免频繁接触麦克风插口，以免造成插口松动而引起接触不良，不可将话筒和音箱插错；
- 为保证锂电池使用寿命，建议使用完再充电，频繁充电将加速电池芯片老化，长时间不用时应每隔两月充一次电；
- 因喇叭磁性较强，不可将机器和银行卡等带磁性的东西放在一起，以免造成损失而带来不必要的麻烦；
- 增加设备和接收器之间的距离，
- 将该设备连接到与接收器所连接电路不同的电路插座。
- 请咨询经销商或有经验的无线电/电视技术人员以获得帮助。
- 为确保持续续航，未经该方明确批准的任何更改或修改。
- 对合规性负责可能会使用户失去操作本设备的权限。（例如：连接到计算机或外围设备时，仅使用屏蔽接口电缆）。
- 本产品在和正常使用过程中可能会轻微发热，这属于正常现象；
- 请使用抗静电软布来清洁擦拭本品，在清洁产品时请先关闭电源开关，并拆卸所有外部附件，请勿用化学物质擦拭(如酒精、苯等化学溶剂)或有磨砂性质的清洁剂擦拭；
- 请勿摔落、挤压或者弯曲本产品，请勿擅自拆解本产品，否则不能享受本公司的免费维修服务。

常见问题的自我解决:

1. 开关开启，没有声音
  - A. 屏幕灯不亮，电源没电，充电解决；
  - B. 音量调节处于最小位置，适当调节音量
2. 有明显啸叫
  - A. 将麦克风风嘴头对准嘴角方向，麦克风与主机保持2-3m距离；
  - B. 空间变小时应适当调低音量以免造成啸叫。

若仍有以上问题，请联系SAINTLARK售后服务。

FCC声明

根据FCC规则的第15部分，本设备已经过测试，符合B类数字设备的限制，这些限制旨在提供合理的保护，防止住宅安装中的有害干扰。本设备产生、使用并可辐射射频能量，如果不能按照说明安装和使用，可能会对无线电通信造成有害干扰。但是，不能保证在特定安装中不会发生干扰。如果本设备确实对无线电电话接收造成有害干扰（可通过关闭和打开设备进行确定），建议用户尝试通过以下一种或多种方法来消除干扰：

- 调整接收天线的方向或位置。
- 增加设备和接收器之间的距离。
- 将该设备连接到与接收器所连接电路不同的电路插座。
- 请咨询经销商或有经验的无线电/电视技术人员以获得帮助。

为了确保持续续航，未经该方明确批准的任何更改或修改。对合规性负责可能会使用户失去操作本设备的权限。（例如：连接到计算机或外围设备时，仅使用屏蔽接口电缆）。

本设备符合FCC规则第15部分的规定。请满足以下两个条件:  
(1)本设备不得造成有害干扰。  
(2)本设备必须接受任何接收到的干扰，包括可能导致额外操作的干扰。

FCC辐射暴露声明:

该装置已经过评估，可满足一般射频暴露要求。该装置可在便携式暴露条件下使用，不受任何限制。

安全警告

- 请勿将产品及配件靠近火源或任何过热的环境中。
- 请勿将产品及配件接触水及湿气，不要在不靠近水的地方使用本设备，也不应将产品浸入任何液体中，避免产品及配件受到水滴或水溅。
- 请勿自行打开或任意拆解、维修电池组，如果电池更换不当会有爆炸危险，严禁将设备投入水、火中或靠近任何过热的环境中。
- 本产品由外接电源适配器(5V-2A)充电后使用，充电后可方便的通过拔掉电源适配器插头断开电网电源。
- 当产品不使用本产品时，请将产品电源开关拨至关闭/关机状态关闭电源(参见产品展示示意图)，避免电池的流失。
- 当禁止使用无线设备或设备的使用会引起电子设备的干扰与安全隐患时，请关闭本产品。
- 在易燃易爆区域，请关闭本产品，并遵守相关标示说明，以免引起火灾或火灾。易燃易爆区域包括但不限于：加油站、易燃或化工制品运输及储存设施、有爆炸危险标志的区域、有关“双向无线电设备”标志的区域。
- 乘坐飞机时，请遵守航空公司有关规定和条例，在飞机起飞前关闭本产品，以免造成安全隐患。
- 仅适用于非热带气候条件下安全使用，仅适用于海拔2000米以上地区安全使用。

深圳市圣百灵科技有限公司  
深圳市宝安区西乡三围空国际兆丰工业园6楼  
Tel : 400 998 5058    www.saintlark.com

CMIT ID: 2022DP12458

K30

## Product Introduction

**TF Card**

**AUX input**

**Previous/Volume**

**Play/Pause**

**Mode**

**Next/Volume**

**USB Slot**

**Power**

**Type-C Slot**

**Handle**

**Status Light**

**Charging Light**

## Specifications

Output Power	≤60W	Frequency Range	60HZ~20KHZ
Battery Model	7.4V/4000mAh	Waterproof	IPx4
Charging Voltage	DC5V=2A	Bluetooth	≈10m
Charging Time	=5hours	Play Time	≈3.5hours

## Instructions

- Power on:** Press the power button for 3-4 seconds.
- Power off:** Press the power button for 3-4 seconds.
- Bluetooth match:** The device automatically enters Bluetooth pairing mode upon startup. Press M to switch to other modes. Long press the Play button to disconnect Bluetooth pairing.
- Mode switch:** Press M to switch between BT/USB/TX/AUX.
- Wireless mode:** Press M to switch.
- Wireless pairing:** Press M to switch to wireless mode and long press M for pairing.
- AUX mode:** Insert AUX cable to switch automatically, and press M key to activate other modes.
- TF mode:** Insert TF card and switch automatically. Press M to switch other modes.
- U disk mode:** Insert U disk and switch automatically. Press M to switch other modes.
- Play/pause:** Press the play/pause button.
- Previous:** Short press the "<" key.
- Next:** Short press the "+" key.
- Volume+:** Long press the + button.
- Volume-:** Long press the - button.
- Pause/play/mute:** Short press Pause button (AUX mode is mute function).
- In charge:** Plug in Type-C Charging Cable (5V 2A).
- Charge completion:** Full charge red LED light off.

## Operation Manual

使用说明书

## Specifications

Output Power	≤60W	Frequency Range	60HZ~20KHZ
Battery Model	7.4V/4000mAh	Waterproof	IPx4
Charging Voltage	DC5V=2A	Bluetooth	≈10m
Charging Time	=5hours	Play Time	≈3.5hours

## Instructions

- Power on:** Press the power button for 3-4 seconds.
- Power off:** Press the power button for 3-4 seconds.
- Bluetooth match:** The device automatically enters Bluetooth pairing mode upon startup. Press M to switch to other modes. Long press the Play button to disconnect Bluetooth pairing.
- Mode switch:** Press M to switch between BT/USB/TX/AUX.
- Wireless mode:** Press M to switch.
- Wireless pairing:** Press M to switch to wireless mode and long press M for pairing.
- AUX mode:** Insert AUX cable to switch automatically, and press M key to activate other modes.
- TF mode:** Insert TF card and switch automatically. Press M to switch other modes.
- U disk mode:** Insert U disk and switch automatically. Press M to switch other modes.
- Play/pause:** Press the play/pause button.
- Previous:** Short press the "<" key.
- Next:** Short press the "+" key.
- Volume+:** Long press the + button.
- Volume-:** Long press the - button.
- Pause/play/mute:** Short press Pause button (AUX mode is mute function).
- In charge:** Plug in Type-C Charging Cable (5V 2A).
- Charge completion:** Full charge red LED light off.

## Product Introduction

**TF Card**

**AUX input**

**Previous/Volume**

**Play/Pause**

**Mode**

**Next/Volume**

**USB Slot**

**Power**

**Type-C Slot**

**Handle**

**Status Light**

**Charging Light**

## Specifications

Output Power	≤60W	Frequency Range	60HZ~20KHZ
Battery Model	7.4V/4000mAh	Waterproof	IPx4
Charging Voltage	DC5V=2A	Bluetooth	≈10m
Charging Time	=5hours	Play Time	≈3.5hours

## Instructions

- Power on:** Press the power button for 3-4 seconds.
- Power off:** Press the power button for 3-4 seconds.
- Bluetooth match:** The device automatically enters Bluetooth pairing mode upon startup. Press M to switch to other modes. Long press the Play button to disconnect Bluetooth pairing.
- Mode switch:** Press M to switch between BT/USB/TX/AUX.
- Wireless mode:** Press M to switch.
- Wireless pairing:** Press M to switch to wireless mode and long press M for pairing.
- AUX mode:** Insert AUX cable to switch automatically, and press M key to activate other modes.
- TF mode:** Insert TF card and switch automatically. Press M to switch other modes.
- U disk mode:** Insert U disk and switch automatically. Press M to switch other modes.
- Play/pause:** Press the play/pause button.
- Previous:** Short press the "<" key.
- Next:** Short press the "+" key.
- Volume+:** Long press the + button.
- Volume-:** Long press the - button.
- Pause/play/mute:** Short press Pause button (AUX mode is mute function).
- In charge:** Plug in Type-C Charging Cable (5V 2A).
- Charge completion:** Full charge red LED light off.

## Product Introduction

**TF Card**

**AUX input**

**Previous/Volume**

**Play/Pause**

**Mode**

**Next/Volume**

**USB Slot**

**Power**

**Type-C Slot**

**Handle**

**Status Light**

**Charging Light**

## Specifications

Output Power	≤60W	Frequency Range	60HZ~20KHZ
Battery Model	7.4V/4000mAh	Waterproof	IPx4
Charging Voltage	DC5V=2A	Bluetooth	≈10m
Charging Time	=5hours	Play Time	≈3.5hours

## Instructions

- Power on:** Press the power button for 3-4 seconds.
- Power off:** Press the power button for 3-4 seconds.
- Bluetooth match:** The device automatically enters Bluetooth pairing mode upon startup. Press M to switch to other modes. Long press the Play button to disconnect Bluetooth pairing.
- Mode switch:** Press M to switch between BT/USB/TX/AUX.
- Wireless mode:** Press M to switch.
- Wireless pairing:** Press M to switch to wireless mode and long press M for pairing.
- AUX mode:** Insert AUX cable to switch automatically, and press M key to activate other modes.
- TF mode:** Insert TF card and switch automatically. Press M to switch other modes.
- U disk mode:** Insert U disk and switch automatically. Press M to switch other modes.
- Play/pause:** Press the play/pause button.
- Previous:** Short press the "<" key.
- Next:** Short press the "+" key.
- Volume+:** Long press the + button.
- Volume-:** Long press the - button.
- Pause/play/mute:** Short press Pause button (AUX mode is mute function).
- In charge:** Plug in Type-C Charging Cable (5V 2A).
- Charge completion:** Full charge red LED light off.

## Product Introduction

**TF Card**

**AUX input**

**Previous/Volume**

**Play/Pause**

**Mode**

**Next/Volume**

**USB Slot**

**Power**

**Type-C Slot**

**Handle**

**Status Light**

**Charging Light**

## Specifications

Output Power	≤60W	Frequency Range	60HZ~20KHZ
Battery Model	7.4V/4000mAh	Waterproof	IPx4
Charging Voltage	DC5V=2A	Bluetooth	≈10m
Charging Time	=5hours	Play Time	≈3.5hours

## Instructions

- Power on:** Press the power button for 3-4 seconds.
- Power off:** Press the power button for 3-4 seconds.
- Bluetooth match:**

The image displays the Saintlark brand logo, which consists of a circle containing a stylized 'S' and 'L' intertwined. Below the logo, the brand name 'SAINTLARK' is written in a large, bold, sans-serif font. Underneath the brand name, the tagline 'LISTEN TO THE WORLD' is written in a smaller, all-caps, sans-serif font. To the right of the tagline is a small registered trademark symbol (®). Below this, there is a horizontal dashed line. Under the dashed line, the text '保修条款' (Warranty Policy) is written in a bold, sans-serif font. This is followed by a numbered list of warranty terms in Chinese. The list includes instructions on how to use the product, how to fill out the warranty card, and the conditions under which the product is covered or not covered by the warranty. The list is numbered 1 through 7. At the bottom of the image, the website address 'WWW.SAINTLARK.COM' is written in a bold, sans-serif font.

SAINTLARK  
LISTEN TO THE WORLD

®

保修条款

一、购买本产品，请认真填写此卡，仔细阅读以下保修条款，以确保产品得到有效保修。

1. 用户在购买产品时认真填写此卡，并请销售商盖章确认。

2. 保修时需同时提供保修卡。

3. 本保修卡所填资料真实，否则无效。

4. 本产品保修期为一年，在保修期内如产品发生故障，属原厂产品不良所致的问题，本公司提供免费维修及部件更换。

二、下列原因造成产品损坏不能正常使用，不在保修范围内。

1. 未按说明书使用及安装造成的损坏。

2. 一切人为或意外造成的产品损坏。

3. 未经本公司认可的维修，改装或产品封贴破损者。

4. 产品表面装饰的老化、褪色及划痕。

三、保修期满后，用户仍可得到本公司提供维修服务，但要支付相应费用。

WWW.SAINTLARK.COM

# SAINTLARK

(保修卡)

描述: \_\_\_\_\_ 流水号: \_\_\_\_\_

型号: \_\_\_\_\_

名字: \_\_\_\_\_

地址: \_\_\_\_\_

邮箱: \_\_\_\_\_

电话: \_\_\_\_\_

产品日期: \_\_\_\_\_

合格

QC01

(名称和地址)



深圳市圣百灵科技有限公司  
深圳市宝安区西乡三围航空港兆丰工业园6楼  
Tel. 0755-23016541    [www.saintlark.com](http://www.saintlark.com)

# SAINTLARK

(保修卡)

描述: \_\_\_\_\_ 流水号: \_\_\_\_\_

型号: \_\_\_\_\_

名字: \_\_\_\_\_

地址: \_\_\_\_\_

邮箱: \_\_\_\_\_

电话: \_\_\_\_\_

产品日期: \_\_\_\_\_

合格

QC01

(名称和地址)



深圳市圣百灵科技有限公司  
深圳市宝安区西乡三围航空港兆丰工业园6楼  
Tel. 400 998 3058    [www.saintlark.com](http://www.saintlark.com)