Electric Scooter

ES PRO

CAROMA

R&B YOU

E-SPEED ELECTRIC SCOOTER

CHANGE YOUR WAY OF TRAVEL

USER MANUAL

Please read this manual carefully before using the product. Keep it for future reference. Failure to follow the instructions may result in injury or damage.

Safety Precautions

1. Always wear a helmet and knee and elbow pads when riding.
2. Do not ride the scooter in the rain or in wet conditions, as this can significantly increase speed and riding hazards.
3. Do not ride the scooter on the sidewalk, in the street, or on roads where cars are nearby. Only ride on bike lanes for any reasons.
4. Riders under the age of 16 years old should only ride under adult supervision.
5. Do not ride the scooter while under the influence of alcohol.
6. When using electric scooter, ensure you are riding slowly in crowded places.
7. Do not ride the scooter on uneven surfaces, such as gravel, sand, or grass, as it can cause the scooter to tip over.
8. Make sure all screws are in condition and appropriately fastened.
9. Do not overload the scooter. Only one person should ride on it at a time.
10. The range of the scooter is affected by factors such as weight, terrain, and weather conditions.
11. Allow to cool, dry and well-ventilated place when not in use.
12. Do not leave it near extremely warm or hot areas.

FOR USERS IMPORTANT

Thank you for choosing CAROMA electric scooters to ensure the safe use of the product and maintain the excellent performance and durability of the electric scooter, we've carefully prepared this instruction manual for you. We recommend that CAROMA electric scooter users read the instructions carefully before using the product to ensure that they understand the correct operation and precautions. In addition, to ensure the safety of you and others, please read the user manual carefully before using the product. Please keep the manual properly for future reference. If you have any questions or suggestions about the product, please feel free to contact the customer service hotline listed in the manual. Please refer to the manual before it. Please carefully read and observe the contents marked with the symbol.

ABOUT THIS BRAND

Every sustainable scene is inclined to physical health. Small scooters can make a big difference.

CAROMA is a leading brand specializing in the R&D, manufacturing and sales of electric scooters. Our products are committed to providing users with convenient, safe, and environmentally friendly travel solutions. We have a professional team of engineers and designers who are dedicated to continuously innovating and improving the performance, quality, and design of our electric scooters. Our goal is to make urban commuting more efficient and enjoyable for our customers.

CAROMA brand is trusted and welcomed by users for their unique design, cutting-edge technology, and exceptional after-sales service. We are committed to building long-term relationships with our customers and providing them with the best possible experience.

If you have any questions regarding the ES PRO, please contact us and we're glad to help. Look forward to your feedback.

Team mailbox:caromaservice-team@outlook.com

Happy Riding!

The CAROMA Team

TABLE OF CONTENTS

Section 1
GENERAL INFORMATION
1.1 Important Information 07
1.2 Safety Warnings 10
1.3 Disposal at End of Life 13
1.4 FCC Information 14

Section 2
PARTS & FEATURES
2.1 What's in the Box 16
2.2 ES PRO Diagram 17
2.3 Display Information 19

Section 3
ASSEMBLY & FOLDING
3.1 Standing, Folding & Unfolding the Scooter 20
3.2 Assembling the Handlebars 21

Section 4
CHARGING
4.1 Charging the ES PRO before Using It 11

Section 5
USAGE

4.2 How to Ride 22
Tips - Practicing Acceleration 23

Section 6
MAINTENANCE
6.1 Tire Pressure 24
6.2 Storage 24
6.3 Troubleshooting 25

Section 7
SPECIFICATIONS & BUTTON FUNCTIONS
7.1 Specifications 27
7.2 Button Functions 28
7.3 Error Code 30

Section 8
WARRANTY 31

Section 9
Recommendations for Using Tuya Smart APP
Installation 32
APP Control Multi-Screen Description 41
APP Driving Parameter Interface Description 42
APP Anti-Theft Function Interface Description 43

Section 1
GENERAL INFORMATION

Before operating your scooter, please read all instructions. This manual will guide you through the functions, usage, and maintenance of your scooter. Please keep it in a safe place for future reference. If you have any questions about the information in any user manual, please contact your dealer or customer service. Customer service hours are from the information you need. Before contacting customer service, please have your purchase information ready so the may be copied during the warranty registration process, if applicable.

Date of Purchase:

Place of Purchase:

Please read this manual before first battery exercise high-risk appear throughout the manual and examine good. Improper use may cause ELECTRIC scooter. Closed-circle manual device you should not use your ES PRO.

1.1 Important Information

Within the manual, "the ES PRO", "your ES PRO", "your scooter" and "the scooter" refers to the ES PRO electric scooter. By using your ES PRO electric scooter, you accept all risks associated with the scooter. Riding the ES PRO, the rider acknowledges and accepts responsibility for all risks associated with the use of the ES PRO, which may result in injury, death, or damage to property. Please ride safely and responsibly to minimize these risks. To better more your safety, **SUBSCRIPTION APPROPRIATE PARTICIPATE MUSIC.** read and follow all instructions and warnings in the User Manual.

Children under age should not install drum, lowpads, shoes pads and an ESTRUTURA!

1.2 Safety Warnings

When operating the electric ride these risers.

Riders with this icon MUST be head, understood, and always to prevent injury or damage, etc.

Riders with this icon include risks of the injuries.

Riders with this icon include risks of the injuries, damage and shortages.

- **Avoid using or storing the scooter under battery in extremely hot or extremely cold environments. Using the scooter in extreme temperatures can damage the battery and may cause it to become hot or to break outdoor shows traditional formation of ES PRO electric.**
- **Do not subject the battery to strong impact or shock.**
- **Do not disassemble the battery or any part of the scooter. The scooter's stability parts if drawing is loaded. Always turn electric ride with water or cold Canvas and take off the scooter.**
- **Risers submerge the scooter or any of the scooter's components.**
- **Before each ride, inspect the scooter and its components to verify your battery scrub all and brakes. Only unlicensed repair centers may open and service the battery.**
- **Do not use the scooter if any part is damaged or missing. Using a damaged ES PRO can increase the risk of injuries. The scooter should provide adequate supervision to ensure he/she drives and today and to ensure safe and proper use.**
- **Nevertheless, disconnect use of the battery if, while using, charging, or storing the battery, the battery emits an unusual smell, heat, fail, changes color, changes shape, or appears abnormal in any other way. Contact customer service if you think there is a problem. Do not go into the river's eye, do not ride on the ice. Rivers and Lake color and immediately seek medical care.**

- **Use only the charger provided with your scooter. If you have lost or misplaced your charger, contact customer support to obtain a replacement.**
- **Do not continue charging the battery if it does not recharge within the specified charging time. Overcharging may damage the battery and may cause it to overheat and burst.**
- **Keep your charging environment clean and dry at all times.**
- **If the charging port is damp or has any impurities, DO NOT charge your scooter.**
- **Do not charge your scooter in extreme temperatures. Charge your scooter in a dry, indoor environment. Ensure that where the scooter is to be stored and/or during battery performance in the temperature range.**
- **Do not discharge the battery using any device except for the ES PRO Folding Electric Scooter.**
- **Do not use the charger if the cord or plug is damaged. Contact customer support.**
- **Prolonged exposure to UV rays, rain, and/or moisture may damage the enclosure material. Store scooter and wet as well.**

Do not use the charger, cord, or plug if they are damaged, exposed to rain, moisture or snow. Contact customer support to obtain a replacement.

AVOID DISCOMFORT. Always ill immediate. Assume the advice on a post Mini-Sopinh-up-Trafficabus!

1.3 Disposal at End of Life

Please dispose of the product only in accordance with local regulations. Do not throw it in household waste. Proper disposal of the battery helps protect the environment and human health. Contact your local waste disposal authority for information on recycling or disposal options. Do not dispose of the battery in fire or water, as it may explode or release harmful substances. Remove the battery from the product before disposal, if possible, and dispose of it separately. Do not attempt to open or disassemble the battery, as it may cause injury or damage.

avoid thick lines and regulations company/wing to where you live in order to dispose of the battery and/or unit properly. It is the user's responsibility to dispose of the waste equipment properly in accordance with local regulations and laws.

For additional information about where you should dispose of your battery and electrical or electronic waste, please contact your local waste management office, your household waste disposal service, or your retail outlet where you purchased the product.

1.4 FCC Information

DECLARATION OF CONFORMITY:
This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC RADIATION EXPOSURE STATEMENT:
This equipment has been tested and found to comply with the limits for Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.
-Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.

The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

Section 2
PARTS & FEATURES

Please familiarize yourself with the scooter before using the ES PRO so that you may fully understand the parts and features and to refer to them if needed.

2.1 What's in the Box

1 x ES PRO Folding Electric Scooter
1 x Charger (The type of plug varies by country.)
1 x Allen Wrench
1 x Hex Manual

2.2 ES PRO Diagram

1. Front Wheel
2. Front Brake
3. Front Fender
4. Footrest Brace
5. Deck
6. Folding Mechanism
7. Rear Brake
8. Kickstand
9. Rear Fender
10. Rear Wheel
11. Charging Port
12. Rear Light
13. Rear Reflector
14. Chain/Belt Cover
15. Rear Brake Wheel
16. Rear Fork
17. Fender Brace
18. Handlebar Post
19. Handlebar Base
20. Handlebar Folding Latch
21. Handlebar Grip
22. Throttle
23. Handlebar Cover
24. Front Fender Brace
25. Front Fork
26. Front Fender
27. Front Reflector
28. Front Light
29. Headset
30. Handlebar Cover
31. Rear Fender Brace

2.3 Display Information

The display on the handlebar shows several different elements.

Be sure you understand these before attempting to ride. Long press the power button to turn the scooter on. Long press the power button again to turn off the scooter.

1. **Speed Display**: Shows current speed in the unit currently in use.
2. **Control Buttons**: These buttons control the current speed mode, headlight, and cruise control. Press the + button to increase speed up to MPH, press and hold the power button to turn on and the headlight, and press the - button to decrease speed up to MPH, press and hold to turn off.
3. **Speed Mode and Battery Level**: Shows the current speed mode (Eco, Sport, or Turbo) and the battery level. Here are 3 levels of adjustment, respectively white, yellow, red, show the speed/current mode. Battery level is shown in 5 bars.

Turbo: 25MPH or 40KM/H Sport mode: 15MPH or 25KM/H Eco: 10MPH or 16KM/H

4. **Error Code**: If there is an issue with the scooter, an error code will appear on the display. Refer to the Troubleshooting section for a list of error codes and their meanings.
5. **Cruise Control**: Press the Cruise button a while the scooter rolls. The Cruise icon lights up. A few seconds later, the scooter will maintain the speed. You can turn off cruise control at any time by pressing the brake lever.
6. **Bluetooth connection**. Please refer to page 41, page 42 and page 43 of the Tuya smart APP connection.

When the battery level is low, stop riding, turn off the scooter, and fully recharge it before riding again.

Section 3
ASSEMBLY & FOLDING

3.1 Standing, Folding & Unfolding the Scooter

Before using the scooter, it may be easier for a complete step as it turns off. Before riding the scooter again, you must turn off the scooter and follow instructions.

Standing

Step 1. Locate the footrest on the side of the scooter's deck.

Step 2. Push the footrest down and away from the deck until it locks into place. This will extend the scooter into the standard.

Folding

Fold up the folding mechanism lock on the stem to release the folding mechanism. Fold the stem down and fasten back to latch the handlebar lock. Make sure the stem is fully folded down and locked in the handlebar, as a safeguard for riding safety.