

USER'S GUIDE

HD 1080P WiFi Manual

English version(Page 4-10)
Deutsche Version (Seite 11-18)



Please read the instruction carefully before use and keep it proper!

THE BASIC



MOUNTING YOUR CAMERA



CAUTIONS

(English version)

- Don not expose the product directly to high temperatures over 40°C.
- Please peel off Transparent protective films on lens and screen of camera before using.
- Please properly protect well the lens and screen of camera after using.
- Keep it safe from falling and dropping.
- Keep it distance from any strong magnetic interference objects like electrical machine to avoid strong radio waves that might be damaging the product and affect the sound or image quality.
- In case of overheating, unwanted smoke from the device, unplug it immediately from the power outlet to prevent hazardous fire.
- Keep it safety from children while on charging.
- Stored the device in a cool, dry and dust free location.
- Do not modify the camera in any way, if the camera has been detached ,the warranty will be void.

Foreword

This product is a high-definition digital sports video device for market demand, and has a number of patents. There are many practical functions such as digital video, photographs, recording, video display, detachable batteries. Suitable for vehicle data records, taking pictures,

outdoor sports, family security, deep water detection, etc., let you shoot anytime, anywhere.



Multifunction

Dash cam

Outdoor Sports

Maritime Sports

Diving

Family Security

Functional Description

Power/MODE Button:

- (1) Long press the Power Button 3s to turn the camera on or off.
- (2) In standby, a short press of the power button switches between Recording, Taking pictures, Playback and Setting mode.

OK Button:

- (1) Press OK Button to turn on/off the recording function in the video interface.

PS:

****A red and yellow dot will flash in the upper left corner of the display.**

****When there is a red dot and time is running out, the video is being**

recorded;

****When a still yellow dot appears and the number next to it is white, it indicates that the recording has stopped.**

(2) Photo mode: Press the OK Button to take the photo with a clicking sound.

(3) Playback Mode: Pressing up and down buttons to select the file you want to play back.

****When the file name is suffixed with AVI meaning a video.**

****When the file name is suffixed with JPG it meaning a photo.**

****Then pressing OK Button to start play the video IN camera.**

(4) Setting mode: Press the up and down button to select the function and press the OK button to confirm.

Up Button:

(1) Press the up button in the video or photo mode can turn on or turn off the Wi-Fi.

NOTE: When the Wi-Fi is on, only the up button and the power button are available.

(2) In playback mode: press the up button to switch to the previous file.

(3) Setting mode: Press the up button to select up.

Down Button:

- (1) Video mode: press the button to turn MIC on/off
- (2) Playback mode: press the button to switch to the next file.
- (3) Setting mode: Press the button to select down.

Charging Light:

When the light is on indicates that the machine is charging, in the process of normal charging if the light is off indicates that the battery is fully charged.

Work Light: This light is on when we turn the camera on; it goes off when we turn the camera off.

Battery Bay:

Please pay attention to the direction of the battery contacts (three metal contacts) before installing the battery, and do not use brute force to avoid damage to the battery contacts, resulting in poor contact.

TF card slot:

Supports 4GB-32GB high-speed memory card.

Since the camera is constantly writing the recorded video to TF card, the low speed memory card will not be able to keep up with the writing speed, which will cause the recorded video to be stuck, the file will be

lost and the camera button will not open, etc. When choosing TF card, please choose the genuine C10 and above high-speed TF card.

Charging Port:

Please use the Micro USB data cable to connect to the camera for charging or reading data.

The camera is charged via this port, and the adapter for charging is recommended to use the output 5V/1A

Through this interface, we can connect the camera to the computer, select the PC Camera function to use as a webcam, or select the Mass Storage function on the computer to directly read the files in the TF card in the camera.

Connected to a computer via a data cable, three modes appear on the camera: Mass Storage, PC Camera, and Charge Mode. You can select the corresponding function by pressing the up/down button and OK button to confirm.

APP Download:

(1) Scan the QR code under the next and download it use your mobile phone (Or search for “GoPlus Cam Pro” in Google Market(Android) or Apple Store (IOS)) .

(2) Open the installed " GoPlus Cam Pro " app on your phone and connect the WiFi to your camera to control your camera from your phone.

****You can see the name and password of the Wi-Fi by pressing the UP button, Find the “action cam*****”network on your smartphone, then enter the original password: 12345678**



GoPlus CamPro

APP: GoPlus Cam Pro

Video resolution	1080FHD/1080P/720P/WVGA/VGA
Video format	AVI
Cylic Record	Off/ 1 minute/2 minutes/3 minutes/5minutes

	(save video according to selected time and recording automatically)
Time-lapse video	Off/1S/2S/5S/10S/30S/60S
Motion Detect	On/Off (If select On, the recording will be automatically opened when the moving object is detected)
Car Mode	On/Off (Please take the battery out before use car mode, connect the car USB to open the automatic loop recording)
Picture resolution	16M/12M/8M/5M/3M/2M/1.3M/VGA
Picture format	JPG
Capture mode	single shot, 3S / 5S / 10S /20S timed shot
Auto power off	Off/3min/5min/10min
Anti-shaking	On/Off
Storage card	micro sd card, Maximum support 32GB
Wi-Fi system	IOS/Android
Wi-Fi app	GoPlus Cam Pro
Charging voltage	DC-5V

Sicherheitsrichtlinien

(Deutsche Version)

- Halten Sie Abstand zu starken magnetischen Störobjekten wie elektrischen Maschinen, um starke Funkwellen zu vermeiden, die das Produkt beschädigen und die Ton- oder Bildqualität beeinträchtigen könnten.
- Setzen Sie das Produkt nicht direkt hohen Temperaturen und starker Sonneneinstrahlung aus
- Wir empfehlen die Verwendung einer hochwertigen Micro-SD-Karte, um die besten Ergebnisse zu erzielen. Bitte formatieren Sie die Micro-SD-, Micro-SDHC- und Micro-SDXC-Speicherkarte auf der Kamera vor der Verwendung und starten Sie die Kamera nach dem Formatieren neu.
- Legen Sie Ihre Micro-SD-Karte nicht in die Nähe starker magnetischer Gegenstände, um Datenfehler oder -verlust zu vermeiden.
- Entfernen Sie den Akku, bevor Sie ihn als Dash-Kamera verwenden.
- Ziehen Sie bei Überhitzung, unerwünschter Rauchentwicklung oder unangenehmem Geruch des Geräts sofort den Netzstecker, um gefährliche Brände zu vermeiden.
- Halten Sie es während des Ladevorgangs vor Kindern geschützt.

- Lagern Sie das Gerät an einem kühlen, trockenen und staubfreien Ort.
- Wenn Sie die Kamera längere Zeit nicht benutzen, legen Sie das Trockenmittel bitte zusammen mit der Kamera in einem versiegelten Beutel im Zubehör ein

Einführung

Action Camera ist ein hochauflösendes digitales Videoaufzeichnungsgerät, das entwickelt wurde, um die Marktnachfrage zu erfüllen. Es verfügt über eine Vielzahl der führenden Funktionen für digitale Videoaufnahmen, Fotoaufnahmen, Audioaufnahmen mit Bildschirmanzeige und abnehmbarem Akku. Bestens geeignet für Fahrzeugaufnahmen, Outdoor-Sportarten, Haussicherheit, Tauchen und ähnliche Aktivitäten. So können Sie die Momente genießen, während Sie jede Szene jederzeit und überall aufnehmen.

Multifunction



Dash cam



Outdoor Sports



Maritime Sports



Diving



Family Security

Funktionsbeschreibung

Netzschalter:

- (1) Halten Sie die Power-Taste 3s lang gedrückt, um die Kamera ein- oder auszuschalten.
- (2) Im Standby-Modus wechselt ein kurzer Druck auf den Netzschalter zwischen Aufnahme-, Bildaufnahme-, Wiedergabe- und Einstellungsmodus.

OK-Taste:

- (1) Drücken Sie die OK-Taste, um die Aufnahmefunktion in der Videoschnittstelle ein- oder auszuschalten.

PS:

****In der oberen linken Ecke des Displays blinken ein roter und ein gelber Punkt.**

****Wenn ein roter Punkt erscheint und die Zeit abläuft, wird das Video aufgezeichnet;**

****Wenn ein immer noch gelber Punkt erscheint und die Zahl daneben weiß ist, bedeutet dies, dass die Aufnahme gestoppt wurde.**

- (2) Fotomodus: Drücken Sie die OK-Taste, um das Foto mit einem Klickgeräusch aufzunehmen.

- (3) Wiedergabemodus: Drücken Sie die Auf- und Ab-Tasten, um die Datei auszuwählen, die Sie wiedergeben möchten.

****Wenn der Dateiname mit AVI angehängt ist, bedeutet ein Video.**

****Wenn der Dateiname mit JPG angehängt ist, bedeutet dies ein Foto.**

****Dann drücken Sie die OK-Taste, um die Wiedergabe der Video-IN-Kamera zu starten.**

(4) Einstellmodus: Drücken Sie die Auf- und Ab-Tasten, um die Funktion auszuwählen und drücken Sie zur Bestätigung die OK-Taste.

Aufwärts-Taste:

(1) Drücken Sie die Aufwärtstaste im Video- oder Fotomodus, um das WIFI ein- oder auszuschalten.

HINWEIS: Wenn das WIFI eingeschaltet ist, sind nur die Aufwärtstaste und die Einschalttaste verfügbar.

(2) Im Wiedergabemodus: Drücken Sie die Aufwärtstaste, um zur vorherigen Datei zu wechseln.

(3) Einstellmodus: Drücken Sie die Aufwärts-Taste, um Aufwärts auszuwählen.

Abwärtstaste:

(1) Video- oder: Drücken Sie die Taste, um das MIC ein- oder auszuschalten

(2) Wiedergabemodus: Drücken Sie die Taste, um zur nächsten Datei zu wechseln.

(3) Einstellmodus: Drücken Sie die Taste, um nach unten auszuwählen.

Ladelicht:

Wenn das Licht aufleuchtet, zeigt dies an, dass das Gerät aufgeladen wird. Wenn das Licht während des normalen Ladevorgangs aus ist, bedeutet dies, dass der Akku vollständig aufgeladen ist.

Arbeitslicht: Dieses Licht ist an, wenn wir die Kamera einschalten; es geht aus, wenn wir die Kamera ausschalten.

Batteriefach:

Das Batteriefach wird verwendet, um die Batterie zu halten.

Bitte achten Sie vor dem Einsetzen des Akkus auf die Ausrichtung der Akkukontakte (drei Metallkontakte) und wenden Sie keine rohe Gewalt an, um eine Beschädigung der Akkukontakte und damit einen schlechten Kontakt zu vermeiden.

TF-Karten-Slot:

unterstützt 4-32 GB Hochgeschwindigkeits-Speicherkarte.

Da die Kamera das aufgezeichnete Video ständig auf die TF-Karte schreibt, kann die langsame Speicherkarte nicht mit der Schreibgeschwindigkeit mithalten, was dazu führt, dass das aufgezeichnete Video hängen bleibt, die Datei verloren geht und die Kamerataste wird nicht geöffnet usw. Wenn Sie sich für eine TF-Karte entscheiden, wählen Sie bitte die echte C10- und höher-Hochgeschwindigkeits-TF-Karte.

Aufladestation:

Bitte verwenden Sie das Micro-USB-Datenkabel, um eine Verbindung zur Kamera zum Laden oder Lesen von Daten herzustellen.

Die Kamera wird über diesen Anschluss aufgeladen, und der Adapter zum Aufladen wird empfohlen, den Ausgang 5V/1A zu verwenden

Über diese Schnittstelle können wir die Kamera an den Computer anschließen, die PC-Kamerafunktion als Webcam auswählen oder die Massenspeicherfunktion auf dem Computer auswählen, um die Dateien auf der TF-Karte in der Kamera direkt zu lesen.

Über ein Datenkabel mit einem Computer verbunden, erscheinen auf der Kamera drei Modi: Massenspeicher, PC-Kamera und Lademodus. Durch Drücken der Auf-/Ab-Taste und der OK-Taste zur Bestätigung können Sie die entsprechende Funktion auswählen.

APP-Download:

(1) Scannen Sie den QR-Code unter dem nächsten und downloaden Sie ihn herunter. Verwenden Sie Ihr Mobiltelefon (oder suchen Sie nach "GoPlus Cam Pro" in Google Market (Android) oder Apple Store (iOS)).

(2) Öffnen Sie die installierte "GoPlus Cam Pro" -App auf Ihrem Telefon und schließen Sie das WLAN an Ihre Kamera an, um Ihre Kamera von Ihrem Telefon zu steuern.

** Sie können den Namen und das Kennwort des WLANs durch Drücken der Taste UP sehen, das Netzwerk "action cam *****" auf Ihrem Smartphone suchen, und dann das Originalkennwort eingeben:
12345678



GoPlus CamPro

APP: GoPlus Cam Pro

Videoauflösung	1080FHD/1080P/720P/WVGA/VGA
Videoformat	AVI
Zylische Aufzeichnung	Aus / 1 minute/2 minutes/5 minutes (save video according to selected time and recording automatically)
Zeitraffer-Video	Aus /1S/2S/5S/10S/30S/60S
Bewegungserkennung	Ein / Aus (Wenn Auswählen aktiviert, wird

	die Aufnahme automatisch geöffnet, wenn das sich bewegende Objekt erkannt wird)
Automodus	Ein / Aus (Bitte nehmen Sie den Akku aus, bevor Sie den Automodus verwenden, verbinden Sie das Auto USB, um die automatische Schleifenaufzeichnung zu öffnen)
Bildauflösung	16M/12M/8M/5M/3M/2M/1.3M/VGA
Bildformat	JPG
Erfassungsmodus	single shot, 3S / 5S / 10S /20S timed shot
Automatische Ausschaltung	Aus /3min/5min/10min
Anti-shaking	ein- / ausschalten
Speicherkarte	Micro SD-Karte, maximale Unterstützung 32 GB
Wi-Fi system	IOS/Android
Wi-Fi app	GoPlus Cam Pro
Ladespannung	DC-5V

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction