

User Manual

MODEL: BP-12279
Rating: 3.7V—1200mA
Input: 5V—1000mA



Business name: AMANTO INTERNATIONAL TRADE LIMITED
Business address:The Imperial, 31-33 St Stephens Gardens, Notting Hill,
London, United Kingdom, W2 5NA
Email: AMANTOUK@outlook.com



Business name: g.L.L., GmbH
Business address: Bauernvogtkoppel, 55c,22393,Hamburg,Germany
Email: g.L.L.DE@outlook.com

Manufacturer:Dongguan Baopinhuanyu Technology Co., Ltd.
Address: Building 3, 2nd Floor, No. 6, Zhangmutou Section, Guanzhang
West Road, Zhangmutou Town, Dongguan City, Guangdong Province, China

Email: support@hivefun.com



Do not approach the fire source!



RoHS FCC UK CE

Made in China

PRODUCT SPECIFICATION

Product Name	MOLONG
Color	Skin Color
Main Material	Liquid Silicone
Product Size	220*41mm
Maximum Noise	≤50dB
Battery Capacity	1000 mA
Waterproof Grade	General Waterproof
Power Supply	USB Charging

Product Structure Diagram

Product Operating instructions

Power Button

Long press 3 seconds to turn on/off, click vibration/telescopic cut frequency, 5 frequency vibration /3 frequency expansion, cyclic mode, double-click to press open/close heating mode, red light flashes to remind (the product is turned off for 10 seconds click inside to adjust)

Remote Control Operation



USAGE INSTRUCTIONS

- Before use, rinse with water or shampoo and then wipe dry immediately;
- Apply the lubricant evenly to the product and the insertion site to avoid dryness and pain;
- Click the switch button to open the vibrator;
- Press the frequency key to select the vibration frequency as required;
- After using the product, please rinse it with water or shampoo , then dry it, and please store it in a cool place.

PRODUCT POWER SUPPLY INSTRUCTIONS

- Charging can be done by connecting the USB cable to any USB power adapter, and you can use any power adapter with a USB port.
- A full charge will take 120-150 minutes. The specific charging time varies according to the internal residual power of the product.
- The battery life of this product is about 50 minutes after full charge. The specific use time depends on the vibration mode you choose. The higher the frequency of vibration mode, the faster the power consumption.

REMOTE POWER SUPPLY INSTRUCTIONS

- 3V button battery is required to maintain remote control operation of this product. If the battery fails, replace it with a new one. The battery should be placed in the battery compartment with correct polarity. If the product has not been used for a long time, please take out the battery in time.
- The battery used for remote control of this product is non-rechargeable battery, which cannot be charged. It is recommended not to mix different types of batteries or old and new batteries, and the battery should not be exposed to sunlight, fire roasting or similar overheated environments and moist temperatures.
- Please wash the product thoroughly before and after each use. Before cleaning, ensure that the product is turned off, the battery is removed, and the product is in the close state.

CAUTIONS

- This product is only suitable for adults. It is not a contraceptive product. Please keep away from children.
- During use, please do not exert too much force and pay attention to avoid injury.
- Do not mix this product with others. If you feel uncomfortable during use, please stop using this product immediately.
- The product shall be inspected regularly for damage, and the use shall be stopped immediately if the damage is found.

- Before discarding the product, the battery must be removed from the appliance. When removing the battery, the appliance must be powered off and the battery should be disposed of safely
- When cleaning, please avoid the charging port to avoid water damage.

Care and Maintenance

- Wash and dry with neutral soap and water before and after each use. Keep away from extreme high or low temperature environment.
- Please store the product in a cool, ventilated and dry place to avoid direct sunlight, high temperature, heavy pressure, humidity and pollution.

Produktparameter

Produktname	Monon
Produktfarbe	Fleisch
Hauptmaterial	Flüssigsilikon
Größe	220 * 41 mm
Maximaler Geräuschwert	50 dB
Akkukapazität	1000 mAh
Stromversorgungsmodus	USB-Stromversorgung
Wasserdichtigkeit	lebenslang wasserdicht


Produktdiagramm

Host-Betrieb:

Einschalttaste:

3 Sekunden lang drücken, um ein- und auszuschalten, antippen, um zu vibrieren/dehnen, um die Frequenz zu verringern, 5-Frequenz-Vibration/3-Frequenz-Dehnung, Zyklusmodus, doppeltes Antippen, um ein- und auszuschalten, um den Heizmodus zu starten, Aufforderung zum Blinken des roten Lichts (Antippen, um die Dehnung invertiert von 10 Sekunden nach dem Ausschalten des Produkts anzupassen)

Fernbedienungsbetrieb:



Anweisungen für den Gebrauch

- Vor dem Gebrauch gut mit Wasser oder Duschgel abspülen und sofort abtrocknen.
- Gleichmäßig Gleitmittel auf das Produkt und die einzuführende Stelle auftragen, um ein Austrocknen und damit Schmerzen zu vermeiden.
- Schalten Sie den Vibrator ein, indem Sie auf die Ein-/Ausschalttaste klicken.
- Drücken Sie dann die Frequenztaaste, um die Frequenz der Vibration auszuwählen.Spülen Sie das Produkt nach dem Gebrauch mit Wasser oder Duschgel ab, trocknen Sie es sofort ab und bewahren Sie es an einem kühlen Ort auf.

Anweisungen für die Stromversorgung

- Schließen Sie das USB-Kabel an einen USB-Netzadapter (Zubehör nicht im Lieferumfang enthalten) oder einen USB-Anschluss an und laden Sie es mit einem beliebigen USB-Netzadapter auf.
- Eine vollständige Aufladung dauert etwa 120-150 Minuten, je nach Reststrommenge im Gerät kann die Ladezeit variieren.
- Das Gerät benötigt nach einer vollen Aufladung etwa 50 Minuten, je nach gewähltem Vibrationsmodus. Je höher die Frequenz des Vibrationsmodus, desto schneller ist der Batterieverbrauch.

Anleitung für die Stromversorgung der Fernbedienung

- Eine 3V Knopf-Batterie ist erforderlich, um dieses Produkt ferngesteuert zu betreiben. Sollte die Batterie ausfallen, ersetzen Sie sie bitte selbst durch eine neue. Die Batterien müssen mit der richtigen Polarität in das Batteriefach eingelegt werden. Wenn das Produkt längere Zeit nicht benutzt wurde, nehmen Sie bitte rechtzeitig die Batterien heraus.
- Die in der Fernbedienung verwendeten Batterien sind nicht wiederaufladbar. Es wird nicht empfohlen, verschiedene Batterietypen oder alte und neue Batterien zu mischen.
- Bitte reinigen Sie das Produkt vor und nach jedem Gebrauch gründlich. Vergewissern Sie sich vor der Reinigung, dass das Gerät ausgeschaltet ist, die Batterien entfernt wurden und das Gerät geschlossen ist.

Vorsicht

- Dieses Produkt ist nur für Erwachsene geeignet, nicht zur Empfängnisverhütung, bitte von Kindern fernhalten.
- Bitte wenden Sie bei der Benutzung keine übermäßige Kraft an und seien Sie vorsichtig, um Verletzungen zu vermeiden.
- Dieses Produkt nicht mit anderen mischen. Sollten Sie während der Anwendung Beschwerden verspüren, beenden Sie bitte sofort die Anwendung des Produkts.
- Überprüfen Sie das Produkt regelmäßig auf Beschädigungen und stellen Sie den Gebrauch sofort ein, wenn eine Beschädigung festgestellt wird.

- Vor der Entsorgung des Geräts muss die Batterie aus dem Gerät entfernt werden. Beim Entfernen der Batterie muss das Gerät vom Stromnetz getrennt werden und die Batterie sollte sicher entsorgt werden.
- Bitte vermeiden Sie beim Reinigen den Ladeanschluss, um das Eindringen von Wasser zu vermeiden, das das Produkt beschädigen könnte.

Pflege und Wartung

- Vor und nach jedem Gebrauch mit neutraler Seife und Wasser abwaschen und abtrocknen, vor extrem hohen oder niedrigen Temperaturen schützen.
- Lagern Sie das Produkt an einem kühlen, belüfteten und trockenen Ort und schützen Sie es vor direkter Sonneneinstrahlung, hohen Temperaturen, starkem Druck, Feuchtigkeit und Verschmutzung.

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is

encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.