

USER MANUAL

Karaoke Machine



Karaoke Machine
with 2 Wireless Microphones

- Welcome**

Thank you very much for purchasing our products, your support and suggestions are the driving force for our improvement. Please feel free to contact us if you have any other questions. We are committed to providing you with good service.
- Products Feature**

K9-M Multi-functional karaoke machine with medium-sized has a fashionable body. Including two hand-held wireless mics and a 6.5-inch HD speaker, which can amplify distance reaches 40m/15m. The powerful TWS function allows you to pair two K9-M systems for stereo effect. There are independent control buttons for microphone volume, reverb, colorful RGB lights on/off, etc. Ideal for family friends party, outdoor activities, musical performance, teaching, etc.
- Packing List**

Karaoke Speaker

Wireless Mics

Type-C charging cable

Shoulder Strap

The diagram shows the top surface of the Pioneer DDJ-SX3 controller. It features two circular jog wheels labeled 'A' and 'B'. Between them are four buttons: 'CUE', 'FX', 'MIXER', and 'PHONES'. To the right of the jog wheels are eight numbered buttons (1-8) and a 'PUSH OPEN' button. Below the jog wheels are three more buttons: 'STOP/PAUSE', 'REWIND', and 'PLAY/FAST FORWARD'. At the bottom are 'MASTER SLIDER' controls for 'L' and 'R' channels.

- ① Priority Mix/Music Only:** Short press the button to turn on/off **priority** function. Long press the button to turn on/off **music only**.
- ② LED:** Short press the LED button to switch a light mode. The LED lights of lane/mixe machine will flash with the rhythm.
- ③ [M] Mode:** Press the button to choose Bluetooth/FM mode.
Bluetooth mode: Search the Bluetooth name "YH4K" on your phone. Click to connect and it will automatically paired next time.
F.M mode: Long press the FM mode button in F.M mode to search for different channels. Then short press the Previous/Next button to switch channel.
- ④ Number Button: ton (+/-)**: When you insert Micro SD card or USB flash drive, you can use these buttons to select tracks.
- ⑤ Previous Stop:** Short press the button to play previous song. Long hold the button to fast reverse.
- ⑥ Play/Pause Stop:** Short press the button to **play/pause** music. In **Bluetooth** mode, long hold the button to disconnect TWOS connection. Please use this button on the second Karaoke Machine. Short double-click to turn on the TWOS function, long press to turn off the TWOS function.
- ⑦ Next Stop:** Press the button to play the next song. Long hold for fast forward.
- ⑧ Accompaniment Knob:** Rotate the knob to control accompn volume.
- ⑨ Mic Echo Knob:** Rotate this knob to adjust mic echo effect.
- ⑩ Accompaniment/Audio Port:** Input accompaniment music and AUX.
- ⑪ TF Card Slot:** Insert USB flash drive to play MP3 files in it.
- ⑫ USB Port:** Insert USB flash drive to play MP3 files in it.
- ⑬ Mic / Instrument Port:** Supports wired microphone and instrument audio input.
- ⑭ DC 5V Charging Port:** Use the included USB charging cable and 5V charger (not include) to charge the karaoke machine.
- ⑮ Power/Volume Knob:** Turn the knob clockwise to turn up device, keep turning to increase volume. Turn the knob anticlockwise to decrease volume, keep turning to turn off device.

LED Lighting

LED	Start Press	RED	GREEN	RED	YELLOW	BLUE	WHITE
-----	-------------	-----	-------	-----	--------	------	-------

Microphone

(not include batteries)

Cautions

- Please notice each wireless microphone needs 2AA (not include).
- When receiving the product please use the included USB charging cable and 5 V charger (not include) to charge the karaoke machine.
- Since the receiver is built-in high capacity, in karaoke machine, please keep the product away from high temperature environment and avoid exposure to sunlight for long time.
- To avoid strident sound, please do not put the microphone too close to the speaker during use.
- If have any questions about our product, do not worry. You can go to your order and click "Contact Seller", we'll do our best to help you!

Microphone and speaker factory configuration has been set up, the user will automatically connect when using

A black portable karaoke machine with a large circular speaker featuring a rainbow-colored LED light ring. It has a carrying handle on top and a control panel with buttons and a small display. Two black wireless microphones with silver grilles and red LED indicators are shown next to it. The background is white with decorative musical notes and a treble clef in the bottom corners.

Willkommen

Vielen Dank für den Kauf unserer Produkte. Ihre Unterstützung und Ihre Vorschläge sind die treibende Kraft für unseren Fortschritt. Bei Fragen stehen wir Ihnen gerne zur Verfügung. Wir sind bestrebt, Ihnen einen guten Service zu bieten.

Merkmale

Die multifunktionale Karaoke-Maschine K9-M ist mittelgroß und verfügt über ein stilvolles Schloss. Enthält zwei drahtlose Handmikrofone und einen 5,25-Zoll-LCD-Display mit einer verstärkten Reichweite von bis zu 15 m. Mit der leistungsstarken TWS-Funktion können Sie zwei K9-M-Systeme für Stereoklang koppeln. Es gibt unabhängige Steuerstationen für die Mikrofonlautstärke, den Hall und das Ein/Aus-Schalten der bunten RGB-Lichter. Ideal für Familien- und Freundschaften, Outdoor-Aktivitäten, Musikaufführungen, Unterricht und mehr.

Packliste

Karaoke-Lautsprecher

Tipp-C-Ladekabel

Drahtlose Mikrofone

Schalterriemen

Button Functions

- ➊ **Nur Mikrofon/Musik priorisieren:** Drücken Sie kurz die Taste, um alle Mikrofonfunktionen zu aktivieren. Drücken Sie lang auf die Taste, um alle die Musik einzuschalten.
- ➋ **LED:** Drücken Sie kurz die LED, um zwischen 6 verschiedenen LEDs zu wechseln. Die LED ist die farbliche Kennzeichnung des angeschlossenen Moduls.
- ➌ **[-] Modus:** Drücken Sie, um den Bluetooth-Modus auszuwählen.
- ➍ **Bluetooth-Modus:** Schalten Sie das Mikrofon aus, indem Sie das Bluetooth mit dem Namen „JBL“ löschen Sie auf „Pairing“ und Sie werden nicht verbinden. Es funktioniert sofort.
- ➎ **FM-Modus:** Halten Sie ein Minus-Symbol die Wiedergabe-Phosphorleuchte gedrückt, bis das Wechseln zwischen FM und AM Modus. Drücken Sie kurz auf die Wiedergabe-Phosphorleuchte, um den Kanal zu wechseln.
- ➏ **Zifferntaste (1-9):** Wenn Sie eine Micro-SD-Karte oder ein USB-Laufwerk, können Sie auf diese Seiten-Menü, um Song auszuwählen.
- ➐ **Verhalten Taste:** Drücken Sie kurz die Taste, um die vorherige Lied zurück zu springen. Halten Sie lang auf die Taste, um die nächste Lied zu springen.
- ➑ **Play/Pause-Taste:** Drücken Sie kurz die Taste, um Musik abzuspielen/stoppen. Halten Sie kurz die Taste, um die Wiedergabe gestoppt, um die nächsten Song zu hören. (Wiedergabe) Bitte verwenden Sie diese Taste auf der zweiten Karaoke-Song. (Musik) Sie kann die Taste, um die Wiedergabe gestoppt, um die nächsten Song, um die FM-Tunerfunktion auszuwählen.
- ➒ **Nächste Lied:** Drücken Sie diese Taste, um die nächste Lied abzuspielen. Halten Sie lang, um schnell auszuwählen.
- ➓ **Mikrofon-Lautstärke-Knopf:** Drücken Sie diese Knopf, um die Mikrofonlautstärke zu steuern.
- ➔ **Mikrofon-Einstieg-Knopf:** Drücken Sie diesen Knopf, um den Mikrofon-Einstieg (Eingang) auszuwählen.
- ➕ **Begehung/Audio-Anschließen:** Begehung und AUX1 verbinden.
- ➖ **[-] Taste/Knopf drücken:** Legen Sie die T-Funkte ein, um die darin enthaltenen MP3-Dateien auszuwählen.
- ➗ **USB-Anschließen:** Legen Sie die USB-Karte ein und sperren Sie die darin enthaltenen MP3-Dateien ab.
- ➙ **Mikrofon-Instrumenten-Anschließen:** Verbinden Sie das elektrische Gitarre/Mikrofon und Instrumenten-Anschließen.
- ➚ **Einstecken-S/L-Ladensymbol:** Verwenden Sie das mitgelieferte USB-Ladekabel, um das Mikrofon zu laden.
- ➛ **Gleichschalt-Taste:** Drücken Sie diese Taste, um die Lautstärke zu erhöhen, um den Sound auszuwählen. Drücken Sie die Taste, um die Lautstärke zu verringern. Drücken Sie den Knopf gegen den Uhrzeigersinn, um die Lautstärke zu erhöhen. Drücken Sie es wieder, um den Sound auszuwählen.

- **LED-Beleuchtung**

LED	Short Press	RGB	WHITE	RED	YELLOW	BLUE	GREEN
-----	-------------	-----	-------	-----	--------	------	-------

- **Mikrofon**

- Bitte beachten Sie, dass jedes kabellose Mikrofon 2AA benötigt (nicht im Lieferumfang enthalten).
- Wenn Sie das Produkt erhalten, verwenden Sie bitte das mitgelieferte USB-Ladekabel und das 544-Ladegerät (nicht im Lieferumfang enthalten), um die Juicebox aufzuladen.
- Da die Karaoke-Maschine über ein integriertes mit großer Kapazität verfügt, halten Sie sie bitte von Umgebungen mit hohen Temperaturen fern und vermeiden Sie längere Sonneneinstrahlung.
- Haltieren Sie das Mikrofon bei der Verwendung nicht zu nahe am Lautsprecher, um keinen harten Klang zu erzeugen.
- Wenn Sie Fragen zu unseren Produkten haben, machen Sie sich bitte keine Sorgen. Sie können Ihre Bestellung eingeben und auf „Klerküfer kontaktieren“ klicken. Wir werden unser Bestes tun, um Ihnen zu helfen!

FCC Statement
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This device generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this device does cause interference to another radio receiving device, you may wish to try the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the interfering device is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement
This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.
This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.
The maximum SAR for this device has been established and operated with minimum distance 20cm between the radiator & body (not for M-RM).

ISEC RSS warning
 This device complies with *Intentional, Science and Economic Development Canada* Compliance
 (also known as **RSS standard (s)**). Operation is subject to the following two conditions:
 (1) This device may not cause interference, and
 (2) This device must accept any interference, including interference that may cause undesired operation of the device.
 Le présent appareil est conforme aux **CNR d'innovation, Sciences et Développement économique Canada** applicables aux appareils radio exempts de licence.
 L'exploitation est autorisée aux deux conditions suivantes:
 (1) L'appareil ne doit pas produire d'interférence,
 (2) L'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.
 This equipment complies with **ISED /CNR** radiation exposure limits set forth for an uncontrolled environment.
 This equipment is designed to be *co-located* or operating in conjunction with any other antenna or transmitter.
 This equipment should be installed and operated with minimum distance 20cm between the antenna and the body (or for KIS-M),
 IC exposure aux radiations.
 Cet équipement est conforme aux limites d'exposition à la radiofréquence (ISEDC /CNR) pour un environnement non contrôlé.
 Cet équipement est conçu pour être *co-localisé* ou fonctionner en conjonction avec une autre antenne ou émetteur.
 L'équipement doit être installé et utilisé avec une distance minimale de 20 cm entre le radiateur et votre corps (uniquement pour le KIS-M).