1：Press the menu key No. 1 after the machine starts automatically. Then short press No. 2 up key to adjust as shown in the picture below

2：Press button No. 3, and then press button No. 2 to adjust as shown in the picture below

3：Press OK key 3 to display the label screen