EX350
USER GUIDE

IBomb®
Enjoy music ,Enjoy life

Web: WWW.I–BOMB.COM

More question please mail to :Info@I–BOMB.COM

Set your
EX350
wireless
Bluetooth™

The IBOMB EX350 delivers stunning
Hi-fi audio in a portable wireless speaker so
Compact you won't believe it when you hear it

10m RANGE

②

PAIR DEVICE

Turn on Bluetooth on your device and search the "IBOMB EX350", Select it to connect.

① PAIRING MODE

Switch to the "ON" posting, IBOMB EX350 will make a loud "beep" and LED light indicator light will flash blue indicating that the speaker is in pairing mode.

The IBOMB EX350 will "beep"; indicating that it has successfully paired with you device

TURN ON/OFF
ON/OFF switch is located at the bottom of the device.

If you are prompted to enter a password to complete pairing,enter"0000"

③ PLAY

If a device is not connected after 30 seconds; it will enter sleep mode automatically.
Turn the speaker OFF and then ON again to re-enter pairing mode.

ⓘ If the IBOMB EX350 is moved out of rang start again to re–enter the connection.

Change function mode

IBomb

Hold the Play/Pause button to disconnect the current connection from Wireless to 3.5 jack input device. Vice versa to return back to Wireless connection mode.

wired

Playing music with a 3.5mm Cable
Plug the provided 3.5mm audio cable into the IBOMB and then your source.

How to use?

	PRESS ONCE	PRESS TWICE	PRESS AND HOLD
▶❚❚	PLAY PAUSE PICK UP PHONE		CHANGE THE MODE (Bluetooth /Micro SD)
+	NEXT SONG		VOLUME UP
–	REPEAT SONG	PREVIOUS SONG	VOLUME DOWN

When your call coming, please plus PLAY/ PAUSE button to pick up your phone .

Embedded microphone for handsfree conversation.

---

fail to pair

TROUBLESHOOTING

Make sure the device is in pairing mode and the blue light is flashing.
Please reset (on/off)the power switch again.

Fail to find IBomb EX350

Check that the speaker is in pairing mode.
Ensure your device is within Wireless use range.
Reset your device to activate Wireless.
Ensure that your device is not connected /paired to any other Wireless devices as Wireless can only be paired to one device at a time.

⚡ Charging FIRST TIME

Make sure the device is turned OFF.
Plug the speaker to a powered USB port.
While charging the Indicator LED light will be red.
Once fully charged ,the red LED light will turn OFF.

⚠ **To avoid damage to your battery only charge them when flat.**

Device only works with Micro SD cards up to 32GB.

32 GB microSD

Play your music anywhere you go; directly from the device using the micro sd slot.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and
(2) this device must accept any interference received,
   including interference that may cause
   undesired operation.

what's in the box?
1 IBOMB EX350
1 Audio cable
1 USB cable
1 User Manual
1 Carrying bag