# cobble
2.4G Wireless Optical Mouse

**Adjustable sensitivity**
Adjustable high resolution sensitivity of 800-1600dpi reduces hand movement.

**Power Management**
Auto motion detection switches the cobble off when it's not in use to increase the life of the batteries.

**Ergonomics**
Sculpted, ergonomic design with soft rubber cover for optimum comfort.

**Operating System** Windows 2000/XP/Vista/7, Mac OS X v10.6 or later.

ECHO CREATIVE
We hear the Eco

Designed by echo-creative
Produced in China.
www.echo-creative.com

100% recyclable

Getting started with cobble :

1. Install Batteries

2. Connecting

Contents :

Cobble        Receiver        Batteries

Reconnecting:

Step 1
Press the black button 5 sec.

Step 2
As the LED light is flashing, please inset the receiver into the USB port.

5sec

Step 3
When connecting up, the LED light at the bottom of mouse will be steady.

max. 10M

Low battery warning :

The red indicator will flash when the battery is low.

low
10%

Power saving :

The cobble will be in power saving mode when it is not use.

Z
Z

**FCC ID: COD-EFM1001**
**2.4G Wireless Optical Mouse**

This device complies with Part 15 of the FCC Rules.
Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and
(2) this device must accept any interference received,
including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna.Increase the separation between the equipment and receiver.Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.Consult the dealer or an experienced radio/ TV technician for help.

Warning: Changes or modifications to this unit not expressly approved by the part responsible for compliance could void the user's authority to operate the equipment.

PANTONE 382C

CMYK=0

FCC ID Lable

FCC ID: COD-EFM1001    9.60 mm

29.00 mm