

4.1 Others-Work Order

Quick Guide

	Welcome Thank you for purchasing this innovative LOGIC product. Due to different software versions and network operators, refer to your phone for the correct details. The specifications in this manual are subject to change without notice. LOGIC reserves the right to interpret the performance of this mobile phone. While the utmost care was taken in the production of this manual, neither LOGIC nor any other affiliated company, assumes responsibility for any mistakes or errors that may be contained in this document. LOGIC and the LOGIC logo are registered trademarks of LOGIC. Other trademarks are the property of their respective owners. Description of Keys Left soft key: Press this key to enter the main menu. Press this key to confirm the menu. Press this key to answer a call. Right soft key: Press this key to enter phonebook. Press this key to go back to previous menu. Press this key to reject a call. Call key: Press this key to make a call. Press to answer an incoming call. Press to enter call history. End key: Press to end a call, press and hold to turn off phone. Power On: Press and hold to turn on phone. Press this key to go back to standby screen. 	Getting Started 1. Inserting the SIM Card and the Battery. Ensure that the gold contact area on the SIM card is facing downward, and the beveled edge is properly aligned with the SIM card slot. Warning: Make sure to switch off the phone before taking out the SIM card, otherwise your SIM card might be damaged. 2. Removing the Battery and the SIM Card. Before removing the battery and the SIM card, ensure that your phone is powered off. 3. Charging Battery. It takes about 2-5 hours to fully charge the battery. While charging, the power indicator on the phone's display will flash and rotate. If the phone is off a charging screen will appear indicating the phone is charging. Once the charging indicator stops flashing, charging has completed. If the phone is off a charging-related icon will appear. It is normal for the battery, phone, and charger to get hot during the charging process. Note: Battery must be charged in a well-ventilated area with a temperature between 0°C-40°C. Only use a charger provided by manufacturer. Using an unauthorized charger might cause damage and void the warranty. If the charging temperature is too high or too low, the phone will automatically give a warning and stop charging to prevent damage. 4. Turn phone on/off. To turn phone on/off, press and hold the End key. If you turned on the phone without a SIM card installed you will see the prompt "Insert SIM card". Once the phone is ready you may see the following prompts: Enter phone password or if you have set up phone lock password: Enter PIN - If you have set up SIM card password. Search - the phone will search all finding appropriate network connection. Basic Functions 1. Making a call When the logo of the service provider appears on the display screen, you can dial or receive calls. The info bar at the upper left corner of the display screen shows network signal strength when there are 5 info bars the signal is at its strongest. The call quality is very likely to be affected by obstructions (therefore movement in a small area can effectively improve call performance. Enter phone number, then press End key to make the call.	2 Emergency calls. Along with a 190 network service range which can be confirmed by checking the signal strength bars, you can always call emergency service. If your network supplier does not provide roaming service in your area, the screen will display "Emergency", to inform you that only emergency calls are permitted. If you are within the network service range, you can also make emergency call even without the SIM card. 3 Answering a call Simply press the Call key to answer an incoming call. If an airplane is not fully connected, use the button on the telephone to answer a call. If it is not convenient for you to press it, turn on automatic answer, assuming that the telephone is plugged in, so as to answer calls automatically while the phone rings or vibrates. If any key answer function is chosen, pressing any key other than End key and option key can answer an incoming call. 4 Call records Your phone can also store call records of the latest missed calls, received calls, dialed calls, time of last call as well as total talk time. 5 Call options When on a call, pressing "Options" will display the options available during a call. Turn on Speaker phone, Put current call on hold, Enter contacts menu, Enter Call log menu, Enter message menu, Record the current call, Mute, Multiple party conference call, Call Waiting. Function menu 1. Scrolling selecting functions In standby mode press left soft key "menu" to enter function menu, or during a call, press "Options" to enter call option menu. Press up or down keys to scroll to the function you need, then press left soft key, or OK key, to enter that function. You can exit a menu by pressing the right soft key, or the End key to return to standby mode.	FCC Statement This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: • Reorient or relocate the receiving antenna. • Increase the separation between the equipment and receiver. • Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. • Consult the dealer or an experienced radio/TV technician for help. This device complies with Part 15 of FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation. Note: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate this equipment. Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.	SAR Statement This Phone meets the government's requirements for exposure to radio waves. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin against exposure to radio waves. All persons regardless of age or health. FCC RF Exposure Information and Statement: The SAR limit of USA (FCC) is 1.6W/kg averaged over one gram of tissue. This device has also been tested against this SAR limit. Detailed SAR information of this device can be viewed on-line at http://www.fcc.gov/overtheair. Please use the device FCC ID number for search. This device was tested for typical body-worn operations with the back of the handset kept 5mm from the body. To maintain compliance with FCC RF exposure requirements, use accessories that maintain at least 5mm separation distance between the user's body. The use of built-in, holders and similar accessories should not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided.
Bienvenido Gracias por haber adquirido este teléfono móvil innovador LOGIC. Le invitamos a leer las instrucciones presentes en este manual para que pueda configurar y utilizar todas las funciones que ofrece su teléfono móvil. Las especificaciones en este manual están sujetas a cambios sin aviso. LOGIC reserva el derecho de interpretar el funcionamiento y rendimiento de este teléfono móvil. Aunque este manual fue elaborado a conciencia y con mucho cuidado, LOGIC ni ninguna empresa afiliada, asume responsabilidad por cualquier error u omisiones contenidos en este documento. LOGIC y el logotipo de LOGIC son marcas registradas de LOGIC. El resto de las marcas comerciales son la propiedad de sus respectivos dueños. Funciones de los Teclas Tecla de Función Izquierda: Oprima esta tecla para ingresar al menú principal. Oprima esta tecla para confirmar una función. Oprima esta tecla para contestar una llamada. Tecla de Función Derecha: Oprima esta tecla para abrir los contactos. Oprima esta tecla para regresar al menú. Oprima esta tecla para rechazar una llamada. Tecla de OK: Oprima esta tecla para confirmar una función y para ingresar al menú principal. Oprimir y aguantar esta tecla para utilizar el teléfono. Oprima esta tecla para contestar una llamada. Oprima esta tecla para contestar una llamada. Oprima esta tecla para regresar al registro de llamadas. Tecla de Finlizar: Oprima esta tecla para terminar una llamada. Oprima y aguantar esta tecla para apagar el teléfono. Para encender el teléfono oprima y aguantar esta tecla. Oprima esta tecla. 	Para Comenzar 1. Insertar la Tarjeta SIM y la Batería. Inserte con cuidado la tarjeta SIM con los contactos dorados hacia abajo, en la ranura. Atención: la tarjeta con la muesca de la cámara. Nota: Para no dañar la tarjeta SIM asegurese de apagar el teléfono antes de retirar o insertar la tarjeta. 2. Retirar la Batería y la Tarjeta SIM. Antes de retirar la batería y la tarjeta SIM asegurese de que el teléfono esté apagado. 3. Como Cargar la Batería. Tome aproximadamente dos horas y media para cargar la batería. La carga restante de la batería se muestra en pantalla por medio del icono que aparece a la derecha de la pantalla en la esquina superior. Cuando se está cargando la batería, una animación aparece en pantalla. Cuando la batería ha terminado de cargar, la animación desaparece. Atención que es carga la batería en normal que el teléfono, la batería y el cargador se calienten. Note: La batería se tiene que cargar en lugar con poca ventilación y con una temperatura entre 0°C-40°C. Si la temperatura es muy alta o muy baja, el teléfono no mostrará un icono. Si los pueden cargar baterías, cargadores y accesorios aprobados por el fabricante. El uso de una batería, cargador o accesorio no aprobados podría dañar el teléfono móvil o causar el daño. 4. Encender y Apagar el Teléfono. Para encender o apagar su teléfono, mantenga oprimida la tecla de Finlizar hasta que encienda la pantalla y aparezca la animación de inicio que aparece la pantalla. Si intenta encender el teléfono sin una tarjeta SIM instalada, el teléfono mostrará el mensaje "Inserte la tarjeta SIM". Al encender el teléfono podrá ver uno de estos mensajes: Ingresa tu clave o si ha programado una clave a través que ingrese esta Ingresa el Código = tiene que ingresar el código de la tarjeta SIM. Cuando el teléfono está buscando automáticamente la red.	2. Llamada de Emergencia Aunque no tenga una tarjeta SIM instalada, puede realizar llamadas de emergencia con el teléfono. En la pantalla, verá un mensaje "Llamada de emergencia" para indicar que solo puede realizar una tipo de llamadas. 3. Como contestar una llamada Oprima la tecla de marcación para contestar una llamada. Si tiene un suflido de manos libres puede contestar una llamada o por medio del botón del audífono. También, con el audífono manos libres conectado, puede activar la función de contestación automática para contestar la llamada en cuanto entra. Si tiene activada la función de contestar con cualquier tecla puede optimizar cualquier tecla, menos (Tecla de Finlizar) y (Tecla de Negociación) para contestar una llamada. 4. Registro de Llamadas El teléfono mantiene un registro de llamadas que incluye la última llamada perdida, llamadas recibidas, llamadas realizadas, tiempo de la última llamada, tiempo total en uso. Durante una llamada aparecerá el mensaje "Opciones" en pantalla para que le muestre las opciones disponibles. Función de espera Poner la llamada actual en espera. Abrir pantalla de contactos. Abrir registro de llamadas. Abrir menú de mensajes. Oprimir y mantener oprimida. Oprimir y mantener oprimida. Llamada multiparte. Llamada en espera. *Algunas funciones dependen de su red o proveedor local.	Normas de la FCC Este equipo ha sido probado y se ha determinado que cumple los límites de un dispositivo digital de clase B, según el apartado 15 de las normas de la FCC. Estos límites están diseñados para proporcionar una protección razonable contra la interferencia perjudicial en una instalación doméstica. Este equipo genera, utiliza y puede emitir energía de radiofrecuencia y si no se instala y utiliza según las instrucciones, puede causar interferencias perjudiciales en las instalaciones de radio. Sin embargo, no se garantiza que no interfiera con la recepción de las emisiones de radiofrecuencia, lo que se puede determinar agitando o desconectando el equipo. El usuario puede intentar corregir las interferencias mediante uno de los siguientes métodos: • Reorientar o reubicar la antena receptora. • Aumentar la separación entre el equipo y el receptor. • Consultar al distribuidor o a un técnico de radioafición para que se aconseje con respecto al receptor. • Consultar al distribuidor o a un técnico de radioafición para recibir ayuda. En referencia a dispositivos receptores asociados al funcionamiento del servicio de radio por Internet, se debe la siguiente afirmación: Este dispositivo cumple la parte 15 de la normativa de la Comisión Federal de Comunicaciones del gobierno de los Estados Unidos. El funcionamiento está sujeto a las dos condiciones siguientes: (1) Este dispositivo está sujeto a la condición de que este dispositivo no provoca interferencias perjudiciales. (2) Este dispositivo debe aceptar cualquier interferencia recibida, incluso la que pueda causar un mal funcionamiento. Nota: Los cambios o las modificaciones no aprobados expresamente por la parte responsable del cumplimiento pueden anular la autorización del usuario para utilizar el equipo.	Tasa de Absorción Específica (SAR) Este teléfono móvil cumple con los requisitos del gobierno para la exposición de las ondas de radio. Su teléfono móvil es un transmisor y receptor de radio. Está diseñado y fabricado para no superar los límites de exposición a las radiofrecuencias. Esta línea forma parte de una serie de estudios científicos y estadísticos que evalúan los niveles de radiofrecuencia autorizados para el público en general. Los estudios científicos se basan en evidencia desarrollada por organizaciones científicas independientes mediante estudios periódicos y continuos de estudios científicos. Dichos estudios indican un margen de seguridad importante diseñado a garantizar la seguridad de todos, sea cual sea la edad o el estado de salud. El límite SAR recomendado por las autoridades públicas, el Comité la Comisión Federal de Comunicaciones del gobierno de los Estados Unidos, es de 1.6W/kg, promediado por 10 g de tejido humano. Las pruebas de SAR se realizan en posiciones de funcionamiento estándar, los teléfonos móviles emiten a su máxima potencia configurados en alta en todas las bandas de frecuencia autorizadas. Para más detalles SAR e información visite la página web http://www.fcc.gov/overtheair. Aunque puede haber diferencias entre los móviles SAR de varios teléfonos móviles y las distintas posiciones, todos ellos cumplen el requisito gubernamental para una exposición a RF. Para usarlo después del cuerpo, el teléfono móvil cumple las que para la FCC exposición a la radiofrecuencia, siempre que se utilice el teléfono o accesorio no metálico y al menos a 10mm del cuerpo. Es posible que el uso de otros accesorios no garantice el cumplimiento de los directrices de la Comisión Federal de Comunicaciones del gobierno de los Estados Unidos sobre la exposición a las radiofrecuencias.	