

NOMA

Indoor/Outdoor Remote Instructions:

1. Plug the receiver into an outlet.
2. Let the switch hang downward so moisture doesn't accumulate on the outlets.
3. Plug your lights or device into receiver. The total cumulative wattage must not exceed 1875 watts.
4. Red indicator is lit when the receiver/switch is on.
5. Store indoor when not in use.

Outdoor Use:

- For best results, plug your remote switch directly into a wall respectable that is at least 1 or 2 feet above the ground with outlets facing down. This prevents snow accumulation on the remote receiver.
- Do not Submerge

BATTERY :

- **Replace battery when the red indicator light on remote does not flicker when a button is pressed.**
1. Open battery door
 2. Remove old battery and dispose of properly.
 3. Insert new battery

Manuel D'utilisation:

1. Branchez le recepteur/commutateur sur une prise secteur.
2. Lorsque le recepteur/commutateur est sous tension
3. Ensuite, branchez les lamps ou appareils que vous desirez controler sur le recepteur/commutateur. La puissance totale cumulative de tous les appareils d'éclairage ne doit pas excéder 1875 watts.
4. Le temoin rouge s'allume.
5. Rangez le recepteur/commutateur a l'interieur.

Exterieur:

- Pour obtenir de meilleurs résultats, branchez directement votre commutateur dans une prise murale située à au moins un ou deux pieds du sol afin d'empêcher que la neige s'y accumule.

NE PAS IMMERGER

PILE:

- **La pile doit etre remplacee lorsque le temoin rouge ne clignote plus lorsqu'un bouton est enfonce.**
1. Ouvrez le compartiment de la pile.
 2. Retirez la vieille pile et jetez-la de la maniere appropriee.
 3. Introduisez la pile neuve.

MAX LOAD: 125V AC/60Hz

15A/ 1875W Resistive

1000W Tungsten/Tungstène

1/2 HP

30 Foot Range

NOTE:

THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THIS EQUIPMENT. SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.