

TDC Power Products CO., LTD

MODEL NO.: EBA120-042L1AL/PLT-42W

User's Manual

- 1.) *The ballast is used with equipment according to UL935.*
- 2.) *The ballast is for type one, outdoor use only.*
- 3.) Operate the ballast supply only under maximum ambient temperature 40 °C, without any cover.
- 4.) *The ballast is not to be repaired and cann't been used if it is damaged or defective.*
- 5.) *Lamp connection:*



上 焱 電 機 股 份 有 限 公 司

TDC Power Products CO., LTD

User's Manual/Bedienungsanleitung

EBA120-042L1AL/PLT-42W

- 1.) Das Netzteil ist für den Betrieb mit Einrichtungen nach EN 60950 konzipiert.

The power supply is for use with equipment according to UL935

- 2.) Das Netzteil ist nur für den Betrieb in trockenen Räumen geeignet.

The power supply is for indoor use in dry locations.

- 3.) Der Steckdose soll nah zum Gerät eingebaut werden und einfach zu erreichensein.

The socket-outlet shall be installed near the equipment and shall be easily accessible.

- 4.) Dieses Gerät kann bis zu einer Umgebungstemperatur von maximal 40°C betrieben werden.

Operate the power supply only on maximum ambient temperature 40 °C, without any cover.

- 5.) Eine beschädigte Anschlußleitung kann nicht ersetzt werden.

Das Netzteil darf nicht mehr betrieben werden

The power supply is not to be repaired and do not to be used any longer if it is damaged or defective.