

Foreword

Thank you for choosing this mobile phone – you have made a wise choice, congratulations!

Our cellular phones are approved for GSM networks and meet stringent European standards. Your phone may be used internationally with various networks depending on your roaming arrangements with your service provider.

To use this phone you must subscribe to a GSM service from a provider. We have included many features in this device but their function depends on the features available with your subscribed wireless network.

Please contact your service provider for more information.

This User Manual is published by the manufacturer without any warranty.

Revisions and improvements resulting from typographical errors, inaccuracy of current information, and improvements to the device or software may be done without any prior notification, but will be incorporated into newer editions. More information and help on your phone may be available at the manufacturer's website. The manufacturer reserves all rights to the contents herein.

Copyrights and trade marks mentioned in this document remain with their respective owner. Reproduction, transfer, storage, or distribution in whole or in part of copyrighted materials without prior written permission is expressly prohibited.

We strongly recommend you carefully read and understand this manual before using your phone in order to keep it under best conditions for your effective usage and utmost satisfaction.

Knowing the Keys

Key	Description
	Left soft key/Right soft key: Implement the functions shown in the lower left/right hand corner. If inserted two GSM SIM cards, the Left soft key can be as Call/Answer key for SIM2 card.
	Call/Answer key (Green key): Make and pick up call. In idle mode, press this key to display recently call records.
	On/Off, End/Cancel key (Red key): End call or reject the incoming call. Long press to switch ON or OFF the phone. Directly return to the idle mode in other interfaces.
	Navigator keys: To move left, right, up or down the cursor or browse the menu. In idle mode: press the Up/Down/Left/Right key to access a certain menu directly (as defined in the menu [Settings/Phone setup/Dedicated key]).
	OK key: In idle mode, press to enter the main menu directly. In general situation, it is identical with the left soft key.
	Alphanumeric keys: These keys are used to dial and input text in edit interface. Long press [0]: open/close the flashlight. Long press [2-9]: to call the contact specified in the [Call center/General call settings/Speed dial].
	* key and # key: In idle mode, long press the # key to activate or deactivate the silent mode, press the left soft key and * key to lock or unlock the keypad. These keys have different functions at the different state or in the different functions interface.

Preparing your phone

- ◆ When the battery current is low, the phone will give warning alert, and when it is too low, the phone will automatically switch Off. Do not keep the battery current low for a long time, otherwise the battery quality and life could be damaged.
- ◆ A pre-charge will occur when the battery voltage is too low so it is normal that the phone may not give charging alert.
- ◆ To guarantee the phone's normal work, please use the designated charger.
- ◆ Do not directly remove the battery panel when charging.
- ◆ The phone must be put in a ventilated place with ambient temperature of 0°C ~ 45°C when charging.

Using your Phone

Powering on/off

Press and hold the **Red key** to switch your phone on or off.

- If there is no SIM card, SIM card is defective, or SIM contact is loose, you will be prompted with a warning. Powering on, shut down and check your SIM and its installation.
- If inserted one GSM SIM card only into the phone, meanwhile phone code and PIN code is turned on. After switched on, after entering the PIN code and phone code, phone enter the standby mode by the current SIM.
- If inserted two GSM SIM cards, meanwhile phone PIN1 code and PIN2 code are all turned on. When switched on, you will be prompted to enter the code one by one. After switched on, the phone will automatically search the network.

◆ If the phone detected authorized network, the screen display the network name and signal strength; if authorized network is found, the phone can only make emergency calls or use non-communications features.

Making a Call

In standby mode, press the corresponding numeric keys to enter the phone number that you want to dial, including necessary area codes. Press the **Right soft key** [Call] to make a call; if inserted one GSM SIM card, press the **Green key** to make a call when done to connect.

Note: If inserted two GSM SIM cards, press the **Left soft key** [Call] to make a call by SIM2 card; press the **Green key** to make a call by SIM1 card.

Note: when you input two digits or upwards of two digits, the list of matching numbers in the call record and phone book will be displayed on the dialing screen.

- 1. Dialing Fixed/Land Line Extensions**
You cannot directly get through some fixed line extensions and need to dial the telephone exchange or trunk line first, then press and hold [0] key to convert until "P/W" appears on the screen. And then dial the extension.

Messages

Message service is a network dependent function, which you to send, receive and edit all kinds of messages, contact the network operator for more details.

Write message

Edit a new message, save or send it to the recipient.

Note:

To send SMS, you need to set the correct SMS service number which can be obtained from network provider. While editing, press the # key to change input method, message can be up to 612 characters in length. Press the OK Key, into add recipient interface, you can add number and add from phonebook, you can add one number, more number, press the Left Soft key [Options] to select when editing:

- Send to: Enter the destination number is sent, or press the address book to find the necessary records, you can the type of SIM card, confirmed, you can send
- Input method: you can select input method.
- Save to Drafts: Save the edited message to the outbox.
- Advanced: you can select insert number, insert name, bookmark.

Inbox

Received SMS messages can be stored either in phone SIM1/SIM2 memory, and are accessed here. When you have received a message, the tones or vibration will alert you and message mark will also be shown on the screen. Press the Left soft key [Read] or the OK key to read the message, press the Right soft key [Back] to return, and also access the inbox to read the new message. If the message memory is full, the indication "Memory full" the message icon will be shown on the screen and Before you can receive new messages, delete some old messages in the inbox folder. If the capacity of new messages is beyond the capacity of the inbox, the information will

ch allows
s. Please

ce center

od, a text

can enter
number or
ct options

s OK into
an select

ox
ne, insert

one or in

ration to
e screen.
the new
d you can

full" and
flashed.
your old
essages
be lost

Reply path: If the network allows, open the function, it receives a text message, the system will send a message.

Voice-mail server: When you can not answer automatically incoming calls to voice mail number, you other party to your message, a message stored in the voice mail system, and afterwards, you can access the system to listen to a message.

Into the voice mail sub-menu, you can see the current message (up to the establishment of two voice mail) Voice mail function needs the support of network operator, you may need to subscribe to the service. For details, please contact with the operator.

Memory status: can view the memory storage status.

Save sent message: open the function, After the success, the message will be automatically saved in the Outbox.

Preferred storage: you can choose to give priority to the stored in SIM card or mobile phone.

Phonebook

The Phone for your well-prepared high-capacity phone space. You can use the phone's contacts feature to store contact name, number and caller ring-tone. The phone can store up to 200 phonebook records, SIM card number of records, the number of records stored in the phonebook. The phone numbers vary because of their capacity.

Quick search

In order to facilitate you to quickly search the phone number, when you enter the desired number, the phone prompts you to quickly find the number. In the contact list interface, you press # key to search, in the method, enter the contact name of the first character to search.

After searching for the name, press the Green key to enter the number and press the Red key to end dialing.

the recipient confirmation

the phone, you can let the network's voice mail

urrent voice operator, you please contact

cess of SMS o messages

one storage to save the can save words stored

book to the d features. switch input to locate to dial the

Call center

This phone can record all received, dialed and made calls as well as their call time. Only when related function is network and phone is switched on and in network mode can record the answered and missed calls. Call records are accessed by pressing the Green key from standby mode through the menu.

Access the Call Center menu using the normal menu submenus are as follow:

Call history

Missed/dialed/Received/all calls

In the call history list, Once on the call records screen, press the Green key to make a call; press the OK key to view current call record; press the left soft key to make the following options:

- View: View the details of current call record.
- Call: call current record.
- Send text message: send SMS to the select number.
- Save to phonebook: Store the number as a phone number.
- Delete: Delete the current call record.
- Edit before call: Edit number before the call history.

Call settings

- SIM call settings

Call waiting:
You can choose to Activate, Deactivate or Query feature.

Activate this feature, if you call any other incoming calls, the phone will beep, and the screen will display the caller number and call waiting information.

Call divert:
This feature allows you to play to your phone calls to your voice mailbox or another phone number you want. This function needs the support of network operator, please contact network operator.

Transfer in the following ways, each way can be

missed calls as
is supported by
service area, it
records may be
y or accessing
menu path, the
list, press the
the details of
the following
per
book entry.
y
status of this
call, the phone
er or name and
s transferred to
u specify. This
ase contact the
set to enable,

Off: When the phone call, no minutes of tone.
Single: Select 1-3000 seconds after the prompt enter either of the time, when you call the phone at the time when prompted.
Periodic: Select 30-60 seconds after the input in any one time, when you call for every minute the phone will be reminded of the time.
Auto quick end:
In order to save the cost of calls, you can turn on auto quick end function, set automatically end time, when the time to call, the mobile phone will automatically hang up
Answer mode:
Any key: Select the feature, all incoming calls, in addition to the red key and right soft keys, all keys can answer the call
Auto answer when headset: Enable this feature, when the phone is in headset mode, there are about 2 seconds after the incoming call, the phone will automatically answer the call.

Settings

Dual SIM settings
You can choose dual-mode card, only SIM1 open or SIM2 open.

Phone settings

Time and date
Set home city: You can choose a phone provided in the city as the current time zone of your location
Set time/date: Under this you can set the phone to the current date and time. The phone allows you to set the date range of calendar 2000 to 2030.

Set format: Under this you can set the time and date display format

Language

A black feature phone with a rectangular screen at the top showing a small game with a yellow speech bubble that says 'GOAT OF THE DAY'. Below the screen is a black plastic frame with a central speaker grille. The keypad consists of a 4x4 grid of buttons. The top row has '1 QWERTY', '2 ABC', and '3 DEF' above the first three buttons. The second row has '4 GHI', '5 JKL', and '6 MNO' above the next three buttons. The third row has '7 PQRS', '8 TUV', and '9 WXYZ' above the next three buttons. The bottom row has a star button on the left, a plus sign button in the center, a zero button on the right, and a hash/pound sign button on the far right. The phone is shown from a slightly elevated angle, highlighting its physical build and screen content.

User Manual

Accessories

Use only batteries, chargers, and accessories approved by the manufacturer with this device. Use of any other types will invalidate the warranty and may be dangerous. Check with your dealer for available accessories. You may opt to buy:

Extra Battery

Extra batteries of various capacities are available from our company or through your dealer.

Charger Plug, charger cable

Charger plug used to connect with the charger cable for charging on wall outlets. Also you can use the charger cable to connect with the other devices such as the personal computers to charge the phone. Charging time is about 2 to 3 hours. The charging condition is displayed on screen. You may use your phone while charging.

Earphone

A mini, practical, hands-free device; you can use its button to answer and end calls. Some models may also come with a volume control knob.

Do not plug or unplug the earphone when connecting dialed or incoming calls.

Please adjust the incoming call alert volume to the felicitousness before you plug in the earphone.

Understanding Display Icons	
Icon	Description
	Network signal level: Shows the received signal strength. Fuller bar means stronger signal.
	SMS icon: Shows on top of the display to indicate there are unread short text messages.
	Missed call: Shows when you have missed call(s) of SIM1/SIM2.
	Keypad lock: Shows on top of the display when the keypad is locked.
	Alarm: Alarm has been set and activated.
	Incoming call alert types: Ring, Vibrate only, vibrate and ring, Vibrate then ring.
	Shows when the earphone is inserted.
	Shows when Bluetooth is activated.
	Battery Power: The fuller the fill, the more the battery electric mass is.

equipment when you use cards like 1-Flash or 3D:
 ♦Improper use or other uncertain factors may cause the damage or loss to the content in the cards.

Installing Battery

1. Align the battery chip with the metallic salient point in battery jar, insert the battery until it is inserted into the battery jar.
2. Slide battery cover into back of the phone until it is locked.




Removing Battery

Switch Off the phone, push down the battery button and lift the back cover at the bottom side of the phone to remove, then lift the battery at the bottom side to remove.

♦All settings or information stored in SIM card and the phone may be lost when the battery is removed.

♦Please remove the battery when the phone is switched Off, because it may suffer from abnormality if you remove the battery when it is switched on.

Charging Battery

Unclose dustproof soft gum of attachment mode on the bottom of the phone, insert one end of the charger, i.e., the charging plug into attachment mode and the other end into electrical outlet, Screen will display the charging sign.

After charging is finished, just pull out the plug.

Menu Structure

- 1. Messages
 - Write message
 - Inbox
 - Drafts
 - Outbox
 - Sent messages
 - Service messages
 - SMS settings
- 2. Phonebook
- 3. Call center
- 4. Settings
 - Dual SIM settings
 - Phone settings
 - Network settings
 - Security settings
 - Connectivity
 - Restore factory settings
- 5. User profiles
- 6. Multimedia
 - Camera
 - Image viewer
 - Video recorder
 - Video player
 - Audio player
 - Sound recorder
 - FM radio
- 7. Extra
 - Flashlight
 - Word clock
 - Calculator
 - Stopwatch
 - Calendar
 - Alarm
- 8. File manager
- 9. Services

symbol "+" of inter-national call displays in screen.

3. Dialing from Phonebook
Enter the Phonebook via the menu, select [Quick search] menu to enter the phonebook list, use Up/Down Navigator keys to scroll to the desired contact, or press the first letter of the name of the contact as saved in your phonebook for quick access to beginning with the letter then scroll to the desired one.
4. Dialing from Call history
Enter the Call center (press the **Green key** from standby mode), use the Up/Down navigator keys to scroll desired contact.

Receiving a Call

When there is an incoming call, the phone will display corresponding alert, if your network supports caller ID, screen will display caller's name or number (depending whether there is information about the caller in your phonebook).

1. Press the **Green key** or press the **Left soft key** and then **[Answer]** to answer the incoming call.
2. If function of **[Settings/Call settings/Common settings/Answer Mode]** is selected as **[Any key]**, press any key to answer the incoming call except the **Right soft key** or the **Red key**.
3. If the earphone is plugged in and the function of **[Profiles/Headset/Customize/Answer Mode]** is selected as **[Auto]**, the incoming call will be automatically answered when the phone is ringing or vibrating for about 5 seconds.
4. If you do not want to answer an incoming call, press the **Left soft key** or the **Right soft key** **[Reject]** to reject it. You can also press the **Red key** to end a call.
5. During a call, you can press the Up/Down navigator keys to adjust receiver volume.

Emergency Service

You can directly dial the emergency service number without a SIM card. Different networks use different urgency service numbers, so for details please inquire the network operation company.

In message list, press the OK key to read the message, press the Left soft key [Options] to make the menu:

- View: view the current message
- Reply: Reply SMS or MMS to the message sender directly
- Call Sender: Select to call the sender number
- Forward: forward the current message to other number
- Delete: Delete the messages.
- Delete all: delete all messages in inbox.
- Save to phonebook: Save the information in the sender to the phonebook.
- Filter by: you can select SIM1/phone to filter the messages in the inbox.

Drafts

Not send SMS, will be stored in the mail within, the operation is the same with inbox

Outbox

Not send SMS or sent successfully SMS, will be stored in the mail within, the operation is the same with inbox

Sent messages

If SMS sent successfully, then be stored in the list.

Automatically save messages need to select [SMS Save sent message], other operation is the same with Service messages

Inbox: received service messages will be stored in the inbox

Service messages

Enable push: you can select accept all push messages or disable.

Enable service loading: you can select prompt, Auto load or disable.

SMS settings

SIM setting: you can setting SIM parameter, including center number, Validity period and Message type.

Delivery report: Open the function, after a successful delivery of messages, the system will return to report.

Browse contacts
In the phonebook list screen, press the up / down key to select the contact record, press the green key to number in the record, then the red key to end the display. The OK Key to display the details of the selected record. In the phonebook list screen, select either the phonebook record or the left key to perform the following operation:

- View: view the select
- Send text message: send SMS to the select number
- Call: call the select number
- Edit: you can edit the select record.
- Delete: Delete the select record
- Copy: this record can copy to "SIM1" "SIM2" or "phonebook"
- Phonebook settings:

Preferred storage: you can set the preferred storage phone or all.

Extra numbers: set this number to own number

Memory Status: Query "SIM1", "SIM2", "phonebook" address book using status

Add new contact

- SIM1: New records added to the SIM1, each name stored under a number.
- SIM2: New records added to the SIM2, each name stored under a number.
- Phone: you can input name, number and set call. This Records stored in your phone.

givation key
to dial the
aling. Press
cord. In the
cord, press
number or set voice mail

Divert if unreachable: When your phone is off
network service area, the transfer of all voice calls
number or set voice mail

Divert if no answer: No answer transfer all voice
phone number or set voice mail

Divert if busy: When the call is busy, the transfer of
to your phone number or set voice mail

Divert all data calls: Transfer all the data calls
number you set, this function is supported by
operator, please contact the network operator.

Cancel all diverts: cancel all call forwarding type.
Call barring:
Set limits each case to answer or dial the phone
operators must first apply for international calling
limit access network password, to set the limit function
This function needs the support of network operator,
contact the network operator.

Call restrictions can be set for activate, deactivate
status

Line switching:
Can switch to Line 1 or Line 2, Line 1 is default, if you
2, then there may be no phone call.

- Advanced settings

Auto redial:
You can enable or disable this feature, the feature
after the dial-up, then if the other party does not answer
over a period of time will be automatically re-dial
number up to 10 times, in this period, the user can
other phone, to end the re-dial, simply press the cancel
button.

Call time reminder:
Can set the prompt type:

Screen prompts	Under this you can choose the language provided by the phone.
Settings in the	Pref. input method
or not on the	You can set default input method.
to your phone	Display
ce calls to your	Wallpaper: The standby interface is used to set the background wallpaper. You can choose from the built-in wallpaper can also be selected from File Manager image file.
of all voice calls	Power on display: The animation can be set to boot, you can choose preset animation for mobile phones.
to the phone	Power off display: The animation can be set to shutdown, set with the power on display
by the network	Show date and time: You can set the idle screen time display on or off.
phone. Network	Dedicated key
g features, and	You can change navigation keys function corresponding to the shortcut in the idle screen
ction.	Flight mode
operator, please	This optional mode in which the phone is normal mode or flight mode, flight mode if you choose, the phone can only use some of the functions of non-communications
rate and query	Misc. settings
you choose line	Under this function can be left / right navigation key to adjust the Brightness and the time
is turned on,	Network settings
swer the phone	Can be set automatically or manually select the network, select
dial, redial the	Automatic, the phone will be SIM card based on the network where the first selection, select Manual, you need to select the SIM card registered with the network operator can use the same network
an not call any	Security settings
right soft key to	SIM security
	You can use the PIN code, PIN2 code, set the boot password and set security features to protect information security.
	PIN password (PIN1) is the SIM card PIN. If the user don't changes the password, the original password is 1234 or 0000. If you enable the boot PIN code, then after each start 4-digit PIN

code is necessary to input, PIN code can be amended, to protect their SIM card is not used by others. Note that, if the input PIN code wrong three times, the phone card will automatically lock and unlock prompted to enter PUK code, this time close to the edge of danger, so if unauthorized modification of the PIN code, we must bear in mind.

PUK password (PUK1) from consists of 8 digits, which users can not change. PIN code when the phone is locked, and when prompted enter the PUK password, do not act rashly, because the PUK code input opportunities is only 10 times and if enter the wrong words for 10 times, SIM card will be permanently locked, that is scrapped. Part of the SIM card PUK code is never used when the user comes with the card, while the other part of the network operators will need to obtain the PIN code if you do not know the PUK code locked, do not random input, then the correct way is to call the SIM card hotline operators, after a simple user data are verified, you can obtain the PUK password to unlock the phone lock, the service is free of charge.

Note: Please use this feature with caution, if forget PUK password, please contact the network operator. If input PUK code in error for 10 times consecutively , SIM card will be scrapped.

PIN lock

Under this you can enable or disable PIN password, PIN code on or off are required to enter the correct PIN password. When open this feature, every time you turn the phone prompts you to enter the PIN password.

Change PIN

If the current PIN password is already open, you can make changes to the PIN password. First enter the old PIN password, after repeated twice to determine and identify new password.

Change PIN2

PIN2 (PersonalIdentificationNumber2) password is to enter a particular function (such as setting a fixed number, set the call billing, etc.) to enter the personal identification number.

Pin2 password is provided by suppliers for SIM card to another password, used to qualify the dial personal identification password, Mainly used to eliminate the call cost information, set

the phone calls and the billing currency unit, the cost limit function, limited dial-up ("Security settings ---" limited dial-up" can only be opened after the phone call which can be used to set the number and do not call this). My phone's SIM card predictive value is 12345. Pin2 after input error password 3 will be locked, needed Puk2 to unlock.

PIN2 password is used to set the phone billing. If you enter three times wrong, the phone will need PUK2 unlock password, the process described in the previous PIN password,PUK password the same. However, both the password and network SIM card billing and modify the internal data, it will not open, and even if PIN2 password locked, it will not affect the normal use of mobile phones. Thus, PIN2 password, and not to deliberately ignore PUK2 password.

Note:

Please use this feature with caution, If input PUK code in error for 10 times consecutively, SIM card will be scrapped.

Change operation with the PIN1.

Phone security

Under this password there you can set the phone to avoid unauthorized use of your mobile phone

Phone lock:Under this you can enable or disable phone password, phone password on or off are required to enter the correct phone password. When open this feature, every time you turn the phone prompts you to enter the phone password.

Change password:You can make changes to the phone password. First enter the old phone password, after repeated twice to determine and identify new password.

Auto keypad lock

Under this you can set the time to open or close the keyboard lock keyboard lock feature. Set the keyboard lock time, the idle screen, mobile phone within the set time the keyboard does not perform any operation, it will be automatically locked, then you can press the # key to unlock.

Note: Keyboard locked and the backlight is off, to be selected button lights up the screen, then press the # key to unlock.

Connectivity

Bluetooth

The phone supports Bluetooth, users can turn the feature on

according to demand.

Bluetooth technology can connect electronic devices wirelessly. Because Bluetooth communicate by radio, so in your phone and another Bluetooth device do not need to be in the opposite direction, please maintain the maximum distance that between two devices is not more than 10 meters during communicating. In some countries or regions may be developed within a number of provisions restricting the use of Bluetooth devices, please contact your local authorities.

Power: Press the OK key or the left soft key to open or close the Bluetooth function. If close some function, then you will end all the Bluetooth connection. Bluetooth connection will consume battery power, reducing cell phone operation time, when using the phone to perform other operations, please consider this factor.

Visibility: Press the OK key or the left soft key to switch on or off, if you select on, other Bluetooth devices can find the phone; if you select off, other Bluetooth devices can't find the phone.

My device: Select to add new equipment, search for Bluetooth devices within range of the signal. After the Bluetooth device is found, you can select the matching connections.

Search audio device: Search within signal range of Bluetooth hands-free devices, such as Bluetooth headsets.

My name: Display the Bluetooth device name of the machine can access to view and edit.

Advanced:

- Audio path: set the audio path, is leave in phone or forward to Bluetooth headsets.
- Storage: set storage location in phone or memory card.
- My address: Display the Bluetooth device address.
- Data account

You can choose the Internet account. You can add Internet accounts by yourself.

In the Internet interface, press [Options], you can do operations as followed:

- Edit: Edit selected network count.
- Add PS account: Mobile support 6 maximum data account. Every account to edit the information: account name, APN, user name, password, auth type, SIM selection, advanced settings

Delete: delete the selected Internet account

Change default: select this function to restore default.

Restore factory settings

Reset the parameter value mobile phone, make your phone reset to default settings. Please enter a privacy password (initial password is 1234), restore factory settings.

User profiles

The phone provides you with four profiles: general, silent, meeting, outdoor. It's help you according to the different events and environments in different custom ring tones. according to different scenarios, choose a different profile, then you only need to personalize your profile and activate.

Activate: Start the selected profile.

Customize: You can set all kinds of effects to your own needs. In the Settings screen, press the down navigation key to move the highlight to the item needs to be set.

Alert type: Press the left/right navigation key to select: vibrate only, vibrate and ring, vibrate then ring or ring only.

Ring type: Press the left/right navigation key to select.

Incoming call: There are ten built-in ring tones to choose for you, and you may also to choose your favorite audio file as your ring-tone from file management.

Ring-tone volume: Press the left/right navigation key to adjust the ring-tone volume.

Message: There are ten built-in ring tones to choose for you, and you may also to choose your favorite audio file as your ring-tone from file management.

Keypad: Press the left/right navigation key to select.

Key-tone volume: Press the left/right navigation key to adjust the key-tone volume.

Power on/off: Phone preset five tone to choose for you, you can also choose silent to turn off the power on/off tone.

System alert: You can set whether to open system alert tone.

Reset: restore the default settings.

Multimedia

Camera

Your phone is fitted with camera allows you to take photos whenever possible. You can store the pictures in phone or customize the wallpaper. In the camera preview screen, Press the OK key to take photo, press the right soft key to return, press the left soft key to option:

Switch to video recorder: select the function can directly switch to video preview screen.

Photos: select the function into image viewer.

Camera settings: Press the OK key to adjust the following options, including Anti-flicker and Delay timer, Profile that is complete, press the left soft key or the OK key to confirm the current setting.

Image settings: can set the image quality and image size.

White balance: can set white balance

Scene mode: can set the photo mode as auto or night.

Storage: set phone or memory card as the storage location

Restore default: select the function and confirmed, the camera parameters can be restored to the default location

After taking pictures, press the back to return camera preview screen, press the left soft key to enter options, can select to send or delete

Image viewer

This feature is convenient for users to view the photos stored in albums, press the OK key to open the picture, press the left soft key to open the option menu:

View: open the current image to view.

Image information: can display the current image information.

Browse style: can set to list style or Matrix style.

Send: Pictures can be selected through the Bluetooth method to send.

Rename: Change the name of the selected picture.

Delete: Delete the select image.

Storage: Set phone or memory card as the storage location

Note: When no pictures in Image viewer, the options menu only displays the browse style and storage.

Video recorder

In the multimedia menu, select the video recorder into the video preview screen, Press up/down navigation key to adjust [Focal distance], press the left soft key into options menu:

Switch to camera: select the function can directly switch to camera preview screen.

Camcorder settings: Press the OK key to adjust the following options:Anti-flicker.

Video settings: Can set the video quality

Storage: Set phone or memory card as the storage location

Press the OK key to start recorder, recording, press the OK key to pause or resume recording; Press the right soft key to stop recording, the screen will be auto save video and auto back to the video preview screen.

Video player

This feature can be played stored in the mobile U disk or video files, supported formats to 3gp, mp4, Avi file player.

In the multimedia menu, select the video player into the video list, press left soft key open the option menu:

Play: Play the current video file

Send: can be selected through "Bluetooth" method to send.

Rename: Change the name of the selected video.

Delete: Delete the select video.

Audio player

Play the audio files saved in the phone or memory card.

In playing interface, press the OK key to start or pause playing, press the up navigation key into the play list screen, press the down navigation key to stop play, press the left/right navigation key to switch previous/next song; press the *#/ key to adjust the volume,

In playing interface, press the red key or the right soft key to exit player interface, Phone into the background playing mode, while the idle screen shows the name of the music.

Press the left soft key into the play list, play the left soft key into option menu:

Play: play the current song.

Details: can view the current song information, include song size and time.

Refresh list: can refresh the play list.
Settings:
Pre. Play list: Press the left/right navigation key to switch phone memory card.
List auto gen.: Select this option enabled, each time the player will automatically update.
Repeat: You can choose play mode repeat all, repeat one or off.
Shuffle: select on, the player will not play in order by list.
Background play: Select ON when playing the exit music player can continue playing.
Sound recorder
Enter the recording screen, press the left key into options menu.
New record: when you choose the function, start new recording, press the left soft key to pause/ continue record, press the right soft key to stop record, the screen will be prompted to save video, press the left soft key to save and return to the recording screen, press the right soft key to not save and directly Back to record screen.
Play*: can play the current recording.
Append: append new record to the current audio file.
Rename*: Change the name of the current recorder file.
Delete*: Delete the current recording.
List: Display recorder files list
Settings: you can set storage location and audio quality.
Send*: Can be current recorder through Bluetooth method to send.
FM radio
FM radio is supported by the phone. Access the function only when you have plugged the earphone.
In FM radio interface, press the up/down navigation key to move forward/backward 0.1 MHZ, the press the left / right navigation key to move forward / backward auto search until the search to the channel so far. Press the ok key to open/close the FM function. Press the *#/ key to adjust play volume. Press the right soft key to red key to exit FM radio, and FM plays in the background.
Press the left soft key to the option menu:
Channel list: Display channel list
Manual input: Manual enter frequency to identify, Radio interface automatically skip to the frequency to listen.

Auto search: Can auto search channel and save channel
Settings:
Background play: Phone back to the idle screen after Select function, FM plays in the background.
Note: Quality of radio subscription is possible influenced environment like indoor or under shield. You can improve situation as following: stand closer to the window, adjust position of earphone line or adjust the channel manually

Extra

Flashlight
Into the flashlight interface, press the OK key or the left soft key to on/off the flashlight. Standby interface, long press the 0 key
Torch on or off quickly
World clock
In this menu, press the left / right navigation key to view some cities in the world relative to the current time the phone correspond to time.
Calculator
Into the calculator, the calculator interface:
Press 0 - 9 numeric keys to enter the number to be calculated.
Press the navigation key to select the location on the screen corresponding to add, subtract, multiply and divide symbols for computing
Press the # key for a decimal point.
Press the right soft key to clear the last bit can be input or the result (no input figures, has withdrawn from the calculator function)
Press the left soft key or the OK button to display the results.
Stopwatch
The phone provide typical stopwatch and nWay stopwatch useful for you.
Calendar
Choose to enter the calendar, the screen will display the system date on the calendar month, and have a background box marked the current date. Press the navigation key to select the

date, calendar information on the screen will be up accordingly.
Select any date, press the left soft key to enter options following:
Jump to date: Jump the selected date.
Go to today: the date of the input query calendar information
Go to weekly/monthly view: can set the calendar display through week or month.
Alarm
You can use the phone as alarm clock, this feature allows set time arrives, make the phone ring or vibrate to remind us. When the alarm is turned on state, the alarm symbol is displayed in the top of the screen.
When the alarm clock for reminders, press the left soft key to terminate the alarm reminder, press the right soft key is the clock to sleep.
The phone number of alarm clocks available, both in the silent mode, set the alarm clock function has been effective. Select any of the alarm clock, press the left soft key or OK the following:
1, can be turned on or off the selected alarm to open before alarm clock icon will be displayed
2, set the alarm, reminder time
3, according to the time you need to set the alarm clock to the period of a day, week or custom to be reminded of a few
4, the selected option when the alarm time to remind ring-to
5, you can set the alarm time to remind the selected mode and vibration, ring, vibration
6, you can set sleep time
Set the required entry, press the right soft key to save and directly.

File manager

In document management, you can open files in the Memory, you can select file or folder to press the left soft key into [Options] you can do the following(Perform different file operations are different, depending on the specific operation by the file):

- Open: open the file or folder.
- New Folder: the folder in the selected directory New Folder
- Rename: you can rename the select folder.
- Delete: delete the selected file or folder.
- use as: if the selected file is audio files, can set the file use as SIM1/SIM2 incoming call; if the selected file is image file, can the file use as wallpaper, Screen saver, Power on display or Ring off display.
- Search: memory card can be customized to find all documents.
- Sort by: can "name", "time", "size", "type" or "none".
- Send: the select file can send by MMS.
- Copy: you can copy the select file to other folders.
- Move: you can move the select file to other folders.
- Details: you can view the select file information.

Note:
Memory card as the default save path, order to facilitate the use of multimedia features, please copy the appropriate files to Audio, music, Photos, Videos etc. folders.

updated	Services The Internet is the combination of wireless communication Internet application platform that enables you to get rich phone and ecommerce and other Internet information resources application. Note: 1. Your ISP may not support some features, in order to ensure the normal operation of the browser, make sure your SIM card is supported and open Internet access. 2. If you browse the web, you need to charge fees related traffic. Homepage This is the WAP settings you set in the homepage address, if you have no other set will have a direct connection to the pre-set or the default home page. Bookmarks In this menu, the display has all the bookmarks in the book, you can add and save you frequently visit the site name address for future quick access. Search or Input URL Enter the need to access the WAP services, and addresses, complete, can be connected to the WAP site want to connect. From the surface in the bookmarks, history, other than to provide you a flexible way to access network. Recent pages: List of pages you have recently visited records, facilitate your browsing history in selected cases, can directly enter to access the page, the record could be deleted. Settings Homepage: Into the function, you can select default home or user-defined. Select profile: you can select always ask/SIM1/SIM2. Data account: Into the function, you can set corresponding card data account. Browser options: Clear the temporary buffer information cookie, it's can avoid congestion and improve web browser speed, periodically clear. Preferences: You can set the appropriate parameters, including the display time, display pictures, cache and cookie.
card, (functions), also use as can set Power all the use of o, My	<h2>Input Methods</h2> <p>This phone provides diversified input modes for you to enter letter information when editing SMS and adding phonebook. Use the # key to switch between different input methods. When editing the key controls:</p> <p>The Left soft key: Generally represents confirmation. The Right soft key: Press to clear one character, long press to clear all. The Red key: Return to the idle interface. "1" key : In every input status, press this key to call out punctuation and symbol input frame (except number input method). ABC (abc) input method Each key is used to input several characters. Fast and repeatedly press key until your required character appears. When you need to input English punctuation and some special signs, press the [1] numeric key to call out special sign input in English input status (include English capitalization). Press the [0] key to input blank once. The Numeric input method To input numerical values, press the respective numeric keys. Smart input method This input method possesses sort of association function, makes you just need to press every letter once to change the whole word. Every key on keyboard represents character, this input method would automatically compare in personal language database and select correct word, so it requires less time than traditional common input method. Fast and repeatedly press the Up/Down Navigator key until your requisite character or word appears, and you can select. You can press the Left soft key to select word or character and press the [0] key to complete word confirmation and input blank.</p>

Safety
Never attempt to disassemble your phone. You alone are responsible for how you use your phone and the consequences of its use.
As a general rule, always switch off your phone wherever use of a phone is prohibited.
Use of your phone is subject to safety measures designed to protect users and their environment.
Do not use your phone in damp areas (bathroom, swimming pool...). Protect it from liquids and other moisture.
Do not expose your phone to extreme temperatures lower than - 10°C and higher than + 55°C.
The physicochemical processes created by chargers can damage the temperature limits when charging the battery. Your phone automatically protects the batteries in extreme temperatures. Do not leave your phone within the reach of small children (certain removable parts may be accidentally ingested).
Electrical safety
Only use the chargers listed in the manufacturer's catalogues. Any other charger may be dangerous; it would also invalidate your warranty. Line voltage must be exactly the one indicated on the charger's serial plate.
Aircraft safety
When traveling by plane, you will need to switch your phone off when so instructed by the cabin crew or the warning signs. Using a mobile phone may be dangerous to the operation of the aircraft and may disrupt the phone network. Its use is illegal and you could be prosecuted or banned from using cellular networks in the future if you do not abide by regulations.
Explosive materials
Please comply with warning signs at petrol station asking you to switch your phone off.
You will need to comply with radio equipment usage regulations in places such as chemical plants, fuel depots and other locations where blasting operations are under way.
Electronic equipment
To avoid the risk of demagnetization, do not let electronic devices close to your phone for a long time.
Electronic medical equipment
Your phone is a radio transmitter which may interfere with electronic medical equipment or implants, such as heart pacemakers, insulin pumps, etc. It is recommended that a minimum separation of 15 cm be maintained between the phone and an implant. Your doctor or the manufacturer of the equipment will be able to give you any advice you may need on this area.
Hospitals
Always make sure that your phone is switched off in hospitals when so instructed by warning signs or by medical staff.
Road safety
Do not use your phone when driving. In order to give your full attention to driving, stop and park safely before making a call. You must comply with any current legislation.
Distance of operation
This phone model has been tested and meets radiofrequency exposure guidelines when used as follows:
Against the ear: place or receive a phone call and hold the phone as you would a wire line telephone,
Body worn: when transmitting, place the phone in an accessory that contains no metal and positions the minimum of 2.5 cm from your body. Use of other accessories may not ensure compliance with radiofrequency exposure guidelines. If you do not use a body worn accessory, not holding the phone at the ear, position the minimum of 2.5 cm conform your body,
Data operation: when using a data feature, position the phone a minimum of 2.5 cm from your body for the duration of the data transmission.

Technical Specifications				
Weight: About 70g (including battery)				
Dimensions: 45*107.2*13.5mm				
Battery: Li-ion Battery, 3.7V				
Band: GSM 900MHz / DCS 1800MHz				
Battery Time (No prior or separate notice is required for changes)				
Battery Type	Battery Capacity	Talk Time	Standby Time	
Li-ion	650 mAh	2.5 hrs.	17 hrs.	
Note: Actual operating conditions depend on the network environment, SIM, and user behavior.				
Warning: Any consequence caused by misuse, abuse, or not following any and all of the above-suggested suggestions and instructions shall not hold the manufacturer responsible in any way responsible to any degree.				
Announcement: The manufacturer reserves the right to change or upgrade specifications or software versions without prior or separate notice. Trade names mentioned or used in this material belong to their respective owners.				
FCC Statement				
1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:				
(1) This device may not cause harmful interference.				
(2) This device must accept any interference received, including interference that may cause undesired operation.				
2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.				
NOTE:				
This equipment has been tested and found to comply with FCC limits for a Class B digital device, pursuant to Part 15 of FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.				
This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to reduce the interference by one or more of the following measures: Reorient or relocate the receiving antenna; Increase the separation between the equipment and receiver; Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.				
Consult the dealer or an experienced radio/TV technician for help.				