YEECORE

Manual

ドライブレコーダーマニュアル

English version
日本語版

Retain owner's manual for future reference

Contents

Safety Warnings — 1
What's in the box ? — 2
Getting to Know the Dash Cam — 3
Function Buttons — 4
Installation — 5
Inserting MicroSD Card
Ejecting MicroSD Card
Installation in the vehicle
Feature Guide — 7
Product Specifications — 11
Troubleshooting — 12
Warranty & Support — 13

Safety Warnings

The laws or rules of certain countries or regions may forbid or restrict to install or use the product in your vehicle. Please obey all applicable laws and rules to use this product. The users should obey all applicable local laws and rules.

- Please don't use, store or transport this product in an extremely high or low temperature environment.
- Please don't put this product into the fire or oven.
- Please don't operate this product while driving. And please always obey safety driving rules and current traffic rules.
- Please don't disassemble this product, otherwise, the internal components may be damaged.
- The installation position of the products should not block the driver's sight or the operation of the airbag.
- Please don't let this product come into contact with liquid, otherwise, the product maybe be damage.
- Please use the original accessories provided with this product.

What's in the box ?

1. Front Camera x 1
2. Suction Mount x 1
3. Rear Wired Camera x 1 (Optional)
4. Rear Camera Cable x 1 (Optional)
5. USB Charger Cable x 1
6. USB Cable x 1
7. User Manual x 1
8. Crowbar x 1
9. Cable Clip x 6

Getting to Know the Dash Cam

Function Buttons

Each button has different functions in different modes

Button	Mode	Preview	Recording	Menu	Playback	Parking
POWER	Long Press	Power off	Power off	Power off	Power off	Power off
	Short Press	Save a picture	Save a picture	Back to previous	Back to playback menu	Save a picture
MODE	Long Press	No	No	No	No	No
	Short Press	Switch to menu	Switch to menu	Back to previous	Back to previous	Switch to normal mode
UP	Long Press	Wi-Fi on	Wi-Fi on	Wi-Fi on	Wi-Fi on	Wi-Fi on
	Short Press	Switch front & rear camera	Switch front & rear camera	Move up	Move up & Switch to previous	Switch front & rear camera
DOWN	Long Press	No	No	No	No	No
	Short Press	Mic on & Mic off	Mic on & Mic off	Move down	Move down & Switch to next	Switch to normal mode
OK	Long Press	No	No	No	No	No
	Short Press	Start video recording	Stop video recording	Confirm, enter into sub-menu	Confirm, enter into sub-menu	Switch to normal mode

Installation

Inserting MicroSD Card
Please insert the MicroSD card into MicroSD card slot diagonally, it will cause damage to the MicroSD card.
2.Please use U3 or above high-speed MicroSD card.
3.Insert the MicroSD card into the dash cam camera, format the MicroSD card on the Camera before first use.

Ejecting MicroSD Card
Push on the top edge of the MicroSD card slowly until it clicks. The lock will be released then pull out the MicroSD card.

Suggestion
Please turn off the dash camera first when insert or eject the MicroSD card.

Installation in the vehicle
1.The installation position of the products should not interfere with the driver's field of vision, such as behind the rear-view mirror.
2.Connect the car charger cable with the USB port of the suction mount. If you have the rear camera(optional), please connect the rear camera cable with the "USB/Rear Camera" port on the dash camera. As shown below.

3.Use the crowbar we provide to stuff the car charger cable on the gap of the windshield nearby then fitting the suction mount to keep the car charger cable away from the sightline and keep it tidy. And connect another end of the car charger cable to the cigarette lighter. As shown below.

4.If you have the rear camera(optional), connect the other end of the rear camera cable to the rear camera. Install the rear camera on the windshield. As shown below.

Feature Guide

Loop Recording
Once the memory card is full, the dash cam camera, it will start loop recording immediately. When the MicroSD card is full, the oldest recording file will be replaced by the new recording file. We strongly recommend to use a high-speed MicroSD card.

Collision Detection Triggered(Emergency Recording)
In recording mode, short press POWER button, camera will take a picture and save it in the PHOTO folder.

Playback
1.Browse files: Short press the "Mode" button to enter the playback mode. In this mode, there are Event/Normal/Photo folders, press the up and down button to browse and press the "OK" button to play.
2.Files playback: Press the "OK" button to pause, press the up and down buttons to select files and press the "Mode" button to exit playback mode.
3.Delete files: When you want to delete the file in playback mode, press the "Power" button to pop up two menus: delete files (delete single and delete all files) and cancel. Then (protect files, cancel protection files, lock files and unlock files). Press "OK" to perform corresponding operation.
4.NOTE: Locked files can't be deleted, you need to unlock the file first.

APP
App named YeecoreViewer, it can be downloaded from App Store & Google Play Store. Using this app, you can download or save the videos or snapshots to your smartphone album directly. Then you can easily share these wonderful videos with friends and families all over the world by social media platform, such as WhatsApp, Facebook, etc.

Note: You use this function, you should use the Hardwire Kit we provide(need to buy separately) to connect to the car battery directly to keep the camera continuously in parking mode, otherwise, running the camera continuously for too long is parking mode.

Taking Photos

Playback

How to connect the APP and dash cam?
Step 1: Long press the "UP" button, the Wi-Fi name and password is show on the dash cam screen.

Step 2: Find the Wi-Fi name and enter password, Connect the Wi-Fi with your phone.

Step 3: Open the APP "YeecoreViewer" and click "JOIN CAM". And then it connect successful.

PC Tools
Please download the latest PC Tools on our official website www.yeecore.com/pc/Yeecore%20Tools
After installing the tool, you can playback the video files on the MicroSD card, it can display speed, time, GPS tracking, G-Sensor information, and so on. As shown below:

Product Specifications

Sensor	Front: 8M Night Vision Rear(optional): 2M Night Vision
Lens	Front: 157 Degree Wide Angle, 6-Glass Lens Rear(optional): 140 Degree Wide Angle, 6-Glass Lens
LCD	3.0 Inches IPS
Video Resolution	Front: 4K30FPS, 1440P30FPS, 1080P30FPS WDR Rear(optional): 1080P30FPS HDR
Wi-Fi	Built-in 2.4G/5G
GPS	Built-in
Audio	Built-in and speaker
G Sensor	Built-in
Photo Format	JPG
File Format	MP4
USB Port	Type-C
Battery Type	Super-capacitor
Working Temperature	14°F~158°F(-10°C~70°C)
Compatible OS(PC Player)	Windows XP/Vista/7/8/10/Mac OS

Troubleshooting

When loop recording does not work or recording is interrupted
1.The MicroSD card may be of low speed card, please use U3 or higher speed card instead.
2.The speed of the MicroSD card will be slowed down after a long period of time, it is recommended to format it on the camera.

Prompt" file error" when playing video or photo files
It is possible that the writing speed of the MicroSD card has decreased and some videos and photo files are damaged. It is recommended to reformat the card and on, the

When the MicroSD card over 64G cannot be read by the dash camera:
It must be formatted as FAT32 (32G) file system on the computer, or formatted on the dash cam.

When the video is hazy
It may be fingerprints or spots on the lens, please keep the lens clean.

When recording indoors, there are horizontal stripes in the video
Please set the flicker to 50Hz or 60Hz according to the local power frequency.

When it is difficult to obtain GPS information
Some car navigation GPS antennas will affect the camera's GPS reception. The dash camera should be installed as far away from the antenna as possible.

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the
user is encouraged to try to correct the interference by one or more of the following measures:
—Reorient or relocate the receiving antenna.
—Increase the separation between the equipment and receiver.
—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
—Consult the dealer or an experienced radio/TV technician for help.
Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.
This equipment should be installed and operated with minimum distance 20cm between the radiator&your body.

YEECORE

ドライビングレコーダー 使用説明書

⚠ 後で参照できるようにオーナーマニュアルを保管してください

目 次

安全上のご注意 — 15
同梱品リスト — 17
製品紹介 — 18
ボタン機能 — 19
取扱 — 20
MicroSDカードを挿入する
MicroSDカードを抜き出す
車内の固定方法
操作一覧 — 22
製品仕様 — 24
故障かな？思った時 — 27
保証サービスとサポート — 28

安全上のご注意

特定の国及び地域の法律・法令により、車内での設置及び使用が禁止または制限される場合があります。予めご了承のうえ、ご使用前に、お住まいの地域に関して適用されるすべての法律及び規則を遵守してください。ユーザーは、すべての地域の法令及び規則を遵守すべきです。

- 極高温/低温の環境下で製品を使用、保管及び運搬を絶対に禁止。
- 火中投入又はオーブンへの設置を厳しくやめてください。
- 運転しながら本品の操作をしないでください。運転中は交通ルールを遵守し、安全運転を心がけてください。
- 本品を解体しないでください。解体した場合、製品内部の各部品を傷付る恐れがあります。
- 運転者の視線を遮るエアバッグを妨害する位置に本品を取り付けないでください。
- 液体などを付けないでください。本品を壊される恐れがあります。
- 必ず本製品の付属品を使用してください。

同梱品リスト

1. フロントカメラ 1 個
2. 吸盤 1 個
3. バックアップカメラ（任意オプション）
4. バックカメラケーブル（任意オプション）
5. 車載充電ケーブル 1 本
6. USBケーブル 1 本
7. 取扱説明書 1 冊
8. バール（1 個）
9. クリート（6個

製品紹介

ボタン機能

再生モードでの操作

	モード	プレビュー	録 画	メニュー	再 生	停 車
電源	長押し	電源オフ	電源オフ	電源オフ	電源オフ	電源オフ
	短押し	保存する	保存する	前へ戻る	再生メニューへ戻る	保存する
モード	長押し	無効	無効	無効	無効	無効
	短押し	設定メニューへ	設定メニューへ	前へ戻る	前へ戻る	通常モードへ戻る
UP	長押し	Wi-Fiオン	Wi-Fiオン	Wi-Fiオン	Wi-Fiオン	Wi-Fiオン
	短押し	フロント/リアカメラ切替	フロント/リアカメラ切替	上へ	上へ	フロント/リアカメラ切替
DOWN	長押し	無効	無効	無効	無効	無効
	短押し	マイク オン/オフ	マイク オン/オフ	下へ	下へ	通常モードへ戻る
OK	長押し	無効	無効	無効	無効	無効
	短押し	録画開始	録画停止	確認、サブメニューへ	確認、サブメニューへ	通常モードへ戻る

取 扱

カードを挿入する
1.初めにMicroSD カードを挿入しないでください。MicroSD カードを誤ま挿入されたカードの破損。
2.U3以上の高速MicroSDカードを使用してください。
3.MicroSDカードを挿入したら初期化を実施してください。初めてご使用になる場合、本品にMicroSDカードをフォーマットしてください。

MicroSD カードを取り出す
「カチッ」という音を聞こえるまで、MicroSD カードの上端のエッジを押してください。ロックを解除した後、MicroSDカードを指を使ぶ。

注意
①Please MicroSD カードを挿入する前、必ずカメラの電源をオフにしてください。

車内での取付方法
1.バックカメラの接続など、運転者の視野を妨ぐ位置に本品を取り付けないでください。
2.車載充電ケーブルの接続はUSB端子に接続してください。もし、バックカメラ（オプション）をご購入ならば、その配線ケーブルを本品上のUSB/Rear Cameraに接続してください。

3.以下のように、バックカメラ（オプション）を接続しない場合、その他機器（バックカメラ）に接続して、本カメラの電子パックのスピンに取付けてください。

4.もしバックカメラ（オプション）を接続しない場合、その他機器（バックカメラ）に接続して、本カメラの電子パックのスピンに取付けてください。

機 能 一 覧

録画開始
電源をスイッチ入る、本品は録画開始を開始します。MicroSDカードの容量を超えて、古いファイルは自動的に上書きされます。録画ファイルは「録画」フォルダに保存されます。

ふつうの検出-録画（緊急録画）
ぶつかった時、例外に加速を検行され、衝ぶ行ったなら、G-Sensor が検知されます。録画ファイルは「緊急」フォルダに保存されます。

手動で写真を撮る
録画モードでは、短押しボタンを押すと、カメラは録画を実施しながら写真をPHOTOフォルダに保存します。

再生
1.ファイル閲覧（Mode）:ボタンを短く押すと、カメラは録画を実施しながら写真をPHOTOフォルダに保存します。
2.ビデオ再生（OK）:ボタンを押して、「再生」ボタンを一時停止する。もう一度、「OK」ボタンを押して、「OK」ボタンを押して再生を実行。
3.ファイルの削除:再生モードでファイルを削除する場合、「POWER」ボタンを押して、ファイルの削除（1個を選択または全ファイル）を選択（ファイルの保護、ファイルの保護解除、ファイルのロック、ファイルのロック解除）メニューを表示。「OK」ボタンを押して対応する操作を実行します。
4.ロックされたファイルは削除できません。ファイルをアンロックする必要があります。

APP
APPは「YeecoreViewer」で、AppStoreとGooglePlayストアからダウンロードできます。このアプリケーションを使用すると、動画やスナップショットをスマートフォンのアルバムにお直接ダウンロードして保存できます。それからソーシャルメディアプラットフォームGoogleドライブなどを通じて、これらのすばらしい瞬間を世界中の友人や家族と共有することができます。

如何にてアプリとダッシュカムを接続しますでしょう

ステップ1：WiFi名とパスワードがダッシュカム画面に表示されるため、「UP」ボタンを長押ししてください。

ステップ2：WiFi名とパスワードを探して入力し、お使いのスマートフォンを保存に接続してください。

ステップ3：アプリ「YeecoreViewer」をクリックし、「JOIN CAM」をクリックする。接続が完了します。

PC Tools

当社のエクスプライヤ
（www.yeecore.com/pc/support-PC%20tools/YeecorePlayer.exe）
→最新バージョンのPCツールをダウンロードしてください。以下にリストアップしたツールをインストールすると、録画ファイルを再生でき、オーディオとビデオ、GPSトラック、GSensorなどを表示できます。

製品仕様

Sensor	フロントカメラ:8M Night Vision バックアップカメラ(オプション):2M Night Vision
レンズ	フロントカメラ: 157度広角、6-Glass Lens バックアップカメラ(オプション): 140度広角、6-Glass Lens
LCD	3.0 Inches IPS
Video Resolution	フロントカメラ:4K30FPS、1440P30FPS、1080P30FPS WDR バックアップカメラ(オプション):1080P30FPS HDR
Wi-Fi	内蔵
GPS	内蔵
G-Sensor	内蔵
オーディオ	内蔵マイク搭載スピーカー
画像のフォーマット	JPG
ファイル形式	MP4
USBポート	Type-C
バッテリータイプ	スーパーキャパシタ
作業温度	14°F~158°F(-10°C~70°C)
対応します OS (PCプレイヤー)	Windows XP/Vista/7/8/10/Mac OS

故障かな思った時

録画開始や録画しないときは録画停止の時。

1.MicroSDカードは高速カードの場合が必要です。U3以上の高速MicroSDカードを使用してください。

2.MicroSDカードを長時間使用すると速度が遅くなりますので、カードをフォーマットすることを推奨します。

動画撮しは写真プライムの現象時にファイルエラーが表示された。
MicroSDカードの書き込み速度が低下し、一部の動画や写真ファイルが破損する可能性があります。カードをフォーマットすることを推奨します。

本品がPC以上のMicroSDカードを認識しない。
コンピューターでFAT32ファイルシステムとしてフォーマットするか、本品でフォーマットする必要があります。

動画が録画する時、ビデオに縦線が表れた。
地域の電源周波数に応じて、フリッカーを50Hz或いは60Hzに設定してください。

本品がGPS情報を取得し難い。
一部のカーナビゲーションGPSアンテナは、本品のGPS受信に影響を与えます。できるだけ本品をアンテナから離して取り付けてください。

保証サービスとサポート

本品は12か月の保証期間を提供しています。弊社のエンジニアが（www.yeecore.com/register）にご購入された商品を登録すると、該保証期間は1か月に延長することができます。

サポート
当社に対応ご質問がいただいましたら、随時アドバイスとご提案はメールで（support@yeecore.biz）までご連絡ください。24時間以内に対応いたします。

なお、ここでもしたを見つけてください

公式サイト

Facebook

MADE IN CHINA

D22说明书20210727