85.00 mm

原声迷你扩音器
使用手册

在使用本产品前请仔细阅读此使用说明书并按照说明正确指引操作本产品
请妥善保管好此说明书以备查阅

70.00 mm

温馨提示

* 本公司不断致力提高产品质量和功能,产品设计如有更新,恕不另行通知
* 本说明书经过仔细核对, 力求精准,若有任何误差, 本公司不承担因此产生的后果.
* 购买时以实物规格为准, 示意图仅供参考. 本公司保留对此资料有关内容的解释权.
* 非专业人士请勿自行拆机,以免对机器造成不必要的损害. 在更换电池时, 只能用同类型或等效类型的电池来更换, 并请注意电池正负极. 不得搁置在过热或潮湿的环境中
* 长时间不使用机器时,请每月给机器充一次电,以保证在需要使用时电池电量充足及机器能正常使用!

操作说明

* 手机蓝牙连接方法

(1)选择蓝牙模式

(2)打开手机蓝牙，搜索并连接配对

(3)本机支持手机蓝牙通话功能

（部分机器无此功能，请以实物为准）

* AUX（外接音源输入）

(1)本机可用3.5mm音频线外接手机，DVD碟机，MP3/4播放器等设备

（部分机器无此功能，请以实物为准）

* USB/TF卡播放（部分机器无此功能，请以实物为准）

(1)将有音乐文件的USB/TF卡插入音箱即可播放

(2)支持MP3格式，支持32G最大容量

功能介绍（功能请以实物为准）

音量旋钮：开关和音量大小与扩音大小

鸣响旋钮：鸣响声音大小（部分机器无此功能）

M 模式键：短按切换蓝牙/收音/TF卡模式
长按进入录音模式（部分机器无此功能）

⏯ 播放键：短按播放与暂停，长按是收音收台。

⏮ 上一曲：短按上一曲，长按是快退

⏭ 下一曲：短按下一曲，长按是快进

UHF无线麦使用方法：(部分机器无此功能)

一：无线麦与扩音器的连接方法

1.出厂默认自动连接.

2.无线麦打开蓝灯长亮，长按M键5秒蓝灯进入闪烁时松开，此时打开扩音器进入自动配对中，稍等数秒后无线麦蓝灯长亮，配对成功即可使用。

二：变频方法

扩音器与无线麦连接成功后，短按无线麦M键，蓝灯进入闪烁3-5秒自动连接成功，此时变频成功。

故障排除

问题点	原因及解决方法
蓝牙配对不成功	* 重断开机配对 * 周边蓝牙设备太多,造成搜索困难，关掉其它蓝牙设备，重新搜索
声时小或失真	* 电池电量不足 * 调节音量到合适大小
蓝牙音乐播放出现断音	* 是否超出音箱有效连接距离（十米有效距离） * 音箱和手机间有障碍物

* 注意: 如以上方法未能排除故障,请联系商家,不可自行拆修机器,否则不予保修

* 充电说明

(1) 请使用标配或同等参数的电源适配器！

(2) 产品在使用中电量低或电量不足时,音箱会发出低电提示音后自动关机，此时应尽快给音箱充电，充电后直至充电指示灯灭，说明电池已充满.

(3) 长时间不使用时，建议每个月给机器充一次电。

Instruction Manual

FCC Statement

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

•Reorient or relocate the receiving antenna.

•Increase the separation between the equipment and receiver.

•Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

•Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Before using the product, please read the manual carefully and operate the product acc rding to the instructions Please keep o the manual properly for reference

Warm Tips

* We always devoted to improve product quality and functions, design is subject to change without notice.
* The manual has been carefully checked and strived to be accurate. If there`re any errors, the company will not bear the consequences.
* The drawing only for reference, please refer to the actual product when purchasing.We reserve all the right for the final explanation of the manual & related detail.
* Non professionals are not allowed to dismantle the machine by themselves, so as to avoid unnecessary damage to the machine.
* When replacing the battery, use the original brand battery,,and pay attention to the positive and negative poles of the battery.
* And should not be placed in the hot and humid environment.

Instructions for using

* Mobile Bluetooth connection method

1.It is in bluetooth mode after power on

2.Turn on the mobile phone Bluetooth, search bluetooth device to connect and pair.

3.This unit supports the Bluetooth call function of mobile phone （Some machines do not have this function, please take the real thing as the standard）

* AUX (external source input)

1.This machine can use 3.5 mm audio line outside the handset, DVD player, MP3/4 player and other equipment（Some machines do not have this function, please take the real thing as the standard）

* Play with card

1.Insert the TF card with music files into the speaker to play.

2.Support MP3/WMA format, support maximum 32G capacity.

Charging instructions

* Please use standard or equivalent power adapter.
* When the power of the product is low or insufficient, the speaker will emit a low-battery tone and then turn off automatically. At this time, charge the speaker as soon as possible. Charging until the indicator light is off, means the battery is fully charged.
* When not in use for a long time, it is recommended to charge the machine once a month.

Troubleshooting

Problem points	Causes and Solutions
Bluetooth pairing failed	* Reboot pairing * There are to o many Bluetooth devices around, which make sit difficult to search. Turn off other Bluetooth devices and search again
Low or distorted sound	* Low battery * Adjust the volume to a suitable level
Interruption of Bluetooth music	* Whether it exceeds the effective connection distance of the speaker (10 meters effective distance) * There are obstacles between speaker and mobile phone

Note: If the above method fails to eliminate the fault, please contact the dealer, do not disassamble and repair the machine by yourself, otherwise the warranty will not be provided