VZ SPORT MATE

V3 User Manual

A. Package Including

After opening the package, check that all items in the list are included in the package. If any items are missing, contact your dealer.

MP3 player Bluetooth headphone x1 (w/ 16GB TF card x1 (The card is inserted into the headset))

Micro USB cable x1



4 pairs earbuds

User Manual x1

B. TF Card Download Guide

1. Gently remove the rubber cover that covers the Micro USB port.
2. Connect the USB end to your computer. The SD card will be read automatically.
3. Copy or drag your music file to the card.

C. Outlook and Controls



Button Functions:

1		Button (ON / OFF, Play/Pause, Pick up/Hang up call)
2		Button (Shuffle/Repeat /Bluetooth and TF card switching)
3		Button (Volume Up)
4		Button (Volume Down)
5		Button (Previous / Fast-reverse)
6		Button (Next / Fast-forward)

Indicator light and Other ports

a	Micro SD Memory Card Slot
b	Micro USB Port
c	Bluetooth LED Indicator
d	Charge LED Indicator/ TF Card Using Indicator

D. Music Playing Control Function

- Once turned on, the device will enter TF card playing mode automatically with a series of tones.
- It can keep its position in a track whether you're in TF card playback mode or Bluetooth music playing mode.
- When playback of the last song is finished, the player automatically restarts playback from the first song and continues in sequential order.

In local music playback mode (Insert TF card)

1. Press and hold " (2)" button to enter "**Shuffle**" play mode.
2. Press and hold " (2)" button again to enter "**repeat**" play mode.
3. Press and hold it again, to back "**order play"** mode.

Note: "Shuffle" mode will be activated only when you insert the TF card.

In Bluetooth music playing mode

1. Press and hold the " (1)" button to turn on the device. A series of tones will sound.
2. Press "(2)" button to enter Bluetooth music playing mode. A series of tones will sound.
3. Step 2 activates the Bluetooth function in your mobile device. The headset will enter pairing mode automatically. Pair the headset with your mobile device.
4. If it is the first pairing with your device, please refer to **Part E** of the manual for details.

Music playback operation function

- While playing music, press " (1)" button to pause the music.
  To resume the music, press it again.
- Press the " (3)" button to increase the volume level.
- Press the " (4)" button to decrease the volume level.
- When maximum or minimum volume is reached, a series of tones will sound.
- Press once the " (6)" button to go to next track.
- Press once the " (5)" button to go to previous track.
- Press and hold the " (6)" button to use fast-forward.
- Press and hold the " (5)" button to use fast-reverse.

Note: There are 15 volume levels on this Bluetooth headset (different from smart phone's 16 volume levels), so a warning tone will sound once it reaches level 15.

E. Power On and Pairing

1. Press and hold the " (1)" button to turn on the device, a series of tones will sound. Both indicator will flash alternately in Blue and Red, and press once " (1)" to enter Bluetooth mode.
2. Activate the Bluetooth function in your mobile device (such as Mobile Phone or Personal Computer). The device will enter Bluetooth searching mode automatically. If this does not work, tap the relate selection to manually enter to searching mode. (refer to your device's manual as necessary)
3. Your mobile device should show "**V3**" in list, and then select it for pairing. Waiting for a few seconds and you will see a "connected" message shown on your mobile device. (For some Bluetooth devices, you may need to input "**0000**" as a pairing password)
4. If pairing is successful, a series of tones will sound and the "**Bluetooth LED (c)**" indicator will blink slowly.

5. You can now play via audio the mobile device using any audio player you choose. Additionally, Bluetooth earphone battery power will show on your mobile phone.
6. Press and hold the " (1)" button to turn Off the device when it is not in use.

Note: *To conserve battery life, the Bluetooth earphone will turn to sleep mode when no device is in paired within in 8 minutes. To restart the device, Press and hold the " (1)" button.*

F. About the Rechargeable Battery & Charging

To recharge the built-in battery:

- Connect the Bluetooth earphone's "**Micro USB socket (b)**" with the Computer's USB port through USB cable.
- The "**Charge LED (d)**" Indicator will turn on in red when the battery is in charging.
- The "**Charge LED (d)**" Indicator will turn Off when the rechargeable battery is fully charged.
- Disconnect the USB cable when it is done.

This Bluetooth earphone has an internal, non-user-replaceable battery. For best results, the first time you use this Bluetooth earphone, let it charge for about 2-3 hours or until the red light is off.

For maintain the battery life and performance, if earphone isn't used for a while, the battery might need to be recharged. Charge the battery at least once every month.

G. Hands Free Function

1. When there is an incoming call during music playing mode:
2. Your phone will ring via your device the playing music will pause automatically.
3. Press " (1)" button to answer a call.
4. Press " (1)" button again to hang up the call when finished. The music will start to play again automatically.

5. Press " (6)" or " (5)" button to ignore an incoming call.

H. Disconnect from Paired Device

1. Press and hold the " (2)" button to switch to new "Searching / Pairing" mode, the paired device will disconnect.
2. You can choose **"Disconnect"** from the Bluetooth paired device list on your mobile device.
3. In this case; the Bluetooth earphone will turn back into **"Searching / Pairing"** mode in seconds. A series of tones will sound and the **"Bluetooth LED (c)"** indicator and **"Charge LED(d) "**indicator will flash alternately in blue and red.
4. Now, you can proceed with new mobile device pairing or power off the Bluetooth earphone as desired.

I. Auto Re-connect with Paired Device and New Pairing

1. Every time you turn on the Bluetooth earphone power, it will first search for the mobile device that was previously paired. The Bluetooth earphone will re-connect to this device by default if it is in Bluetooth searching device mode.
2. If not found within a few seconds, the Bluetooth earphone then enters into new pairing mode automatically.
3. You can now proceed with pairing your new device (refer to item D.3~6 methods)

J. Redial for Last Call Function

1. To redial the last called number, even it is in music playing mode, press the " (1)" button twice. The playback will pause and switch to hands free function for redial.
2. Press the " (1)" button again to disconnect the call.
3. Make sure that your mobile phone has last dialed call. If not, the redial for last call function will not function.

K. Low Power Reminder and Auto Sleep

1. The Bluetooth earphone will send a series of tones and a light will illuminate in red if it is low on power. When you hear this reminder, please connect the device to the USB power for charging.
2. If the battery is empty, it will power off and will power back on automatically after recharging for 10-15 minutes
3. Press and hold the " (1)" button to turn on the device after charging

L. Specification

Dimensions	130mm (L) x 120mm (W) x 33mm (H)	
Weight	28g (approximate)	
PC connection	USB 1.0 / 1.1 / 2.0	
Memory Card Slot	Micro SD Card (1-128GB)	
Battery	Lithium 3.7V, 130mAh	
	Playing Time: 4.5H	
Power Source	DC Input: 5V 500mA	
Bluetooth	Specification	V4.2
	Frequency	2.402 ~ 2.480GHz
	RF Transmit Power	Class II
	Connection Distance	In 10 meters (open area)
Audio	Earphone Output	2mW*2(at 16 Ohm)
	Support Format	MP3,WMA,APE,FLAC,WAV
Operating Temperature	0 to 40℃	
Operating System	Window 2000/XP/Vista/Win7,8,10;	
	Mac 9.2 or Higher	

M. Disclamer

Updates to Firmware and/or hardware components are made regularly. Therefore, some of the instructions, specifications and pictures in this documentation may differ slightly from your particular device. All items described in this guide are for illustrative purposes only and may not apply to particular device. No legal right or entitlements may be obtained from the descriptions presented in this manual.

N. Attention

Cautions

- Do not place open flames, such as lighted candles on or near the product.
- Do not place objects filled with liquids, such as vases on or near the product.
- Do not use or store this product in a place where it is subject to direct sunlight, heat, excessive dust or vibration.
- Do not keep or store this product in wet conditions for long periods of time.
- Do not clean this product with water or other liquids.
- Do not block or cover the slots and holes in the product.
- Do not push foreign objects into the slots or holes in the product.
- Do not attempt to open this product yourself. There are no user serviceable parts inside.
- Do not allow children access to the plastic packaging.

Safety Instructions

- Before using this product, read and follow all warnings and instructions.
- Please ensure young children are supervised while using this product.
- This product is intended for household use only and not for commercial or industrial use.
- Do not expose this product to dripping or splashing.
- No open flame sources, such as lighted candles, should be placed on or near the product.
- Ventilation should not be impeded by covering ventilation openings with items such as

newspapers, table cloths, curtains, etc.

- Make sure the unit is adjusted to a stable position. Damage caused by using this product in an unstable position or by failure to follow any other warnings or precautions contained within this user manual will not be covered by warranty.

Warning

- Never remove the casing of this apparatus.
- Never place this apparatus near other electrical equipment.

WARNING: To prevent possible hearing damage, do not listen at high volume levels for long periods.

Notice

- If at any time in the future you should need to dispose of this product please note that: All batteries and accumulators need to be removed from this product (Removal of Waste Batteries and Accumulators).
- Always bring your product to a professional to remove the built-in battery.

O. Trouble Shooting

If the device does not function as expected, try the following steps to resolve the issue.

- Find the symptoms of the issue in this user manual, and try any corrective actions listed.
- You may be able to resolve some issues by changing the battery.
- Reset the device.
- If the operations above do not work, consult our customer service.

support@vzsportmate.com

www.vzsportmate.com

FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approve by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

It this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into and outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure condition without restriction.

FCC ID: 2AFDR-BTH17V3