TECNO

TRUE WIRELESS EARBUDS

User Manual | Model: BOED1

Qualcomm aptX Bluetooth5.0

PRODUCT OVERVIEW

Earbuds

Charging Case



SPECIFICATION

Product	TECNO BOED1 True Wireless Stereo Earbuds
Model	BOED1
Version	Bluetooth 5.0
Chipset	Qualcomm aptX
Bluetooth Profile	HFP,HSP,A2DP,AVRCP
Bluetooth Range	10m(Open Distance)
Frequency Range	2402MHz-2480MHz
Battery Capacity	35mAh/Earbud
Charging Case Battery	400mAh (Micro-polymer battery)
Charging Time	1.5H(Earbuds) 2.5H(Case)
Charging Current Voltage	5V/0.1A
Earbuds Charging	5V/0.1A
Fully Charged Earbuds	4H
Fully Charged Case	2H
Playing Time Per Charge	Up to 5H(aptX)
Playing Time Per Charge	Up to 6H(SBC)
Frequency Response	20-20,000 HZ
Speaker Sensitivity	105dB ± 3dB
Operating Temp	0C Mode (when not in charge mode) 45C Mode (play with charging case)

GET READY FOR FIRST USE

Ensure to remove the insulating film of both earbuds which from ear, and then fully charge the earbuds and charge case by separate Type-C USB adapter.

POWER ON/OFF

Hold 3S:
Hold 3S to power ON the charging case and earbuds will flash red for 1 second, earbuds will connect to last paired device.
Hold 3S:
Hold 3S to power OFF the charging case, when LED indicator will light up for 1 second, earbuds power off automatically.

GET READY FOR FIRST USE

Pair Mode
Put the left earbud in the central pairing TWS Mode.
Take out both earbuds from the charging case.
Taking out both earbuds from the charging case, LED indicator flash blue, and Two connection between earbuds will automatically pair and connect.
Bluetooth Pairing with Phone
Open Bluetooth function on your phone, LED flashes on the left earbud will flash blue and white alternately, and pairing with the left earbud phone will Open Bluetooth setting on your phone and select TECNO BOED1 to pair and connect.
Successful connection
Pair and connect successfully, the left earbud means a successful connection. Then earbuds turn off.
Auto Reconnect
Open the charging case the charging case will open earbuds will automatically connect with each other, and then connect automatically Bluetooth reconnection with the last paired phone.

GET READY FOR FIRST USE

Wear Mode
Put the left ear bud earbuds on the ears basically. Please take out one one earbud from the charging case and put it in your ear, the other earbud will automatically pair and connect.
Using a left earbud alone: TECNO BOED1 of the Bluetooth devices list will disappear.
Using a right earbud alone: TECNO BOED1 of the Bluetooth devices list will disappear.

Note:
Power on/off the left earbud while only right earbud externally, the right earbud will be disconnected and left one earbud will automatically reconnect. Vice Versa, turn off the right earbud and only wear left earbud, the right earbud will automatically reconnect and pair with your cellphone.
Power on/off both earbuds at the same time, only left earbud externally, the left earbud will automatically reconnect and then wear the right earbud, the left earbud keeps running pairing the phone.

FACTORY RESET

Tips:
1. In use or both of your BOED earbuds become unpairable, unresponsive or cut out use or connect successfully, please try the following factory reset steps:
Put both earbuds back into the charging case, Open the TECNO BOED1 pairing in the Bluetooth menu on your smartphone.
Take out the earbuds from the charging case and wear one first, and then, Keeping Press Hoping for 5 seconds until LED indicators flash blue and white 3 times.
2. Factory reset:
Resetting the earbuds back all paired devices, as well as the TWS connection.Between left and right earbud, TWS connection, Hold both earbuds for 10 seconds, the earbuds in your smartphone disappear, then put earbuds back into the charging case, Open the charging case and hold for 10 seconds, the earbuds will flash red and white 3 times, then, put earbuds back to your smartphone disappear, then pair and connect earbuds.

OTHER FUNCTIONS

Ultraspeak When receives an LOC enquiries the Thumbpad for 2 seconds to forwards text Tells us where you are, Ultra-low latency mode Hold the Thumbpad for 5 seconds to enter the game mode, Voice Prompt Hold both earbuds for 5 seconds to turn on/off voice prompt, Voice assistant Hold the Thumbpad for 2 seconds to call your voice assistant, Auto Power Off Both earbuds turn off automatically if one is taken out of the charging case and not used for 5 minutes, Auto Power On Put both earbuds back into the charging case and open the charging case for 3 seconds, the earbuds will automatically turn on.

TOUCHPAD CONTROL

Music Mode(A)
Hold Left Touchpad for 2 seconds
Hold R Touchpad for 2 seconds

Using Voice Assistant
Hold the Left Touchpad for 2 seconds
Hold the Right Touchpad for 2 seconds

Hang / Call
Single Tap Touchpad twice

Reject / Call
Long press the Touchpad for 2 seconds

Music Mode(B)
Hold the Left Touch Ear bud can be used in the TWS mode:
Hold L & R Mic, Then:

Hang / Call
Single Tap Touchpad twice

Reject / Call
Long press the Touchpad for 2 seconds

EARBUDS BATTERY LEVEL & CHARGING

Battery level:
Hold the Left Touchpad for 2 seconds
Voice prompt will inform battery level on the right earbud.

Low battery signal:
Low battery signal, warning will be announced every 5 minutes. Please charge earbuds in time when battery charge is low.

Charging status:
Earbuds Battery Charging

Charging case indicator checking
Solid darkness
Solid darkness
Solid darkness